




# Flowcode

## Activate Flowcode


 This copy of Flowcode is activated to: 51401178  
License version: Free/Demo Version.  
This is a single user license of Flowcode  
You are licensed to use Flowcode for personal use only  
You have 0 day(s) remaining, after which time the product will become feature-limited.

Matrix account name:

Password:

7) Enter the **Flowcode Username** at the top, copy and paste the entire key (including (====Start key==== and ====End key====) into the box provided

# Flowcode



8) Click the “...” button and point the dialogue box at the “**Licence Key File**” downloaded earlier.

9) Click the “Activate” button

Flowcode should restart and the new licence applied.

Unique solution ID: #1066

Author: DavidA

# Flowcode

Last update: 2016-11-17 11:15