

Flowcode

Manual offline license activation for Flowcode 7

1) First you will need to log in to your account via this link using your Matrix username and password: <http://www.matrixtsl.com/accounts/login.php>

2) Secondly you will need to go the manual registration page here:

http://www.matrixtsl.com/accounts/v7_key_files/manual_v7_reg.php

Automatic activation via the internet is the preferred method of activating your Flowcode. If however you have no access to the internet or have strict firewall rules which prevent the automatic activation, then you will need to use the manual activation technique outlined in our [FAQ here](#).

To perform manual activation you will need three pieces of information, all present on this page:

- Flowcode Username
- Licence File
- Activation Key

Flowcode Username: Dev User

Activation Key

====Start key====
[Blurred text]
====End key====



Download File

Click on the download button to the left, this will download a '.key' file, you will need to note where you save the file as you will need it to activate Flowcode.


3) Download the **Licence key file** and make a note of the **Flowcode Username** and **Activation Key**.

4) Load up Flowcode


5) Go to Help >> Manage licences...

6) Select "My Flowcode Licence" and click "OK"

Flowcode




7) Select the "Manual Activation"



Flowcode

7) Enter the **Flowcode Username** at the top, copy and paste the entire key (including (=====Start key===== and =====End key=====) into the box provided



The image shows a 'Manual Activation' dialog box for Flowcode. It has a dark grey background and a red border. At the top left is a green information icon. To its right, text states: 'This copy of Flowcode is activated to: Dev User', 'License version: Professional Version.', '1 users can use Flowcode on the same network', and 'You are licensed to use Flowcode for personal use only'. Below this, there are two input fields: 'Flowcode user name:' containing 'Dev User' and 'Flowcode activation key:' containing a long key starting with '=====Start key====='. At the bottom left is a 'License file:' label above an input field containing 'E:\Downloads\fc_v6_key_231115145601E1A542C85E.key' and a browse button '...'. At the bottom right are 'Activate' and 'Close' buttons. A small red question mark icon is in the bottom left corner.

Manual Activation

This copy of Flowcode is activated to: Dev User
License version: Professional Version.
1 users can use Flowcode on the same network
You are licensed to use Flowcode for personal use only

Flowcode user name:
Dev User

Flowcode activation key:
=====Start key=====

=====End key=====

License file:
E:\Downloads\fc_v6_key_231115145601E1A542C85E.key

Activate

Close

8) Click the “...” button and point the dialogue box at the “**Licence Key File**” downloaded earlier.

9) Click the “Activate” button

Flowcode

Flowcode should restart and the new licence applied.

Flowcode

Unique solution ID: #1076

Author: DavidA

Last update: 2016-11-17 11:13