

AT Commands Reference Guide

80000ST10025a Rev. 9 – 2010-10-04



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

This document substitute any issue of the AT Commands Reference Guide for GC864-DUAL document 80300ST10037a.



DISCLAIMER

The information contained in this document is the proprietary information of Telit Communications S.p.A. and its affiliates ("TELIT").

The contents are confidential and any disclosure to persons other than the officers, employees, agents or subcontractors of the owner or licensee of this document, without the prior written consent of Telit, is strictly prohibited.

Telit makes every effort to ensure the quality of the information it makes available. Notwithstanding the foregoing, Telit does not make any warranty as to the information contained herein, and does not accept any liability for any injury, loss or damage of any kind incurred by use of or reliance upon the information.

Telit disclaims any and all responsibility for the application of the devices characterized in this document, and notes that the application of the device must comply with the safety standards of the applicable country, and where applicable, with the relevant wiring rules.

Telit reserves the right to make modifications, additions and deletions to this document due to typographical errors, inaccurate information, or improvements to programs and/or equipment at any time and without notice.

Such changes will, nevertheless be incorporated into new editions of this document.

Copyright: Transmittal, reproduction, dissemination and/or editing of this document as well as utilization of its contents and communication thereof to others without express authorization are prohibited. Offenders will be held liable for payment of damages. All rights are reserved.

Copyright © Telit Communications S.p.A. 2010.



1.7. Document History

Revision	Date	SW release	Changes						
ISSUE #0	2006-08-04	7.02.01	Initial release						
ISSUE #1	2006-10-26	7.02.02	<p>3.2.2.1 +CME ERROR: - ME Error Result Code: updated</p> <p>3.2.2.2 +CMS ERROR - Message Service Failure Result Code: updated</p> <p>3.2.6 Factory and user profile: updated</p> <p>-“GPS Commands Set” total update</p> <p>-updated the following commands description under SELINT 0, SELINT 1 and SELINT 2 paragraph: +COPN, +CCFC, +CCWA, +CPIN, +CIND, +CNMI, +COPS, +CMEE, #SKTD, #AUTOATT, +CALA, +CAOC, +CACM, +CAMP, +CPUC, S12</p> <p>-updated under SELINT 0 and SELINT 1 command +CPAS, #FTPOPEN, \Q, #CSURV, #CSURVC</p> <p>-updated the following commands only under SELINT 2: +CMUX, +CLCC, +CMGL, +CMGR, #LSCRIPT</p> <p>-removed from the AT commands table under SELINT 0 and SELINT 1 the following commands: #CBC and #EMAILMSG</p> <p>-added new commands (for SELINT 2): #EXECSCR, #STARTMODESCR</p>						
ISSUE #2	2007-03-16	7.02.03	<p>-Revision of the whole document form.</p> <p>-Added new commands: #ENS, +WS46, +CPOL, +PACSP, #SPN, #SLED, #SLEDSAV, #VAUXSAV, #V24CFG, #V24, #AXE, #ACALEXT, #MBN, #MWI, #SPKMUT, multisocket commands, SIM toolkit commands, \$GPSS, \$GPSCON, \$GPSRPG, \$GPSPTS, \$GPSWK</p> <p>-3.2.6 Factory and user profile: updated</p> <p>-Removed AT commands for camera and #I2S1</p> <p>-Updated following AT commands: +CNUM, +CPIN, +CPBW, +CPBS, +CLIP, #STGI, #FTPOPEN, \$GPSACP,</p>						
ISSUE #3	2007-08-10		Update list of products to which this document can be applied						
ISSUE #4	2007-11-19	7.02.04	<p>Added new commads: #CEER, #SMSMODE, #Z, #TEMPMON, #HFRECG, #HSRECG, #PRST, #PSEL, #PSAV, #PSET, #SHFAGC, #SHFNR, #SHSAGC, #SHSEC, #SHSNR, #SHSSD, #GSMAD, #CSURVP, #CSURVPC</p> <p>Added: 3.5.7.12 Telefonica OpenGate M2M AT Commands Set</p> <p>modified description of AT#SD and AT#SL, ...</p>						
ISSUE #5	2008-07-09	7.02.05 / 7.03.00	<p>New commands</p> <table border="1"> <tr> <td>+CGEREP</td> <td>#TSVOL</td> <td>#REGMODE</td> </tr> <tr> <td>#TXMONMODE</td> <td>#SIMDET</td> <td>#ENHSIM</td> </tr> </table>	+CGEREP	#TSVOL	#REGMODE	#TXMONMODE	#SIMDET	#ENHSIM
+CGEREP	#TSVOL	#REGMODE							
#TXMONMODE	#SIMDET	#ENHSIM							



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

			#TTY	#CPUMODE	#GSMCONT
			#CGPADDR	#NWSCANTMR	#OSC32KHZ
			#CACHEDNS	#DNS	#ICMP
			#TCPMAXDAT	#TCPREASS	
ISSUE #6	2009-08-03	SW 7.03.01 / 7.02.06 SW 10.0.1	<ul style="list-style-type: none"> - Applied new layout. - Deleted ME Error Result Code [566 – 573] (§3.2.2.1) - Reorganized the availability table (merged columns by family of product, exported GPS commands to their own table). - Updated the commands whose values are automatically stored in NVM. Specified those for the SW 10.xx.xxx platform. - Added/edited the following commands: #ACAL, #ATRUN, #AXE, #BIQUADIN, #CCLK, #CEER, #CESTHLCK, #CFLO, #CGDATA, #CGPADDR, #CPASMODE, #EMAIL, #EVMONI, #SMSATRUN, #SMSATRUNCFG, #SMSATWL, #TCPATRUNCFG, #TCPATRUNL, #TCPATRUNFRWL, #TCPATRUNAETH, #TCPATRUND, #TCPATRUNCLOSE, #TCPATRUNCMDSEQ, #TCPATCONSER, #ATRUNDELAY, #ENAEVMONI, #ENAEVMONICFG, #FASTCCID, #FTPAPP, #FTPFSIZE, #FTPGET, #FTPGETPKT, #FTPPUT, #FTPFCV, #FTPREST, #GPIO, #GPPPCFG, #GSMAD, #GSMCONT, #HFMICG, #HFRECG, #HSMICG, #HSRECG, #I2CWR, #I2CRD, #JDR, #LCSCRIPT, #MONI, #NITZ, #OAP, #OTASNAP, #OTASUAN, #CMGS, #CMGW, #PING, #PSMRI, #QSS, #REBOOT, #SA, #SCFG, #SCFGEXT, #SD, #SERVINFO, #SGACTAUTH, #SGACTCFG, #SIMDET, #SKTD, #SKTL, #SL, #/, #SLUDP, #SMOV, #SPCM, #SRECV, #SS, #SEND, #STARTMODESCR, #SWLEVEL, #TEMPMON, #TONEEXT, #TSVOL, #VAUX, #V24MODE, #V24CFG, #Z, \$GPSACP, \$GPSAP, \$GPSCON, \$GPSPS, \$GPSWK, +CCLK, +CEER, +CFUN, +CGPADDR, +CGSMS, +CMGD, +CMGW, +CNMI, +CPBS, +CSMP, +DS, +VTS, S0. - Deleted commands: AT\B, AT\K, AT\N. - Specified SW10.xx.xxx default values 		
ISSUE #7	2010-05-07	SW 7.03.02 / 7.02.07 SW 10.0.2	<ul style="list-style-type: none"> - New commands added for SW 7.03.02 / 7.02.07: #SCFGEXT2, #CMGLCONCINDEX, #CODECINFO, #GSMCONTCFG, #SNUM, #SENDEXT, +CMAR - New commands added for SW 10.0.2: #PADFWD, #PADCMD; new parameters for CFUN: CFUN=1,1 - Updated Timeout Table par. 3.2.4 - Removed note 18 - Updated Table Factory Profile and User Profile par. 3.3.1 - Deleted commands: &G, &Q - Updated commands: #JDR, #FTPDELE, +CNMI, #CMGW, 		



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

			#OTASUAN, #I2CWR, #I2CRD, #ATS38, #GSMAD, +CFUN, &D, #E2ESC, #TXMONMODE, #SNUM, #STIA, #FTPFSIZE, #COPSMODE, # SCFGEXT, #SCFGEXT2, #SD, #SELINT, #ADC, #DVI, #EMAILD, #EVMONI, #GPPPCFG, #MSCLASS, #SEMAIL, #SPCM, #SWLEVEL, #TONEEXT, #UDTSET, +CMER, #E2ESC, #SLUDP, #SIMATR
ISSUE#8	2010-07-26	SW 7.03.02 / 7.02.07 SW 10.0.3	<ul style="list-style-type: none"> - Updated commands: #SCFGEXT2, S38, #SEMAIL, #EMAILD, #CSURVF, +CMAR, #CCLK, +CMGL, +CFUN, #FTPOPEN, #OTASNAP, #OTASUAN, #AUTOBND, #STIA, #STGI, +CLCC, +CNMI, +CPMS, +CSAS, #PLMNMODE, #SMSMODE, #REGMODE, #AUTOBND, #ENHSIM, #SWLEVEL, #NITZ, #STIA, #JDR, #TSVOL - New commands added for SW 10.0.3: +CPLS, +CGCMOD, #STTA, #CMEEMODE, #SGACTCFGEXT, #BASE64, #CEERNET, #ENHRST, #SII, #OTASETTRI - Updated references specification from 07.05, 07.07, 03.40 to 27.005, 27.007, 23.040, etc
ISSUE#9	2010-10-04	SW 7.03.02 / 7.02.07 SW 10.0.3	<ul style="list-style-type: none"> - Added GL865-DUAL to applicability table and the matrix



An enhanced test command (trailing =??) has been introduced to maintain backward compatibility for those commands whose subparameters changed the range of possible values from version to version.

- *(for #SELINT=2 only)*
The response to the Test Command (trailing =?) may be changed in the future by Telit to allow the description of new values/functionalities
- *(for #SELINT=2 only)*
If all the subparameters of a parameter type command +CMD (or #CMD or \$CMD) are optional, issuing AT+CMD=<CR> (or AT#CMD=<CR> or AT\$CMD=<CR>) causes the OK result code to be returned and the previous values of the omitted subparameters to be retained.

3.2.1. String Type Parameters

A string, either enclosed between quotes or not, is considered to be a valid string type parameter input. According to V25.ter space characters are ignored on the command line and may be used freely for formatting purposes, unless they are embedded in numeric or quoted string constants; therefore a string containing a space character has to be enclosed between quotes to be considered a valid string type parameter (e.g. typing AT+COPS=1,0,"A1" is the same as typing AT+COPS=1,0,A1; typing AT+COPS=1,0,"A BB" is different from typing AT+COPS=1,0,A BB).

When #SELINT=0 (or 1) mode is selected, a string not enclosed between quotes is changed in upper case (e.g. **mickey** become **MICKEY**), while a string enclosed between quotes is case sensitive.

When #SELINT=2 mode is selected, a string is always case sensitive.

A small set of commands requires always to write the input string parameters within quotes: this is explicitly reported in the specific descriptions.

3.2.2. Command Lines

A command line is made up of three elements: the **prefix**, the **body** and the **termination character**.

The **command line prefix** consists of the characters "AT" or "at", or, to repeat the execution of the previous command line, the characters "A/" or "a/" or AT#/ or at#/.

The **termination character** may be selected by a user option (parameter S3), the default being <CR>.



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

The basic structures of the command line are:

- **ATCMD1<CR>** where **AT** is the command line prefix, **CMD1** is the body of a **basic command** (nb: the name of the command never begins with the character “+”) and **<CR>** is the command line terminator character
- **ATCMD2=10<CR>** where 10 is a subparameter
- **AT+CMD1;+CMD2=, ,10<CR>** These are two examples of **extended commands** (nb: the name of the command always begins with the character “+”²). They are delimited with semicolon. In the second command the subparameter is omitted.
- **+CMD1?<CR>** This is a Read command for checking current subparameter values
- **+CMD1=?<CR>** This is a test command for checking possible subparameter values

These commands might be performed in a single command line as shown below:

ATCMD1 CMD2=10+CMD1;+CMD2=, ,10;+CMD1?;+CMD1=?<CR>

anyway it is always preferable to separate into different command lines the basic commands and the extended commands; furthermore it is suggested to avoid placing several action commands in the same command line, because if one of them fails, then an error message is received but it is not possible to argue which one of them has failed the execution.

If command **V1** is enabled (verbose responses codes) and all commands in a command line has been performed successfully, result code **<CR><LF>OK<CR><LF>** is sent from the TA to the TE, if subparameter values of a command are not accepted by the TA or command itself is invalid, or command cannot be performed for some reason, result code **<CR><LF>ERROR<CR><LF>** is sent and no subsequent commands in the command line are processed.

If command **V0** is enabled (numeric responses codes), and all commands in a command line has been performed successfully, result code **0<CR>** is sent from the TA to the TE, if sub-parameter values of a command are not accepted by the TA or command itself is invalid, or command cannot be performed for some reason, result code **4<CR>** and no subsequent commands in the command line are processed.

In case of errors depending on ME operation, **ERROR** (or **4**) response may be replaced by **+CME ERROR: <err>** or **+CMS ERROR: <err>**.

² The set of **proprietary AT commands** differentiates from the standard one because the name of each of them begins with either “@”, “#”, “\$” or “*”. **Proprietary AT commands** follow the same syntax rules as **extended commands**



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

Numeric Format	Verbose Format
731	Unspecified
732	Activation command is busy
733	Activation started with CMUX off
734	Activation started on invalid CMUX
736	Remote SIM already active
737	Invalid parameter

*(values in parentheses are GSM 04.08 cause codes)

3.2.2.2. Message Service Failure Result Code - +CMS ERROR: <err>

This is NOT a command, it is the error response to +Cxxx 3GPP TS 27.005 commands.

Syntax: **+CMS ERROR: <err>**

Parameter: **<err>** - numeric error code.

The **<err>** values are reported in the table:

Numeric Format	Meaning
0...127	GSM 04.11 Annex E-2 values
128...255	3GPP TS 23.040 sub clause 9.2.3.22 values
300	ME failure
301	SMS service of ME reserved
302	operation not allowed
303	operation not supported
304	invalid PDU mode parameter
305	invalid text mode parameter
310	SIM not inserted
311	SIM PIN required
312	PH-SIM PIN required
313	SIM failure
314	SIM busy
315	SIM wrong
316	SIM PUK required
317	SIM PIN2 required
318	SIM PUK2 required
320	memory failure
321	invalid memory index
322	memory full
330	SMSC address unknown
331	no network service



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

The **&F** command resets to factory profile values only the command of the base section of profile, while the **&F1** resets to factory profile values the full set of base + extended section commands.

The values set by other commands are stored in NVM outside the profile: some of them are stored always, without issuing any **&W**, some other are stored issuing specific commands (**+CSAS**, **#SLEDSAV**, **#VAUXSAV**, **#SKTSAV**, **#ESAV** and **\$GPSSAV**); all of these values are read at power-up.

The values set by following commands are stored in the profile base section; if **#SELINT=2** they depend on the specific AT instance:

GSM DATA MODE	+CBST
AUTOBAUD	+IPR
COMMAND ECHO	E
RESULT MESSAGES	Q
VERBOSE MESSAGES	V
EXTENDED MESSAGES	X
FLOW CONTROL OPTIONS	&K, +IFC
DSR (C107) OPTIONS	&S
DTR (C108) OPTIONS	&D
DCD (C109) OPTIONS	&C
RI (C125) OPTIONS	\R
POWER SAVING	+CFUN
DEFAULT PROFILE	&Y0
S REGISTERS	S0;S2;S3;S4;S5;S7;S12;S25;S30;S38
CHARACTER FORMAT	+ICF

The values set by following commands are stored in the profile extended section and, if the newer AT command interface style has been selected (see **#SELINT=2**), they depend on the specific AT instance (see **+CMUX**):

+FCLASS	+ILRR	+DR
+CSCS	+CR	+CRLP
+CRC	+CSNS	+CVHU
+CREG	+CLIP	+CLIR
+CCWA	+CUSD	+CAOC
+CSSN	+CIND	+CMER
+CPBS	+CMEE	+CGREG
+CGEREP	+CMGF	+CSDH
+CNMI	#QSS	#ACAL ⁵
#TEMPMON ⁶	#ACALEXT	#ECAM

⁵ If **#SELINT=2** they depend on the CMUX 0 instance only



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

The values set by following commands are automatically stored in NVM, without issuing any storing command and independently from the profile (unique values), and are automatically restored at startup:

#SELINT	+COPS ⁹	+CGCLASS
+CGDCONT	+CGQMIN	+CGQREQ
#REGMODE	#PLMNODE	#COPSMODE
#DIALMODE	#BND	#AUTOBND
#ENS	#SCFG	#JDR
#ENHSIM	#AUTOATT	#TXMONMODE
#TTY	#ICMP	#GSMCONT
#NWSCANTMR	#SMSMODE	#DNS
#TCPMAXDAT	#TCPREASS	#SWLEVEL
#CPASMODE	#FASTCCID	+CGSMS
#V24MODE		

The values set by following commands are stored in NVM on demand, issuing specific commands and independently from the profile:

+CSCA	+CSMP	+CSCB
-------	-------	-------

stored by +CSAS¹⁰ command and restored by +CRES⁹ command

#SLED		
-------	--	--

stored by #SLEDSAV¹¹ command

#VAUX		
-------	--	--

stored by #VAUXSAV¹² command

#USERID	#PASSW	#PKTSZ
#DSTO	#SKTTO	#SKTSET
#SKTCT		

stored by #SKTSAV command and automatically restored at startup; factory default values are restored by #SKTRST command

#ESMTP	#EADDR	#EUSER
--------	--------	--------

⁹ It is partially stored in NVM; see command description.

¹⁰ Both commands **+CSAS** (see §3.x.3.2.5) and **+CRES** (see §3.x.3.2.6) deal with non-volatile memory, intending for it either the NVM and the SIM storage.

¹¹ Valid for **#SELINT=2** only.

¹² Valid for **#SELINT=2** only.



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862- QUAD, GM862- QUAD- PY, GM862- GPS	GE863- PRO ³	GE863- QUAD, GE863- PY, GT863- PY GE863- SIM, GE863- GPS	GE864- QUAD Automotive	SW 7.03.xx2	SW 10.00.xx3	Function	Page
					GE864- QUAD, GE864- PY, GT864- QUAD, GT864-PY GC864- QUAD, GC864- PY, GC864- DUAL	GE865- QUAD, GL865- DUAL, GC864- QUAD, GC864- QUAD V2, GC864- DUAL V2, GE864- QUAD, GE864- QUAD V2, GE864- DUAL V2, GE864- QUAD Automotive V2, GE864- QUAD Atex		
&V	•	•	•	•	•	•	Display Current Base Configuration And Profile	54
&V0	•	•	•	•	•	•	Display Current Configuration And Profile	54
&V1	•	•	•	•	•	•	S Registers Display	55
&V3	•	•	•	•	•	•	Extended S Registers Display	55
&V2	•	•	•	•	•	•	Display Last Connection Statistics	56
\V	•	•	•	•	•	•	Single Line Connect Message	56
+GCI	•	•	•	•	•	•	Country Of Installation	56
%L	•	•	•	•	•	•	Line Signal Level	56
%Q	•	•	•	•	•	•	Line Quality	57
L	•	•	•	•	•	•	Speaker Loudness	57
M	•	•	•	•	•	•	Speaker Mode	57
+CMAR	•	•	•	•	•	•	Master Reset	57
Hayes AT Commands – DTE-Modem Interface Control								
E	•	•	•	•	•	•	Command Echo	58
Q	•	•	•	•	•	•	Quiet Result Codes	58
V	•	•	•	•	•	•	Response Format	59
X	•	•	•	•	•	•	Extended Result Codes	60
I	•	•	•	•	•	•	Identification Information	61
&C	•	•	•	•	•	•	Data Carrier Detect (DCD) Control	61
&D	•	•	•	•	•	•	Data Terminal Ready (DTR) Control	61
\Q	•	•	•	•	•	•	Standard Flow Control	63
&K	•	•	•	•	•	•	Flow Control	63
&S	•	•	•	•	•	•	Data Set Ready (DSR) Control	64
\R	•	•	•	•	•	•	Ring (RI) Control	65
+IPR	•	•	•	•	•	•	Fixed DTE Interface Rate	65
+IFC	•	•	•	•	•	•	DTE-Modem Local Flow Control	67
+ILRR	•	•	•	•	•	•	DTE-Modem Local Rate Reporting	67
+ICF	•	•	•	•	•	•	DTE-Modem Character Framing	68
Hayes AT Commands – Call Control								
D	•	•	•	•	•	•	Dial	69
T	•	•	•	•	•	•	Tone Dial	74
P	•	•	•	•	•	•	Pulse Dial	74
A	•	•	•	•	•	•	Answer	74



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862- QUAD, GM862- QUAD- PY, GM862- GPS	GE863- PRO ³	GE863- QUAD, GE863- PY, GT863- PY GE863- SIM, GE863- GPS	GE864- QUAD Automotive	SW 7.03.xx2 GE864- QUAD, GE864- PY, GT864- QUAD, GT864-PY GC864- QUAD, GC864- PY, GC864- DUAL	SW 10.00.xx3 GE865- QUAD, GL865- DUAL, GC864- QUAD, GC864- QUAD V2, GC864- DUAL V2, GE864- QUAD, GE864- QUAD V2, GE864- DUAL V2, GE864- QUAD Automotive V2, GE864- QUAD Atex	Function	Page
H	•	•	•	•	•	•	Disconnect	74
O	•	•	•	•	•	•	Return To On Line Mode	75
Hayes AT Commands – Modulation Control								
+MS	•	•	•	•	•	•	Modulation Selection	75
%E	•	•	•	•	•	•	Line Quality Monitor And Auto Retrain Or Fallback/Fallforward	76
Hayes AT Commands – Compression Control								
+DS	•	•	•	•	•	•	Data Compression	76
+DR	•	•	•	•	•	•	Data Compression Reporting	76
Hayes AT Commands – S Parameters								
S0	•	•	•	•	•	•	Number Of Rings To Auto Answer	78
S1	•	•	•	•	•	•	Ring Counter	79
S2	•	•	•	•	•	•	Escape Character	79
S3	•	•	•	•	•	•	Command Line Termination Character	80
S4	•	•	•	•	•	•	Response Formatting Character	81
S5	•	•	•	•	•	•	Command Line Editing Character	82
S7	•	•	•	•	•	•	Connection Completion Time-Out	83
S10	•	•	•	•	•	•	Carrier off with firm time	83
S12	•	•	•	•	•	•	Escape Prompt Delay	83
S25	•	•	•	•	•	•	Delay To DTR Off	85
S30	•	•	•	•	•	•	Disconnect Inactivity Timer	86
S38	•	•	•	•	•	•	Delay Before Forced Hang Up	86
3GPP TS 27.007 – General								
+CGMI	•	•	•	•	•	•	Request Manufacturer Identification	88
+CGMM	•	•	•	•	•	•	Request Model Identification	88
+CGMR	•	•	•	•	•	•	Request Revision Identification	88
+CGSN	•	•	•	•	•	•	Request Product SN Identification	89
+CSCS	•	•	•	•	•	•	Select TE Character Set	89
+CIMI	•	•	•	•	•	•	Request IMSI	90
+CMUX	•	•	•	•	•	•	Multiplexing Mode	91
+WS46	•	•	•	•	•	•	PCCA STD-101 Select Wireless Network	91
3GPP TS 27.007 – Call Control								
+CHUP	•	•	•	•	•	•	Hang Up Call	92



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862- QUAD, GM862- QUAD- PY, GM862- GPS	GE863- PRO ³	GE863- QUAD, GE863- PY, GT863- PY GE863- SIM, GE863- GPS	GE864- QUAD Automotive	SW 7.03.xx2	SW 10.00.xx3	Function	Page
					GE864- QUAD, GE864- PY, GT864- QUAD, GT864-PY GC864- QUAD, GC864- PY, GC864- DUAL	GE865- QUAD, GL865- DUAL, GC864- QUAD, GC864- QUAD V2, GC864- DUAL V2, GE864- QUAD, GE864- QUAD V2, GE864- DUAL V2, GE864- QUAD Automotive V2, GE864- QUAD Atex		
+CBST	•	•	•	•	•	•	Select Bearer Service Type	92
+CRLP	•	•	•	•	•	•	Radio Link Protocol	94
+CR	•	•	•	•	•	•	Service Reporting Control	95
+CEER	•	•	•	•	•	•	Extended Error Report	95
+CRC	•	•	•	•	•	•	Cellular Result Codes	96
+CSNS	•	•	•	•	•	•	Single Numbering Scheme	98
+CVHU	•	•	•	•	•	•	Voice Hang Up Control	98
3GPP TS 27.007 – Network Service Handling								
+CNUM	•	•	•	•	•	•	Subscriber Number	99
+COPN	•	•	•	•	•	•	Read Operator Names	100
+CREG	•	•	•	•	•	•	Network Registration Report	101
+COPS	•	•	•	•	•	•	Operator Selection	105
+CLCK	•	•	•	•	•	•	Facility Lock/Unlock	107
@CLCK	•	•	•	•	•	•	Facility Improved Lock/Unlock	112
+CPWD	•	•	•	•	•	•	Change Facility Password	114
+CLIP	•	•	•	•	•	•	Calling Line Identification Presentation	115
+CLIR	•	•	•	•	•	•	Calling Line Identification Restriction	118
+CCFC	•	•	•	•	•	•	Call Forwarding Number And Conditions	120
+CCWA	•	•	•	•	•	•	Call Waiting	121
+CHLD	•	•	•	•	•	•	Call Holding Services	125
+CUSD	•	•	•	•	•	•	Unstructured Supplementary Service Data	127
+CAOC	•	•	•	•	•	•	Advice Of Charge	130
+CLCC	•	•	•	•	•	•	List Current Calls	132
+CSSN	•	•	•	•	•	•	SS Notification	134
+CCUG	•	•	•	•	•	•	Closed User Group Supplementary Service Control	136
+CPOL	•	•	•	•	•	•	Preferred Operator List	138
+CPLS	•	•	•	•	•	•	Selection of preferred PLMN list	138
3GPP TS 27.007 – Mobile Equipment Control								
+CPAS	•	•	•	•	•	•	Phone Activity Status	139
+CFUN	•	•	•	•	•	•	Set Phone Functionality	140
+CPIN	•	•	•	•	•	•	Enter PIN	142
+CSQ	•	•	•	•	•	•	Signal Quality	148



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862- QUAD, GM862- QUAD- PY, GM862- GPS	GE863- PRO ³	GE863- QUAD, GE863- PY, GT863- PY GE863- SIM, GE863- GPS	GE864- QUAD Automotive	SW 7.03.xx2 GE864- QUAD, GE864- PY, GT864- QUAD, GT864-PY GC864- QUAD, GC864- PY, GC864- DUAL	SW 10.00.xx3 GE865- QUAD, GL865- DUAL, GC864- QUAD, GC864- QUAD V2, GC864- DUAL V2, GE864- QUAD, GE864- QUAD V2, GE864- DUAL V2, GE864- QUAD Automotive V2, GE864- QUAD Atex	Function	Page
+CGQREQ	•	•	•	•	•	•	Quality Of Service Profile (Requested)	195
+CGACT	•	•	•	•	•	•	PDP Context Activate Or Deactivate	198
+CGPADDR	•	•	•	•	•	•	Show PDP Address	200
+CGDATA	•	•	•	•	•	•	Enter Data State	201
+CGCMOD	•	•	•	•	•	•	Modify PDP context	202
3GPP TS 27.007 – Commands For Battery Charger								
+CBC	•	•	•	•	•	•	Battery Charge	203
3GPP TS 27.005 – General Configuration								
+CSMS	•	•	•	•	•	•	Select Message Service	205
+CPMS	•	•	•	•	•	•	Preferred Message Storage	206
+CMGF	•	•	•	•	•	•	Message Format	210
3GPP TS 27.005 – Message Configuration								
+CSCA	•	•	•	•	•	•	Service Center Address	211
+CSMP	•	•	•	•	•	•	Set Text Mode Parameters	213
+CSDH	•	•	•	•	•	•	Show Text Mode Parameters	218
+CSCB	•	•	•	•	•	•	Select Cell Broadcast Message Types	219
+CSAS	•	•	•	•	•	•	Save Settings	221
+CRES	•	•	•	•	•	•	Restore Settings	222
3GPP TS 27.005 – Message Receiving And Reading								
+CNMI	•	•	•	•	•	•	New Message Indications To Terminal Equipment	223
+CMGL	•	•	•	•	•	•	List Messages	236
@CMGL	•	•	•	•	•	•	List Messages Improved	244
+CMGR	•	•	•	•	•	•	Read Message	246
@CMGR	•	•	•	•	•	•	Read Message Improved	254
3GPP TS 27.005 – Message Sending And Writing								
+CMGS	•	•	•	•	•	•	Send Message	258
+CMSS	•	•	•	•	•	•	Send Message From Storage	266
+CMGW	•	•	•	•	•	•	Write Message To Memory	268
+CMGD	•	•	•	•	•	•	Delete Message	276
+CGSMS	•	•	•	•	•	•	Select service for MO SMS messages	279
FAX AT Commands – General Configuration								
+FMI	•	•	•	•	•	•	Manufacturer ID	280
+FMM	•	•	•	•	•	•	Model ID	280



AT Commands Reference Guide

80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862- QUAD, GM862- QUAD- PY, GM862- GPS	GE863- PRO ³	GE863- QUAD, GE863- PY, GT863- PY GE863- SIM, GE863- GPS	GE864- QUAD Automotive	SW 7.03.xx2	SW 10.00.xx3	Function	Page
					GE864- QUAD, GE864- PY, GT864- QUAD, GT864-PY GC864- QUAD, GC864- PY, GC864- DUAL	GE865- QUAD, GL865- DUAL, GC864- QUAD, GC864- QUAD V2, GC864- DUAL V2, GE864- QUAD, GE864- QUAD V2, GE864- DUAL V2, GE864- QUAD Automotive V2, GE864- QUAD Atex		
#PLMNMODE	•	•	•	•	•	•	PLMN List Selection	304
#PCT	•	•	•	•	•	•	Display PIN Counter	305
#SHDN	•	•	•	•	•	•	Software Shut Down	306
#Z	•	•	•	•	•	•	Extended Reset	306
#ENHRST						•	Periodic reset	307
#WAKE	•	•	•	•	•	•	Wake From Alarm Mode	307
#QTEMP	•	•	•	•	•	•	Query Temperature Overflow	309
#TEMPMON	•	•	•	•	•	•	Temperature Monitor	310
#SGPO	•	•	•	•	•		Set General Purpose Output	313
#GGPI	•	•	•	•	•		General Purpose Input	313
#GPIO	•	•	•	•	•	•	General Purpose I/O Pin Control	314
#SLED	•	•	•	•	•	•	STAT_LED GPIO Setting	316
#SLEDSAV	•	•	•	•	•	•	Save STAT_LED GPIO Setting	317
#E2SMSRI	•	•	•	•	•	•	SMS Ring Indicator	318
#ADC	•	•	•	-	•	•	Analog/Digital Converter Input	319
#DVI	• ¹³	•	•	•	•	•	Digital Voiceband Interface	317
#DAC		•	•		•	•	Digital/Analog Converter Control	321
#VAUX		•	•	•	•	• ¹⁴	Auxiliary Voltage Output Control	322
#VAUXSAV		•	•	•	•	•	#VAUX Saving	324
#V24MODE	•	•	•	•	•	•	V24 Output pins mode	324
#V24CFG	•	•	•	•	•	•	V24 Output Pins Configuration	326
#V24	•	•	•	•	•	•	V24 Output Pins Control	326
#AXE	•	•	•	•	•	• ¹⁵	AXE Pin Reading	327
#TXMONMODE		•	•	•	•	•	TTY-CTM-DSP Operating Mode	328
#CBC	•	•	•		•	•	Battery and Charger Status	328
#AUTOATT	•	•	•	•	•	•	GPRS Auto-Attach Property	329
#MSCCLASS	•	•	•	•	•	•	Multislot Class Control	330

¹³ GM862-GPS excluded.

¹⁴ Command available only on GE864-QUAD and GC864-QUAD with SW 10.00.xxx

¹⁵ Command not available on GE865-QUAD



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862- QUAD, GM862- QUAD- PY, GM862- GPS	GE863- PRO ³	GE863- QUAD, GE863- PY, GT863- PY GE863- SIM, GE863- GPS	GE864- QUAD Automotive	SW 7.03.xx2 GE864- QUAD, GE864- PY, GT864- QUAD, GT864-PY GC864- QUAD, GC864- PY, GC864- DUAL	SW 10.00.xx3 GE865- QUAD, GL865- DUAL, GC864- QUAD, GC864- QUAD V2, GC864- DUAL V2, GE864- QUAD, GE864- QUAD V2, GE864- DUAL V2, GE864- QUAD Automotive V2, GE864- QUAD Atex	Function	Page
#MONI	•	•	•	•	•	•	Cell Monitor	331
#SERVINFO	•	•	•	•	•	•	Serving Cell Information	335
#COPSMODE	•	•	•	•	•	•	+COPS Mode	339
#QSS	•	•	•	•	•	•	Query SIM Status	340
#DIALMODE	•	•	•	•	•	•	ATD Dialing Mode	342
#ACAL	•	•	•	•	•	•	Automatic Call	343
#ACALEXT	•	•	•	•	•	•	Extended Automatic Call	344
#ECAM	•	•	•	•	•	•	Extended Call Monitoring	345
#SMOV	•	•	•	•	•	•	SMS Overflow	347
#MBN	•	•	•	•	•	•	Mailbox Numbers	348
#MWI	•	•	•	•	•	•	Message Waiting Indicator	349
#CODEC	•	•	•	•	•	•	Audio Codec	351
#SHFEC	•	•	•	•	•	•	Handsfree Echo Canceller	352
#HFMICG	•	•	•	•	•	•	Handsfree Microphone Gain	353
#HSMICG	•	•	•	•	•	•	Handset Microphone Gain	354
#SHFSD	•	•	•	•	•	•	Set Headset Sidetone	355
#SPKMUT	•	•	•	•	•	•	Speaker Mute Control	356
#HFRECG	•	•	•	•	•	•	Handsfree Receiver Gain	356
#HSRECG	•	•	•	•	•	•	Handset Receiver Gain	357
#PRST	•	•	•	•	•	•	Audio Profile Factory Configuration	357
#PSAV	•	•	•	•	•	•	Audio Profile Configuration Save	358
#PSEL	•	•	•	•	•	•	Audio Profile Selection	359
#PSET	•	•	•	•	•	•	Audio Profile Setting	359
#SHFAGC	•	•	•	•	•	•	Handsfree Automatic Gain Control	360
#SHFNRR	•	•	•	•	•	•	Handsfree Noise Reduction	360
#SHSAGC	•	•	•	•	•	•	Handset Automatic Gain	361
#SHSEC	•	•	•	•	•	•	Handset Echo Canceller	361
#SHSNR	•	•	•	•	•	•	Handset Noise Reduction	362
#SHSSD	•	•	•	•	•	•	Set Handset Sidetone	362
#OAP	•	•	•	•	•	•	Open Audio Path	354
#NITZ	•	•	•	•	•	•	Network Timezone	364
#CCLK	•	•	•	•	•	•	Clock management	367
#ENS	•	•	•	•	•	•	Enhanced Network Selection	368



AT Commands Reference Guide

80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862- QUAD, GM862- QUAD- PY, GM862- GPS	GE863- PRO ³	GE863- QUAD, GE863- PY, GT863- PY GE863- SIM, GE863- GPS	GE864- QUAD Automotive	SW 7.03.xx2 GE864- QUAD, GE864- PY, GT864- QUAD, GT864-PY GC864- QUAD, GC864- PY, GC864- DUAL	SW 10.00.xx3 GE865- QUAD, GL865- DUAL, GC864- QUAD, GC864- QUAD V2, GC864- DUAL V2, GE864- QUAD, GE864- QUAD V2, GE864- DUAL V2, GE864- QUAD Automotive V2, GE864- QUAD Atex	Function	Page
#BND ¹⁶	•	•	•	•	•	•	Select Band	369
#AUTOBND ¹⁷	•	•	•	•	•	•	Automatic Band Selection	370
#SKIPESC	•	•	•	•	•	•	Skip Escape Sequence	371
#E2ESC	•	•	•	•	•	•	Escape Sequence Guard Time	373
#GAUTH	•	•	•	•	•	•	PPP-GPRS Connection Authentication Type	374
#GPPPCFG	•	•	•	•	•	•	PPP-GPRS Parameters Configuration	375
#RTCSTAT	•	•	•	•	•	•	RTC Status	376
#GSMAD	•	•	•	•	•	•	GSM Antenna Detection	377
#SIMDET	•	•	•	•	•	•	SIM Detection Mode	379
#ENHSIM	•	•	•	•	•	•	SIM Enhanced Speed	380
#SNUM	•	•	•	•	•	-	Subscriber Number	380
#SIMATR	•	•	•	•	•	•	SIM Answer to reset	381
#TTY	•	•	•	•	•	•	Teletype Writer Support	382
#CPUMODE	•	•	•	•	•	•	CPU Clock Mode	382
#GSMCONT	•	•	•	•	•	•	GSM Context Definition	382
#GSMCONTCFG	•	•	•	•	•	•	IPEGSM configurations	383
#CGPADDR	•	•	•	•	•	•	Show Address	384
#NWSCANTMR	•	•	•	•	•	•	Network Selection Timer	385
#BIQUADIN	•	•	•	•	•	•	Cascaded filters	386
#BIQUADOUT	•	•	•	•	•	•	Cascaded filters	387
#CESTHLCK	•	•	•	•	•	•	Call Establishment Lock	388
#CPASMODE	•	•	•	•	•	•	Phone activity status	388
#FASTCCID	•	•	•	•	•	•	ICCID SIM file reading mode	389
#I2CWR	•	•	•	•	•	•	I2C data via GPIO	389
#I2CRD	•	•	•	•	•	•	I2C data from GPIO	391
#PSMRI	•	•	•	•	•	•	Power saving mode ring	391
#SPCM	•	•	•	•	•	•	PCM Play and Receive	362
#SWLEVEL	•	•	•	•	•	•	Software level selection	392
#CFLO	•	•	•	•	•	•	Command flow control	393
#UDTSET	•	•	•	•	•	•	UDTSET command	299

¹⁶ Not available for GC864-DUAL, GC864-DUAL V2 and GE864-DUAL V2

¹⁷ Not available for GC864-DUAL, GC864-DUAL V2 and GE864-DUAL V2



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862- QUAD, GM862- QUAD- PY, GM862- GPS	GE863- PRO ³	GE863- QUAD, GE863- PY, GT863- PY GE863- SIM, GE863- GPS	GE864- QUAD Automotive	SW 7.03.xx2	SW 10.00.xx3	Function	Page
					GE864- QUAD, GE864- PY, GT864- QUAD, GT864-PY GC864- QUAD, GC864- PY, GC864- DUAL	GE865- QUAD, GL865- DUAL, GC864- QUAD, GC864- QUAD V2, GC864- DUAL V2, GE864- QUAD, GE864- QUAD V2, GE864- DUAL V2, GE864- QUAD Automotive V2, GE864- QUAD Atex		
#UDTSAV	•	•	•	•	•	•	UDTSAV command	300
#UDTRST	•	•	•	•	•	•	UDTRST command	300
#CMGLCONCINDEX	•	•	•	•	•	•	Report concatenated SMS indexes	393
#CODECINFO	•	•	•	•	•	•	Codec Information	394
#SII						•	Second Interface Instance	396
Custom AT Commands – General Configuration – Special Issues								
#OSC32KHZ				•			External 32kHz Oscillator	398
#LANG						•	Select language	399
+CAPD						•	Postpone alarm	399
+CCWE						•	Call meter maximum event	400
+CSDF						•	Setting date format	400
+CSIL						•	Silence command	401
+CSTF						•	Setting time format	402
+CTFR						•	Call deflection	402
+CTZR						•	Time zone reporting	403
+CTZU						•	Automatic time zone update	403
Custom AT Commands – AT Run Commands								
#SMSATRUN	•	•	•	•	•	•	Enable SMS Run AT Service	404
#SMSATRUNCFG	•	•	•	•	•	•	Set SMS Run AT Service parameters	406
#SMSATWL	•	•	•	•	•	•	SMS AT Run white list	407
#TCPATRUNCFG	•	•	•	•	•	•	Set TCP Run AT service parameters	408
#TCPATRUNL	•	•	•	•	•	•	TCP Run AT Service in server mode	410
#TCPATRUNFRWL	•	•	•	•	•	•	TCP AT Run Firewall list	411
#TCPATRUNAUTH	•	•	•	•	•	•	TCP AT Run authentication param list	412
#TCPATRUND	•	•	•	•	•	•	TCP AT Run in client mode	413
#TCPATRUNCLOSE	•	•	•	•	•	•	Close TCP Run AT socket	414
#TCPATCMDSEQ	•	•	•	•	•	•	TCP AT Run command sequence	415
#TCPATCONSER	•	•	•	•	•	•	TCP Run AT service to serial port	415
#ATRUNDELAY	•	•	•	•	•	•	Run AT Command execution	416
#ENAEVMONI	•	•	•	•	•	•	Enable EvMoni Service	417
#ENAEVMONICFG	•	•	•	•	•	•	EvMoni Service params	417
#EVMONI	•	•	•	•	•	•	Event monitoring	418
#CMGS	•	•	•	•	•	•	Send message	421



AT Commands Reference Guide

80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862- QUAD, GM862- QUAD- PY, GM862- GPS	GE863- PRO ³	GE863- QUAD, GE863- PY, GT863- PY GE863- SIM, GE863- GPS	GE864- QUAD Automotive	SW 7.03.xx2 GE864- QUAD, GE864- PY, GT864- QUAD, GT864-PY GC864- QUAD, GC864- PY, GC864- DUAL	SW 10.00.xx3 GE865- QUAD, GL865- DUAL, GC864- QUAD, GC864- QUAD V2, GC864- DUAL V2, GE864- QUAD, GE864- QUAD V2, GE864- DUAL V2, GE864- QUAD Automotive V2, GE864- QUAD Atex	Function	Page
#ICMP	•	•	•	•	•	•	ICMP Support	503
#TCPMAXDAT	•	•	•	•	•	•	Maximum TCP Payload Size	504
#TCPREASS	•	•	•	•	•	•	TCP Reassembly	504
#PING	•	•	•	•	•	•	Ping command	505
Custom AT Commands - E-Mail Management								
#ESMTP	•	•	•	•	•	•	E-mail SMTP Server	507
#EADDR	•	•	•	•	•	•	E-mail Sender Address	508
#EUSER	•	•	•	•	•	•	E-mail Authentication User Name	509
#EPASSW	•	•	•	•	•	•	E-mail Authentication Password	510
#SEMAIL	•	•	•	•	•	•	E-mail Sending With GPRS Context Activation	511
#EMAILACT	•	•	•	•	•	•	E-mail GPRS Context Activation	513
#EMAILD	•	•	•	•	•	•	E-mail Sending	516
#ESAV	•	•	•	•	•	•	E-mail Parameters Save	518
#ERST	•	•	•	•	•	•	E-mail Parameters Reset	518
#EMAILMSG	•	•	•	•	•	•	SMTP Read Message	519
Custom AT Commands - Easy Scan® Extension								
#CSURV	•	•	•	•	•	•	Network Survey	519
#CSURVC	•	•	•	•	•	•	Network Survey (Numeric Format)	526
#CSURVU	•	•	•	•	•	•	Network Survey Of User Defined Channels	532
#CSURVUC	•	•	•	•	•	•	Network Survey Of User Defined Channels (Numeric Format)	533
#CSURVB	•	•	•	•	•	•	BCCH Network Survey	535
#CSURVBC	•	•	•	•	•	•	BCCH Network Survey (Numeric Format)	536
#CSURVF	•	•	•	•	•	•	Network Survey Format	537
#CSURVNLF	•	•	•	•	•	•	<CR><LF> Removing On Easy Scan® Commands Family	538
#CSURVEXT	•	•	•	•	•	•	Extended Network Survey	538
#CSURVP	•	•	•	•	•	•	PLMN Network Survey	539
#CSURVPC	•	•	•	•	•	•	PLMN Network Survey (Numeric Format)	540
Custom AT Commands - SIM Toolkit								
#STIA	•	•	•	•	•	•	SIM Toolkit Interface Activation	540
#STGI	•	•	•	•	•	•	SIM Toolkit Get Information	547
#STSR	•	•	•	•	•	•	SIM Toolkit Send Response	554



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

COMMAND	GM862-QUAD, GM862-QUAD-PY, GM862-GPS	GE863-PRO ³	GE863-QUAD, GE863-PY, GT863-PY GE863-SIM, GE863-GPS	GE864-QUAD Automotive	SW 7.03.xx2 GE864-QUAD, GE864-PY, GT864-QUAD, GT864-PY GC864-QUAD, GC864-PY, GC864-DUAL	SW 10.00.xx3 GE865-QUAD, GL865-DUAL, GC864-QUAD, GC864-QUAD V2, GC864-DUAL V2, GE864-QUAD, GE864-QUAD V2, GE864-DUAL V2, GE864-QUAD, GE864-QUAD V2, GE864-DUAL V2, GE864-QUAD Automotive V2, GE864-QUAD ATEX	Function	Page
#STTA						•	SIM Toolkit Terminal Attach	555
Jammed Detect & Report AT commands								
#JDR	•	•	•	•	•	•	Jammed Detect & Report	556
Custom AT Commands - Easy Script® Extension - Python Interpreter¹⁸								
#WSCRIPT	•		•	•	•	•	Write Script	560
#ESCRIP	•		•	•	•	•	Select Active Script	562
#STARTMODESCR	•		•	•	•	•	Script Execution Start Mode	564
#EXECSCR	•		•	•	•	•	Execute Active Script	566
#RSCRIPT	•		•	•	•	•	Read Script	566
#LSCRIPT	•		•	•	•	•	List Script Names	568
#DSCRIPT	•		•	•	•	•	Delete Script	571
#REBOOT	•	•	•	•	•	•	Reboot	571
#CMUXSCR	•		•	•	•	•	CMUX Interface Enable	572
Custom AT Commands - SAP								
#RSEN	•	•	•	•	•	•	Remote SIM Enable	585

General Configuration Commands – AT Interface Backward Compatibility								
COMMAND	GM862- QUAD, GM862-QUAD- PY, GM862-GPS, GE863-QUAD, GE863-PY, GE863-SIM, GE863-GPS, GE864-QUAD, GC864-QUAD, GC864-PY, GE864-PY, GC864-QUAD V2, GE864-QUAD V2,				GE864-QUAD Automotive, GE863-PRO ³ , GC864-DUAL, GE865-QUAD, GE864-QUAD Automotive V2, GE864-DUAL V2, GC864-DUAL V2, GE864-QUAD ATEX		Function	Page
#SELINT		•					Select Interface Style	49

¹⁸ Python is a registered trademark of the Python Software Foundation.



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

Custom AT Commands - GPS Application					
COMMAND	All the other modules	GM862-GPS	GE863-GPS	Function	Page
\$GPSP	-	•	•	GPS Controller Power Management	573
\$GPSR	-	•	•	GPS Reset	574
\$GPSD	-	•	•	GPS Device Type Set	574
\$GPSSW	-	•	•	GPS Software Version	578
\$GPSAT	-	•	•	GPS Antenna Type Definition	575
\$GPSAV	-	•	•	GPS Antenna Supply Voltage Readout	576
\$GPSAI	-	•	•	GPS Antenna Current Readout	576
\$GPSAP	-	•	•	GPS Antenna Protection	577
\$GPSS ¹⁹	-	•	•	GPS NMEA Serial Port Speed	578
\$GPSNMUN	-	•	•	Unsolicited GPS NMEA Data Configuration	578
\$GPSACP	-	•	•	GPS Actual Position Information	580
\$GPSCON	-	•	•	Direct Access To GPS Module	581
\$GPSPRG	-	•	•	Set The GPS Module In Programming Mode	582
\$GPSPS	-	•	•	Set the GPS Module In Power Saving Mode	582
\$GPSWK	-	•	•	Wake Up GPS From Power Saving Mode	583
\$GPSSAV	-	•	•	Save GPS Parameters Configuration	584
\$GPSRST	-	•	•	Restore Default GPS Parameters	584
\$GPSCMODE	-	•	•	GPS Controller Disabled at Start-up With Charger Inserted	585

3.5. AT Commands References

3.5.1. Command Line General Format

3.5.1.1. Command Line Prefixes

3.5.1.1.1. Starting A Command Line - AT

AT - Starting A Command Line		SELINT 0 / 1 / 2
AT	The prefix AT , or at , is a two-character abbreviation (AT tention), always used to start a command line to be sent from TE to TA, with the only exception of AT#/ prefix	
Reference	3GPP TS 27.007	

3.5.1.1.2. Last Command Automatic Repetition - A/

A/ - Last Command Automatic Repetition		SELINT 0 / 1 / 2
A/	If the prefix A/ or a/ is issued, the MODULE immediately execute once again the body of the preceding command line. No editing is possible and no termination character is necessary. A command line may be repeated multiple times through this mechanism, if desired. If A/ is issued before any command line has been executed, the preceding	

¹⁹ Available for the GPS products with the following Order-Num.: 3990250689 and 3990250690



A/ - Last Command Automatic Repetition		SELINT 0 / 1 / 2
	<p>command line is assumed to have been empty (that results in an OK result code).</p> <p>Note: this command works only at fixed IPR.</p> <p>Note: the custom prefix AT#/ has been defined: it causes the last command to be executed again too; but it doesn't need a fixed IPR.</p>	
Reference	V25ter	

3.5.1.1.3. Repeat Last Command - AT#

AT#/- Repeat Last Command		SELINT 0 / 1 / 2
AT#	The prefix is used to execute again the last received command.	

3.5.2. General Configuration Commands

3.5.2.1. AT Interface Backward Compatibility

There are some slight modifications amongst the AT interfaces of Telit products. In order to keep backward compatibility and on the same time to give the opportunity to the customer to get competitor compatibility, Telit modules offer the specific command **#SELINT** to switch the behaviour of the device and its AT command interface. It is up to the user to select the AT interface he prefers.

The following table shows which AT commands interface can be applied and is default for the specific product:

Product	#SELINT=0	#SELINT=1	#SELINT=2
GT863-PY	•	•(default)	•
GT864-QUAD	•	•	•(default)
GT864-PY	•	•(default)	•
GM862-QUAD	•(default)	•	•
GM862-QUAD-PY	•	•(default)	•
GM862-GPS	•	•	•(default)



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

Product	#SELINT=0	#SELINT=1	#SELINT=2
GE863-QUAD	•	•(default)	•
GE863-PY	•	•(default)	•
GE863-SIM	•	•(default)	•
GE863-GPS	•	•	•(default)
GE863-PRO ³			•(default)
GE864-QUAD	•	•	•(default)
GE864-QUAD V2			•(default)
GE864-QUAD ATEX			•(default)
GE864-PY	•	•	•(default)
GE864-QUAD Automotive and GE864-QUAD Automotive V2			•(default)
GC864-QUAD with and without SIM Holder	•	•	•(default)
GC864-PY with and without SIM Holder	•	•	•(default)
GC864-QUAD V2 with and without SIM Holder			•(default)
GC864-DUAL and GC864-DUAL V2			•(default)
GE865-QUAD			•(default)



#SELINT - Select Interface Style		SELINT 2
	code to be returned.	
Note	Issuing AT#SELINT=<v> when the ENS functionality has been previously enabled (see #ENS) causes an ERROR result code to be returned.	
Note	Issuing AT#SELINT=<v> when the SMS Commands Operation Mode has been previously enabled (see #SMSMODE) causes an ERROR result code to be returned.	

3.5.3. Hayes Compliant AT Commands

3.5.3.1. Generic Modem Control

3.5.3.1.1. Set To Factory-Defined Configuration - &F

&F - Set To Factory-Defined Configuration		SELINT 0 / 1 / 2
AT&F[<value>]	<p>Execution command sets the configuration parameters to default values specified by manufacturer; it takes in consideration hardware configuration switches and other manufacturer-defined criteria.</p> <p>Parameter: <value>: 0 - just the factory profile base section parameters are considered. 1 - either the factory profile base section and the extended section are considered (full factory profile).</p> <p>Note: if parameter <value> is omitted, the command has the same behaviour as AT&F0</p>	
Reference	V25ter.	

3.5.3.1.2. Soft Reset - Z

Z - Soft Reset		SELINT 0 / 1 / 2
ATZ[<n>]	<p>Execution command loads the base section of the specified user profile and the extended section of the default factory profile.</p> <p>Parameter: <n> 0..1 - user profile number</p> <p>Note: any call in progress will be terminated.</p> <p>Note: if parameter <n> is omitted, the command has the same behaviour as ATZ0.</p>	



Z - Soft Reset		SELINT 0 / 1 / 2
Reference	V25ter.	

3.5.3.1.3. Select Active Service Class - +FCLASS

+FCLASS - Select Active Service Class		SELINT 0 / 1 / 2
AT+FCLASS=<n>	Set command sets the wireless module in specified connection mode (data, fax, voice), hence all the calls done afterwards will be data or voice. Parameter: <n> 0 - data 1 - fax class 1 8 - voice	
AT+FCLASS?	Read command returns the current configuration value of the parameter <n> .	
AT+FCLASS=?	Test command returns all supported values of the parameters <n> .	
Reference	3GPP TS 27.007	

3.5.3.1.4. Default Reset Basic Profile Designation - &Y

&Y - Default Reset Basic Profile Designation		SELINT 0 / 1 / 2
AT&Y[<n>]	Execution command defines the basic profiles which will be loaded on startup. Parameter: <n> 0..1 - profile (default is 0): the wireless module is able to store 2 complete configurations (see &W). Note: differently from command Z<n> , which loads just once the desired profile, the one chosen through command &Y will be loaded on every startup. Note: if parameter is omitted, the command has the same behaviour as AT&Y0	



3.5.3.1.5. Default Reset Full Profile Designation - &P

&P - Default Reset Full Profile Designation		SELINT 0 / 1 / 2
AT&P[<n>]	<p>Execution command defines which full profile will be loaded on startup.</p> <p>Parameter: <n> 0..1 – profile number: the wireless module is able to store 2 full configurations (see command &W).</p> <p>Note: differently from command Z<n>, which loads just once the desired profile, the one chosen through command &P will be loaded on every startup.</p> <p>Note: if parameter is omitted, the command has the same behaviour as AT&P0</p>	
Reference	Telit Specifications	

3.5.3.1.6. Store Current Configuration - &W

&W - Store Current Configuration		SELINT 0 / 1 / 2
AT&W[<n>]	<p>Execution command stores on profile <n> the complete configuration of the device.</p> <p>Parameter: <n> 0..1 - profile</p> <p>Note: if parameter is omitted, the command has the same behaviour of AT&W0.</p>	

3.5.3.1.7. Store Telephone Number - &Z

&Z - Store Telephone Number In The Wireless Module Internal Phonebook		SELINT 0 / 1 / 2
AT&Z<n>=<nr>	<p>Execution command stores in the record <n> the telephone number <nr>. The records cannot be overwritten, they must be cleared before rewriting.</p> <p>Parameters: <n> - phonebook record <nr> - telephone number (string type)</p> <p>Note: the wireless module has a built in non volatile memory in which 10 telephone numbers of a maximum 24 digits can be stored</p>	



&V0 - Display Current Configuration And Profile	SELINT 0 / 1 / 2
Note: the row of information about CTS (C106) OPTIONS is in the output of &V0 only for compatibility reasons and represents only a dummy value.	

3.5.3.1.16. S Registers Display - &V1

&V1 - S Registers Display	SELINT 0 / 1 / 2
AT&V1	<p>Execution command returns the value of the S registers in decimal and hexadecimal value in the format:</p> <pre> REG DEC HEX <reg0> <dec> <hex> <reg1> <dec> <hex> ... </pre> <p>where <reg<i>n</i>> - S register number 000..005 007 012 025 038 <dec> - current value in decimal notation <hex> - current value in hexadecimal notation</p>

3.5.3.1.17. Extended S Registers Display - &V3

&V3 - Extended S Registers Display	SELINT 0 / 1 / 2
AT&V3	<p>Execution command returns the value of the S registers in decimal and hexadecimal value in the format:</p> <pre> REG DEC HEX <reg0> <dec> <hex> <reg1> <dec> <hex> ... </pre> <p>where <reg<i>n</i>> - S register number 000..005 007 012 025 030 038 <dec> - current value in decimal notation</p>



	code. It must be verified before performing the master reset. Note: issuing the command will cause an NVM formatting. After the formatting is completed the module will automatically reboot.
AT+CMAR=?	Test command tests for command existence.

3.5.3.2. DTE - Modem Interface Control

3.5.3.2.1. Command Echo - E

E - Command Echo		SELINT 0 / 1 / 2
ATE[<n>]	Set command enables/disables the command echo. Parameter: <n> 0 - disables command echo 1 - enables command echo (factory default) , hence command sent to the device are echoed back to the DTE before the response is given. Note: if parameter is omitted, the command has the same behaviour of ATE0	
Reference	V25ter	

3.5.3.2.2. Quiet Result Codes - Q

Q - Quiet Result Codes		SELINT 0 / 1
ATQ[<n>]	Set command enables or disables the result codes. Parameter: <n> 0 - enables result codes (factory default) 1 - every result code is replaced with a <CR> 2 - disables result codes Note: After issuing either ATQ1 or ATQ2 every information text transmitted in response to commands is not affected Note: if parameter is omitted, the command has the same behaviour as ATQ0	
Example	<i>After issuing ATQ1</i>	



Q - Quiet Result Codes		SELINT 0 / 1
	<p>AT+CGACT=? +CGACT: (0-1) a <cr> ends the response</p> <p>After issuing ATQ2</p> <p>AT+CGACT=? +CGACT: (0-1) nothing is appended to the response</p>	
Reference	V25ter	
Q - Quiet Result Codes		SELINT 2
ATQ[<n>]	<p>Set command enables or disables the result codes.</p> <p>Parameter: <n> 0 - enables result codes (factory default) 1 - disables result codes 2 - disables result codes (only for backward compatibility)</p> <p>Note: After issuing either ATQ1 or ATQ2 every information text transmitted in response to commands is not affected</p> <p>Note: if parameter is omitted, the command has the same behaviour of ATQ0</p>	
Example	<p>After issuing ATQ1 or ATQ2</p> <p>AT+CGACT=? +CGACT: (0-1) nothing is appended to the response</p>	
Reference	V25ter	

3.5.3.2.3. Response Format - V

V - Response Format		SELINT 0 / 1 / 2
ATV[<n>]	<p>Set command determines the contents of the header and trailer transmitted with result codes and information responses. It also determines if result codes are transmitted in a numeric form or an alphanumeric form (see [§3.2.3 Information Responses And Result Codes] for the table of result codes).</p> <p>Parameter: <n> 0 - limited headers and trailers and numeric format of result codes</p>	



V - Response Format		SELINT 0 / 1 / 2								
	<table border="1"> <tr> <td>information responses</td> <td><text><CR><LF></td> </tr> <tr> <td>result codes</td> <td><numeric code><CR></td> </tr> </table> <p>1 - full headers and trailers and verbose format of result codes (factory default)</p> <table border="1"> <tr> <td>information responses</td> <td><CR><LF> <text><CR><LF></td> </tr> <tr> <td>result codes</td> <td><CR><LF> <verbose code><CR><LF></td> </tr> </table> <p>Note: the <text> portion of information responses is not affected by this setting.</p> <p>Note: if parameter is omitted, the command has the same behaviour of ATV0</p>	information responses	<text><CR><LF>	result codes	<numeric code><CR>	information responses	<CR><LF> <text><CR><LF>	result codes	<CR><LF> <verbose code><CR><LF>	
information responses	<text><CR><LF>									
result codes	<numeric code><CR>									
information responses	<CR><LF> <text><CR><LF>									
result codes	<CR><LF> <verbose code><CR><LF>									
Reference	V25ter									

3.5.3.2.4. Extended Result Codes - X

X - Extended Result Codes		SELINT 0 / 1 / 2
ATX[<n>]	<p>Set command selects the result code messages subset used by the modem to inform the DTE of the result of the commands.</p> <p>Parameter: <n> - (factory default is 1)</p> <p>0 - on entering dial-mode CONNECT result code is given; OK, CONNECT, RING, NO CARRIER, ERROR, NO ANSWER result codes are enabled . Dial tone and busy detection (NO DIALTONE and BUSY result codes) are disabled.</p> <p>1..4 - on entering dial-mode CONNECT <text> result code is given; all the other result codes are enabled.</p> <p>Note: If parameter is omitted, the command has the same behaviour of ATX0</p>	
Note	For complete control on CONNECT response message see also +DR command.	
Reference	V25ter	



3.5.3.2.5. Identification Information - I

I - Identification Information		SELINT 0 / 1 / 2
ATI[<n>]	<p>Execution command returns one or more lines of information text followed by a result code.</p> <p>Parameter: <n> 0 - numerical identifier 1 - module checksum 2 - checksum check result 3 - manufacturer 4 - product name 5 - DOB version</p> <p>Note: this is one of the commands whose output differs depending on the last #SELINT setting.</p> <p>Note: if parameter is omitted, the command has the same behaviour of ATI0</p>	
Reference	V25ter	

3.5.3.2.6. Data Carrier Detect (DCD) Control - &C

&C - Data Carrier Detect (DCD) Control		SELINT 0 / 1 / 2
AT&C[<n>]	<p>Set command controls the RS232 DCD output behaviour.</p> <p>Parameter: <n> 0 - DCD remains high always. 1 - DCD follows the Carrier detect status: if carrier is detected DCD is high, otherwise DCD is low. (factory default) 2 - DCD off while disconnecting</p> <p>Note: if parameter is omitted, the command has the same behaviour of AT&C0</p>	
Reference	V25ter	

3.5.3.2.7. Data Terminal Ready (DTR) Control - &D

&D - Data Terminal Ready (DTR) Control		SELINT 0 / 1
--	--	--------------



&D - Data Terminal Ready (DTR) Control		SELINT 0 / 1
AT&D[<n>]	<p>Set command controls the Module behaviour to the RS232 DTR transitions.</p> <p>Parameter: <n></p> <ul style="list-style-type: none"> 0 - device ignores DTR transitions (factory default) 1 - when the MODULE is connected, the High to Low transition of DTR pin sets the device in command mode, the current connection is NOT closed 2 - when the MODULE is connected , the High to Low transition of DTR pin sets the device in command mode and the current connection is closed 3 - device ignores DTR transitions 4 - C108/1 operation is disabled 5 - C108/1 operation is enabled; same behaviour as for <n>=2 <p>Note: if a connection has been set up issuing either #SKTD or #SKTOP, then AT&D1 has the same effect as AT&D2.</p> <p>Note: if AT&D2 has been issued and the DTR has been tied low, autoanswering is inhibited and it is possible to answer only issuing command ATA.</p> <p>Note: if parameter is omitted, the command has the same behaviour as AT&D0</p>	
Reference	V25ter	

&D - Data Terminal Ready (DTR) Control		SELINT 2
AT&D[<n>]	<p>Set command controls the Module behaviour to the RS232 DTR transitions.</p> <p>Parameter: <n></p> <ul style="list-style-type: none"> 0 - device ignores DTR transitions (factory default); if +CVHU current setting is different from 2 then every setting AT&D0 is equivalent to AT&D5 1 - when the MODULE is connected, the High to Low transition of DTR pin sets the device in command mode, the current connection is NOT closed; if +CVHU current setting is different from 2 then issuing AT&D1 is equivalent to AT&D5 2 - when the MODULE is connected , the High to Low transition of DTR pin sets the device in command mode and the current connection is closed; if +CVHU current setting is different from 2 then issuing AT&D2 is equivalent to AT&D5 3 - device ignores DTR transitions; if +CVHU current setting is different from 2 then issuing AT&D3 is equivalent to AT&D5 4 - C108/1 operation is disabled; if +CVHU current setting is different from 2 then issuing AT&D4 is equivalent to AT&D5 	



&D - Data Terminal Ready (DTR) Control		SELINT 2
	<p>5 - C108/1 operation is enabled; same behaviour as for <n>=2</p> <p>Note: if a connection has been set up issuing either #SKTD or #SKTOP, then AT&D1 has the same effect as AT&D2. If a connection has been set up issuing AT#SD then AT&D1 and AT&D2 have different effect, as described above.</p> <p>Note: if AT&D2 has been issued and the DTR has been tied Low, autoanswering is inhibited and it is possible to answer only issuing command ATA.</p> <p>Note: if parameter is omitted, the command has the same behaviour of AT&D0</p>	
Reference	V25ter	

3.5.3.2.8. Standard Flow Control - \Q

\Q - Standard Flow Control		SELINT 0 / 1 / 2
AT\Q[<n>]	<p>Set command controls the RS232 flow control behaviour.</p> <p>Parameter: <n></p> <ul style="list-style-type: none"> 0 - no flow control 1 - software bi-directional with filtering (XON/XOFF) 2 - hardware mono-directional flow control (only CTS active) 3 - hardware bi-directional flow control (both RTS/CTS active) (factory default) <p>Note: if parameter is omitted, the command has the same behaviour as AT\Q0</p> <p>Note: Hardware flow control (AT\Q3) is not active in command mode.</p> <p>Note: \Q's settings are functionally a subset of &K's ones.</p>	
Reference	V25ter	

3.5.3.2.9. Flow Control - &K

&K - Flow Control		SELINT 0 / 1 / 2
AT&K[<n>]	Set command controls the RS232 flow control behaviour.	



&K - Flow Control	SELINT 0 / 1 / 2
	<p>Parameter:</p> <p><n></p> <ul style="list-style-type: none"> 0 - no flow control 1 - hardware mono-directional flow control (only CTS active) 2 - software mono-directional flow control (XON/XOFF) 3 - hardware bi-directional flow control (both RTS/CTS active) (factory default) 4 - software bi-directional with filtering (XON/XOFF) 5 - pass through: software bi-directional without filtering (XON/XOFF) 6 - both hardware bi-directional flow control (both RTS/CTS active) and software bi-directional flow control (XON/XOFF) with filtering <p>Note: if parameter is omitted, the command has the same behaviour as AT&K0</p> <p>Note: &K has no Read Command. To verify the current setting of &K, simply check the settings of the active profile issuing AT&V.</p> <p>Note: Hardware flow control (AT&K3) is not active in command mode.</p>

3.5.3.2.10. Data Set Ready (DSR) Control - &S

&S - Data Set Ready (DSR) Control	SELINT 0 / 1 / 2
<p>AT&S<n></p>	<p>Set command controls the RS232 DSR pin behaviour.</p> <p>Parameter:</p> <p><n></p> <ul style="list-style-type: none"> 0 - always High 1 - follows the GSM traffic channel indication. 2 - High when connected 3 - High when device is ready to receive commands (factory default). <p>Note: if option 1 is selected then DSR is tied High when the device receives from the network the GSM traffic channel indication.</p> <p>Note: in power saving mode the DSR pin is always tied Low.</p> <p>Note: if parameter is omitted, the command has the same behaviour of AT&S0</p> <p>Note: If Selint=2 is selected, and option 1 and 2 are active, DSR will not tied</p>



&S - Data Set Ready (DSR) Control	SELINT 0 / 1 / 2
High in case of GSM voice connection	

3.5.3.2.11. Ring (RI) Control - \R

\R - Ring (RI) Control	SELINT 0 / 1 / 2
AT\R[<n>]	<p>Set command controls the RING output pin behaviour.</p> <p>Parameter: <n> 0 - RING on during ringing and further connection 1 - RING on during ringing (factory default) 2 - RING follows the ring signal</p> <p>Note: to check the ring option status use the &V command.</p> <p>Note: if parameter is omitted, the command has the same behaviour of AT\R0</p>

3.5.3.2.12. Fixed DTE Interface Rate - +IPR

+IPR - Fixed DTE Interface Rate	SELINT 0 / 1
AT+IPR=<rate>	<p>Set command specifies the DTE speed at which the device accepts commands during command mode operations; it may be used to fix the DTE-DCE interface speed.</p> <p>Parameter: <rate> 0 ..300 1200 2400 4800 9600 19200 38400 57600 115200</p> <p>If <rate> is set to 0, then automatic speed detection is enabled and also character format (see +ICF) is set to auto-detect. (default) If <rate> is specified and not 0, DTE-DCE speed is fixed at that</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

+IPR - Fixed DTE Interface Rate		SELINT 0 / 1
	<p>speed, hence no speed auto-detection (autobauding) is enabled.</p> <p>Note: While in autobauding mode the 300 baud rate is not supported.</p>	
AT+IPR?	Read command returns the current value of +IPR parameter.	
AT+IPR=?	Test command returns the supported serial port speed list.	
Reference	V25ter	

+IPR - Fixed DTE Interface Rate		SELINT 2
AT+IPR=<rate>	<p>Set command specifies the DTE speed at which the device accepts commands during command mode operations; it may be used to fix the DTE-DCE interface speed.</p> <p>Parameter: <rate> 0 ..300 1200 2400 4800 9600 19200 38400 57600 115200</p> <p>If <rate> is set to 0, then automatic speed detection is enabled and also character format (see +ICF) is set to auto-detect. (default)</p> <p>If <rate> is specified and not 0, DTE-DCE speed is fixed at that speed, hence no speed auto-detection (autobauding) is enabled.</p> <p>Note: While in autobauding mode the 300 baud rate is not supported.</p>	
AT+IPR?	Read command returns the current value of +IPR parameter.	
AT+IPR=?	<p>Test command returns the list of supported autodetectable <rate> values and the list of fixed-only <rate> values in the format:</p> <p>+IPR:(list of supported autodetectable <rate> values), (list of fixed-only <rate> values)</p>	
Reference	V25ter	



+ILRR - DTE-Modem Local Rate Reporting		SELINT 0 / 1 / 2
	Note: this information if enabled is sent upon connection.	
AT+ILRR?	Read command returns active setting of <n>.	
AT+ILRR=?	Test command returns all supported values of the parameter <n>	
Reference	V25ter	

3.5.3.2.15. DTE-Modem Character Framing - +ICF

+ICF - DTE-Modem Character Framing		SELINT 0 / 1 / 2
AT+ICF=<format> [,<parity>]	<p>Set command defines the asynchronous character framing to be used when autobauding is disabled.</p> <p>Parameters:</p> <p><format> - determines the number of bits in the data bits, the presence of a parity bit, and the number of stop bits in the start-stop frame.</p> <ul style="list-style-type: none"> 0 - autodetection 1 - 8 Data, 2 Stop 2 - 8 Data, 1 Parity, 1 Stop 3 - 8 Data, 1 Stop 5 - 7 Data, 1 Parity, 1 Stop <p><parity> - determines how the parity bit is generated and checked, if present; setting this subparameter is mandatory and has a meaning only if <format> subparameter is either 2 or 5.</p> <ul style="list-style-type: none"> 0 - Odd 1 - Even 	
AT+ICF?	Read command returns current settings for subparameters <format> and <parity>. If current setting of subparameter <format> is neither 2 nor 5, the current setting of subparameter <parity> will always represented as 0.	
AT+ICF=?	Test command returns the ranges of values for the parameters <format> and <parity>	
Reference	V25ter	
Example	<p><i>Auto detect</i></p> <pre>AT+ICF = 0 OK</pre> <p><i>8N2</i></p> <pre>AT+ICF = 1 OK</pre> <p><i>801</i></p>	



+ICF - DTE-Modem Character Framing		SELINT 0 / 1 / 2
	AT+ICF = 2,0 OK <i>8E1</i> AT+ICF = 2,1 OK <i>8N1</i> AT+ICF = 3 OK <i>7O1</i> AT+ICF = 5,0 OK <i>7E1</i> AT+ICF = 5,1 OK	

3.5.3.3. Call Control

3.5.3.3.1. Dial - D

D - Dial		SELINT 0 / 1
ATD<number>[;]	<p>Execution command starts a call to the phone number given as parameter. If ";" is present, a VOICE call to the given number is performed, regardless of the current value of the connection mode set by +FCLASS command.</p> <p>Parameter: <number> - phone number to be dialed</p> <p>Note: type of call (data, fax or voice) depends on last +FCLASS setting.</p> <p>Note: the numbers accepted are 0-9 and *,#, "A", "B", "C", "D", "+".</p> <p>Note: for backwards compatibility with landline modems modifiers "T", "P", "R", ",", "W", "!", "@ are accepted but have no effect.</p>	
ATD><str>[;]	<p>Issues a call to phone number which corresponding alphanumeric field is <str>; all available memories will be searched for the correct entry.</p> <p>If ";" is present a voice call is performed.</p> <p>Parameter:</p>	



D – Dial	SELINT 0 / 1
	<p><str> - alphanumeric field corresponding to phone number; it must be enclosed in quotation marks.</p> <p>Note: parameter <str> is case sensitive.</p> <p>Note: used character set should be the one selected with command Select TE character set +CSCS.</p>
<p>ATD<mem><n>[;]</p>	<p>Issues a call to phone number in phonebook memory storage <mem>, entry location <n> (available memories may be queried with AT+CPBS=?). If ";" is present a voice call is performed.</p> <p>Parameters:</p> <p><mem> - phonebook memory storage; it must not be enclosed in quotation marks.</p> <p>SM - SIM phonebook FD - SIM fixed dialling-phonebook LD - SIM last-dialling-phonebook MC - device missed (unanswered received) calls list RC - ME received calls list</p> <p><n> - entry location; it should be in the range of locations available in the memory used.</p>
<p>ATD<n>[;]</p>	<p>Issues a call to phone number in entry location <n> of the active phonebook memory storage (see +CPBS). If ";" is present a voice call is performed.</p> <p>Parameter:</p> <p><n> - active phonebook memory storage entry location; it should be in the range of locations available in the active phonebook memory storage.</p>
<p>ATDL</p>	<p>Issues a call to the last number dialed.</p>
<p>ATDS=<nr>[;]</p>	<p>Issues a call to the number stored in the MODULE internal phonebook position number <nr>. If ";" is present a VOICE call is performed.</p> <p>Parameter:</p> <p><nr> - internal phonebook position to be called (See either &N and &Z)</p>
<p>ATD<number>I[;] ATD<number>i[;]</p>	<p>Issues a call overwriting the CLIR supplementary service subscription default value for this call If ";" is present a VOICE call is performed.</p> <p>I - invocation, restrict CLI presentation i - suppression, allow CLI presentation</p>



D – Dial	SELINT 2
	<p>Note: the numbers accepted are 0-9 and *,#,"A", "B", "C", "D", "+".</p> <p>Note: for backwards compatibility with landline modems modifiers "T", "P", "R", ",", "W", "!", "@ are accepted but have no effect.</p>
<p>ATD<str>[;]</p>	<p>Issues a call to phone number which corresponding alphanumeric field is <str>; all available memories will be searched for the correct entry.</p> <p>If ";" is present a voice call is performed.</p> <p>Parameter: <str> - alphanumeric field corresponding to phone number; it must be enclosed in quotation marks.</p> <p>Note: parameter <str> is case sensitive.</p> <p>Note: used character set should be the one selected with +CSCS.</p>
<p>ATD<mem><n>[;]</p>	<p>Issues a call to phone number in phonebook memory storage <mem>, entry location <n> (available memories may be queried with AT+CPBS=?). If ";" is present a voice call is performed.</p> <p>Parameters: <mem> - phonebook memory storage; it must not be enclosed in quotation marks. SM - SIM phonebook FD - SIM fixed dialling-phonebook LD - SIM last-dialling-phonebook MC - device missed (unanswered received) calls list RC - ME received calls list MB - mailbox numbers stored on SIM, if this service is provided by the SIM (see #MBN). <n> - entry location; it should be in the range of locations available in the memory used.</p>
<p>ATD<n>[;]</p>	<p>Issues a call to phone number in entry location <n> of the active phonebook memory storage (see +CPBS). If ";" is present a voice call is performed.</p> <p>Parameter: <n> - active phonebook memory storage entry location; it should be in the range of locations available in the active phonebook memory storage.</p>
<p>ATDL</p>	<p>Issues a call to the last number dialed.</p>
<p>ATDS=<nr>[;]</p>	<p>Issues a call to the number stored in the MODULE internal phonebook position number <nr>.</p>



D – Dial	SELINT 2
	<p>If “;” is present a voice call is performed.</p> <p>Parameter: <nr> - internal phonebook position to be called (See commands &N and &Z)</p>
<p>ATD<number>l[;] ATD<number>i[;]</p>	<p>Issues a call overwriting the CLIR supplementary service subscription default value for this call If “;” is present a voice call is performed.</p> <p>l - invocation, restrict CLI presentation i - suppression, allow CLI presentation</p>
<p>ATD<number>G[;] ATD<number>g[;]</p>	<p>Issues a call checking the CUG supplementary service information for the current call. Refer to +CCUG command. If “;” is present a voice call is performed.</p>
<p>ATD*<gprs_sc> [*<addr>][* [<L2P>] [*<cid>]]#</p>	<p>This command is specific of GPRS functionality and causes the MT to perform whatever actions are necessary to establish communication between the TE and the external PDN.</p> <p>Parameters: <gprs_sc> - GPRS Service Code, a digit string (value 99) which identifies a request to use the GPRS <addr> - string that identifies the called party in the address space applicable to the PDP. <L2P> - a string which indicates the layer 2 protocol to be used (see +CGDATA command). For communications software that does not support arbitrary characters in the dial string, the following numeric equivalents shall be used: 1 - PPP <cid> - a digit which specifies a particular PDP context definition (see +CGDCONT command).</p>
<p>Example</p>	<p><i>To dial a number in SIM phonebook entry 6:</i> ATD>SM6 OK</p> <p><i>To have a voice call to the 6-th entry of active phonebook:</i> ATD>6 ; OK</p> <p><i>To call the entry with alphanumeric field “Name”:</i> ATD>“Name” ; OK</p>
<p>Reference</p>	<p>V25ter.</p>



3.5.3.3.6. Return To On Line Mode - 0

0 - Return To On Line Mode		SELINT 0 / 1
ATO	<p>Execution command is used to return to on-line mode from command mode. If there's no active connection it returns ERROR.</p> <p>Note: After issuing this command, if the device is in conversation, to send other commands to the device you must return to command mode by issuing the escape sequence (see register S2) or tying low DTR pin if &D1 option is active.</p>	
Reference	V25ter.	

0 - Return To On Line Mode		SELINT 2
ATO	<p>Execution command is used to return to on-line mode from command mode. If there's no active connection it returns NO CARRIER.</p> <p>Note: After issuing this command, if the device is in conversation, to send other commands to the device you must return to command mode by issuing the escape sequence (see register S2) or tying low DTR pin if &D1 option is active.</p>	
Reference	V25ter.	

3.5.3.4. Modulation Control

3.5.3.4.1. Modulation Selection - +MS

+MS - Modulation Selection		SELINT 0 / 1 / 2
AT+MS= <carrier> [,<automode> [,<min_rate> [,<max_rate>]]]	<p>Set command has no effect is included only for backward compatibility with landline modems.</p> <p>Parameters:</p> <p><carrier> - a string which specifies the preferred modem carrier to use in originating or answering a connection</p> <p>V21 V22 V22B V23C V32 V34</p> <p><automode> - it enables/disables automatic modulation negotiation.</p> <p>0 - disabled 1 - enabled. It has effect only if it is defined for the associated modulation.</p>	



+MS - Modulation Selection		SELINT 0 / 1 / 2
	<p><min_rate> - it specifies the lowest value at which the DCE may establish a connection. 0 - unspecified</p> <p><max_rate> - it specifies the highest value at which the DCE may establish a connection. 0 - unspecified 300..14400 - rate in bps</p> <p>Note: to change modulation requested use +CBST command.</p>	
AT+MS?	Read command returns the current value of <carrier>, <automode>, <min_rate>, <max_rate> parameters.	
AT+MS=?	Test command returns all supported values of the <carrier>, <automode>, <min_rate>, <max_rate> parameters.	

3.5.3.4.2. Line Quality And Auto Retrain - %E

%E - Line Quality Monitor And Auto Retrain Or Fallback/Fallforward		SELINT 0 / 1 / 2
AT%E<n>	Execution command has no effect and is included only for backward compatibility with landline modems.	

3.5.3.5. Compression Control

3.5.3.5.1. Data Compression - +DS

+DS - Data Compression		SELINT 0 / 1 / 2
AT+DS=[<n>]	Set command sets the V42 compression parameter. Parameter: <n> 0 - no compression, it is currently the only supported value; the command has no effect, and is included only for backward compatibility	
AT+DS?	Read command returns current value of the data compression parameter.	
AT+DS=?	Test command returns all supported values of the parameter <n>	
Reference	V25ter	

3.5.3.5.2. Data Compression Reporting - +DR

+DR - Data Compression Reporting		SELINT 0 / 1 / 2
AT+DR=<n>	Set command enables/disables the data compression reporting upon connection.	



+DR - Data Compression Reporting		SELINT 0 / 1 / 2
	Parameter: <n> 0 - data compression reporting disabled; 1 - data compression reporting enabled upon connection. Note: if enabled, the following intermediate result code is transmitted before the final result code: +DR: <compression> (the only supported value for <compression> is "NONE")	
AT+DR?	Read command returns current value of <n>.	
AT+DR=?	Test command returns all supported values of the parameter <n>	
Reference	V25ter	

3.5.3.6. S Parameters

Basic commands that begin with the letter "S" are known as "S-Parameters". The number following the "S" indicates the "parameter number" being referenced. If the number is not recognized as a valid parameter number, an **ERROR** result code is issued.

If no value is given for the subparameter of an **S-Parameter**, an **ERROR** result code will be issued and the stored value left unchanged.

Note: what follows is a special way to select and set an **S-parameter**:

1. **ATS<n><CR>** selects *n* as current parameter number. If the value of *n* is in the range (0, 2, 3, 4, 5, 7, 10, 12, 25, 30, 38), this command establishes **S*n*** as last selected parameter. Every value out of this range and less than 256 can be used but has no meaning and is maintained only for backward compatibility with landline modems.
2. **AT=<value><CR>** or **ATS=<value><CR>** set the contents of the selected **S-parameter**

Example:

ATS7<CR>	establishes S7 as last selected parameter.
AT=40<CR>	sets the content of S7 to 40
ATS=15<CR>	sets the content of S7 to 15.



3. **AT?** returns the current value of the last **S-parameter** accessed

Reference	V25ter and RC56D/RC336D
-----------	-------------------------

3.5.3.6.1. Number Of Rings To Auto Answer - S0

S0 - Number Of Rings To Auto Answer		SELINT 0 / 1
ATS0[=<n>]	Set command sets the number of rings required before device automatically answers an incoming call. Parameter: <n> - number of rings 0 - auto answer disabled (factory default) 1..255 - number of rings required before automatic answer.	
ATS0?	Read command returns the current value of S0 parameter.	
ATS0=?	Test command returns the range for <n> without command echo and parenthesis.	
Note	For either Read and Test command the format of the numbers in output is always 3 digits, left-filled with 0s	
Note	Automatically answer is not enabled if current instance is in online mode	
Reference	V25ter	

S0 - Number Of Rings To Auto Answer		SELINT 2
ATS0[=<n>]	Set command sets the number of rings required before device automatically answers an incoming call. Parameter: <n> - number of rings 0 - auto answer disabled (factory default) 1..255 - number of rings required before automatic answer.	
ATS0?	Read command returns the current value of S0 parameter.	
Reference	V25ter	



S2 - Escape Character		SELINT 2
	Parameter: <char> - escape character decimal ASCII 0..255 - factory default value is 43 (+). Note: the escape sequence consists of three escape characters preceded and followed by <i>n</i> ms of idle (see S12 to set <i>n</i>).	
ATS2?	Read command returns the current value of S2 parameter. Note: the format of the numbers in output is always 3 digits, left-filled with 0s	

3.5.3.6.4. Command Line Termination Character - S3

S3 - Command Line Termination Character		SELINT 0 / 1
ATS3[=<char>]	Set command sets the value of the character either recognized by the device as command line terminator and generated by the device as part of the header, trailer, and terminator for result codes and information text, along with S4 parameter. Parameter: <char> - command line termination character (decimal ASCII) 0..127 - factory default value is 13 (ASCII CR) Note: the “previous” value of S3 is used to determine the command line termination character for entering the command line containing the S3 setting command. However the result code issued shall use the “new” value of S3 (as set during the processing of the command line).	
ATS3?	Read command returns the current value of S3 parameter.	
ATS3=?	Test command returns the range for <char> without command echo and parenthesis.	
Note	For either Read and Test command the format of the numbers in output is always 3 digits, left-filled with 0s	
Reference	V25ter	

S3 - Command Line Termination Character		SELINT 2
ATS3=[<char>]	Set command sets the value of the character either recognized by the device as command line terminator and generated by the device as part of the header, trailer, and terminator for result codes and information text, along with S4 parameter. Parameter:	



S3 - Command Line Termination Character		SELINT 2
	<p><char> - command line termination character (decimal ASCII) 0..127 - factory default value is 13 (ASCII <CR>)</p> <p>Note: the “previous” value of S3 is used to determine the command line termination character for entering the command line containing the S3 setting command. However the result code issued shall use the “new” value of S3 (as set during the processing of the command line)</p>	
ATS3?	<p>Read command returns the current value of S3 parameter.</p> <p>Note: the format of the numbers in output is always 3 digits, left-filled with 0s</p>	
Reference	V25ter	

3.5.3.6.5. Response Formatting Character - S4

S4 - Response Formatting Character		SELINT 0 / 1
ATS4[=<char>]	<p>Set command sets the value of the character generated by the device as part of the header, trailer, and terminator for result codes and information text, along with the S3 parameter.</p> <p>Parameter: <char> - response formatting character (decimal ASCII) 0..127 - factory default value is 10 (ASCII LF)</p> <p>Note: if the value of S4 is changed in a command line the result code issued in response of that command line will use the new value of S4.</p>	
ATS4?	Read command returns the current value of S4 parameter.	
ATS4=?	Test command returns the range for <char> without command echo and parenthesis	
Note	For either Read and Test command the format of the numbers in output is always 3 digits, left-filled with 0s	
Reference	V25ter	

S4 - Response Formatting Character		SELINT 2
ATS4=[<char>]	<p>Set command sets the value of the character generated by the device as part of the header, trailer, and terminator for result codes and information text, along with the S3 parameter.</p> <p>Parameter: <char> - response formatting character (decimal ASCII) 0..127 - factory default value is 10 (ASCII LF)</p>	



S4 - Response Formatting Character		SELINT 2
	Note: if the value of S4 is changed in a command line the result code issued in response of that command line will use the new value of S4 .	
ATS4?	Read command returns the current value of S4 parameter. Note: the format of the numbers in output is always 3 digits, left-filled with 0s	
Reference	V25ter	

3.5.3.6.6. Command Line Editing Character - S5

S5 - Command Line Editing Character		SELINT 0 / 1
ATS5[=<char>]	Set command sets the value of the character recognized by the device as a request to delete from the command line the immediately preceding character. Parameter: <char> - command line editing character (decimal ASCII) 0..127 - factory default value is 8 (ASCII BS).	
ATS5?	Read command returns the current value of S5 parameter.	
ATS5=?	Test command returns the range for <char> without command echo and parenthesis.	
Note	For either Read and Test command the format of the numbers in output is always 3 digits, left-filled with 0s	
Reference	V25ter	

S5 - Command Line Editing Character		SELINT 2
ATS5=[<char>]	Set command sets the value of the character recognized by the device as a request to delete from the command line the immediately preceding character. Parameter: <char> - command line editing character (decimal ASCII) 0..127 - factory default value is 8 (ASCII BS)	
ATS5?	Read command returns the current value of S5 parameter. Note: the format of the numbers in output is always 3 digits, left-filled with 0s	
Reference	V25ter	



S12 - Escape Prompt Delay		SELINT 0 / 1
ATS12[=<time>]	<p>Set command sets:</p> <ol style="list-style-type: none"> 1) the minimum period, before receipt of the first character of the three escape character sequence, during which no other character has to be detected in order to accept it as valid first character; 2) the maximum period allowed between receipt of first, or second, character of the three escape character sequence and receipt of the next; 3) the minimum period, after receipt of the last character of the three escape character sequence, during which no other character has to be detected in order to accept the escape sequence as a valid one. <p>Parameter: <time> - expressed in fiftieth of a second 20..255 - factory default value is 50.</p> <p>Note: after CONNECT result code it is possible to accept the first character of the three escape character sequence without having to wait for a minimum period to be passed.</p>	
ATS12?	Read command returns the current value of S12 parameter.	
ATS12=?	Test command returns the range for <time> without command echo and parenthesis.	
Note	For either Read and Test command the format of the numbers in output is always 3 digits, left-filled with 0s	

S12 - Escape Prompt Delay		SELINT 2
ATS12=[<time>]	<p>Set command sets:</p> <ol style="list-style-type: none"> 1) the minimum period, before receipt of the first character of the three escape character sequence, during which no other character has to be detected in order to accept it as valid first character; 2) the maximum period allowed between receipt of first or second character of the three escape character sequence and receipt of the next; 3) the minimum period, after receipt of the last character of the three escape character sequence, during which no other character has to be detected in order to accept the escape sequence as a valid one. <p>Parameter: <time> - expressed in fiftieth of a second 20..255 - factory default value is 50.</p>	



S38 -Delay Before Forced Hang Up		SELINT 0 / 1
	<p>Parameter:</p> <p><delay> - expressed in seconds</p> <p>0..254 - the device will wait <delay> seconds for the remote device to acknowledge all data in the device buffer before disconnecting (factory default value is 0).</p> <p>255 - the device doesn't time-out and continues to deliver data in the buffer until the connection is lost or the data is delivered.</p> <p>Note: <delay> parameter can be used to ensure that data in device buffer is sent before device disconnects.</p>	
ATS38?	Read command returns the current value of S38 parameter.	
ATS38=?	Test command returns the range of supported values for <delay> without command echo and parenthesis.	
Note	For either Read and Test command the format of the numbers in output is always 3 digits, left-filled with 0s	

S38 -Delay Before Forced Hang Up		SELINT 2
ATS38=[<delay>]	<p>Set command sets the delay, in seconds, between the device's receipt of H command (or ON-to-OFF transition of DTR) and the disconnect operation.</p> <p>Parameter:</p> <p><delay> - acknowledge timer in units of seconds</p> <p>0..254 - the device will wait <delay> seconds for the remote device to acknowledge all data in the device buffer before disconnecting (factory default value is 0).</p> <p>255 - the device doesn't time-out and continues to attempt to deliver data in the buffer until the connection is lost or the data is delivered.</p> <p>Note: <delay> parameter can be used to ensure that data in device buffer is sent before device disconnects.</p>	
ATS38?	<p>Read command returns the current value of S38 parameter.</p> <p>Note: the format of the numbers in output is always 3 digits, left-filled with 0s</p>	



+CRC - Cellular Result Codes		SELINT 0 / 1
	<p>0 - disables extended format reporting (factory default) 1 - enables extended format reporting</p> <p>When enabled, an incoming call is indicated to the TE with unsolicited result code:</p> <p>+CRING:<type></p> <p>instead of the normal RING.</p> <p>where <type> - call type: DATA FAX - facsimile (TS 62) VOICE - normal voice (TS 11)</p>	
AT+CRC?	Read command returns current value of the parameter <mode> .	
AT+CRC=?	Test command returns supported values of the parameter <mode> .	
Reference	3GPP TS 27.007	

+CRC - Cellular Result Codes		SELINT 2
AT+CRC=[<mode>]	<p>Set command controls whether or not the extended format of incoming call indication is used.</p> <p>Parameter: <mode> 0 - disables extended format reporting (factory default) 1 - enables extended format reporting:</p> <p>When enabled, an incoming call is indicated to the TE with unsolicited result code</p> <p>+CRING: <type></p> <p>instead of the normal RING.</p> <p>where <type> - call type: ASYNC - asynchronous transparent data SYNC - synchronous transparent data REL ASYNC - asynchronous non-transparent data REL SYNC - synchronous non-transparent data FAX - facsimile (TS 62)</p>	



+CVHU - Voice Hang Up Control		SELINT 0 / 1
	<p><mode></p> <p>0 - "Drop DTR" ignored but OK result code given. ATH disconnects.</p> <p>1 - "Drop DTR" and ATH ignored but OK result code given.</p> <p>2 - "Drop DTR" behaviour according to &D setting. ATH disconnects (factory default).</p> <p>Note: if parameter <mode> is omitted the behaviour of Set command is the same as Read command.</p>	
AT+CVHU?	Read command reports the current value of the <mode> parameter, +CVHU: <mode>	
AT+CVHU=?	Test command reports the range of supported values for parameter <mode>	

+CVHU - Voice Hang Up Control		SELINT 2
AT+CVHU= [<mode>]	<p>Set command selects whether ATH or "drop DTR" shall cause a voice connection to be disconnected or not.</p> <p>Parameter:</p> <p><mode></p> <p>0 - "Drop DTR" ignored but OK result code given. ATH disconnects.</p> <p>1 - "Drop DTR" and ATH ignored but OK result code given.</p> <p>2 - "Drop DTR" behaviour according to &D setting. ATH disconnects (factory default).</p>	
AT+CVHU?	Read command reports the current value of the <mode> parameter, in the format: +CVHU: <mode>	
AT+CVHU=?	Test command reports the range of supported values for parameter <mode>	

3.5.4.3. Network Service Handling

3.5.4.3.1. Subscriber Number - +CNUM

+CNUM - Subscriber Number		SELINT 0 / 1
AT+CNUM	<p>Execution command returns the MSISDN (if the phone number of the device has been stored in the SIM card) in the format:</p> <p>+CNUM: <number>,<type></p> <p>where</p>	



+CREG - Network Registration Report	SELINT 0 / 1
	<p>identification data</p> <p>If <mode>=1, network registration result code reports:</p> <p>+CREG: <stat></p> <p>where <stat></p> <ul style="list-style-type: none"> 0 - not registered, ME is not currently searching a new operator to register to 1 - registered, home network 2 - not registered, but ME is currently searching a new operator to register to 3 - registration denied 4 - unknown 5 - registered, roaming <p>If <mode>=2, network registration result code reports:</p> <p>+CREG: <stat>[,<Lac>,<Ci>]</p> <p>where: <Lac> - Local Area Code for the currently registered on cell <Ci> - Cell Id for the currently registered on cell</p> <p>Note: <Lac> and <Ci> are reported only if <mode>=2 and the mobile is registered on some network cell.</p> <p>Note: issuing AT+CREG<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CREG=<CR> is the same as issuing the command AT+CREG=0<CR>.</p>
AT+CREG?	<p>Read command reports the <mode> and <stat> parameter values in the format:</p> <p>+CREG: <mode>,<stat>[,<Lac>,<Ci>]</p> <p>Note: <Lac> and <Ci> are reported only if <mode>=2 and the mobile is registered on some network cell.</p>
AT+CREG=?	Test command returns the range of supported <mode>
Example	<pre>AT OK at+creg? +CREG: 0,2 OK (the MODULE is in network searching state) at+creg? +CREG: 0,2</pre>



+CREG - Network Registration Report		SELINT 0 / 1
	<pre>OK at+creg? +CREG: 0,2 OK at+creg? +CREG: 0,2 OK at+creg? +CREG: 0,1 OK (the MODULE is registered) at+creg? +CREG: 0,1 OK</pre>	
Reference	3GPP TS 27.007	

+CREG - Network Registration Report		SELINT 2
AT+CREG= [<mode>]	<p>Set command enables/disables network registration reports depending on the parameter <mode>.</p> <p>Parameter: <mode> 0 - disable network registration unsolicited result code (factory default) 1 - enable network registration unsolicited result code 2 - enable network registration unsolicited result code with network Cell identification data</p> <p>If <mode>=1, network registration result code reports:</p> <p>+CREG: <stat></p> <p>where <stat> 0 - not registered, ME is not currently searching a new operator to register to 1 - registered, home network 2 - not registered, but ME is currently searching a new operator to register to 3 - registration denied 4 - unknown 5 - registered, roaming</p>	



+CREG - Network Registration Report	SELINT 2
	<p>If <mode>=2, network registration result code reports:</p> <p>+CREG: <stat>[,<Lac>,<Ci>]</p> <p>where:</p> <p><Lac> - Local Area Code for the currently registered on cell <Ci> - Cell Id for the currently registered on cell</p> <p>Note: <Lac> and <Ci> are reported only if <mode>=2 and the mobile is registered on some network cell.</p>
AT+CREG?	<p>Read command reports the <mode> and <stat> parameter values in the format:</p> <p>+CREG: <mode>,<stat>[,<Lac>,<Ci>]</p> <p>Note: <Lac> and <Ci> are reported only if <mode>=2 and the mobile is registered on some network cell.</p>
AT+CREG=?	<p>Test command returns the range of supported <mode></p>
Example	<pre>AT OK at+creg? +CREG: 0,2 OK <i>(the MODULE is in network searching state)</i> at+creg? +CREG: 0,2 OK at+creg? +CREG: 0,2 OK at+creg? +CREG: 0,2 OK at+creg? +CREG: 0,1 OK <i>(the MODULE is registered)</i> at+creg? +CREG: 0,1 OK</pre>
Reference	3GPP TS 27.007
Note	<p>There are situations in which the presentation of the URC controlled by +CREG is slightly different from ETSI specifications: e.g. it is possible to</p>



+CREG - Network Registration Report	SELINT 2
	<p>have an excessive presentation of the URC +CREG: 4. We identified this behaviour and decided to maintain it as default for backward compatibility issues. It is indeed possible to avoid it simply issuing AT#REGMODE=1 (see #REGMODE): this puts the Operation Mode of Registration Status Commands in 'Enhanced Registration Operation Mode' which is more formal.</p>

3.5.4.3.4. Operator Selection - +COPS

+COPS - Operator Selection	SELINT 0 / 1
<p>AT+COPS=[<mode> [,<format> [,<oper>]]]</p>	<p>Set command forces an attempt to select and register the GSM network operator.</p> <p><mode> parameter defines whether the operator selection is done automatically or it is forced by this command to operator <oper>. The operator <oper> shall be given in format <format>.</p> <p>The behaviour of +COPS command depends on the last #COPSMODE setting.</p> <p style="text-align: center;">(#COPSMODE=0)</p> <p>Parameters:</p> <p><mode></p> <ul style="list-style-type: none"> 0 - automatic choice (the parameter <oper> will be ignored) (factory default) 1 - manual choice unlocked (network is kept as long as available, then it can be changed with some other suited networks to guarantee the service) 2 - deregister from GSM network; the MODULE is kept unregistered until a +COPS with <mode>=0, 1, 4 or 5 is issued 3 - set only <format> parameter (the parameter <oper> will be ignored) 4 - manual/automatic (<oper> field shall be present); if manual selection fails, automatic mode (<mode>=0) is entered 5 - manual choice locked (network is kept fixed, if the chosen network is not available, then the mobile has no service) <p><format></p> <ul style="list-style-type: none"> 0 - alphanumeric long form (max length 16 digits) 1 - alphanumeric short form 2 - Numeric 5 or 6 digits [country code (3) + network code (2 or 3)] <p><oper>: network operator in format defined by <format> parameter.</p>



+COPS - Operator Selection	SELINT 0 / 1
	<p style="text-align: center;">(#COPSMODE=1)</p> <p>Parameters:</p> <p><mode> 0 - automatic choice (the parameter <oper> will be ignored) (default) 1 - manual choice (<oper> field shall be present) 2 - deregister from GSM network; the MODULE is kept unregistered until a +COPS with <mode>=0, 1 or 4 is issued 3 - set only <format> parameter (the parameter <oper> will be ignored) 4 - manual/automatic (<oper> field shall be present); if manual selection fails, automatic mode (<mode>=0) is entered</p> <p><format> 0 - alphanumeric long form (max length 16 digits) 2 - Numeric 5 or 6 digits [country code (3) + network code (2 or 3)]</p> <p><oper>: network operator in format defined by <format> parameter.</p> <p>Note: <mode> parameter setting is stored in NVM and available at next reboot, if it is not 3 (i.e.: set only <format> parameter).</p> <p>Note: if <mode>=1 or 4 (or 5 if #COPSMODE=0), the selected network is stored in NVM too and is available at next reboot (this will happen even with a new SIM inserted)</p> <p>Note: <format> parameter setting is never stored in NVM</p> <p>Note: issuing AT+COPS<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+COPS=<CR> is the same as issuing the command AT+COPS=0<CR>.</p>
AT+COPS?	<p>Read command returns current value of <mode>, <format> and <oper> in format <format>; if no operator is selected, <format> and <oper> are omitted</p> <p>+COPS: <mode>[, <format>, <oper>]</p>
AT+COPS=?	<p>Test command returns a list of quadruplets, each representing an operator present in the network.</p> <p>The behaviour of Test command depends on the last #COPSMODE setting.</p>



+COPS - Operator Selection	SELINT 0 / 1
	<p style="text-align: center;">(#COPSMODE=0)</p> <p>The command outputs as many rows as the number of quadruplets, each of them in the format:</p> <p>+COPS: (<stat> ,<oper (in <format>=0)>,"",<oper (in <format>=2)>)</p> <p>where</p> <p><stat> - operator availability</p> <ul style="list-style-type: none"> 0 - unknown 1 - available 2 - current 3 - forbidden <p style="text-align: center;">(#COPSMODE=1)</p> <p>The quadruplets in the list are separated by commas:</p> <p>+COPS: [list of supported (<stat> ,<oper (in <format>=0)>),,<oper (in <format>=2)>]s[,,(list of supported <mode>s), (list of supported<format>s)]</p> <p>where</p> <p><stat> - operator availability</p> <ul style="list-style-type: none"> 0 - unknown 1 - available 2 - current 3 - forbidden <p>Note: since with this command a network scan is done, this command may require some seconds before the output is given.</p> <p>Note: The value of parameter <oper> (in <format>=0) is the same as the former GM862 family products.</p>
Reference	3GPP TS 27.007

+COPS - Operator Selection	SELINT 2
AT+COPS= [<mode> [,<format> [,<oper>]]]	<p>Set command forces an attempt to select and register the GSM network operator.</p> <p><mode> parameter defines whether the operator selection is done automatically or it is forced by this command to operator <oper>.</p>



+COPS - Operator Selection		SELINT 2
	2 - current 3 - forbidden Note: since with this command a network scan is done, this command may require some seconds before the output is given.	
Reference	3GPP TS 27.007	

3.5.4.3.5. Facility Lock/Unlock - +CLCK

+CLCK - Facility Lock/Unlock		SELINT 0 / 1
AT+CLCK= <fac>,<mode> [,<passwd> [,<class>]]	<p>Execution command is used to lock or unlock a ME o a network facility.</p> <p>Parameters:</p> <p><fac> - facility "SC" - SIM (PIN request) (device asks SIM password at power-up and when this lock command issued) "AO" - BAOC (Barr All Outgoing Calls) "OI" - BOIC (Barr Outgoing International Calls) "OX" - BOIC-exHC (Barr Outgoing International Calls except to Home Country) "AI" - BAIC (Barr All Incoming Calls) "IR" - BIC-Roam (Barr Incoming Calls when Roaming outside the home country) "AB" - All Barring services (applicable only for <mode>=0) "AG" - All outGoing barring services (applicable only for <mode>=0) "AC" - All inComing barring services (applicable only for <mode>=0) "FD" - SIM fixed dialling memory feature (if PIN2 authentication has not been done during the current session, PIN2 is required as <passwd>) "PN" - network Personalisation "PU" - network subset Personalisation</p> <p><mode> - defines the operation to be done on the facility 0 - unlock facility 1 - lock facility 2 - query status</p> <p><passwd> - shall be the same as password specified for the facility from the DTE user interface or with command Change Password +CPWD</p>	



+CLCK - Facility Lock/Unlock		SELINT 0 / 1
	<p><class> - sum of integers each representing a class of information (default is 7)</p> <ul style="list-style-type: none"> 1 - voice (telephony) 2 - data (refers to all bearer services) 4 - fax (facsimile services) 8 - short message service 16 - data circuit sync 32 - data circuit async 64 - dedicated packet access 128 - dedicated PAD access <p>Note: when <mode>=2 and command successful, it returns:</p> <p>+CLCK: <status></p> <p>where</p> <p><status> - current status of the facility</p> <ul style="list-style-type: none"> 0 - not active 1 - active 	
AT+CLCK=?	Test command reports all the facility supported by the device.	
Reference	3GPP TS 27.007	
Note	The improving command @CLCK has been defined.	

+CLCK - Facility Lock/Unlock		SELINT 2
<p>AT+CLCK= <fac>,<mode> [,<passwd> [,<class>]]</p>	<p>Execution command is used to lock or unlock a ME o a network facility.</p> <p>Parameters:</p> <p><fac> - facility</p> <ul style="list-style-type: none"> "PS" - PH-SIM (lock PHone to SIM card) MT asks password when other than current SIM card inserted; MT may remember certain amount of previously used cards thus not requiring password when they are inserted "PF" - lock Phone to the very First inserted SIM card (MT asks password when other than the first SIM card is inserted) "SC" - SIM (PIN request) (device asks SIM password at power-up and when this lock command issued) "AO"- BAOC (Barr All Outgoing Calls) "OI" - BOIC (Barr Outgoing International Calls) "OX" - BOIC-exHC (Barr Outgoing International Calls except to Home Country) "AI" - BAIC (Barr All Incoming Calls) "IR" - BIC-Roam (Barr Incoming Calls when Roaming outside the home 	



+CLCK - Facility Lock/Unlock	SELINT 2
	<p>country)</p> <p>"AB" - All Barring services (applicable only for <mode>=0)</p> <p>"AG" - All outGoing barring services (applicable only for <mode>=0)</p> <p>"AC" - All inComing barring services (applicable only for <mode>=0)</p> <p>"FD" - SIM fixed dialling memory feature (if PIN2 authentication has not been done during the current session, PIN2 is required as <passwd>)</p> <p>"PN" - network Personalisation</p> <p>"PU" - network subset Personalisation</p> <p>"PP" - service Provider Personalization</p> <p>"PC" - Corporate Personalization</p> <p><mode> - defines the operation to be done on the facility</p> <p>0 - unlock facility</p> <p>1 - lock facility</p> <p>2 - query status</p> <p><passwd> - shall be the same as password specified for the facility from the DTE user interface or with command Change Password +CPWD</p> <p><class> - sum of integers each representing a class of information (default is 7)</p> <p>1 - voice (telephony)</p> <p>2 - data (refers to all bearer services)</p> <p>4 - fax (facsimile services)</p> <p>8 - short message service</p> <p>16 - data circuit sync</p> <p>32 - data circuit async</p> <p>64 - dedicated packet access</p> <p>128 - dedicated PAD access</p> <p>Note: when <mode>=2 and command successful, it returns: +CLCK: <status>[,<class1>[<CR><LF>+CLCK: <status>,<class2>[...]]</p> <p>where</p> <p><status> - the current status of the facility</p> <p>0 - not active</p> <p>1 - active</p> <p><classn> - class of information of the facility</p>
AT+CLCK=?	Test command reports all the facilities supported by the device.
Reference	3GPP TS 27.007
Example	<i>Querying such a facility returns an output on three rows, the first for voice, the second for data, the third for fax:</i>



+CLCK - Facility Lock/Unlock	SELINT 2
	AT+CLCK = "AO", 2 +CLCK: <status>, 1 +CLCK: <status>, 2 +CLCK: <status>, 4

3.5.4.3.6. Facility Improved Lock/Unlock - @CLCK

@CLCK - Facility Improved Lock/Unlock	SELINT 0 / 1
AT@CLCK= <fac>,<mode> [,<passwd> [,<class>]]	<p>Execution command is used to lock or unlock a ME o a network facility.</p> <p>Parameters:</p> <p><fac> - facility</p> <p>"SC" - SIM (PIN request) (device asks SIM password at power-up and when this lock command issued)</p> <p>"AO" - BAOC (Barr All Outgoing Calls)</p> <p>"OI" - BOIC (Barr Outgoing International Calls)</p> <p>"OX" - BOIC-exHC (Barr Outgoing International Calls except to Home Country)</p> <p>"AI" - BAIC (Barr All Incoming Calls)</p> <p>"IR" - BIC-Roam (Barr Incoming Calls when Roaming outside the home country)</p> <p>"AB" - All Barring services (applicable only for <mode>=0)</p> <p>"AG" - All outGoing barring services (applicable only for <mode>=0)</p> <p>"AC" - All inComing barring services (applicable only for <mode>=0)</p> <p>"FD" - SIM fixed dialling memory feature (if PIN2 authentication has not been done during the current session, PIN2 is required as <passwd>)</p> <p>"PN" - network Personalisation</p> <p>"PU" - network subset Personalisation</p> <p><mode> - defines the operation to be done on the facility</p> <p>0 - unlock facility</p> <p>1 - lock facility</p> <p>2 - query status</p> <p><passwd> - shall be the same as password specified for the facility from</p>



@CLCK - Facility Improved Lock/Unlock	SELINT 0 / 1
	<p>the DTE user interface or with command Change Password +CPWD</p> <p><class> - sum of integers each representing a class of information (default is 7)</p> <ul style="list-style-type: none"> 1 - voice (telephony) 2 - data (refers to all bearer services) 4 - fax (facsimile services) 8 - short message service 16 - data circuit sync 32 - data circuit async 64 - dedicated packet access 128 - dedicated PAD access <p>Note: when <mode>=2 and command successful, it returns: @CLCK: <status>[,<class1> [<CR><LF>@CLCK: <status>,<class2>[...]]</p> <p>where</p> <ul style="list-style-type: none"> <status> - the current status of the facility <ul style="list-style-type: none"> 0 - not active 1 - active <classn> - class of information of the facility
AT@CLCK=?	Test command reports all the facilities supported by the device.
Reference	3GPP TS 27.007
Example	<p><i>Querying such a facility returns an output on three rows, the first for voice, the second for data, the third for fax:</i></p> <pre> AT@CLCK = "AO" , 2 @CLCK: <status>,1 @CLCK: <status>,2 @CLCK: <status>,4 OK </pre>



+CLIP - Calling Line Identification Presentation		SELINT 0 / 1
Note	The command changes only the report behaviour of the device, it does not change CLI supplementary service setting on the network.	
+CLIP - Calling Line Identification Presentation		SELINT 2
AT+CLIP=[<n>]	<p>Set command enables/disables the presentation of the CLI (Calling Line Identity) at the TE. This command refers to the GSM supplementary service CLIP (Calling Line Identification Presentation) that enables a called subscriber to get the CLI of the calling party when receiving a mobile terminated call.</p> <p>Parameters:</p> <p><n></p> <ul style="list-style-type: none"> 0 - disables CLI indication (factory default) 1 - enables CLI indication <p>If enabled the device reports after each RING the response:</p> <p>+CLIP: <number>,<type>,"",128,<alpha>,<CLI_validity></p> <p>where:</p> <ul style="list-style-type: none"> <number> - string type phone number of format specified by <type> <type> - type of address octet in integer format <ul style="list-style-type: none"> 128 - both the type of number and the numbering plan are unknown 129 - unknown type of number and ISDN/Telephony numbering plan 145 - international type of number and ISDN/Telephony numbering plan (contains the character "+") <alpha> - string type; alphanumeric representation of <number> corresponding to the entry found in phonebook; used character set should be the one selected with command Select TE character set +CSCS. <CLI_validity> <ul style="list-style-type: none"> 0 - CLI valid 1 - CLI has been withheld by the originator. 2 - CLI is not available due to interworking problems or limitation or originating network. <p>Note: in the +CLIP: response they are currently not reported either the subaddress information (it's always "" after the 2nd comma) and the subaddress type information (it's always 128 after the 3rd comma)</p>	
AT+CLIP?	Read command returns the presentation status of the CLI in the format:	



+CLIP - Calling Line Identification Presentation		SELINT 2
	<p>+CLIP: <n>,<m> where: <n> 0 - CLI presentation disabled 1 - CLI presentation enabled <m> - status of the CLIP service on the GSM network 0 - CLIP not provisioned 1 - CLIP provisioned 2 - unknown (e.g. no network is present)</p> <p>Note: This command issues a status request to the network, hence it may take a few seconds to give the answer due to the time needed to exchange data with it.</p>	
AT+CLIP=?	Test command returns the supported values of parameter <n>	
Reference	3GPP TS 27.007	
Note	The command changes only the report behaviour of the device, it does not change CLI supplementary service setting on the network.	

3.5.4.3.9. Calling Line Identification Restriction - +CLIR

+CLIR - Calling Line Identification Restriction		SELINT 0 / 1
AT+CLIR=[<n>]	<p>Set command overrides the CLIR subscription when temporary mode is provisioned as a default adjustment for all following outgoing calls. This adjustment can be revoked by using the opposite command. This command refers to CLIR-service (GSM 02.81) that allows a calling subscriber to enable or disable the presentation of the CLI to the called party when originating a call.</p> <p>Parameter: <n> - facility status on the Mobile 0 - CLIR facility according to CLIR service network status 1 - CLIR facility active (CLI not sent) 2 - CLIR facility not active (CLI sent)</p> <p>Note: issuing AT+CLIR<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CLIR=<CR> is the same as issuing the command AT+CLIR=0<CR>.</p>	
AT+CLIR?	Read command gives the default adjustment for all outgoing calls (<n>) and also triggers an interrogation of the provision status of the CLIR service	



+CCWA - Call Waiting	SELINT 2
	<p>1 - voice (telephony) 2 - data 4 - fax (facsimile services) 8 - short message service 16 - data circuit sync 32 - data circuit async 64 - dedicated packet access 128 - dedicated PAD access</p> <p>Note: the response to the query command is in the format:</p> <p>+CCWA: <status>,<class1>[<CR><LF> +CCWA: <status>,<class2>[...]]</p> <p>where <status> represents the status of the service: 0 - inactive 1 - active <classn> - same as <class></p> <p>Note: the unsolicited result code enabled by parameter <n> is in the format::</p> <p>+CCWA: <number>,<type>,<class>,[<alpha>],[<cli_validity>] where: <number> - string type phone number of calling address in format specified by <type> <type> - type of address in integer format <class> - see before <alpha> - string type; alphanumeric representation of <number> corresponding to the entry found in phonebook; used character set should be the one selected with +CSCS. <cli_validity> 0 - CLI valid 1 - CLI has been withheld by the originator 2 - CLI is not available due to interworking problems or limitations of originating network</p> <p>Note: if parameter <cmd> is omitted then network is not interrogated.</p> <p>Note: in the query command the class parameter must not be issued.</p>



+CCWA - Call Waiting		SELINT 2
	<p>Note: the difference between call waiting report disabling (AT+CCWA = 0,1,7) and call waiting service disabling (AT+CCWA = 0,0,7) is that in the first case the call waiting indication is sent to the device by network but this last one does not report it to the DTE; instead in the second case the call waiting indication is not generated by the network. Hence the device results busy to the third party in the 2nd case while in the 1st case a ringing indication is sent to the third party.</p> <p>Note: The command AT+CCWA=1,0 has no effect a non sense and must not be issued..</p>	
AT+CCWA?	Read command reports the current value of the parameter <n> .	
AT+CCWA=?	Test command reports the supported values for the parameter <n> .	
Reference	3GPP TS 27.007	

3.5.4.3.12. Call Holding Services - +CHLD

+CHLD - Call Holding Services		SELINT 0 / 1
AT+CHLD=<n>	<p>Execution command controls the network call hold service. With this service it is possible to disconnect temporarily a call and keep it suspended while it is retained by the network, contemporary it is possible to connect another party or make a multiparty connection.</p> <p>Parameter: <n></p> <ul style="list-style-type: none"> 0 - releases all held calls, or sets the UDUB (User Determined User Busy) indication for a waiting call. 1 - releases all active calls (if any exist), and accepts the other (held or waiting) call 1X - releases a specific active call X 2 - places all active calls (if any exist) on hold and accepts the other (held or waiting) call. 2X - places all active calls on hold except call X with which communication shall be supported 3 - adds an held call to the conversation <p>Note: "X" is the numbering (starting with 1) of the call given by the sequence of setting up or receiving the calls (active, held or waiting) as seen by the served subscriber. Calls hold their number until they are released. New calls take the lowest available number.</p> <p>Note: where both a held and a waiting call exist, the above procedures apply</p>	



+CHLD - Call Holding Services		SELINT 0 / 1
	to the waiting call (i.e. not to the held call) in conflicting situation.	
AT+CHLD=?	Test command returns the list of supported <n>s. +CHLD: (0,1,2,3) Note: consider what has been written about the Set command relating the actions on a specific call (X).	
Reference	3GPP TS 27.007	
Note	ONLY for VOICE calls	

+CHLD - Call Holding Services		SELINT 2
AT+CHLD=[<n>]	Execution command controls the network call hold service. With this service it is possible to disconnect temporarily a call and keep it suspended while it is retained by the network, contemporary it is possible to connect another party or make a multiparty connection. Parameter: <n> 0 - releases all held calls, or sets the UDUB (User Determined User Busy) indication for a waiting call. (only from version D) 1 - releases all active calls (if any exist), and accepts the other (held or waiting) call 1X - releases a specific active call X 2 - places all active calls (if any exist) on hold and accepts the other (held or waiting) call. 2X - places all active calls on hold except call X with which communication shall be supported (only from version D). 3 - adds an held call to the conversation 4 - connects the two calls and disconnects the subscriber from both calls (Explicit Call Transfer (ECT)) Note: "X" is the numbering (starting with 1) of the call given by the sequence of setting up or receiving the calls (active, held or waiting) as seen by the served subscriber. Calls hold their number until they are released. New calls take the lowest available number. Note: where both a held and a waiting call exist, the above procedures apply to the waiting call (i.e. not to the held call) in conflicting situation.	
AT+CHLD=?	Test command returns the list of supported <n>s. +CHLD: (0,1,1X,2,2X,3,4)	



+CHLD - Call Holding Services		SELINT 2
Reference	3GPP TS 27.007	
Note	ONLY for VOICE calls	

3.5.4.3.13. Unstructured Supplementary Service Data - +CUSD

+CUSD - Unstructured Supplementary Service Data		SELINT 0 / 1
AT+CUSD=[[<n>[,<str> [,<dcs>]]]]	<p>Set command allows control of the Unstructured Supplementary Service Data (USSD [GSM 02.90]).</p> <p>Parameters:</p> <ul style="list-style-type: none"> <n> - is used to disable/enable the presentation of an unsolicited result code. <ul style="list-style-type: none"> 0 - disable the result code presentation in the DTA 1 - enable the result code presentation in the DTA <str> - USSD-string (when <str> parameter is not given, network is not interrogated) <ul style="list-style-type: none"> - If <dcs> indicates that GSM338 default alphabet is used ME/TA converts GSM alphabet into current TE character set (see +CSCS) - If <dcs> indicates that 8-bit data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number; e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65). <dcs> - GSM 3.38 Cell Broadcast Data Coding Scheme in integer format (default is 0). <p>Note: the unsolicited result code enabled by parameter <n> is in the format:</p> <p>+CUSD: <m>[,<str>,<dcs>] to the TE</p>	



+CUSD - Unstructured Supplementary Service Data		SELINT 0 / 1
	<p>where:</p> <p><m>:</p> <ul style="list-style-type: none"> 0 - no further user action required (network initiated USSD-Notify, or no further information needed after mobile initiated operation). 1 - further user action required (network initiated USSD-Request, or further information needed after mobile initiated operation) 2 - USSD terminated by the network 3 - other local client has responded 4 - operation not supported 5 - network time out <p>Note: in case of successful mobile initiated operation, DTA waits the USSD response from the network and sends it to the DTE before the final result code. This will block the AT command interface for the period of the operation.</p> <p>Note: issuing AT+CUSD<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CUSD=<CR> is the same as issuing the command AT+CUSD=0<CR>.</p>	
AT+CUSD?	Read command reports the current value of the parameter <n>	
AT+CUSD=?	Test command reports the supported values for the parameter <n>	
Reference	3GPP TS 27.007	
Note	Only mobile initiated operations are supported	

+CUSD - Unstructured Supplementary Service Data		SELINT 2
AT+CUSD= [<n>[,<str> [,<dcs>]]]	<p>Set command allows control of the Unstructured Supplementary Service Data (USSD [GSM 02.90]).</p> <p>Parameters:</p> <ul style="list-style-type: none"> <n> - is used to disable/enable the presentation of an unsolicited result code. <ul style="list-style-type: none"> 0 - disable the result code presentation in the DTA 1 - enable the result code presentation in the DTA 2 - cancel an ongoing USSD session (not applicable to read command response) <str> - USSD-string (when <str> parameter is not given, network is not interrogated) 	



+CUSD - Unstructured Supplementary Service Data	SELINT 2
	<ul style="list-style-type: none"> - If <dc> indicates that GSM338 default alphabet is used ME/TA converts GSM alphabet into current TE character set (see +CSCS). - If <dc> indicates that 8-bit data coding scheme is used: ME/TA converts each 8-bit octet into two IRA character long hexadecimal number; e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65). <p><dc> - GSM 3.38 Cell Broadcast Data Coding Scheme in integer format (default is 0).</p> <p>Note: the unsolicited result code enabled by parameter <n> is in the format:</p> <p>+CUSD: <m>[,<str>,<dc>] to the TE</p> <p>where:</p> <p><m>:</p> <ul style="list-style-type: none"> 0 - no further user action required (network initiated USSD-Notify, or no further information needed after mobile initiated operation). 1 - further user action required (network initiated USSD-Request, or further information needed after mobile initiated operation) 2 - USSD terminated by the network 3 - other local client has responded 4 - operation not supported 5 - network time out
AT+CUSD?	Read command reports the current value of the parameter <n>
AT+CUSD=?	Test command reports the supported values for the parameter <n>
Reference	3GPP TS 27.007
Note	Only mobile initiated operations are supported



3.5.4.3.14. Advice Of Charge - +CAOC

+CAOC - Advice Of Charge	SELINT 0 / 1
<p>AT+CAOC[= [<mode>]]</p>	<p>Set command refers to the Advice of Charge supplementary services that enable subscriber to get information about the cost of calls; the command also includes the possibility to enable an unsolicited event reporting of the Current Call Meter (CCM) information.</p> <p>Parameter: <mode> 0 - query CCM value 1 - disables unsolicited CCM reporting 2 - enables unsolicited CCM reporting</p> <p>Note: the unsolicited result code enabled by parameter <mode> is in the format:</p> <p>+CCCM: <ccm></p> <p>where: <ccm> - current call meter in home units, string type: three bytes of the CCM value in hexadecimal format (e.g. "00001E" indicates decimal value 30)</p> <p>Note: the unsolicited result code +CCCM is sent when the CCM value changes, but not more than every 10 seconds.</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

+CAOC - Advice Of Charge		SELINT 0 / 1
	<p>Note: issuing AT+CAOC<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CAOC=<CR> is the same as issuing the command AT+CAOC=0<CR>.</p>	
AT+CAOC?	<p>Read command reports the value of parameter <mode> in the format:</p> <p>+CAOC: <mode></p>	
AT+CAOC=?	<p>Test command reports the supported values for <mode> parameter.</p> <p>Note: the representation format doesn't match the v.25ter §5.7.3 "Information text formats for test commands". The output is:</p> <p>+CAOC: 0, 1, 2</p>	
Reference	3GPP TS 27.007	
Note	<p>+CAOC command returns an estimate of the cost of the current call only, produced by the MS and based on the information provided by either AoCI or AOCC supplementary services; it is not stored in the SIM.</p>	

+CAOC - Advice Of Charge		SELINT 2
AT+CAOC=<mode>	<p>Set command refers to the Advice of Charge supplementary services that enable subscriber to get information about the cost of calls; the command also includes the possibility to enable an unsolicited event reporting of the Current Call Meter (CCM) information.</p> <p>Parameter: <mode> 0 - query CCM value 1 - disables unsolicited CCM reporting 2 - enables unsolicited CCM reporting</p> <p>Note: the unsolicited result code enabled by parameter <mode> is in the format:</p> <p>+CCCM: <ccm></p> <p>where: <ccm> - current call meter in home units, string type: three bytes of the CCM value in hexadecimal format (e.g. "00001E" indicates decimal value 30)</p> <p>Note: the unsolicited result code +CCCM is sent when the CCM value changes, but not more than every 10 seconds.</p>	



+CAOC - Advice Of Charge		SELINT 2
AT+CAOC?	Read command reports the value of parameter <mode> in the format: +CAOC: <mode>	
AT+CAOC=?	Test command reports the supported values for <mode> parameter.	
Reference	3GPP TS 27.007	
Note	+CAOC command returns an estimate of the cost of the current call only, produced by the MS and based on the information provided by either AoCI or AOCC supplementary services; it is not stored in the SIM.	

3.5.4.3.15. List Current Calls - +CLCC

+CLCC - List Current Calls		SELINT 0 / 1
AT+CLCC	<p>Execution command returns the list of current calls and their characteristics in the format:</p> <p>[+CLCC:<id1>,<dir>,<stat>,<mode>,<mpty>,<number>,<type> [<CR><LF>+CLCC:<id2>,<dir>,<stat>,<mode>,<mpty>,<number>,<type> [...]]]</p> <p>where:</p> <p><idn> - call identification number</p> <p><dir> - call direction 0 - mobile originated call 1 - mobile terminated call</p> <p><stat> - state of the call 0 - active 1 - held 2 - dialling (MO call) 3 - alerting (MO call) 4 - incoming (MT call) 5 - waiting (MT call)</p>	



+CLCC - List Current Calls		SELINT 0 / 1
	<p><mode> - call type</p> <ul style="list-style-type: none"> 0 - voice 1 - data 2 - fax 9 - unknown <p><mpty> - multiparty call flag</p> <ul style="list-style-type: none"> 0 - call is not one of multiparty (conference) call parties 1 - call is one of multiparty (conference) call parties <p><number> - string type phone number in format specified by <type></p> <p><type> - type of phone number octet in integer format</p> <ul style="list-style-type: none"> 129 - national numbering scheme 145 - international numbering scheme (contains the character "+") <p>Note: If no call is active then only OK message is sent. This command is useful in conjunction with command +CHLD to know the various call status for call holding.</p>	
Reference	3GPP TS 27.007	

+CLCC - List Current Calls		SELINT 2
AT+CLCC	<p>Execution command returns the list of current calls and their characteristics in the format:</p> <p>[+CLCC:<id1>,<dir>,<stat>,<mode>,<mpty>,<number>,<type>,<alpha>[<CR><LF>+CLCC:<id2>,<dir>,<stat>,<mode>,<mpty>,<number>,<type>,<alpha>[...]]]</p> <p>where:</p> <ul style="list-style-type: none"> <id<i>n</i>> - call identification number <dir> - call direction <ul style="list-style-type: none"> 0 - mobile originated call 1 - mobile terminated call <stat> - state of the call <ul style="list-style-type: none"> 0 - active 1 - held 2 - dialing (MO call) 3 - alerting (MO call) 4 - incoming (MT call) 5 - waiting (MT call) <mode> - call type 	



+CSSN - SS Notification		SELINT 2
	<p>1 - enable</p> <p>When <n>=1 and a supplementary service notification is received after a mobile originated call setup, an unsolicited code:</p> <p>+CSSI: <code1> is sent to TE before any other MO call setup result codes, where: <code1>:</p> <ul style="list-style-type: none"> 1 - some of the conditional call forwardings are active 2 - call has been forwarded 3 - call is waiting 5 - outgoing calls are barred 6 - incoming calls are barred <p>When <m>=1 and a supplementary service notification is received during a mobile terminated call setup or during a call, an unsolicited result code:</p> <p>+CSSU: <code2> is sent to TE, where: <code2>:</p> <ul style="list-style-type: none"> 0 - this is a forwarded call (MT call setup) 2 - call has been put on hold (during a voice call) 3 - call has been retrieved (during a voice call). 	
AT+CSSN?	Read command reports the current value of the parameters.	
AT+CSSN=?	Test command reports the supported range of values for parameters <n> , <m> .	
Reference	3GPP TS 27.007	

3.5.4.3.17. Closed User Group - +CCUG

+CCUG - Closed User Group Supplementary Service Control		SELINT 0 / 1
AT+CCUG=[<n>[,<index>[,<info>]]]	<p>Set command allows control of the Closed User Group supplementary service [GSM 02.85].</p> <p>Parameters:</p> <p><n></p> <ul style="list-style-type: none"> 0 - disable CUG temporary mode (factory default). 1 - enable CUG temporary mode: it enables to control the CUG information on the air interface as a default adjustment for all following outgoing calls. 	



+CFUN - Set Phone Functionality	SELINT 2
	<p>sent or received. ME exits SLEEP mode only, if AT+CFUN=1 is entered 9 – just as 0 but with different wake-up events (see SW User Guide)</p> <p><rst> - reset flag 0 - do not reset the ME before setting it to <fun> functionality level 1 – reset the device. The device is fully functional after the reset. This value is available only for <fun> = 1 and for 10.00.xxx release</p> <p>Note: issuing AT+CFUN=4[,0] actually causes the module to perform either a network deregistration and a SIM deactivation.</p> <p>Note: if power saving enabled, it reduces the power consumption during the idle time, thus allowing a longer standby time with a given battery capacity.</p> <p>Note: to place the module in power saving mode, set the <fun> parameter at value = 5 and the line DTR (RS232) must be set to OFF. Once in power saving, the CTS line switch to the OFF status to signal that the module is really in power saving condition.</p> <p>During the power saving condition, before sending any AT command on the serial line, the DTR must be set to ON (0V) to exit from power saving and it must be waited for the CTS (RS232) line to go in ON status.</p> <p>Until the DTR line is ON, the module will not return back in the power saving condition.</p> <p>Note: the power saving function does not affect the network behaviour of the MODULE, even during the power save condition the module remains registered on the network and reachable for incoming calls or SMS. If a call incomes during the power save, then the module will wake up and proceed normally with the unsolicited incoming call code</p>
AT+CFUN?	Read command reports the current setting of <fun> .
AT+CFUN=?	Test command returns the list of supported values for <fun> and <rst> .
Reference	3GPP TS 27.007

3.5.4.4.3. Enter PIN - +CPIN

+CPIN - Enter PIN	SELINT 0 / 1
AT+CPIN[=<pin> [,<newpin>]]	<p>Set command sends to the device a password which is necessary before it can be operated (SIM PIN, SIM PUK, PH-SIM PIN, etc.).</p> <p>If the PIN required is SIM PUK or SIM PUK2, the <newpin> is required. This second pin, <newpin>, will replace the old pin in the SIM.</p> <p>The command may be used to change the SIM PIN by sending it with both</p>



+CPIN - Enter PIN	SELINT 0 / 1
	<p>parameters <pin> and <newpin> when PIN request is pending; if no PIN request is pending the command will return an error code and to change the PIN the command +CPWD must be used instead.</p> <p>Parameters: <pin> - string type value <newpin> - string type value.</p> <p>To check the status of the PIN request use the command AT+CPIN?</p> <p>Note: If all parameters are omitted then the behaviour of Set command is the same as Read command.</p>
<p>AT+CPIN?</p>	<p>Read command reports the PIN/PUK/PUK2 request status of the device in the form:</p> <p>+CPIN:<code> where: <code> - PIN/PUK/PUK2 request status code READY - ME is not pending for any password SIM PIN - ME is waiting SIM PIN to be given SIM PUK - ME is waiting SIM PUK to be given PH-SIM PIN - ME is waiting phone-to-SIM card password to be given PH-FSIM PIN - ME is waiting phone-to-very first SIM card password to be given PH-FSIM PUK - ME is waiting phone-to-very first SIM card unblocking password to be given SIM PIN2 - ME is waiting SIM PIN2 to be given; this <code> is returned only when the last executed command resulted in PIN2 authentication failure (i.e. +CME ERROR: 17) SIM PUK2 - ME is waiting SIM PUK2 to be given; this <code> is returned only when the last executed command resulted in PUK2 authentication failure (i.e. +CME ERROR: 18) PH-NET PIN - ME is waiting network personalization password to be given PH-NET PUK - ME is waiting network personalization unblocking password to be given PH-NETSUB PIN - ME is waiting network subset personalization password to be given PH-NETSUB PUK - ME is waiting network subset personalization unblocking password to be given PH-SP PIN - ME is waiting service provider personalization password to be given PH-SP PUK - ME is waiting service provider personalization unblocking</p>



+CPIN - Enter PIN	SELINT 2
	<p>Parameters: <pin> - string type value <newpin> - string type value.</p> <p>To check the status of the PIN request use the command AT+CPIN?</p> <p>Note: If all parameters are omitted then the behaviour of Set command is the same as Read command.</p>
<p>AT+CPIN?</p>	<p>Read command reports the PIN/PUK/PUK2 request status of the device in the form: +CPIN: <code> where: <code> - PIN/PUK/PUK2 request status code READY - ME is not pending for any password SIM PIN - ME is waiting SIM PIN to be given SIM PUK - ME is waiting SIM PUK to be given PH-SIM PIN - ME is waiting phone-to-SIM card password to be given PH-FSIM PIN - ME is waiting phone-to-very first SIM card password to be given PH-FSIM PUK - ME is waiting phone-to-very first SIM card unblocking password to be given SIM PIN2 - ME is waiting SIM PIN2 to be given; this <code> is returned only when the last executed command resulted in PIN2 authentication failure (i.e. +CME ERROR: 17) SIM PUK2 - ME is waiting SIM PUK2 to be given; this <code> is returned only when the last executed command resulted in PUK2 authentication failure (i.e. +CME ERROR: 18) PH-NET PIN - ME is waiting network personalization password to be given PH-NET PUK - ME is waiting network personalization unblocking password to be given PH-NETSUB PIN - ME is waiting network subset personalization password to be given PH-NETSUB PUK - ME is waiting network subset personalization unblocking password to be given PH-SP PIN - ME is waiting service provider personalization password to be given PH-SP PUK - ME is waiting service provider personalization unblocking password to be given PH-CORP PIN - ME is waiting corporate personalization password to be given PH-CORP PUK - ME is waiting corporate personalization unblocking password to be given</p>



+CPIN - Enter PIN			SELINT 2	
	\Q	#SPKMUT	+CGMM	+FDD
	\R	#ESMTP	+CGMR	\$GPS
	\V	#EADDR	+GMI	\$GPS
	#SELINT	#EUSER	+GMM	\$GPS
	#CGMI	#EPASSW	+GMR	\$GPS
	#CGMM	#SEMAIL	+CGSN	\$GPS
	#CGMR	#EMAILD	+GSN	\$GPS
	#CGSN	#ESAV	+CMUX	\$GPS
	#CAP	#ERST	+CHUP	\$GPS
	#SRS	#EMAILMSG	+CRLP	\$GPS
	#SRP	#CSURV	+CR	\$GPS
	#STM	#CSURVC	+CRC	\$GPS
	#PCT	#CSURVU	+CSNS	\$GPS
	#SHDN	#CSURVUC	+CREG	\$GPS
	#WAKE	#CSURVB	+COPS	\$GPS
	#QTEMP	#CSURVBC	+CLIP	\$GPS
	#GPIO	#CSURVF	+CPAS	\$GPS
	#ADC		+CFUN	\$GPS

All the above commands, but the ones in the grayed cells, can be issued even if the SIM card is not inserted yet.

All the above commands, but **+CSDH** and **+CNMI**, can be issued even if ME is waiting for phone-To-SIM card password to be given

Reference	3GPP TS 27.007
-----------	----------------

3.5.4.4. Signal Quality - +CSQ

+CSQ - Signal Quality		SELINT 0 / 1
AT+CSQ	<p>Execution command reports received signal quality indicators in the form:</p> <p>+CSQ: <rsssi>,<ber> where <rsssi> - received signal strength indication 0 - (-113) dBm or less 1 - (-111) dBm 2..30 - (-109)dBm..(-53)dBm / 2 dBm per step 31 - (-51)dBm or greater 99 - not known or not detectable</p>	



+CSQ - Signal Quality		SELINT 0 / 1
	<p><ber> - bit error rate (in percent)</p> <ul style="list-style-type: none"> 0 - less than 0.2% 1 - 0.2% to 0.4% 2 - 0.4% to 0.8% 3 - 0.8% to 1.6% 4 - 1.6% to 3.2% 5 - 3.2% to 6.4% 6 - 6.4% to 12.8% 7 - more than 12.8% 99 - not known or not detectable <p>Note: this command should be used instead of the %Q and %L commands, since GSM relevant parameters are the radio link ones and no line is present, hence %Q %L and have no meaning.</p>	
AT+CSQ?	Read command has the same effect as Execution command.	
AT+CSQ=?	Test command returns the supported range of values of the parameters <rssi> and <ber> .	
Reference	3GPP TS 27.007	
		SELINT 2
AT+CSQ	<p>Execution command reports received signal quality indicators in the form:</p> <p>+CSQ: <rssi>,<ber></p> <p>where</p> <p><rssi> - received signal strength indication</p> <ul style="list-style-type: none"> 0 - (-113) dBm or less 1 - (-111) dBm 2..30 - (-109)dBm..(-53)dBm / 2 dBm per step 31 - (-51)dBm or greater 99 - not known or not detectable <p><ber> - bit error rate (in percent)</p> <ul style="list-style-type: none"> 0 - less than 0.2% 1 - 0.2% to 0.4% 2 - 0.4% to 0.8% 3 - 0.8% to 1.6% 4 - 1.6% to 3.2% 5 - 3.2% to 6.4% 6 - 6.4% to 12.8% 7 - more than 12.8% 99 - not known or not detectable 	



+CSQ - Signal Quality		SELINT 0 / 1
	Note: this command should be used instead of the %Q and %L commands, since GSM relevant parameters are the radio link ones and no line is present, hence %Q and %L have no meaning.	
AT+CSQ=?	Test command returns the supported range of values of the parameters <rssI> and <ber>. Note: although +CSQ is an execution command without parameters, ETSI 07.07 requires the Test command to be defined.	
Reference	3GPP TS 27.007	

3.5.4.4.5. Indicator Control - +CIND

+CIND - Indicator Control		SELINT 0/1/2
AT+CIND= [<state> [,<state>[,...]]]	Set command is used to control the registration state of ME indicators, in order to automatically send the +CIEV URC, whenever the value of the associated indicator changes. The supported indicators (<descr>) and their order appear from test command AT+CIND=? Parameter: <state> - registration state 0 - the indicator is deregistered; there's no unsolicited result code (+CIEV URC) automatically sent by the ME to the application, whenever the value of the associated indicator changes; the value can be directly queried with +CIND? 1 - the indicator is registered: an unsolicited result code (+CIEV URC) is automatically sent by the ME to the application, whenever the value of the associated indicator changes; it is still possible to query the value through +CIND? (default) Note: When the ME is switched on all of the indicators are in registered mode.	
AT+CIND?	Read command returns the current value of ME indicators, in the format: +CIND: <ind>[,<ind>[,...]] Note: the order of the values <ind>s is the same as that in which the associated indicators appear from test command AT+CIND=?	
AT+CIND=?	Test command returns pairs, where string value <descr> is a description (max. 16 chars) of the indicator and compound value is the supported values for the indicator, in the format: +CIND: ((<descr>, (list of supported <ind>s))[,<descr>, (list of supported <ind>s))[,...]]	



+CPBS - Select Phonebook Memory Storage		SELINT 2
	<storage> .	
Reference	3GPP TS 27.007	

3.5.4.4.8. Read Phonebook Entries - +CPBR

+CPBR - Read Phonebook Entries		SELINT 0 / 1
AT+CPBR= <index1> [,<index2>]	<p>Execution command returns phonebook entries in location number range <index1>..<index2> from the current phonebook memory storage selected with +CPBS. If <index2> is omitted, only location <index1> is returned.</p> <p>Parameters:</p> <p><index1> - integer type value in the range of location numbers of phonebook memory</p> <p><index2> - integer type value in the range of location numbers of phonebook memory</p> <p>The response format is:</p> <p>+CPBR: <index>,<number>,<type>,<text></p> <p>where:</p> <p><index> - the current position number of the PB index (to see the range of values use +CPBR=?)</p> <p><number> - string type phone number in format <type></p> <p><type> - type of phone number octet in integer format</p> <p>129 - national numbering scheme</p> <p>145 - international numbering scheme (contains the character "+")</p> <p><text> - the alphanumeric text associated to the number; used character set should be the one selected with command +CSCS.</p> <p>Note: if "MC" is the current selected phonebook memory storage, all the missed calls coming from the same number will be saved as one missed call and +CPBR will show just one line of information.</p> <p>Note: If all queried locations are empty (but available), no information text lines will be returned, while if listing fails in an ME error, +CME ERROR: <err> is returned.</p>	
AT+CPBR=?	Test command returns the supported range of values of the parameters in the form:	



+CPBR - Read Phonebook Entries		SELINT 0 / 1
	<p>+CPBR: (<minIndex> - <maxIndex>),<nlength>,<tlength></p> <p>where: <minIndex> - the minimum <index> number, integer type <maxIndex> - the maximum <index> number, integer type <nlength> - maximum <number> field length, integer type <tlength> - maximum <name> field length, integer type</p>	
Note	Remember to select the PB storage with +CPBS command before issuing PB commands.	
Reference	3GPP TS 27.007	

+CPBR - Read Phonebook Entries		SELINT 2
AT+CPBR=<index1>[,<index2>]	<p>Execution command returns phonebook entries in location number range <index1>..<index2> from the current phonebook memory storage selected with +CPBS. If <index2> is omitted, only location <index1> is returned.</p> <p>Parameters: <index1> - integer type, value in the range of location numbers of the currently selected phonebook memory storage (see +CPBS). <index2> - integer type, value in the range of location numbers of the currently selected phonebook memory storage (see +CPBS).</p> <p>The response format is: [+CPBR: <index1>,<number>,<type>,<text>[<CR><LF>+CPBR: <index2>,<number>,<type>,<text>[...]]]</p> <p>where: <indexn> - the location number of the phonebook entry <number> - string type phone number of format <type> <type> - type of phone number octet in integer format 129 - national numbering scheme 145 - international numbering scheme (contains the character "+") <text> - the alphanumeric text associated to the number; used character set should be the one selected with command +CSCS.</p> <p>Note: if "MC" is the currently selected phonebook memory storage, a sequence of missed calls coming from the same number will be saved as one missed call and +CPBR will show just one line of information.</p> <p>Note: If all queried locations are empty (but available), no information text lines will be returned, while if listing fails in an ME error, +CME ERROR:</p>	



+CPBF - Find Phonebook Entries		SELINT 0 / 1
	<p>where <index<i>n</i>>, <number>, <type>, and <text> have the same meaning as in the command +CPBR report.</p> <p>Note: +CPBF is not applicable if the current selected storage (see +CPBS) is either "MC", either "RC" or "LD".</p> <p>Note: if no PB records satisfy the search criteria then an ERROR message is reported.</p>	
AT+CPBF=?	<p>Test command reports the maximum lengths of <number> and <text> fields.</p> <p>+CPBF: [<max_number_length>],[<max_text_length>]</p>	
Note	Remember to select the PB storage with +CPBS command before issuing PB commands.	
Reference	3GPP TS 27.007	

+CPBF - Find Phonebook Entries		SELINT 2
AT+CPBF= <findtext>	<p>Execution command returns phonebook entries (from the current phonebook memory storage selected with +CPBS) which alphanumeric field start with string <findtext>.</p> <p>Parameter: <findtext> - string type; used character set should be the one selected with command +CSCS.</p> <p>The command returns a report in the form:</p> <p>[+CPBF: <index1>,<number>,<type>,<text>[<CR><LF> +CPBF: <index2>,<number>,<type>,<text>[...]]]</p> <p>where:</p> <p><index<i>n</i>> - the location number of the phonebook entry <number> - string type phone number of format <type> <type> - type of phone number octet in integer format 129 - national numbering scheme 145 - international numbering scheme (contains the character "+") <text> - the alphanumeric text associated to the number; used character set should be the one selected with command +CSCS.</p> <p>Note: +CPBF is not applicable if the current selected storage (see +CPBS) is either "MC", either "RC" or "LD".</p>	



+CPBW - Write Phonebook Entry		SELINT 0 / 1
	<p>Note: If record number <index> already exists, it will be overwritten.</p> <p>Note: if only <index> is given, the record number <index> is deleted.</p> <p>Note: if <index> is omitted or <index>=0, the number <number> is stored in the first free phonebook location. (example <code>at+cpbw=0,2,129,"Testo"</code> and <code>at+cpbw=,2,129,"Testo"</code>)</p> <p>Note: omission of all the subparameters causes an ERROR result code.</p>	
AT+CPBW=?	<p>Test command returns location range supported by the current storage as a compound value, the maximum length of <number> field, supported number format of the storage and maximum length of <text> field. The format is:</p> <p>+CPBW: (list of supported <index>s),<nlength>, (list of supported <type>s),<tlength></p> <p>where:</p> <p><nlength> - integer type value indicating the maximum length of field <number></p> <p><tlength> - integer type value indicating the maximum length of field <text></p>	
Reference	3GPP TS 27.007	
Note	Remember to select the PB storage with +CPBS command before issuing PB commands.	

+CPBW - Write Phonebook Entry		SELINT 2
AT+CPBW= [<index>] [,<number> [<type> [,<text>]]]	<p>Execution command writes phonebook entry in location number <index> in the current phonebook memory storage selected with +CPBS.</p> <p>Parameters:</p> <p><index> - integer type, value in the range of location numbers of the currently selected phonebook memory storage (see +CPBS).</p> <p><number> - string type, phone number in the format <type></p> <p><type> - the type of number 129 - national numbering scheme 145 - international numbering scheme (contains the character "+")</p> <p><text> - the text associated to the number, string type; used character set should be the one selected with command +CSCS.</p>	



+CPBW - Write Phonebook Entry	SELINT 2
	<p>Note: If record number <index> already exists, it will be overwritten.</p> <p>Note: if either <number>, <type> and <text> are omitted, the phonebook entry in location <index> is deleted.</p> <p>Note: if <index> is omitted or <index>=0, the number <number> is stored in the first free phonebook location. (example <code>at+cpbw=0,"+390404192701",129,"Text"</code> and <code>at+cpbw="+390404192701",129,"Text"</code>)</p> <p>Note: if either "LD", "MC" or "RC" memory storage has been selected (see +CPBS) it is possible just to delete the phonebook entry in location <index>, therefore parameters <number>, <type> and <text> must be omitted.</p>
AT+CPBW=?	<p>Test command returns location range supported by the current storage as a compound value, the maximum length of <number> field, supported number format of the storage and maximum length of <text> field. The format is:</p> <p>+CPBW: (list of supported <index>s),<nlength>, (list of supported <type>s),<tlength></p> <p>where:</p> <p><nlength> - integer type value indicating the maximum length of field <number>.</p> <p><tlength> - integer type value indicating the maximum length of field <text></p> <p>Note: the value of <nlength> could vary, depending on whether or not the ENS functionality has been previously enabled (see #ENS), in the following situations:</p> <ol style="list-style-type: none"> 1. if "SM" memory storage has been selected (see +CPBS) and the SIM supports the Extension1 service 2. if "FD" memory storage has been selected (see +CPBS) and the SIM supports the Extension2 service <ol style="list-style-type: none"> 1. if "MB" memory storage has been selected (see +CPBS) and the SIM supports the Extension6 service
Reference	3GPP TS 27.007
Note	Remember to select the PB storage with +CPBS command before issuing PB commands.



+CCLK - Clock Management		SELINT 2
	OK	
Reference	3GPP TS 27.007	

3.5.4.4.13. Alarm Management - +CALA

+CALA - Alarm Management		SELINT 0 / 1
<p>AT+CALA[= <time>[,<n>[,<type> [,<text>[,<recurr> [,<silent>]]]]]]</p>	<p>Set command stores in the internal Real Time Clock an alarm time with respective settings. It is possible to set up a recurrent alarm for one or more days in the week. Currently just one alarm can be set.</p> <p>When the RTC time reaches the alarm time then the alarm starts, the behaviour of the MODULE depends upon the setting <type> and if the device was already ON at the moment when the alarm time had come.</p> <p>Parameters:</p> <p><time> - current alarm time as quoted string "" - (empty string) deletes the current alarm and resets all the +CALA parameters to the "factory default" configuration "hh:mm:ss±zz" - format to be used only when issuing +CALA with parameter <recurr> too. "yy/MM/dd,hh:mm:ss±zz" - generic format: it's the same as defined for +CCLK (see)</p> <p><n> - index of the alarm 0 - The only value supported is 0.</p> <p><type> - alarm behaviour type 0 - reserved for other equipment use. 1 - the MODULE simply wakes up fully operative as if the ON/OFF button had been pressed. If the device is already ON at the alarm time, then it does nothing (default). 2 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE issues an unsolicited code every 3s:</p> <p>+CALA: <text></p>	



+CALA - Alarm Management		SELINT 0 / 1
	Note: If the parameter is omitted the behavior of Set command is the same as Read command.	
AT+CALA?	Read command returns the list of current active alarm settings in the ME, in the format: [+CALA: <time>,<n>,<type>,<[text]>,<recurr>,<silent>] Note: if no alarm is present a <CR><LF> is issued.	
AT+CALA=?	Test command returns the list of supported index values (currently just 0), alarm types and maximum length of the text to be displayed, in the format: +CALA: (list of supported <n>s),(list of supported <type>s),<tlength> where: <n> and <type> as before <tlength> - maximum <text> field length, integer type Note: an enhanced version of Test command has been defined, AT+CALA=?? , providing the range of available values for <rlength> and <silent> too.	
AT+CALA=??	Test command returns the list of supported index values (currently just 0), alarm types, maximum length of the text to be displayed, maximum length of <recurr> and supported <silent>s, in the format: +CALA: (list of supported <n>s),(list of supported <type>s),<tlength>,<rlength>,(list of supported <silent>s) where: <n>, <type>, <tlength> and <silent> as before <rlength> - maximum <recurr> field length, integer type	
Example	AT+CALA= "02/09/07, 23:30:00+00" OK	
Reference	ETSI 07.07, ETSI 27.007	

+CALA - Alarm Management		SELINT 2
AT+CALA= <time>[,<n>[,<type> [,<text>[,<recurr> [,<silent>]]]]]	Set command stores in the internal Real Time Clock an alarm time with respective settings. It is possible to set up a recurrent alarm for one or more days in the week. Currently just one alarm can be set. When the RTC time reaches the alarm time then the alarm starts, the behaviour of the MODULE depends upon the setting <type> and if the device	



+CALA - Alarm Management	SELINT 2
	<p>was already ON at the moment when the alarm time had come.</p> <p>Parameters:</p> <p><time> - current alarm time as quoted string "" - (empty string) deletes the current alarm and resets all the +CALA parameters to the "factory default" configuration "hh:mm:ss±zz" - format to be used only when issuing +CALA with parameter <recurr> too. "yy/MM/dd, hh:mm:ss±zz" - generic format: it's the same as defined for +CCLK (see)</p> <p><n> - index of the alarm 0 - The only value supported is 0.</p> <p><type> - alarm behaviour type 0 - reserved for other equipment use. 1 - the MODULE simply wakes up fully operative as if the ON/OFF button had been pressed. If the device is already ON at the alarm time, then it does nothing (default). 2 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE issues an unsolicited code every 3s:</p> <p style="padding-left: 40px;">+CALA: <text></p> <p style="padding-left: 40px;">where <text> is the +CALA optional parameter previously set.</p> <p>The device keeps on sending the unsolicited code every 3s until a #WAKE or #SHDN command is received or a 90 seconds timer expires. If the device is in "alarm mode" and it does not receive the #WAKE command within 90s then it shuts down.</p> <p>3 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE starts playing the alarm tone on the selected path for the ringer (see command #SRP) The device keeps on playing the alarm tone until a #WAKE or #SHDN command is received or a 90 s time-out occurs. If the device is in "alarm mode" and it does not receive the #WAKE command within 90s then it shuts down.</p> <p>4 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE brings the pin GPIO6 high, provided its <direction> has been set to alarm output, and keeps it in this state until a #WAKE or #SHDN command is received or a 90 seconds timer expires. If the device is in "alarm mode"</p>



+CALA - Alarm Management	SELINT 2
	<p>and it does not receive the #WAKE command within 90s then it shuts down.</p> <p>5 - the MODULE will make both the actions as for type=2 and <type>=3.</p> <p>6 - the MODULE will make both the actions as for type=2 and <type>=4.</p> <p>7 - the MODULE will make both the actions as for type=3 and <type>=4.</p> <p>8 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE sets High the RI output pin. The RI output pin remains High until next #WAKE issue or until a 90s timer expires. If the device is in "alarm mode" and it does not receive the #WAKE command within 90s. After that it shuts down.</p> <p><text> - unsolicited alarm code text string. It has meaning only if <type> is equal to 2 or 5 or 6.</p> <p><recurr> - string type value indicating day of week for the alarm in one of the following formats: " <1..7>[, <1..7>[, ...]]" - it sets a recurrent alarm for one or more days in the week; the digits 1 to 7 corresponds to the days in the week (Monday is 1). "0" - it sets a recurrent alarm for all days in the week.</p> <p><silent> - integer type indicating if the alarm is silent or not. 0 - the alarm will not be silent; 1 - the alarm will be silent.</p> <p>During the "alarm mode" the device will not make any network scan and will not register to any network and therefore is not able to dial or receive any call or SMS, the only commands that can be issued to the MODULE in this state are the #WAKE and #SHDN, every other command must not be issued during this state.</p> <p>Note: it is mandatory to set at least once the RTC (issuing +CCLK) before it is possible to issue +CALA with <type>=8</p>
AT+CALA?	<p>Read command returns the list of current active alarm settings in the ME, in the format:</p> <p>[+CALA: <time>, <n>, <type>, [<text>], <recurr>, <silent>]</p>
AT+CALA=?	<p>Test command returns the list of supported index values (currently just 0), alarm types, maximum length of the text to be displayed, maximum length of <recurr> and supported <silent>s, in the format:</p> <p>+CALA: (list of supported <n>s), (list of supported <type>s), <tlength>, <rlength>, (list of supported <silent>s)</p>
Example	AT+CALA="02/09/07, 23:30:00+00"



+CALA - Alarm Management		SELINT 2
	OK	
Reference	ETSI 07.07, ETSI 27.007	

3.5.4.4.14. Restricted SIM Access - +CRSM

+CRSM - Restricted SIM Access		SELINT 0 / 1 / 2
<p>AT+CRSM= <command> [,<fileid> [,<P1>,<P2>,<P3> [,<data>]]]</p>	<p>Execution command transmits to the ME the SIM <command> and its required parameters. ME handles internally all SIM-ME interface locking and file selection routines. As response to the command, ME sends the actual SIM information parameters and response data.</p> <p>Parameters:</p> <p><command> - command passed on by the ME to the SIM</p> <ul style="list-style-type: none"> 176 - READ BINARY 178 - READ RECORD 192 - GET RESPONSE 214 - UPDATE BINARY 220 - UPDATE RECORD 242 - STATUS <p><fileid> - identifier of an elementary data file on SIM. Mandatory for every command except STATUS.</p> <p><P1>,<P2>,<P3> - parameter passed on by the ME to the SIM; they are mandatory for every command except GET RESPONSE and STATUS</p> <p>0..255</p> <p><data> - information to be read/written to the SIM (hexadecimal character format).</p> <p>The response of the command is in the format:</p>	



+CRSM - Restricted SIM Access		SELINT 0 / 1 / 2
	<p>+CRSM: <sw1>,<sw2>[,<response>]</p> <p>where:</p> <p><sw1>,<sw2> - information from the SIM about the execution of the actual command either on successful or on failed execution.</p> <p><response> - on a successful completion of the command previously issued it gives the requested data (hexadecimal character format). It's not returned after a successful UPDATE BINARY or UPDATE RECORD command.</p> <p>Note: this command requires PIN authentication. However commands READ BINARY and READ RECORD can be issued before PIN authentication and if the SIM is blocked (after three failed PIN authentication attempts) to access the contents of the Elementary Files.</p> <p>Note: use only decimal numbers for parameters <command>, <fileid>, <P1>, <P2> and <P3>.</p>	
AT+CRSM=?	Test command returns the OK result code	
Reference	3GPP TS 27.007, GSM 11.11	

3.5.4.4.15. Alert Sound Mode - +CALM

+CALM - Alert Sound Mode		SELINT 0 / 1
AT+CALM[=<mode>]	<p>Set command is used to select the general alert sound mode of the device.</p> <p>Parameter:</p> <p><mode></p> <p>0 - normal mode</p> <p>1 - silent mode; no sound will be generated by the device, except for alarm sound</p> <p>2 - stealth mode; no sound will be generated by the device</p> <p>Note: if silent mode is selected then incoming calls will not produce alerting sounds but only the unsolicited messages RING or +CRING.</p> <p>Note: If parameter is omitted then the behaviour of Set command is the same as Read command.</p>	
AT+CALM?	Read command returns the current value of parameter <mode> .	
AT+CALM=?	<p>Test command returns the supported values for the parameter <mode> as compound value.</p> <p>For compatibility with previous versions, Test command returns</p>	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

+CALM - Alert Sound Mode		SELINT 0 / 1
	<p>+CALM: (0,1)</p> <p>An enhanced version of Test command has been defined: AT+CALM=??, that provides the complete range of values for <mode>.</p>	
AT+CALM=??	<p>Enhanced test command returns the complete range of values for the parameter <mode> as compound value:</p> <p>+CALM: (0-2)</p>	
Reference	3GPP TS 27.007	

+CALM - Alert Sound Mode		SELINT 2
AT+CALM=<mode>	<p>Set command is used to select the general alert sound mode of the device.</p> <p>Parameter: <mode></p> <ul style="list-style-type: none"> 0 - normal mode 1 - silent mode; no sound will be generated by the device, except for alarm sound 2 - stealth mode; no sound will be generated by the device <p>Note: if silent mode is selected then incoming calls will not produce alerting sounds but only the unsolicited messages RING or +CRING.</p>	
AT+CALM?	Read command returns the current value of parameter <mode> .	
AT+CALM=?	<p>Test command returns the supported values for the parameter <mode> as compound value.</p> <p>+CALM: (0-2)</p>	
Reference	3GPP TS 27.007	

3.5.4.4.16. Ringer Sound Level - +CRSL

+CRSL - Ringer Sound Level		SELINT 0
AT+CRSL[=<level>]	<p>Set command is used to select the incoming call ringer sound level of the device.</p> <p>Parameter: <level> - ringer sound level</p> <ul style="list-style-type: none"> 0 - Off 1 - low 2 - middle 3 - high 4 - progressive 	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

+CRSL - Ringer Sound Level		SELINT 0
	Note: if parameter is omitted then the behaviour of Set command is the same as Read command	
AT+CRSL?	Read command reports the current <level> setting of the call ringer in the format: +CRSL: <level>	
AT+CRSL=?	Test command reports <level> supported values as compound value. For compatibility with previous versions, Test command returns +CRSL: (0-3) An enhanced version of Test command has been defined: AT+CRSL=?? , that provides the complete range of values for <level> .	
AT+CRSL=??	Enhanced Test command returns the complete range of supported values for the parameter <mode> : +CRSL: (0-4)	
Reference	3GPP TS 27.007	

+CRSL - Ringer Sound Level		SELINT 1
AT+CRSL[= <level>]	Set command is used to select the incoming call ringer sound level of the device. Parameter: <level> - ringer sound level 0 - Off 1 - low 2 - middle 3 - high 4 - progressive Note: if parameter is omitted then the behaviour of Set command is the same as Read command	
AT+CRSL?	Read command reports the current <level> setting of the call ringer in the format: +CRSL: <level>	
AT+CRSL=?	Test command reports <level> supported values as compound value, in the format:	



+CRSL - Ringer Sound Level		SELINT 1
	+CRSL: (0-4) Note: an enhanced version of Test command has been defined: AT+CRSL=?? .	
AT+CRSL=??	Enhanced Test command returns the complete range of supported values for the parameter <mode> :	
	+CRSL: (0-4)	
Reference	3GPP TS 27.007	

+CRSL - Ringer Sound Level		SELINT 2
AT+CRSL=<level>	Set command is used to select the incoming call ringer sound level of the device. Parameter: <level> - ringer sound level 0 - Off 1 - low 2 - middle 3 - high 4 - progressive	
AT+CRSL?	Read command reports the current <level> setting of the call ringer in the format: +CRSL: <level>	
AT+CRSL=?	Test command reports <level> supported values as compound value. +CRSL: (0-4)	
Reference	3GPP TS 27.007	

3.5.4.4.17. Loudspeaker Volume Level - +CLVL

+CLVL - Loudspeaker Volume Level		SELINT 0 / 1
AT+CLVL[=<level>]	Set command is used to select the volume of the internal loudspeaker audio output of the device. Parameter: <level> - loudspeaker volume 0.. <i>max</i> - the value of <i>max</i> can be read by issuing the Test command AT+CLVL=? Note: If the parameter is omitted the behavior of Set command is the same	



+CLVL - Loudspeaker Volume Level		SELINT 0 / 1
	as Read command.	
AT+CLVL?	Read command reports the current <level> setting of the loudspeaker volume in the format: +CLVL: <level>	
AT+CLVL=?	Test command reports <level> supported values range in the format: +CLVL: (0-<i>max</i>)	
Reference	3GPP TS 27.007	

+CLVL - Loudspeaker Volume Level		SELINT 2
AT+CLVL=<level>	Set command is used to select the volume of the internal loudspeaker audio output of the device. Parameter: <level> - loudspeaker volume 0.. <i>max</i> - the value of <i>max</i> can be read by issuing the Test command AT+CLVL=?	
AT+CLVL?	Read command reports the current <level> setting of the loudspeaker volume in the format: +CLVL: <level>	
AT+CLVL=?	Test command reports <level> supported values range in the format: +CLVL: (0-<i>max</i>)	
Reference	3GPP TS 27.007	

3.5.4.4.18. Microphone Mute Control - +CMUT

+CMUT - Microphone Mute Control		SELINT 0 / 1
AT+CMUT[=<n>]]	Set command enables/disables the muting of the microphone audio line during a voice call. Parameter: <n> 0 - mute off, microphone active (factory default) 1 - mute on, microphone muted. Note: this command mutes/activates both microphone audio paths, internal mic and external mic. Note: issuing AT+CMUT<CR> is the same as issuing the Read command.	



+CMUT - Microphone Mute Control		SELINT 0 / 1
	Note: issuing AT+CMUT=<CR> is the same as issuing the command AT+CMUT=0<CR> .	
AT+CMUT?	Read command reports whether the muting of the microphone audio line during a voice call is enabled or not, in the format: +CMUT: <n>	
AT+CMUT=?	Test command reports the supported values for <n> parameter.	
Reference	3GPP TS 27.007	

+CMUT - Microphone Mute Control		SELINT 2
AT+CMUT=<n>	Set command enables/disables the muting of the microphone audio line during a voice call. Parameter: <n> 0 - mute off, microphone active (factory default) 1 - mute on, microphone muted. Note: this command mutes/activates both microphone audio paths, internal mic and external mic.	
AT+CMUT?	Read command reports whether the muting of the microphone audio line during a voice call is enabled or not, in the format: +CMUT: <n>	
AT+CMUT=?	Test command reports the supported values for <n> parameter.	
Reference	3GPP TS 27.007	

3.5.4.4.19. Accumulated Call Meter - +CACM

+CACM - Accumulated Call Meter		SELINT 0 / 1
AT+CACM[= <pwd>]	Set command resets the Advice of Charge related Accumulated Call Meter stored in SIM (ACM): it contains the total number of home units for both the current and preceding calls. Parameter: <pwd> - to access this command PIN2 is required; if PIN2 has been already input once after startup, it is required no more Note: If the parameter is omitted the behavior of Set command is the same as Read command.	



+CAMP - Accumulated Call Meter Maximum		SELINT 0 / 1
	<p>Parameter:</p> <p><acmmax> - ACMmax value, integer type: it is the maximum number of home units allowed to be consumed by the subscriber.</p> <p><pwd> - PIN2; if PIN2 has been already input once after startup, it is required no more</p> <p>Note: <acmmax>=0 value disables the feature.</p> <p>Note: if the parameters are omitted the behavior of Set command is the same as Read command.</p>	
AT+CAMP?	<p>Read command reports the ACMmax value stored in SIM in the format:</p> <p>+CAMP : <acmm></p> <p>where:</p> <p><acmm> - ACMmax value in home units, string type: three bytes of the ACMmax value in hexadecimal format (e.g. "00001E" indicates decimal value 30)</p>	
Reference	3GPP TS 27.007	

+CAMP - Accumulated Call Meter Maximum		SELINT 2
AT+CAMP= [<acmmax> [,<pwd>]]	<p>Set command sets the Advice of Charge related Accumulated Call Meter Maximum Value stored in SIM (ACMmax). This value represents the maximum number of home units allowed to be consumed by the subscriber. When ACM reaches <acmmax> value further calls are prohibited.</p> <p>Parameter:</p> <p><acmmax> - ACMmax value, integer type: it is the maximum number of home units allowed to be consumed by the subscriber.</p> <p><pwd> - PIN2; if PIN2 has been already input once after startup, it is required no more</p> <p>Note: <acmmax> = 0 value disables the feature.</p>	
AT+CAMP?	<p>Read command reports the ACMmax value stored in SIM in the format:</p> <p>+CAMP : <acmm></p> <p>where:</p> <p><acmm> - ACMmax value in home units, string type: three bytes of the ACMmax value in hexadecimal format (e.g. "00001E" indicates decimal value 30)</p>	



+CAMP - Accumulated Call Meter Maximum		SELINT 2
AT+CAMP=?	Test command returns the OK result code	
Reference	3GPP TS 27.007	

3.5.4.4.21. Price per Unit and Currency Table - +CPUC

+CPUC - Price Per Unit And Currency Table		SELINT 0 / 1
AT+CPUC=[<currency>, <ppu>[,<pwd>]]	<p>Set command sets the values of Advice of Charge related Price per Unit and Currency Table stored in SIM (PUCT). The PUCT information can be used to convert the home units (as used in commands +CAOC, +CACM and +CAMP) into currency units.</p> <p>Parameters:</p> <p><currency> - string type; three-character currency code (e.g. LIT, USD, DEM etc..); used character set should be the one selected with command +CSCS.</p> <p><ppu> - price per unit, string type (dot is used as decimal separator) e.g. "1989.27"</p> <p><pwd> - SIM PIN2; if PIN2 has been already input once after startup, it is required no more</p> <p>Note: if the parameters are omitted the behavior of Set command is the same as Read command.</p>	
AT+CPUC?	<p>Read command reports the current values of <currency> and <ppu> parameters in the format:</p> <p>+CACM : <currency>,<ppu></p>	
Reference	3GPP TS 27.007	

+CPUC - Price Per Unit And Currency Table		SELINT 2
AT+CPUC= <currency>, <ppu>[,<pwd>]	<p>Set command sets the values of Advice of Charge related Price per Unit and Currency Table stored in SIM (PUCT). The PUCT information can be used to convert the home units (as used in commands +CAOC, +CACM and +CAMP) into currency units.</p> <p>Parameters:</p> <p><currency> - string type; three-character currency code (e.g. "LIT", "L. ", "USD", "DEM" etc..); used character set should be the one selected with command +CSCS.</p> <p><ppu> - price per unit, string type (dot is used as decimal separator) e.g. "1989.27"</p> <p><pwd> - SIM PIN2; if PIN2 has been already input once after startup, it is</p>	



+CPUC - Price Per Unit And Currency Table		SELINT 2
	required no more	
AT+CPUC?	Read command reports the current values of <currency> and <ppu> parameters in the format: +CACM : <currency>,<ppu>	
AT+CPUC=?	Test command returns the OK result code	
Reference	3GPP TS 27.007	

3.5.4.4.22. Available AT Commands - +CLAC

+CLAC - Available AT Commands		SELINT 2
AT+CLAC	Execution command causes the ME to return the AT commands that are available for the user, in the following format: <AT cmd1>[<CR><LF><AT cmd2>[...]] where: <AT cmdn> - defines the AT command including the prefix AT	
AT+CLAC=?	Test command returns the OK result code	
Reference	3GPP TS 27.007	

3.5.4.4.23. Delete Alarm - +CALD

+CALD - Delete Alarm		SELINT 2
AT+CALD=<n>	Execution command deletes an alarm in the ME Parameter: <n> - alarm index 0	
AT+CALD=?	Test command reports the range of supported values for <n> parameter.	
Reference	3G TS 27.007	



	<p><mode>: 0 – disable support of GPRS related error codes by AT+CMEE (default) 1 – enable support of GPRS related error codes by AT+CMEE</p> <p>This parameter is stored in the user profile</p>
AT#CMEEMODE?	<p>Read command reports the currently selected < mode > in the format: #CMEEMODE: <mode></p>
AT#CMEEMODE=?	<p>Test command reports the supported range of values for parameter < mode ></p>

3.5.4.6. Voice Control

3.5.4.6.1. DTMF Tones Transmission - +VTS

+VTS - DTMF Tones Transmission		SELINT 0 / 1
AT+VTS= <dtmfstring> [,duration]	<p>Execution command allows the transmission of DTMF tones.</p> <p>Parameters: <dtmfstring> - string of <dtmf>s, i.e. ASCII characters in the set (0-9), #, *, (A-D); it allows the user to send a sequence of DTMF tones, each of them with a duration that was defined through +VTD command. <duration> - duration of a tone in 1/100 sec.; this parameter can be specified only if the length of first parameter is just one ASCII character 0 - a single DTMF tone will be transmitted for a duration depending on the network, no matter what the current +VTD setting is. 1..255 - a single DTMF tone will be transmitted for a time <duration> (in 10 ms multiples), no matter what the current +VTD setting is.</p> <p>Note: this commands operates in voice mode only (see +FCLASS).</p>	
AT+VTS=?	<p>For compatibility with previous versions, Test command returns +VTS: (),(),()</p> <p>An enhanced version of Test command has been defined: AT+VTS=??, that provides the correct range of values for <DTMF>.</p>	
AT+VTS=??	<p>Test command provides the list of supported <dtmf>s and the list of supported <duration>s in the format:</p>	



+VTD - Tone Duration		SELINT 0 / 1
	<p><duration> - duration of a tone</p> <p>0 - the duration of every single tone is dependent on the network (factory default)</p> <p>1..255 - duration of every single tone in 1/10 sec.</p> <p>Note: If parameter is omitted the behavior of Set command is the same as Read command.</p>	
AT+VTD?	Read command reports the current Tone Duration, in the format: <duration>	
AT+VTD=?	Test command provides the list of supported <duration>s in the format: (list of supported <duration>s)	
Reference	3GPP TS 27.007 and TIA IS-101	

+VTD - Tone Duration		SELINT 2
AT+VTD= <duration>	<p>Set command sets the length of tones transmitted with +VTS command.</p> <p>Parameter:</p> <p><duration> - duration of a tone</p> <p>0 - the duration of every single tone is dependent on the network (factory default)</p> <p>1..255 - duration of every single tone in 1/10 sec.</p>	
AT+VTD?	Read command reports the current Tone Duration, in the format: <duration>	
AT+VTD=?	Test command provides the list of supported <duration>s in the format: (list of supported <duration>s)	
Reference	3GPP TS 27.007 and TIA IS-101	

3.5.4.7. Commands For GPRS

3.5.4.7.1. GPRS Mobile Station Class - +CGCLASS



+CGATT - GPRS Attach Or Detach		SELINT 0 / 1
AT+CGATT[= <state>]	<p>Execution command is used to attach the terminal to, or detach the terminal from, the GPRS service depending on the parameter <state>.</p> <p>Parameter: <state> - state of GPRS attachment 0 - detached 1 - attached</p> <p>Note: If the parameter is omitted the behavior of Execution command is the same as Read command.</p>	
AT+CGATT?	Read command returns the current GPRS service state.	
AT+CGATT=?	Test command requests information on the supported GPRS service states.	
Example	<pre>AT+CGATT? +CGATT: 0 OK AT+CGATT=? +CGATT: (0,1) OK AT+CGATT=1 OK</pre>	
Reference	3GPP TS 27.007	
		SELINT 2
AT+CGATT=[<state>]	<p>Execution command is used to attach the terminal to, or detach the terminal from, the GPRS service depending on the parameter <state>.</p> <p>Parameter: <state> - state of GPRS attachment 0 - detached 1 - attached</p>	
AT+CGATT?	Read command returns the current GPRS service state.	
AT+CGATT=?	Test command requests information on the supported GPRS service states.	
Example	<pre>AT+CGATT? +CGATT: 0 OK AT+CGATT=? +CGATT: (0,1) OK AT+CGATT=1 OK</pre>	
Reference	3GPP TS 27.007	



+CGEREP - GPRS Event Reporting	SELINT 2
	<p>was used to activate the context is provided if known to TA</p> <p>+CGEV: NW DETACH The network has forced a GPRS detach. This implies that all active contexts have been deactivated. These are not reported separately</p> <p>+CGEV: ME DETACH The mobile equipment has forced a GPRS detach. This implies that all active contexts have been deactivated. These are not reported separately</p> <p>+CGEV: ME CLASS <class> The mobile equipment has forced a change of MS class. The highest available class is reported (see +CGCLASS)</p>
AT+CGEREP?	<p>Read command returns the current <mode> and <bfr> settings, in the format:</p> <p>+CGEREP: <mode>,<bfr></p>
AT+CGEREP=?	<p>Test command reports the supported range of values for the +CGEREP command parameters.</p>
Reference	3GPP TS 27.007

3.5.4.7.4. GPRS Network Registration Status - +CGREG



+CGREG - GPRS Network Registration Status		SELINT 0 / 1
AT+CGREG[= [<n>]]	<p>Set command controls the presentation of an unsolicited result code +CGREG: (see format below).</p> <p>Parameter: <n> - result code presentation mode 0 - disable network registration unsolicited result code 1 - enable network registration unsolicited result code; if there is a change in the terminal GPRS network registration status, it is issued the unsolicited result code:</p> <p>+CGREG: <stat></p> <p>where: <stat> - registration status 0 - not registered, terminal is not currently searching a new operator to register to 1 - registered, home network 2 - not registered, but terminal is currently searching a new operator to register to 3 - registration denied 4 - unknown 5 - registered, roaming</p> <p>2 - enable network registration and location information unsolicited result code; if there is a change of the network cell, it is issued the unsolicited result code:</p> <p>+CGREG: <stat>[,<lac>,<ci>]</p> <p>where: <stat> - registration status (see above for values) <lac> - location area code in hexadecimal format (e.g. "00C3" equals 195 in decimal) <ci> - cell ID in hexadecimal format</p> <p>Note: issuing AT+CGREG<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CGREG=<CR> is the same as issuing the command AT+CGREG=0<CR>.</p>	
AT+CGREG?	<p>Read command returns the status of result code presentation mode <n> and the integer <stat> which shows whether the network has currently indicated the registration of the terminal in the format:</p>	



+CGREG - GPRS Network Registration Status		SELINT 0 / 1
	+CGREG:<n>,<stat>.	
AT+CGREG=?	Test command returns supported values for parameter <n>	
Reference	3GPP TS 27.007	

+CGREG - GPRS Network Registration Status		SELINT 2
AT+CGREG=<n>	<p>Set command controls the presentation of an unsolicited result code +CGREG: (see format below).</p> <p>Parameter: <n> - result code presentation mode 0 - disable network registration unsolicited result code 1 - enable network registration unsolicited result code; if there is a change in the terminal GPRS network registration status, it is issued the unsolicited result code:</p> <p>+CGREG: <stat></p> <p>where: <stat> - registration status 0 - not registered, terminal is not currently searching a new operator to register to 1 - registered, home network 2 - not registered, but terminal is currently searching a new operator to register to 3 - registration denied 4 - unknown 5 - registered, roaming</p> <p>2 - enable network registration and location information unsolicited result code; if there is a change of the network cell, it is issued the unsolicited result code:</p> <p>+CGREG: <stat>[,<lac>,<ci>]</p> <p>where: <stat> - registration status (see above for values) <lac> - location area code in hexadecimal format (e.g. "00C3" equals 195 in decimal) <ci> - cell ID in hexadecimal format.</p>	
AT+CGREG?	<p>Read command returns the status of result code presentation mode <n> and the integer <stat> which shows whether the network has currently indicated the registration of the terminal in the format:</p>	



+CGREG - GPRS Network Registration Status		SELINT 2
	+CGREG: <n>,<stat>	
AT+CGREG=?	Test command returns supported values for parameter <n>	
Reference	3GPP TS 27.007	
Note	There are situations in which the presentation of the URC controlled by +CGREG is slightly different from ETSI specifications. We identified this behaviour and decided to maintain it as default for backward compatibility issues. It is indeed possible to avoid it simply issuing AT#REGMODE=1 (see #REGMODE): this puts the Operation Mode of Registration Status Commands in 'Enhanced Registration Operation Mode' which is more formal.	

3.5.4.7.5. Define PDP Context - +CGDCONT

+CGDCONT - Define PDP Context		SELINT 0 / 1
AT+CGDCONT[= <cid> ,<PDP_type> ,<APN> ,<PDP_addr> ,<d_comp> ,<h_comp> ,<pd1> ,...[,pdN]]]]]]]]]	<p>Set command specifies PDP context parameter values for a PDP context identified by the (local) context identification parameter, <cid></p> <p>Parameters:</p> <p><cid> - (PDP Context Identifier) numeric parameter which specifies a particular PDP context definition.</p> <p>1..<i>max</i> - where the value of <i>max</i> is returned by the Test command</p> <p><PDP_type> - (Packet Data Protocol type) a string parameter which specifies the type of packet data protocol</p> <p>"IP" - Internet Protocol</p> <p><APN> - (Access Point Name) a string parameter which is a logical name that is used to select the GGSN or the external packet data network. If the value is empty ("") or omitted, then the subscription value will be requested.</p> <p><PDP_addr> - a string parameter that identifies the terminal in the address space applicable to the PDP. The allocated address may be read using the +CGPADDR command.</p> <p><d_comp> - numeric parameter that controls PDP data compression</p> <p>0 - off (default if value is omitted)</p> <p>1 - on</p> <p><h_comp> - numeric parameter that controls PDP header compression</p> <p>0 - off (default if value is omitted)</p> <p>1 - on</p> <p><pd1>, ..., <pdN> - zero to N string parameters whose meanings are specific to the <PDP_type></p> <p>Note: a special form of the Set command, +CGDCONT=<cid>, causes the values for context number <cid> to become undefined.</p>	



+CGDCONT - Define PDP Context		SELINT 0 / 1
	<p>Note: issuing AT+CGDCONT<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CGDCONT=<CR> returns the OK result code.</p>	
AT+CGDCONT?	<p>Read command returns the current settings for each defined context in the format:</p> <pre>+CGDCONT: <cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp>[,<pd1>[,...[,<pdN>]]]<CR><LF>[<CR><LF>+CGDCONT:<cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp>[,<pd1>[,...[,<pdN>]]]<CR><LF>[...]]</pre>	
AT+CGDCONT=?	<p>Test command returns values supported as a compound value</p>	
Example	<pre>AT+CGDCONT=1,"IP","APN","10.10.10.10",0,0 OK AT+CGDCONT? +CGDCONT: 1,"IP","APN","10.10.10.10",0,0 OK AT+CGDCONT=? +CGDCONT: (1-5),"IP",,(0-1),(0-1) OK</pre>	
Reference	3GPP TS 27.007	

+CGDCONT - Define PDP Context		SELINT 2
AT+CGDCONT= [<cid> [,<PDP_type> [,<APN> [,<PDP_addr> [,<d_comp> [,<h_comp> [,<pd1> [,...[,<pdN>]]]]]]]]	<p>Set command specifies PDP context parameter values for a PDP context identified by the (local) context identification parameter, <cid></p> <p>Parameters:</p> <p><cid> - (PDP Context Identifier) numeric parameter which specifies a particular PDP context definition.</p> <p>1..<i>max</i> - where the value of <i>max</i> is returned by the Test command</p> <p><PDP_type> - (Packet Data Protocol type) a string parameter which specifies the type of packet data protocol</p> <p>"IP" - Internet Protocol</p> <p><APN> - (Access Point Name) a string parameter which is a logical name that is used to select the GGSN or the external packet data network. If the value is empty ("") or omitted, then the subscription value will be requested.</p> <p><PDP_addr> - a string parameter that identifies the terminal in the address space applicable to the PDP. The allocated address may be read using the +CGPADDR command.</p> <p><d_comp> - numeric parameter that controls PDP data compression</p>	



+CGQMIN - Quality Of Service Profile (Minimum Acceptable)	SELINT 0 / 1
	<p><mean> - mean throughput class</p> <p>If a value is omitted for a particular class then this class is not checked.</p> <p>Note: a special form of the Set command, +CGQMIN=<cid> causes the requested profile for context number <cid> to become undefined.</p> <p>Note: issuing AT+CGQMIN<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CGQMIN=<CR> returns the OK result code.</p>
AT+CGQMIN?	<p>Read command returns the current settings for each defined context in the format:</p> <p>+CGQMIN: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean><CR><LF>[<CR><LF>+CGQMIN: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean><CR><LF>[...]]</p> <p>If no PDP context has been defined, it has no effect and OK result code is returned.</p>
AT+CGQMIN=?	<p>Test command returns as a compound value the type of the current PDP context and the supported values for the subparameters in the format:</p> <p>+CGQMIN: <PDP_Type>,(list of supported <precedence>s),(list of supported <delay>s),(list of supported <reliability>s),(list of supported <peak>s),(list of supported <mean>s)</p> <p>Note: only the "IP" PDP_Type is currently supported.</p>
Example	<pre>AT+CGQMIN=1,0,0,3,0,0 OK AT+CGQMIN? +CGQMIN: 1,0,0,5,0,0 OK AT+CGQMIN=? +CGQMIN: "IP", (0-3), (0-4), (0-5), (0-9), (0-19,31) OK</pre>
Reference	3GPP TS 27.007; GSM 03.60

+CGQMIN - Quality Of Service Profile (Minimum Acceptable)	SELINT 2
AT+CGQMIN=[<cid> [,<precedence> [,<delay>	<p>Set command allows to specify a minimum acceptable profile which is checked by the terminal against the negotiated profile returned in the Activate PDP Context Accept message.</p>



+CGQREQ - Quality Of Service Profile (Requested)		SELINT 0 / 1
	OK AT+CGQREQ=? +CGQREQ: "IP", (0-3), (0-4), (0-5), (0-9), (0-19, 31) OK	
Reference	3GPP TS 27.007; GSM 03.60	

+CGQREQ - Quality Of Service Profile (Requested)		SELINT 2
AT+CGQREQ= [<cid> [,<precedence> [,<delay> [,<reliability> [,<peak> [,<mean>]]]]]	<p>Set command allows to specify a Quality of Service Profile that is used when the terminal sends an Activate PDP Context Request message to the network. It specifies a profile for the context identified by the (local) context identification parameter, <cid>.</p> <p>Parameters: <cid> - PDP context identification (see +CGDCONT command). <precedence> - precedence class <delay> - delay class <reliability> - reliability class <peak> - peak throughput class <mean> - mean throughput class</p> <p>If a value is omitted for a particular class then this class is not checked.</p> <p>Note: a special form of the Set command, +CGQREQ=<cid> causes the requested profile for context number <cid> to become undefined.</p>	
AT+CGQREQ?	<p>Read command returns the current settings for each defined context in the format:</p> <p>+CGQREQ: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean>[<CR><LF>+CGQREQ: <cid>,<precedence>,<delay>,<reliability>,<peak>,<mean>[...]]</p> <p>If no PDP context has been defined, it has no effect and OK result code is returned.</p>	
AT+CGQREQ=?	<p>Test command returns as a compound value the type of the current PDP context and the supported values for the subparameters in the format:</p> <p>+CGQREQ: <PDP_Type>,(list of supported <precedence>s),(list of supported <delay>s),(list of supported <reliability>s),(list of supported <peak>s),(list of supported <mean>s)</p> <p>Note: only the "IP" PDP_Type is currently supported.</p>	
Example	AT+CGQREQ?	



+CGACT - PDP Context Activate Or Deactivate		SELINT 0 / 1
	OK	
Reference	3GPP TS 27.007	

+CGACT - PDP Context Activate Or Deactivate		SELINT 2
AT+CGACT= [<state>[,<cid>[,<cid>[,...]]]]	<p>Execution command is used to activate or deactivate the specified PDP context(s)</p> <p>Parameters:</p> <p><state> - indicates the state of PDP context activation 0 - deactivated 1 - activated</p> <p><cid> - a numeric parameter which specifies a particular PDP context definition (see +CGDCONT command)</p> <p>Note: if no <cid>s are specified the activation/deactivation form of the command activates/deactivates all defined contexts.</p>	
AT+CGACT?	<p>Read command returns the current activation state for all the defined PDP contexts in the format:</p> <p>+CGACT: <cid>,<state>[<CR><LF>+CGACT: <cid>,<state>[...]]</p>	
AT+CGACT=?	<p>Test command reports information on the supported PDP context activation states parameters in the format:</p> <p>+CGACT: (0,1)</p>	
Example	<pre>AT+CGACT=1,1 OK AT+CGACT? +CGACT: 1,1 OK</pre>	
Reference	3GPP TS 27.007	



3.5.4.7.9. Show PDP Address - +CGPADDR

+CGPADDR - Show PDP Address		SELINT 0 / 1
AT+CGPADDR= [<cid>[,<cid> [,...]]]	Execution command returns a list of PDP addresses for the specified context identifiers in the format: +CGPADDR: <cid>[,<PDP_addr>]<CR><LF>[<CR><LF> +CGPADDR: <cid>[,<PDP_addr>]<CR><LF>[...]] Parameters: <cid> - a numeric parameter which specifies a particular PDP context definition (see +CGDCONT command). If no <cid> is specified, the addresses for all defined contexts are returned. <PDP_addr> - a string that identifies the terminal in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the +CGDCONT command when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid> ; if no address is available the <PDP_addr> parameter is not shown	
AT+CGPADDR=?	Test command returns a list of defined <cid> s.	
Example	<pre>AT#GPRS=1 +IP: xxx.yyy.zzz.www OK AT+CGPADDR=1 +CGPADDR: 1,"xxx.yyy.zzz.www" OK AT+CGPADDR=? +CGPADDR: (1) OK</pre>	
Reference	3GPP TS 27.007	

+CGPADDR - Show PDP Address		SELINT 2
AT+CGPADDR= [<cid>[,<cid> [,...]]]	Execution command returns a list of PDP addresses for the specified context identifiers in the format: +CGPADDR: <cid>,<PDP_addr>[<CR><LF>+CGPADDR: <cid> <PDP_addr>[...]] Parameters:	



+CGPADDR - Show PDP Address		SELINT 2
	<p><cid> - a numeric parameter which specifies a particular PDP context definition (see +CGDCONT command). If no <cid> is specified, the addresses for all defined contexts are returned.</p> <p><PDP_addr> - a string that identifies the terminal in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the +CGDCONT command when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid>; if no address is available the empty string ("") is represented as <PDP_addr></p>	
AT+CGPADDR=?	Test command returns a list of defined <cid> s.	
Example	<pre>AT#GPRS=1 +IP: xxx.yyy.zzz.www OK AT+CGPADDR=1 +CGPADDR: 1,"xxx.yyy.zzz.www" OK AT+CGPADDR=? +CGPADDR: (1) OK</pre>	
Reference	3GPP TS 27.007	

3.5.4.7.10. Enter Data State - +CGDATA

+CGDATA - Enter Data State		SELINT 0 / 1
AT+CGDATA=[<L2P>,<cid>[,<cid>[,...]]]	<p>Execution command causes to perform whatever actions are necessary to establish a communication with the network using one or more GPRS PDP types.</p> <p>Parameters:</p> <p><L2P> - string parameter that indicates the layer 2 protocol to be used "PPP" - PPP Point-to-point protocol</p> <p><cid> - numeric parameter which specifies a particular PDP context definition (see +CGDCONT command).</p> <p>Note: if parameter <L2P> is omitted, the layer 2 protocol is unspecified</p>	
AT+CGDATA=?	<p>Test command reports information on the supported layer 2 protocols.</p> <p>Note: the representation format of the Test command output is not included</p>	



+CBC - Battery Charge		SELINT 0 / 1
	Note: although +CBC is an execution command, ETSI 07.07 requires the Test command to be defined.	
AT+CBC=??	Enhanced test command returns the complete range of values for <bcs> and <bcl> : +CBC: (0-3),(0-100)	
Example	AT+CBC +CBC: 0,75 OK	
Note	The ME does not make differences between being powered by a battery or by a power supply on the VBATT pins, so it is not possible to distinguish between these two cases.	
Reference	3GPP TS 27.007	

+ CBC - Battery Charge		SELINT 2
AT+CBC	<p>Execution command returns the current Battery Charge status in the format:</p> <p>+CBC: <bcs>,<bcl></p> <p>where:</p> <p><bcs> - battery status</p> <ul style="list-style-type: none"> 0 - ME is powered by the battery 1 - ME has a battery connected, and charger pin is being powered 2 - ME does not have a battery connected 3 - Recognized power fault, calls inhibited <p><bcl> - battery charge level, only if <bcs>=0</p> <ul style="list-style-type: none"> 0 - battery is exhausted, or ME does not have a battery connected 25 - battery charge remained is estimated to be 25% 50 - battery charge remained is estimated to be 50% 75 - battery charge remained is estimated to be 75% 100 - battery is fully charged. <p>Note: <bcs>=1 indicates that the battery charger supply is inserted and the battery is being recharged if necessary with it. Supply for ME operations is taken anyway from VBATT pins.</p> <p>Note: without battery/power connected on VBATT pins or during a power fault the unit is not working, therefore values <bcs>=2 and <bcs>=3 will never appear.</p>	



+ CBC - Battery Charge		SELINT 2
	Note: <bcl> indicates battery charge level only if battery is connected and charger is not connected	
AT+CBC=?	Test command returns parameter values supported as a compound value. +CBC: (0-3),(0-100) Note: although +CBC is an execution command, ETSI 07.07 requires the Test command to be defined.	
Example	AT+CBC +CBC: 0,75 OK	
Note	The ME does not make differences between being powered by a battery or by a power supply on the VBATT pins, so it is not possible to distinguish between these two cases.	
Reference	3GPP TS 27.007	

3.5.5. 3GPP TS 27.005 AT Commands for SMS and CBS

3.5.5.1. General Configuration

3.5.5.1.1. Select Message Service - +CSMS

+CSMS - Select Message Service		SELINT 0 / 1
AT+CSMS [=<service>]	<p>Set command selects messaging service <service>. It returns the types of messages supported by the ME:</p> <p>Parameter: <service> 0 - The syntax of SMS AT commands is compatible with GSM 27.005 (factory default)</p> <p>Set command returns current service setting along with the types of messages supported by the ME:</p> <p>+CSMS: <service>,<mt>,<mo>,<bm></p> <p>where: <mt> - mobile terminated messages support 0 - type not supported 1 - type supported <mo> - mobile originated messages support</p>	



+CSMS - Select Message Service		SELINT 0 / 1
	<p>0 - type not supported 1 - type supported <bm> - broadcast type messages support 0 - type not supported 1 - type supported</p> <p>Note: If parameter is omitted then the behavior of Set command is the same as Read command.</p>	
AT+CSMS?	<p>Read command reports current service setting along with supported message types in the format:</p> <p>+CSMS: <service>,<mt>,<mo>,<bm></p> <p>where: <service> - messaging service (see above) <mt> - mobile terminated messages support (see above) <mo> - mobile originated messages support (see above) <bm> - broadcast type messages support (see above)</p>	
AT+CSMS=?	<p>Test command reports a list of all services supported by the device. The supported value of the parameter <service>.</p>	
Reference	GSM 27.005; 3GPP TS 23.040; 3GPP TS 23.041	

+CSMS - Select Message Service		SELINT 2
AT+CSMS= <service>	<p>Set command selects messaging service <service>. It returns the types of messages supported by the ME:</p> <p>Parameter: <service> 0 - The syntax of SMS AT commands is compatible with GSM 27.005 (factory default)</p> <p>Set command returns the types of messages supported by the ME:</p> <p>+CSMS: <mt>,<mo>,<bm></p> <p>where: <mt> - mobile terminated messages support 0 - type not supported 1 - type supported <mo> - mobile originated messages support 0 - type not supported 1 - type supported <bm> - broadcast type messages support</p>	



+CPMS - Preferred Message Storage		SELINT 2
# S M S M O D E = 0		<p>The command returns the memory storage status in the format:</p> <p>+CPMS: <usedr>,<totalr>,<usedw>,<totalw>,<useds>,<totals></p> <p>where:</p> <p><usedr> - number of SMs stored into <memr> <totalr> - max number of SMs that <memr> can contain <usedw> - number of SMs stored into <memw> <totalw> max number of SMs that <memw> can contain <useds> - number of SMs stored into <mems> <totals> - max number of SMs that <mems> can contain</p> <p>Note: The only supported memory storage for writing and sending SMs is the SIM internal memory "SM", so <memw>=<mems>="SM".</p> <p>Note: the received class 0 SMS are stored in the "ME" memory regardless the <mems> setting and they are automatically deleted at power off.</p>
# S M S M O D E = 0	AT+CPMS?	<p>Read command reports the message storage status in the format:</p> <p>+CPMS: <memr>,<usedr>,<totalr>,<memw>,<usedw>,<totalw>,<mems>,<useds>,<totals></p> <p>where <memr>, <memw> and <mems> are the selected storage memories for reading, writing and storing respectively.</p>
# S M S M O D E = 0	AT+CPMS=?	Test command reports the supported values for parameters <memr> , <memw> and <mems>
# S M S M O D E = 0	Example	<p>AT+CPMS? +CPMS: "SM",5,10,"SM",5,10,"SM",5,10</p> <p>OK <i>(you have 5 out of 10 SMS SIM positions occupied)</i></p>
# S M S M O D E = 0	Reference	GSM 27.005
[#SMSMODE=1]		
# S M S M O D E = 0	AT+CPMS= <memr> [,<memw> [,<mems>]]	<p>Set command selects memory storages <memr>, <memw> and <mems> to be used for reading, writing, sending and storing SMs.</p> <p>Parameters:</p> <p><memr> - memory from which messages are read and deleted "SM" - SIM SMS memory storage</p>



+CPMS - Preferred Message Storage		SELINT 2
D E = 1 # S M S M O D E = 1 # S M S M O D E = 1		<p><memw> - memory to which writing and sending operations are made "SM" - SIM SMS memory storage</p> <p><mems> - memory to which received SMs are preferred to be stored "SM" - SIM SMS memory storage</p> <p>The command returns the memory storage status in the format:</p> <p>+CPMS: <usedr>,<totalr>,<usedw>,<totalw>,<useds>,<totals></p> <p>where:</p> <p><usedr> - number of SMs stored into <memr> <totalr> - max number of SMs that <memr> can contain <usedw> - number of SMs stored into <memw> <totalw> max number of SMs that <memw> can contain <useds> - number of SMs stored into <mems> <totals> - max number of SMs that <mems> can contain</p> <p>Note: The only supported memory storage for reading, writing and sending SMs is the SIM internal memory "SM": <memr>=<memw>=<mems>="SM".</p>
	AT+CPMS?	<p>Read command reports the message storage status in the format:</p> <p>+CPMS: <memr>,<usedr>,<totalr>,<memw>,<usedw>,<totalw>,<mems>,<useds>,<totals></p> <p>where <memr>, <memw> and <mems> are the selected storage memories for reading, writing and storing respectively.</p>
	AT+CPMS=?	Test command reports the supported values for parameters <memr> , <memw> and <mems>
	Example	AT+CPMS? +CPMS: "SM",5,10,"SM",5,10,"SM",5,10 OK <i>(you have 5 out of 10 SMS SIM positions occupied)</i>
	Reference	GSM 27.005

3.5.5.1.3. Message Format - +CMGF

+CMGF - Message Format		SELINT 0 / 1
AT+CMGF[=	Set command selects the format of messages used with send, list, read and	



+CSCA - Service Center Address		SELINT 0 / 1
	<p>145 - international numbering scheme (contains the character "+")</p> <p>Note: to use the SM service, is mandatory to set a Service Center Address at which service requests will be directed.</p> <p>Note: in Text mode, this setting is used by send and write commands; in PDU mode, setting is used by the same commands, but only when the length of the SMSC address coded into the <pdu> parameter equals zero.</p> <p>Note: the current settings are stored through +CSAS</p> <p>Note: issuing AT+CSCA<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CSCA=<CR> causes an OK result code to be issued.</p>	
AT+CSCA?	<p>Read command reports the current value of the SCA in the format:</p> <p>+CSCA: <number>,<type></p> <p>Note: if SCA is not present the device reports an error message.</p>	
AT+ CSCA=?	Test command returns the OK result code.	
Reference	GSM 27.005	

+CSCA -Service Center Address		SELINT 2
AT+CSCA= <number> [,<type>]	<p>Set command sets the Service Center Address to be used for mobile originated SMS transmissions.</p> <p>Parameter: <number> - SC phone number in the format defined by <type> <type> - the type of number 129 - national numbering scheme 145 - international numbering scheme (contains the character "+")</p> <p>Note: to use the SM service, is mandatory to set a Service Center Address at which service requests will be directed.</p> <p>Note: in Text mode, this setting is used by send and write commands; in PDU mode, setting is used by the same commands, but only when the length of the SMSC address coded into the <pdu> parameter equals zero.</p> <p>Note: the current settings are stored through +CSAS</p>	
AT+CSCA?	Read command reports the current value of the SCA in the format:	



+CSCA -Service Center Address		SELINT 2
	<p>+CSCA: <number>,<type></p> <p>Note: if SCA is not present the device reports an error message.</p>	
AT+CSCA=?	Test command returns the OK result code.	
Reference	GSM 27.005	

3.5.5.2.2. Set Text Mode Parameters - +CSMP

+CSMP - Set Text Mode Parameters		SELINT 0 / 1
<p>AT+CSMP[= [<fo> [,<vp> [,<pid> [,<dc>]]]]]</p>	<p>Set command is used to select values for additional parameters for storing and sending SMs when the text mode is used (+CMGF=1)</p> <p>Parameters:</p> <p><fo> - depending on the command or result code: first octet of 3GPP TS 23.040 SMS-DELIVER, SMS-SUBMIT (default 17), SMS-STATUS-REPORT, or SMS-COMMAND (default 2) in integer format.</p> <p><vp> - depending on SMS-SUBMIT <fo> setting: 3GPP TS 23.040 TP-Validity-Period either in integer format (default 167) or in quoted time-string format</p> <p><pid> - 3GPP TS 23.040 TP-Protocol-Identifier in integer format.</p> <p><dc> - depending on the command or result code: 3GPP TS 23.038 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme</p> <p>Note: the current settings are stored through +CSAS</p> <p>Note: issuing AT+CSMP<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CSMP=<CR> is the same as issuing the command AT+CSMP=0<CR>.</p>	
AT+CSMP?	<p>Read command reports the current setting in the format:</p> <p>+CSMP: < fo>,<vp>,<pid>,<dc></p>	
AT+CSMP=?	Test command reports the supported range of values for <fo> , <vp> , <pid> and <dc> parameters.	
Example	<p><i>Set the parameters for an outgoing message with 24 hours of validity period and default properties:</i></p> <p>AT+CSMP=17,167,0,0</p>	



+CSMP - Set Text Mode Parameters		SELINT 0 / 1
	OK	
Reference	GSM 27.005; 3GPP TS 23.040; 3GPP TS 23.038	

+CSMP - Set Text Mode Parameters		SELINT 2
<i>Note: the behaviour of command +CPMS differs depending on whether or not the improved SMS commands operation mode has been enabled (see #SMSMODE)</i>		

[#SMSMODE=0]

# S M S M O D E = 0	AT+CSMP= [<fo> [,<vp> [,<pid> [,<dc>]]]]	<p>Set command is used to select values for additional parameters for storing and sending SMS when the text mode is used (AT+CMGF=1)</p> <p>Parameters:</p> <p><fo> - first octet of 3GPP TS 23.040 SMS-SUBMIT in integer format (default 17, i.e. SMS-SUBMIT with validity period in relative format). As first octet of a PDU has the following bit field description (we'll refer to bit[7]bit[6]bit[5]bit[4]bit[3]bit[2]bit[1]bit[0]):</p> <p>bit[1]bit[0]: Message Type Indicator, 2-bit field describing the message type: all the combinations are converted in [01] (default is [01]);</p> <p>[00] - converted in [01] [01] - SMS-SUBMIT [10] - converted in [01] [11] - converted in [01]</p> <p>bit[2]: Reject Duplicates, 1-bit field: user is not responsible for setting this bit and, if any set, it will have no meaning (default is [0]);</p> <p>bit[4]bit[3]: Validity Period Format, 2-bit field indicating whether or not the Validity Period field is present (default is [10]):</p> <p>[00] - Validity Period field <i>not present</i> [01] - Validity Period field present in <i>enhanced format</i>: it is currently converted in [00], i.e. <i>not present</i> [10] - Validity Period field present in <i>relative format</i>, (i.e. integer type, see below) [11] - Validity Period field present in <i>absolute format</i> (i.e. quoted time-string type); we strongly suggest to not use this format because its implementation is currently under refinement</p> <p>bit[5]: Status Report Request, 1-bit field indicating the MS is requesting a status report (default is [0]);</p> <p>[0] - MS is not requesting a status report [1] - MS is requesting a status report</p> <p>bit[6]: User Data Header Indicator, 1-bit field: user is not</p>
# S M S M O D E = 0		
# S M S M O D E		



+CSMP - Set Text Mode Parameters		SELINT 2
# S M S M O D E = 0		<p>responsible for setting this bit and, if any set, it will have no meaning (default is [0]);</p> <p>bit[7]: Reply Path, 1-bit field indicating the request for Reply Path (default is [0]);</p> <p>[0] - Reply Path not requested [1] - Reply Path requested</p> <p><vp> - depending on <fo> setting: if <fo> asks for a Validity Period in <i>relative format</i> <vp> shall be integer type (default 167, i.e. 24 hours); if <fo> asks for a Validity Period in <i>absolute format</i> we strongly suggest to modify it in <i>relative format</i>, because the implementation of this topic is currently under refinement and it is currently not possible to set <vp> with a quoted time string type.</p> <p>(for <i>relative format</i> only:)</p> <p>0..143 - [<vp> + 1] x 5 minutes; 144..167 - 12 hours + [(<vp> - 143) x 30 minutes]; 168..196 - [<vp> - 166] x 1 day; 197..255 - [<vp> - 192] x 1 week;</p> <p><pid> - 3GPP TS 23.040 TP-Protocol-Identifier in integer format. <dc> - depending on the command or result code: 3GPP TS 23.038 SMS Data Coding Scheme (default 0), or Cell Broadcast Data Coding Scheme</p> <p>Note: the current settings are stored through <u>+CSAS</u></p>
	AT+CSMP?	Read command reports the current setting in the format: +CSMP: < fo>,<vp>,<pid>,<dc>
	AT+CSMP=?	Test command returns the OK result code.
	Example	<p>Set the parameters for an outgoing message with 24 hours of validity period and default properties:</p> <pre>AT+CSMP=17,167,0,0 OK</pre>
	Reference	GSM 27.005; 3GPP TS 23.040; 3GPP TS 23.038
[#SMSMODE=1]		
# S M S	AT+CSMP= [<fo> [,<vp> [,<pid>	Set command is used to select values for additional parameters for storing and sending SMs when the text mode is used (AT+CMGF=1)
		Parameters:



+CSMP - Set Text Mode Parameters		SELINT 2
M O D E = 1 # S M S M O D E = 1 # S M S M O D E = 1 # S M S M O D E = 1	[, < dcs >]]]	<p><fo> - first octet of 3GPP TS 23.040 SMS-SUBMIT or SMS-DELIVER, in integer format (default 17, i.e. SMS-SUBMIT with validity period in relative format). As first octet of a PDU has the following bit field description (bit[7]bit[6]bit[5]bit[4]bit[3]bit[2]bit[1]bit[0]):</p> <p>bit[1]bit[0]: Message Type Indicator, 2-bit field describing the message type;</p> <p>[00] - SMS-DELIVER;</p> <p>[01] - SMS-SUBMIT (default) ;</p> <p>bit[2]: Reject Duplicates, 1-bit field: user is not responsible for setting this bit and, if any set, it will have no meaning (default is [0]);</p> <p>bit[4]bit[3]: Validity Period Format, 2-bit field indicating whether or not the Validity Period field is present (default is [10]):</p> <p>[00] - Validity Period field <i>not present</i></p> <p>[01] - Validity Period field present in <i>enhanced format</i> (i.e. quoted time-string type, see below)</p> <p>[10] - Validity Period field present in <i>relative format</i>, (i.e. integer type, see below)</p> <p>[11] - Validity Period field present in <i>absolute format</i> (i.e. quoted time-string type, see below)</p> <p>bit[5]: Status Report Request, 1-bit field indicating the MS is requesting a status report (default is [0]);</p> <p>[0] - MS is not requesting a status report</p> <p>[1] - MS is requesting a status report</p> <p>bit[6]: User Data Header Indicator, 1-bit field: user is not responsible for setting this bit and, if any set, it will have no meaning (default is [0]);</p> <p>bit[7]: Reply Path, 1-bit field indicating the request for Reply Path (default is [0]);</p> <p>[0] - Reply Path not requested</p> <p>[1] - Reply Path requested</p> <p><vp> - depending on <fo> setting:</p> <p>a) if <fo> asks for a <i>Not Present</i> Validity Period, <vp> can be any type and it will be not considered;</p> <p>b) if <fo> asks for a Validity Period in <i>relative format</i>, <vp> shall be integer type (default 167, i.e. 24 hours);</p> <p>0..143 - {<vp> + 1} x 5 minutes</p> <p>144..167 - 12 hours + {(<vp> - 143) x 30 minutes}</p> <p>168..196 - {<vp> - 166} x 1 day</p> <p>197..255 - {<vp> - 192} x 1 week</p> <p>c) if <fo> asks for a Validity Period in <i>absolute format</i>, <vp> shall be quoted time-string type (see +CCLK)</p>



+CSMP - Set Text Mode Parameters		SELINT 2
1		<p>+CSMP: <fo>,<vp>,<pid>,<dcs></p> <p>Note: if the Validity Period Format (<fo>'s bit[4]bit[3]) is [00] (i.e. <i>Not Present</i>), <vp> is represented just as a quoted empty string ("").</p>
# S M S M O D E = 1	AT+CSMP=?	Test command returns the OK result code.
# S M S M O D E = 1	Example	<p><i>Set the parameters for an outgoing message with 24 hours of validity period and default properties:</i></p> <pre>AT+CSMP=17,167,0,0 OK</pre> <p><i>Set the parameters for an outgoing message with validity period in enhanced format: the <vp> string actually codes 24 hours of validity period.</i></p> <pre>AT+CSMP=9,"01A80000000000" OK</pre> <p><i>Set the parameters for an outgoing message with validity period in enhanced format: the <vp> string actually codes 60 seconds of validity period.</i></p> <pre>AT+CSMP=9,"023C0000000000" OK</pre> <p><i>Set the parameters for an outgoing message with validity period in enhanced format: the <vp> string actually codes 29 hours 85 minutes 30 seconds of validity period.</i></p> <pre>AT+CSMP=9,"03925803000000" OK</pre>
	Reference	GSM 27.005; 3GPP TS 23.040; 3GPP TS 23.038

3.5.5.2.3. Show Text Mode Parameters - +CSDH

+CSDH - Show Text Mode Parameters		SELINT 0 / 1
AT+CSDH=[<show>]	Set command controls whether detailed header information is shown in text mode (+CMGF=1) result codes.	
	Parameter: <show>	



+CSDH - Show Text Mode Parameters		SELINT 0 / 1
	<p>0 - do not show header values defined in commands +CSCA and +CSMP (<sca>, <tosca>, <fo>, <vp>, <pid> and <dcs>) nor <length>, <toda> or <toa> in +CMT, +CMGL, +CMGR result codes for SMS-DELIVERs and SMS-SUBMITs in text mode. For SMS-COMMANDs in +CMGR result code do not show <pid>, <mn>, <da>, <toda>, <length> or <cdata></p> <p>1 - show the values in result codes</p> <p>Note: issuing AT+CSDH<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CSDH=<CR> is the same as issuing the command AT+CSDH=0<CR>.</p>	
AT+CSDH?	Read command reports the current setting in the format:	
	+CSDH: <show>	
AT+CSDH=?	Test command reports the supported range of values for parameter <show>	
Reference	GSM 27.005	

+CSDH - Show Text Mode Parameters		SELINT 2
AT+CSDH=<show>	Set command controls whether detailed header information is shown in text mode (AT+CMGF=1) result codes.	
	<p>Parameter:</p> <p><show></p> <p>0 - do not show header values defined in commands +CSCA and +CSMP (<sca>, <tosca>, <fo>, <vp>, <pid> and <dcs>) nor <length>, <toda> or <toa> in +CMT, +CMGL, +CMGR result codes for SMS-DELIVERs and SMS-SUBMITs in text mode. For SMS-COMMANDs in +CMGR result code do not show <pid>, <mn>, <da>, <toda>, <length> or <cdata></p> <p>1 - show the values in result codes</p>	
AT+CSDH?	Read command reports the current setting in the format:	
	+CSDH: <show>	
AT+CSDH=?	Test command reports the supported range of values for parameter <show>	
Reference	GSM 27.005	

3.5.5.2.4. Select Cell Broadcast - +CSCB

+CSCB -Select Cell Broadcast Message Types		SELINT 0 / 1
AT+CSCB[=	Set command selects which types of Cell Broadcast Messages are to be	



+CSCB -Select Cell Broadcast Message Types		SELINT 0 / 1
<p>[<mode> [,<mids> [,<dcss>]]]</p>	<p>received by the device.</p> <p>Parameter: <mode> 0 - the message types defined by <mids> and <dcss> are accepted (factory default) 1 - the message types defined by <mids> and <dcss> are rejected <mids> - Message Identifiers, string type: all different possible combinations of the CBM message identifiers; default is empty string [""]. <dcss> - Data Coding Schemes, string type: all different possible combinations of CBM data coding schemes; default is empty string [""].</p> <p>Note: the current settings are stored through +CSAS</p> <p>Note: issuing AT+CSCB<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CSCB=<CR> is the same as issuing the command AT+CSCB=0<CR>.</p>	
AT+CSCB?	Read command reports the current value of parameters <mode>, <mids> and <dcss>.	
AT+CSCB=?	Test command returns the range of values for parameter <mode>.	
Example	<p>AT+CSCB? +CSCB: 1, "", ""</p> <p>OK <i>(all CBMs are accepted, none is rejected)</i> AT+CSCB=0, "0,1,300-315,450", "0-3" OK</p>	
Reference	GSM 27.005, 3GPP TS 23.041, 3GPP TS 23.038.	

+CSCB -Select Cell Broadcast Message Types		SELINT 2
<p>AT+CSCB= [<mode>[,<mids> [,<dcss>]]]</p>	<p>Set command selects which types of Cell Broadcast Messages are to be received by the device.</p> <p>Parameters: <mode> 0 - the message types defined by <mids> and <dcss> are accepted (factory default) 1 - the message types defined by <mids> and <dcss> are rejected <mids> - Message Identifiers, string type: all different possible combinations of the CBM message identifiers; default is empty string [""].</p>	



+CSCB -Select Cell Broadcast Message Types		SELINT 2
	<p><dcss> - Data Coding Schemes, string type: all different possible combinations of CBM data coding schemes; default is empty string ("").</p> <p>Note: the current settings are stored through +CSAS</p>	
AT+CSCB?	Read command reports the current value of parameters <mode> , <mids> and <dcss> .	
AT+CSCB=?	Test command returns the range of values for parameter <mode> .	
Example	<pre>AT+CSCB? +CSCB: 1, "", "" OK (all CBMs are accepted, none is rejected) AT+CSCB=0, "0,1,300-315,450", "0-3" OK</pre>	
Reference	GSM 27.005, 3GPP TS 23.041, 3GPP TS 23.038.	

3.5.5.2.5. Save Settings - +CSAS

+CSAS - Save Settings		SELINT 0 / 1
AT+CSAS [=<profile>]	<p>Execution command saves settings which have been made by the +CSCA, +CSMP and +CSCB commands in local non volatile memory.</p> <p>Parameter: <profile> 0 - it saves the settings to NVM (factory default). 1..n - SIM profile number; the value of n depends on the SIM and its max is 3.</p> <p>Note: certain settings may not be supported by the SIM and therefore they are always saved to NVM, regardless the value of <profile>.</p> <p>Note: If parameter is omitted the settings are saved in the non volatile memory.</p> <p>Note: +CSCB <mids> (Message Identifiers) parameter can be saved to SIM only if the "Cell broadcast message identifier selection" file is present on the SIM itself. This file, if present, has storage for only a single set of data. Therefore, it is not possible to save different <mids> in different SIM profiles; <mids> value, once changed and saved, will be the same for all SIM profiles.</p>	
AT+CSAS?	Read command has the same effect as Execution command with parameter omitted.	
AT+CSAS=?	Test command returns the possible range of values for the parameter	



+CSAS - Save Settings		SELINT 0 / 1
	<profile>.	
Reference	GSM 27.005	

+CSAS - Save Settings		SELINT 2
AT+CSAS [=<profile>]	<p>Execution command saves settings which have been made by the +CSCA, +CSMP and +CSCB commands in local non volatile memory.</p> <p>Parameter: <profile> 0 - it saves the settings to NVM (factory default). 1..n - SIM profile number; the value of n depends on the SIM and its max is 3.</p> <p>Note: certain settings may not be supported by the SIM and therefore they are always saved to NVM, regardless the value of <profile>.</p> <p>Note: If parameter is omitted the settings are saved in the non volatile memory.</p> <p>Note: +CSCB <mids> (Message Identifiers) parameter can be saved to SIM only if the "Cell broadcast message identifier selection" file is present on the SIM itself. This file, if present, has storage for only a single set of data. Therefore, it is not possible to save different <mids> in different SIM profiles; <mids> value, once changed and saved, will be the same for all SIM profiles.</p>	
AT+CSAS=?	Test command returns the possible range of values for the parameter <profile> .	
Reference	GSM 27.005	

3.5.5.2.6. Restore Settings - +CRES

+CRES - Restore Settings		SELINT 0 / 1
AT+CRES [=<profile>]	<p>Execution command restores message service settings saved by +CSCA command from either NVM or SIM.</p> <p>Parameter: <profile> 0 - it restores message service settings from NVM. 1..n - it restores message service settings from SIM. The value of n depends on the SIM and its max is 3.</p>	



+CRES - Restore Settings		SELINT 0 / 1
	<p>Note: certain settings may not be supported by the SIM and therefore they are always restored from NVM, regardless the value of <profile>.</p> <p>Note: If parameter is omitted the command restores message service settings from NVM.</p>	
AT+CRES?	Read command has the same effect as Execution command with parameter omitted.	
AT+CRES=?	Test command returns the possible range of values for the parameter <profile> .	
Reference	GSM 27.005	

+CRES - Restore Settings		SELINT 2
AT+CRES [=<profile>]	<p>Execution command restores message service settings saved by +CSAS command from either NVM or SIM.</p> <p>Parameter: <profile> 0 - it restores message service settings from NVM. 1..n - it restores message service settings from SIM. The value of n depends on the SIM and its max is 3.</p> <p>Note: certain settings may not be supported by the SIM and therefore they are always restored from NVM, regardless the value of <profile>.</p> <p>Note: If parameter is omitted the command restores message service settings from NVM.</p>	
AT+CRES=?	Test command returns the possible range of values for the parameter <profile> .	
Reference	GSM 27.005	

3.5.5.3. Message Receiving And Reading

3.5.5.3.1. New Message Indications - +CNMI

+CNMI - New Message Indications To Terminal Equipment		SELINT 0 / 1
AT+CNMI [= <mode> [, <mt> [, <bm> [, <ds> [, <bfr>]]]]]	<p>Set command selects the behaviour of the device on how the receiving of new messages from the network is indicated to the DTE.</p> <p>Parameter: <mode> - unsolicited result codes buffering option</p>	



+CNMI - New Message Indications To Terminal Equipment	SELINT 0 / 1
	<p>0 - Buffer unsolicited result codes in the TA. If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications.</p> <p>1 - Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved, otherwise forward them directly to the TE.</p> <p>2 - Buffer unsolicited result codes in the TA in case the DTE is busy and flush them to the TE after reservation. Otherwise forward them directly to the TE.</p> <p>3 - if <mt> is set to 1 an indication via 100 ms break is issued when a SMS is received while the module is in GPRS online mode. It enables the hardware ring line for 1 s. too.</p> <p><mt> - result code indication reporting for SMS-DELIVER</p> <p>0 - No SMS-DELIVER indications are routed to the TE.</p> <p>1 - If SMS-DELIVER is stored into ME/TA, indication of the memory location is routed to the TE using the following unsolicited result code: +CMTI: <memr>,<index> where: <memr> - memory storage where the new message is stored "SM" "ME" <index> - location on the memory where SM is stored.</p> <p>2 - SMS-DELIVERs (except class 2 messages and messages in the message waiting indication group) are routed directly to the TE using the following unsolicited result code:</p> <p style="text-align: center;">(PDU Mode)</p> <p>+CMT: ,<length><CR><LF><pdu> where: <length> - PDU length <pdu> - PDU message</p> <p style="text-align: center;">(TEXT Mode)</p> <p>+CMT:<oa>,,<scts>[,<toa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data> (the information written in italics will be present depending on +CSDH last setting) where: <oa> - originating address, string type converted in the currently selected character set (see +CSCS) <scts> - arrival time of the message to the SC</p>



+CNMI - New Message Indications To Terminal Equipment		SELINT 0 / 1
	<p style="text-align: center;">(PDU Mode)</p> <p>+CDS: <length><CR><LF><PDU> where: <length> - PDU length <PDU> - message PDU</p> <p style="text-align: center;">(TEXT Mode)</p> <p>+CDS: <fo>,<mr>,,,<scts>,<dt>,<st> where: <fo> - first octet of the message PDU <mr> - message reference number <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU</p> <p>2 - if a status report is stored, then the following unsolicited result code is sent: +CDSI: <memr>,<index> where: <memr> - memory storage where the new message is stored "SM" <index> - location on the memory where SM is stored</p> <p><bfr> - buffered result codes handling method: 0 - TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode>=1..3 is entered (OK response shall be given before flushing the codes) 1 - TA buffer of unsolicited result codes defined within this command is cleared when <mode>=1..3 is entered.</p> <p>Note: issuing AT+CNMI<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+CNMI=<CR> is the same as issuing the command AT+CNMI=0<CR>.</p>	
AT+CNMI?	Read command returns the current parameter settings for +CNMI command in the form: +CNMI: <mode>,<mt>,<bm>,<ds>,<bfr>	
AT+CNMI=?	Test command reports the supported range of values for the +CNMI command parameters. For compatibility with previous versions, Test command returns:	



+CNMI - New Message Indications To Terminal Equipment		SELINT 0 / 1
	+CNMI: (0-2),(0-3),(0,2),(0-2),(0,1)	
	An enhanced version of Test command has been defined: AT+CNMI=?? , that provides the complete range of values for parameter <mode> .	
AT+CNMI=??	Enhanced test command reports the supported range of values for all the +CNMI command parameters.	
Reference	GSM 27.005	
Note	DTR signal is ignored, hence the indication is sent even if the DTE is inactive (DTR signal is Low). In this case the unsolicited result code may be lost so if MODULE remains active while DTE is not, at DTE startup is suggested to check whether new messages have reached the device meanwhile with command AT+CMGL=0 that lists the new messages received.	

+CNMI - New Message Indications To Terminal Equipment		SELINT 2
<i>Note: the behaviour of command +CNMI differs depending on whether or not the improved SMS commands operation mode has been enabled (see #SMSMODE)</i>		
(#SMSMODE=0)		
# S M S M O D E = 0	AT+CNMI=[<mode>[,<mt> [,<bm>[,<ds> [,<bfr>]]]]]	Set command selects the behaviour of the device on how the receiving of new messages from the network is indicated to the DTE . Parameter: <mode> - unsolicited result codes buffering option 0 - Buffer unsolicited result codes in the TA . If TA result code buffer is full, indications can be buffered in some other place or the oldest indications may be discarded and replaced with the new received indications. 1 - Discard indication and reject new received message unsolicited result codes when TA-TE link is reserved, otherwise forward them directly to the TE . 2 - Buffer unsolicited result codes in the TA in case the DTE is busy and flush them to the TE after reservation. Otherwise forward them directly to the TE . 3 - if <mt> is set to 1 an indication via 100 ms break is issued when a SMS is received while the module is in GPRS online mode. It enables the hardware ring line for 1 s. too. <mt> - result code indication reporting for SMS-DELIVER 0 - No SMS-DELIVER indications are routed to the TE . 1 - If SMS-DELIVER is stored into ME/TA , indication of the memory location is routed to the TE using the following unsolicited result code:
# S M S M O D E = 0		



+CNMI - New Message Indications To Terminal Equipment		SELINT 2
# S M S M O D E = 0		<p>+CMTI: <mems>,<index> where: <mems> - memory storage where the new message is stored (see +CPMS) <index> - location on the memory where SMS is stored.</p> <p>2 - SMS-DELIVERs (except class 2 messages and messages in the "store" message waiting indication group) are routed directly to the TE using the following unsolicited result code:</p> <p style="text-align: center;">(PDU Mode)</p> <p>+CMT: <alpha>,<length><CR><LF><pdu> where: <alpha> - alphanumeric representation of originator/destination number corresponding to the entry found in MT phonebook; used character set should be the one selected with command +CSCS. <length> - PDU length <pdu> - PDU message</p> <p style="text-align: center;">(TEXT Mode)</p> <p>+CMT:<oa>,<alpha>,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data> (the information written in italics will be present depending on +CSDH last setting) where: <oa> - originating address, string type converted in the currently selected character set (see +CSCS) <alpha> - alphanumeric representation of <oa>; used character set should be the one selected with command +CSCS. <scts> - arrival time of the message to the SC <tooa> , <tosca> - type of number <oa> or <sca>: 129 - number in national format 145 - number in international format (contains the "+") <fo> - first octet of 3GPP TS 23.040 <pid> - Protocol Identifier <dcs> - Data Coding Scheme <sca> - Service Centre address, string type, converted in the currently selected character set (see +CSCS) <length> - text length <data> - TP-User-Data <ul style="list-style-type: none"> • If <dcs> indicates that GSM03.38 default alphabet is used and <fo> indicates that GSM03.40 TP-User-Data-Header- </p>
# S M S M O D E = 0		
# S M S M O D E = 0		



+CNMI - New Message Indications To Terminal Equipment		SELINT 2
# S M S M O D E = 0		<p>Indication is not set (bit 6 of <fo> is 0), each character of GSM alphabet will be converted into current TE character set (see +CSCS)</p> <ul style="list-style-type: none"> If <dcs> indicates that 8-bit or UCS2 data coding scheme is used or <fo> indicates that GSM03.40 TP-User-Data-Header-Indication is set (bit 6 of <fo> is 1), each 8-bit octet will be converted into two IRA character long hexadecimal number (e.g. octet 0x2A will be converted as two characters 0x32 0x41) <p>Class 2 messages and messages in the “store” message waiting indication group result in indication as defined in <mt>=1.</p> <p>3 - Class 3 SMS-DELIVERs are routed directly to TE using unsolicited result codes defined in <mt>=2. Messages of other data coding schemes result in indication as defined in <mt>=1.</p> <p><bm> - broadcast reporting option</p> <p>0 - Cell Broadcast Messages are not sent to the DTE</p> <p>2 - New Cell Broadcast Messages are sent to the DTE with the unsolicited result code:</p> <p style="text-align: center;">(PDU Mode)</p> <p>+CBM: <length><CR><LF><PDU></p> <p>where:</p> <p><length> - PDU length</p> <p><PDU> - message PDU</p> <p style="text-align: center;">(TEXT Mode)</p> <p>+CBM:<sn>,<mid>,<dcs>,<pag>,<pags><CR><LF><data></p> <p>where:</p> <p><sn> - message serial number</p> <p><mid> - message ID</p> <p><dcs> - Data Coding Scheme</p> <p><pag> - page number</p> <p><pags> - total number of pages of the message</p> <p><data> - CBM Content of Message</p> <ul style="list-style-type: none"> If <dcs> indicates that GSM03.38 default alphabet is used , each character of GSM alphabet will be converted into current TE character set (see +CSCS) If <dcs> indicates that 8-bit or UCS2 data coding scheme is used, each 8-bit octet will be converted into two IRA character long hexadecimal number (e.g. octet 0x2A will be converted as two characters 0x32 0x41)
# S M S M O D E = 0		
# S M		



+CNMI - New Message Indications To Terminal Equipment		SELINT 2
S M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0 # S M S M		<p><ds> - SMS-STATUS-REPORTs reporting option</p> <p>0 - status report receiving is not reported to the DTE</p> <p>1 - the status report is sent to the DTE with the following unsolicited result code:</p> <p style="text-align: center;">(PDU Mode)</p> <p>+CDS: <length><CR><LF><PDU></p> <p>where:</p> <p><length> - PDU length</p> <p><PDU> - message PDU</p> <p style="text-align: center;">(TEXT Mode)</p> <p>+CDS: <fo>,<mr>,,,<scts>,<dt>,<st></p> <p>where:</p> <p><fo> - first octet of the message PDU</p> <p><mr> - message reference number; 3GPP TS 23.040 TP-Message-Reference in integer format</p> <p><scts> - arrival time of the message to the SC</p> <p><dt> - sending time of the message</p> <p><st> - message status as coded in the PDU</p> <p>2 - if a status report is stored, then the following unsolicited result code is sent:</p> <p>+CDSI: <memr>,<index></p> <p>where:</p> <p><memr> - memory storage where the new message is stored "SM"</p> <p><index> - location on the memory where SMS is stored</p> <p><bfr> - buffered result codes handling method:</p> <p>0 - TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode>=1..3 is entered (OK response shall be given before flushing the codes)</p> <p>1 - TA buffer of unsolicited result codes defined within this command is cleared when <mode>=1..3 is entered.</p>
# S M S M	AT+CNMI?	Read command returns the current parameter settings for +CNMI command in the form: +CNMI: <mode>,<mt>,<bm>,<ds>,<bfr>
	AT+CNMI=?	Test command reports the supported range of values for the +CNMI



+CNMI - New Message Indications To Terminal Equipment		SELINT 2
O D E = 1 # S M S M O D E = 1 # S M S M O D E = 1 # S M S M O D E		<p>the TE using the following unsolicited result code:</p> <p style="text-align: center;">(PDU Mode)</p> <p>+CMT: <alpha>,<length><CR><LF><pdu></p> <p>where:</p> <p><alpha> - alphanumeric representation of originator/destination number corresponding to the entry found in MT phonebook; used character set should be the one selected with command +CSCS.</p> <p><length> - PDU length</p> <p><pdu> - PDU message</p> <p style="text-align: center;">(TEXT Mode)</p> <p>+CMT:<oa>,<alpha>,<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data> (the information written in italics will be present depending on +CSDH last setting)</p> <p>where:</p> <p><oa> - originating address, string type converted in the currently selected character set (see +CSCS)</p> <p><alpha> - alphanumeric representation of <oa>; used character set should be the one selected with command +CSCS.</p> <p><scts> - arrival time of the message to the SC</p> <p><tooa>,<tosca> - type of number <oa> or <sca>:</p> <p>129 - number in national format</p> <p>145 - number in international format (contains the "+")</p> <p><fo> - first octet of 3GPP TS 23.040</p> <p><pid> - Protocol Identifier</p> <p><dcs> - Data Coding Scheme</p> <p><sca> - Service Centre address, string type, converted in the currently selected character set (see +CSCS)</p> <p><length> - text length</p> <p><data> - TP-User-Data</p> <ul style="list-style-type: none"> • If <dcs> indicates that GSM03.38 default alphabet is used and <fo> indicates that GSM03.40 TP-User-Data-Header-Indication is not set (bit 6 of <fo> is 0), each character of GSM alphabet will be converted into current TE character set (see +CSCS) • If <dcs> indicates that 8-bit or UCS2 data coding scheme is used or <fo> indicates that GSM03.40 TP-User-Data-Header-Indication is set (bit 6 of <fo> is 1), each 8-bit octet will be converted into two IRA character long hexadecimal



+CNMI - New Message Indications To Terminal Equipment		SELINT 2
= 1 # S M S M O D E = 1 # S M S M O D E = 1 # S M S M O D E = 0		<p>number (e.g. octet 0x2A will be converted as two characters 0x32 0x41)</p> <p>Class 2 messages and messages in the “store” message waiting indication group result in indication as defined in <mt>=1.</p> <p>3 - Class 3 SMS-DELIVERs are routed directly to TE using unsolicited result codes defined in <mt>=2. Messages of other data coding schemes result in indication as defined in <mt>=1.</p> <p><bm> - broadcast reporting option</p> <p>0 - Cell Broadcast Messages are not sent to the DTE</p> <p>2 - New Cell Broadcast Messages are sent to the DTE with the unsolicited result code:</p> <p style="text-align: center;">(PDU Mode)</p> <p>+CBM: <length><CR><LF><PDU></p> <p>where:</p> <p><length> - PDU length</p> <p><PDU> - message PDU</p> <p style="text-align: center;">(TEXT Mode)</p> <p>+CBM:<sn>,<mid>,<dcs>,<pag>,<pags><CR><LF><data></p> <p>where:</p> <p><sn> - message serial number</p> <p><mid> - message ID</p> <p><dcs> - Data Coding Scheme</p> <p><pag> - page number</p> <p><pags> - total number of pages of the message</p> <p><data> - CBM Content of Message</p> <ul style="list-style-type: none"> • If <dcs> indicates that GSM03.38 default alphabet is used , each character of GSM alphabet will be converted into current TE character set (see +CSCS) • If <dcs> indicates that 8-bit or UCS2 data coding scheme is used, each 8-bit octet will be converted into two IRA character long hexadecimal number (e.g. octet 0x2A will be converted as two characters 0x32 0x41) <p><ds> - SMS-STATUS-REPORTs reporting option</p> <p>0 - status report receiving is not reported to the DTE and is not stored</p> <p>1 - the status report is sent to the DTE with the following unsolicited result code:</p>



+CNMI - New Message Indications To Terminal Equipment		SELINT 2
# S M S M O D E = 1		<p style="text-align: center;">(PDU Mode)</p> <p>+CDS: <length><CR><LF><PDU> where: <length> - PDU length <PDU> - message PDU</p> <p style="text-align: center;">(TEXT Mode)</p> <p>+CDS: <fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st> where: <fo> - first octet of the message PDU <mr> - message reference number; 3GPP TS 23.040 TP-Message-Reference in integer format <ra> - recipient address, string type, represented in the currently selected character set (see +CSCS) <tora> - type of number <ra> <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU</p> <p>2 - if a status report is stored, then the following unsolicited result code is sent: +CDSI: <memr>,<index></p> <p>where: <memr> - memory storage where the new message is stored "SM" <index> - location on the memory where SMS is stored</p> <p><bfr> - buffered result codes handling method: 0 - TA buffer of unsolicited result codes defined within this command is flushed to the TE when <mode>=1..3 is entered (OK response shall be given before flushing the codes) 1 - TA buffer of unsolicited result codes defined within this command is cleared when <mode>=1..3 is entered.</p>
# S M S M O D E = 1	AT+CNMI?	Read command returns the current parameter settings for +CNMI command in the form: +CNMI: <mode>,<mt>,<bm>,<ds>,<bfr>
# S M S M O D E = 1	AT+CNMI=?	Test command reports the supported range of values for the +CNMI command parameters.
	Reference	GSM 27.005
	Note	DTR signal is ignored, hence the indication is sent even if the DTE is



+CNMI - New Message Indications To Terminal Equipment		SELINT 2																											
# S M S M O D E = 1		<p>inactive (DTR signal is Low). In this case the unsolicited result code may be lost so if MODULE remains active while DTE is not, at DTE startup is suggested to check whether new messages have reached the device meanwhile with command AT+CMGL=0 that lists the new messages received.</p>																											
	Note	<p>It has been necessary to take the following decisions to get over any incoherence problem in a multiplexed environment (see +CMUX), due to the possibility to have contemporaneous different settings of parameter <mt> in different sessions:</p> <table border="1" style="margin-left: 20px;"> <tr> <td style="text-align: center;"> Message Class or Indication group, as in the DCS <mt> settings in different sessions </td> <td style="text-align: center;"> SM Class is No Class <i>OR</i> SM Class is 0 or 1 or 3 <i>OR</i> SM is an Indication with group "Discard" </td> <td style="text-align: center;"> SM Class is 3 </td> </tr> <tr> <td style="text-align: center;"> <mt>=2 for session "0" <i>AND</i> <mt>=anyvalue for other session(s) </td> <td style="text-align: center;"> URC is shown only on session "0" </td> <td></td> </tr> <tr> <td style="text-align: center;"> <mt>=3 for session "0" <i>AND</i> <mt>=0 or 1 for other session(s) </td> <td></td> <td style="text-align: center;"> URC is shown only on session "0" </td> </tr> </table>	Message Class or Indication group, as in the DCS <mt> settings in different sessions	SM Class is No Class <i>OR</i> SM Class is 0 or 1 or 3 <i>OR</i> SM is an Indication with group "Discard"	SM Class is 3	<mt>=2 for session "0" <i>AND</i> <mt>=anyvalue for other session(s)	URC is shown only on session "0"		<mt>=3 for session "0" <i>AND</i> <mt>=0 or 1 for other session(s)		URC is shown only on session "0"																		
Message Class or Indication group, as in the DCS <mt> settings in different sessions	SM Class is No Class <i>OR</i> SM Class is 0 or 1 or 3 <i>OR</i> SM is an Indication with group "Discard"	SM Class is 3																											
<mt>=2 for session "0" <i>AND</i> <mt>=anyvalue for other session(s)	URC is shown only on session "0"																												
<mt>=3 for session "0" <i>AND</i> <mt>=0 or 1 for other session(s)		URC is shown only on session "0"																											
# S M S M O D E = 1	Note	<p>The following table clarifies which URC is shown and if the DELIVER SM is stored, depending on the <mt> parameter value and the SM class.</p> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th colspan="2"></th> <th colspan="5">SM CLASS</th> </tr> <tr> <th colspan="2"></th> <th>0 / msg waiting discard</th> <th>1 / no class</th> <th>2</th> <th>3</th> <th>msg waiting store</th> </tr> </thead> <tbody> <tr> <th rowspan="2"><mt></th> <th>0</th> <td>Store in <mems></td> <td>Store in <mems></td> <td>Store in SIM</td> <td>Store in <mems></td> <td>Store in <mems></td> </tr> <tr> <th>1</th> <td>Store in <mems> - Send ind +CMTI</td> <td>Store in <mems> - Send ind +CMTI</td> <td>Store in SIM - Send ind +CMTI</td> <td>Store in <mems> - Send ind +CMTI</td> <td>Store in <mems> - Send ind +CMTI</td> </tr> </tbody> </table>			SM CLASS							0 / msg waiting discard	1 / no class	2	3	msg waiting store	<mt>	0	Store in <mems>	Store in <mems>	Store in SIM	Store in <mems>	Store in <mems>	1	Store in <mems> - Send ind +CMTI	Store in <mems> - Send ind +CMTI	Store in SIM - Send ind +CMTI	Store in <mems> - Send ind +CMTI	Store in <mems> - Send ind +CMTI
		SM CLASS																											
		0 / msg waiting discard	1 / no class	2	3	msg waiting store																							
<mt>	0	Store in <mems>	Store in <mems>	Store in SIM	Store in <mems>	Store in <mems>																							
	1	Store in <mems> - Send ind +CMTI	Store in <mems> - Send ind +CMTI	Store in SIM - Send ind +CMTI	Store in <mems> - Send ind +CMTI	Store in <mems> - Send ind +CMTI																							



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

+CNMI - New Message Indications To Terminal Equipment						SELINT 2
	2	Route msg to TE: +CMT²¹	Route msg to TE: +CMT¹	Store in SIM - Send ind +CMTI	Route msg to TE: +CMT¹	Store in <mems> - Send ind +CMTI
	3	Store in <mems> - Send ind +CMTI	Store in <mems>- Send ind +CMTI	Store in SIM - Send ind +CMTI	Route msg to TE: +CMT¹	Store in <mems> - Send ind +CMTI
		where <mems> is the memory where the received messages are stored (see +CPMS)				
Note	It has been necessary to take the following decision to get over an incoherence problem in a multiplexed environment (see +CMUX), due to the possibility to have contemporaneous different settings of parameter <ds> in different sessions:					
		<ds> settings in different sessions				
		<ds>=1 for session "0" AND <ds>=2 for at least one of the other sessions		URC +CDS is shown only on session "0" and no status report is stored on SIM		
		<ds>=0 for session "0" AND <ds>=2 for at least one of the other sessions		no URC is shown on any session and no status report is stored on SIM		

3.5.5.3.2. List Messages - **+CMGL**

+CMGL - List Messages		SELINT 0 / 1
AT+CMGL [=<stat>]	<p>Execution command reports the list of all the messages with status value <stat> stored into <memr> message storage (<memr> is the message storage for read and delete SMs as last settings of command +CPMS).</p> <p>The parameter type and the command output depend on the last settings of command +CMGF (message format to be used)</p> <p style="text-align: center;">(PDU Mode)</p>	

²¹ The SM is not stored!



+CMGL - List Messages	SELINT 0 / 1
<p>Parameter: <stat> 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent 4 - all messages.</p> <p>Each message to be listed is represented in the format:</p> <p>+CMGL: <index>,<stat>,<length><CR><LF><pdu></p> <p>where <index> - message position in the memory storage list. <stat> - status of the message <length> - length of the PDU in bytes <pdu> - message in PDU format according to GSM 3.40</p> <p style="text-align: center;">(Text Mode)</p> <p>Parameter: <stat> "REC UNREAD" - new message "REC READ" - read message "STO UNSENT" - stored message not yet sent "STO SENT" - stored message already sent "ALL" - all messages.</p> <p>Each message to be listed is represented in the format (the information written in <i>italics</i> will be present depending on +CSDH last setting):</p> <p>+CMGL: <index>,<stat>,<oa/da>,,[,<toa/toda>,<length>] <CR><LF> <data></p> <p>where <index> - message position in the storage <stat> - message status <oa/da> - originator/destination address, string type, represented in the currently selected character set (see +CSCS) <toa/toda> - type of number <oa/da> 129 - number in national format 145 - number in international format (contains the "+") <length> - text length</p>	



+CMGL - List Messages		SELINT 2
S M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0 # S M S M O	<p>command +CPMS).</p> <p>The parameter type and the command output depend on the last settings of command +CMGF (message format to be used)</p> <p style="text-align: center;">(PDU Mode)</p> <p>Parameter: <stat> 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent 4 - all messages.</p> <p>If there is at least one message to be listed the representation format is:</p> <p>+CMGL: <index>,<stat>,<alpha>,<length><CR><LF><pdu> [<CR><LF> +CMGL: <index>,<stat>,<alpha>,<length><CR><LF><pdu>[...]]</p> <p>where: <index> - message position in the memory storage list. <stat> - status of the message <alpha> - string type alphanumeric representation of <da> or <oa>, corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS. <length> - length of the PDU in bytes <pdu> - message in PDU format according to GSM 3.40</p> <p style="text-align: center;">(Text Mode)</p> <p>Parameter: <stat> "REC UNREAD" - new message "REC READ" - read message "STO UNSENT" - stored message not yet sent "STO SENT" - stored message already sent "ALL" - all messages.</p> <p>The representation format for stored messages (either sent or unsent) or received messages (either read or unread, not message delivery confirm) is (the information written in italics will be present</p>	



+CMGL - List Messages		SELINT 2
= 0		<p>Reference in integer format <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU</p> <p>Note: If parameter is omitted the command returns the list of sms with "REC UNREAD" status.</p> <p>Note: the order in which the messages are reported by +CMGL is the same order in which these messages have been processed by the module</p>
# S M S M O D E = 0	AT+CMGL?	Read command has the same effect as Execution command with parameter omitted.
= 0	AT+CMGL=?	Test command returns a list of supported <stat>s
	Reference	GSM 27.005, 3GPP TS 23.040
[#SMSMODE=1]		
# S M S M O D E = 1	AT+CMGL [=<stat>]	<p>Execution command reports the list of all the messages with status value <stat> stored into <memr> message storage (<memr> is the message storage for read and delete SMs as last settings of command +CPMS).</p> <p>The parameter type and the command output depend on the last settings of command +CMGF (message format to be used)</p> <p style="text-align: center;">(PDU Mode)</p> <p>Parameter: <stat> 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent 4 - all messages.</p> <p>If there is at least one message to be listed the representation format is:</p> <p>+CMGL: <index>,<stat>,<alpha>,<length><CR><LF><pdu>[<CR><LF> +CMGL: <index>,<stat>,<alpha>,<length><CR><LF><pdu>[...]]</p>
# S M S M O D E = 1		



+CMGL - List Messages		SELINT 2
# S M S M O D E = 1		<p>where:</p> <p><index> - message position in the memory storage list.</p> <p><stat> - status of the message</p> <p><alpha> - string type alphanumeric representation of <da> or <oa>, corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS.</p> <p><length> - length of the PDU in bytes</p> <p><pdu> - message in PDU format according to GSM 3.40</p> <p style="text-align: center;">(Text Mode)</p> <p>Parameter:</p> <p><stat> "REC UNREAD" - new message "REC READ" - read message "STO UNSENT" - stored message not yet sent "STO SENT" - stored message already sent "ALL" - all messages.</p> <p>The representation format for stored messages (either sent or unsent) or received messages (either read or unread, not message delivery confirm) is (the information written in italics will be present depending on +CSDH last setting):</p> <p>+CMGL: <i><index></i>,<i><stat></i>,<i><oa/da></i>,<i><alpha></i>,<i><scts></i> [<i>,<toa/toda></i>, <i><length></i>]<i><CR><LF><data></i>[<i><CR><LF></i> +CMGL: <i><index></i>,<i><stat></i>,<i><oa/da></i>,<i><alpha></i>,<i><scts></i> [<i>,<toa/toda></i>, <i><length></i>]<i><CR><LF><data></i>[...]]</p> <p>where:</p> <p><index> - message position in the storage</p> <p><stat> - message status</p> <p><oa/da> - originator/destination address, string type , represented in the currently selected character set (see +CSCS)</p> <p><alpha> - string type alphanumeric representation of <da> or <oa>, corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS.</p> <p><scts> - TP-Service Centre Time Stamp in Time String Format</p> <p><toa/toda> - type of number <oa/da> 129 - number in national format 145 - number in international format (contains the "+")</p>
# S M S M O D E = 1		
# S M S M O D E = 1		



+CMGL - List Messages		SELINT 2
# S M S M O D E = 1		<p><length> - text length <data> - TP-User-Data</p> <ul style="list-style-type: none"> • If <dc> indicates that GSM03.38 default alphabet is used , each character of GSM alphabet will be converted into current TE character set (see +CSCS) • If <dc> indicates that 8-bit or UCS2 data coding scheme is used, each 8-bit octet will be converted into two IRA character long hexadecimal number (e.g. octet 0x2A will be converted as two characters 0x32 0x41) • If <fo> indicates that a UDH is present each 8-bit octet will be converted into two IRA character long hexadecimal number. The <length> indicates text length in characters without UDH length. <p>If there is at least one message delivery confirm to be listed the representation format is:</p> <p>+CMGL: <index>,<stat>,<fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st> [<CR><LF> +CMGL: <index>,<stat>,<fo>,<mr>,<ra>,<tora>,<scts>,<dt>,<st> [...]]</p> <p>where</p> <p><index> - message position in the storage <stat> - message status <fo> - first octet of the message PDU <mr> - message reference number; 3GPP TS 23.040 TP-Message-Reference in integer format <ra> - recipient address, string type , represented in the currently selected character set (see +CSCS) <tora> - type of number <ra> <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU</p> <p>Note: If parameter is omitted the command returns the list of sms with "REC UNREAD" status.</p> <p>Note: the order in which the messages are reported by +CMGL corresponds to their position in the memory storage</p>
	AT+CMGL=?	Test command returns a list of supported <stat> s
	Reference	GSM 27.005, 3GPP TS 23.040



3.5.5.3.3. List Messages - @CMGL

@CMGL - List Messages Improved	SELINT 0
<p>AT@CMGL [=<stat>]</p>	<p>Execution command reports the list of all the messages with status value <stat> stored into <memr> message storage (<memr> is the message storage for read and delete SMs as last settings of command +CPMS).</p> <p>The parameter type and the command output depend on the last settings of command +CMGF (message format to be used)</p> <p style="text-align: center;">(PDU Mode)</p> <p>Parameter: <stat> 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent 4 - all messages.</p> <p>Each message to be listed is represented in the format:</p> <p>@CMGL: <index>,<stat>,<length><CR><LF><pdu></p> <p>where <index> - message position in the memory storage list. <stat> - status of the message <length> - length of the PDU in bytes <pdu> - message in PDU format according to GSM 3.40</p> <p style="text-align: center;">(Text Mode)</p> <p>Parameter: <stat> "REC UNREAD" - new message "REC READ" - read message "STO UNSENT" - stored message not yet sent "STO SENT" - stored message already sent "ALL" - all messages.</p> <p>Each message to be listed is represented in the format (the information written in italics will be present depending on +CSDH last setting):</p> <p>@CMGL: <index>,<stat>,<oa/da>,,[,<toa/toda>,<length>]</p>



@CMGL - List Messages Improved	SELINT 0
	<p><CR><LF> <data></p> <p>where</p> <p><index> - message position in the storage</p> <p><stat> - message status</p> <p><oa/da> - originator/destination address, string type, represented in the currently selected character set (see +CSCS)</p> <p><tooa/toda> - type of number <oa/da></p> <p>129 - number in national format</p> <p>145 - number in international format (contains the "+")</p> <p><length> - text length</p> <p><data> - TP-User-Data</p> <p>Each message delivery confirm is represented in the format:</p> <p>@CMGL: <index>,<stat>,<fo>,<mr>,,,<scts>,<dt>,<st></p> <p>where</p> <p><index> - message position in the storage</p> <p><stat> - message status</p> <p><fo> - first octet of the message PDU</p> <p><mr> - message reference number</p> <p><scts> - arrival time of the message to the SC</p> <p><dt> - sending time of the message</p> <p><st> - message status as coded in the PDU</p> <p>Note: The command differs from the +CMGL because at the end of the listing a <CR><LF> is put before the OK result code.</p> <p>Note: If parameter is omitted the command returns the list of sms with "REC UNREAD" status.</p>
AT@CMGL?	Read command has the same effect as Execution command with parameter omitted
AT@CMGL=?	Test command returns a list of supported <stat>s
Note	<p>If Text Mode (+CMGF=1) the Test command output is not included in parenthesis</p> <p>AT@CMGL=? @CMGL: "REC UNREAD","REC READ","STO UNSENT", "STO SENT","ALL"</p>
Reference	GSM 27.005



@CMGL - List Messages Improved	SELINT 1
	<p><stat> - message status <oa/da> - originator/destination address, string type, represented in the currently selected character set (see +CSCS) <tooa/toda> - type of number <oa/da> 129 - number in national format 145 - number in international format (contains the "+") <length> - text length <data> - TP-User-Data</p> <p>Each message delivery confirm is represented in the format:</p> <p>@CMGL: <index>,<stat>,<fo>,<mr>,,,<scts>,<dt>,<st></p> <p>where <index> - message position in the storage <stat> - message status <fo> - first octet of the message PDU <mr> - message reference number <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU</p> <p>Note: The command differs from the +CMGL because at the end of the listing a <CR><LF> is put before the OK result code.</p> <p>Note: If parameter is omitted the command returns the list of sms with "REC UNREAD" status.</p>
AT@CMGL?	Read command has the same effect as Execution command with parameter omitted
AT@CMGL=?	Test command returns a list of supported <stat>s
Note	<p>If Text Mode (+CMGF=1) the Test command output is not included in parenthesis</p> <p>AT@CMGL=? @CMGL: "REC UNREAD", "REC READ", "STO UNSENT", "STO SENT", "ALL"</p>
Reference	GSM 27.005

3.5.5.3.4. Read Message - +CMGR

+CMGR - Read Message	SELINT 0 / 1
----------------------	--------------



+CMGR - Read Message	SELINT 0 / 1
<p>AT+CMGR= <index></p>	<p>Execution command reports the message with location value <index> from <memr> message storage (<memr> is the message storage for read and delete SMs as last settings of command +CPMS).</p> <p>Parameter: <index> - message index.</p> <p>The output depends on the last settings of command +CMGF (message format to be used)</p> <p style="text-align: center;">(PDU Mode)</p> <p>The output has the following format:</p> <p>+CMGR: <stat>,<length><CR><LF><pdu></p> <p>where <stat> - status of the message 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent <length> - length of the PDU in bytes. <pdu> - message in PDU format according to GSM 3.40.</p> <p>The status of the message and entire message data unit <pdu> is returned.</p> <p style="text-align: center;">(Text Mode)</p> <p>Output format for received messages (the information written in italics will be present depending on +CSDH last setting):</p> <p>+CMGR: <stat>,<oa>,,<scts> <i>l,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length></i><CR><LF><data></p> <p>Output format for either sent or unsent messages: +CMGR: <stat>,<da>,<i>l,<toda>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length></i><CR><LF><data></p> <p>Output format for message delivery confirm: +CMGR: <stat>,<fo>,<mr>,,,<scts>,<dt>,<st></p> <p>where:</p>



+CMGR - Read Message		SELINT 2
M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0 # S M S M O D	Parameter: <index> - message index. The output depends on the last settings of command +CMGF (message format to be used) <p style="text-align: center;">(PDU Mode)</p> If there is a message in location <index> , the output has the following format: +CMGR: <stat>,<alpha>,<length><CR><LF><pdu> where <stat> - status of the message 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent <alpha> - string type alphanumeric representation of <da> or <oa> , corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS . <length> - length of the PDU in bytes. <pdu> - message in PDU format according to GSM 3.40. The status of the message and entire message data unit <pdu> is returned. <p style="text-align: center;">(Text Mode)</p> If there is a Received message in location <index> the output format is (the information written in <i>italics</i> will be present depending on +CSDH last setting): +CMGR: <stat>,<oa>,<alpha>,<scts>[,<toa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data> If there is either a Sent or an Unsent message in location <index> the output format is: +CMGR: <stat>,<da>,<alpha>[,<toda>,<fo>,<pid>,<dcs>,<vp>,<sca>,<tosca>,<length>]<CR><LF><data> If there is a Message Delivery Confirm in location <index> the output format is: +CMGR: <stat>,<fo>,<mr>,,,<scts>,<dt>,<st>	



+CMGR - Read Message		SELINT 2
E = 0 # S M S M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0		<p>where:</p> <p><stat> - status of the message "REC UNREAD" - new received message unread "REC READ" - received message read "STO UNSENT" - message stored not yet sent "STO SENT" - message stored already sent</p> <p><fo> - first octet of the message PDU</p> <p><mr> - message reference number; 3GPP TS 23.040 TP-Message-Reference in integer format</p> <p><scts> - arrival time of the message to the SC</p> <p><dt> - sending time of the message</p> <p><st> - message status as coded in the PDU</p> <p><pid> - Protocol Identifier</p> <p><dcs> - Data Coding Scheme</p> <p><vp> - Validity period; only the integer format is supported</p> <p><oa> - Originator address, string type represented in the currently selected character set (see +CSCS)</p> <p><da> - Destination address, string type represented in the currently selected character set (see +CSCS)</p> <p><alpha> - string type alphanumeric representation of <da> or <oa>, corresponding to an entry found in the phonebook; used character set is the one selected with command +CSCS.</p> <p><sca> - Service Centre number</p> <p><tooa>, <toda >, <tosca> - type of number <oa>, <da>, <sca> 129 - number in national format 145 - number in international format (contains the "+")</p> <p><length> - text length</p> <p><data> - TP-User_data</p> <ul style="list-style-type: none"> • If <dcs> indicates that GSM03.38 default alphabet is used , each character of GSM alphabet will be converted into current TE character set (see +CSCS) • If <dcs> indicates that 8-bit or UCS2 data coding scheme is used, each 8-bit octet will be converted into two IRA character long hexadecimal number (e.g. octet 0x2A will be converted as two characters 0x32 0x41) <p>Note: in both cases if status of the message is 'received unread', status in the storage changes to 'received read'.</p> <p>Note: an error result code is sent on empty record <index>.</p>
	AT+CMGR=?	Test command returns the OK result code



@CMGR - Read Message Improved	SELINT 0
<p>0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent <length> - length of the PDU in bytes. <pdu> - message in PDU format according to GSM 3.40.</p> <p>The status of the message and entire message data unit <pdu> is returned.</p> <p style="text-align: center;">(Text Mode)</p> <p>Output format for received messages (the information written in italics will be present depending on +CSDH last setting):</p> <p>@CMGR: <stat>,<oa>,,<scts> /,<toa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><text></p> <p>Output format for either sent or unsent messages: @CMGR: <stat>,<da>,<l>,<toda>,<fo>,<pid>,<dcs>,,<sca>,<tosca>,<length>]<CR><LF><text></p> <p>Output format for message delivery confirm: @CMGR: <stat>,<fo>,<mr>,,,<scts>,<dt>,<st></p> <p>where:</p> <ul style="list-style-type: none"> <stat> - status of the message "REC UNREAD" - new received message unread "REC READ" - received message read "STO UNSENT" - message stored not yet sent "STO SENT" - message stored already sent <fo> - first octet of the message PDU <mr> - message reference number <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU <pid> - Protocol Identifier <dcs> - Data Coding Scheme <oa> - Originator address, string type represented in the currently selected character set (see +CSCS) <da> - Destination address, string type represented in the currently selected character set (see +CSCS) <sca> - Service Centre number 	



@CMGR - Read Message Improved		SELINT 0
	<p><toa>, < toda >, <tosca> - type of number <oa>, <da>, <sca> 129 - number in national format 145 - number in international format (contains the "+") <length> - text length <text> - message text</p> <p>Note: the command differs from the +CMGR because after the message <pdu> or <text> a <CR><LF> is put before the OK result code.</p> <p>Note: in both cases if status of the message is 'received unread', status in the storage changes to 'received read'.</p> <p>Note: an error result code is sent on empty record <index>.</p>	
AT@CMGR=?	Test command has no effect; the answer is OK	
Reference	GSM 27.005	

@CMGR - Read Message Improved		SELINT 1
AT@CMGR= <index>	<p>Execution command reports the message with location value <index> from <memr> message storage (<memr> is the message storage for read and delete SMs as last settings of command +CPMS).</p> <p>Parameter: <index> - message index.</p> <p>The output depends on the last settings of command +CMGF (message format to be used)</p> <p style="text-align: center;">(PDU Mode)</p> <p>The output has the following format:</p> <p>@CMGR: <stat>,<length><CR><LF><pdu></p> <p>where</p> <p><stat> - status of the message 0 - new message 1 - read message 2 - stored message not yet sent 3 - stored message already sent <length> - length of the PDU in bytes. <pdu> - message in PDU format according to GSM 3.40.</p> <p>The status of the message and entire message data unit <pdu> is</p>	



@CMGR - Read Message Improved	SELINT 1
<p>returned.</p> <p style="text-align: center;">(Text Mode)</p> <p>Output format for received messages:</p> <p>@CMGR: <stat>,<oa>,,<scts> [,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><text></p> <p>Output format for either sent or unsent messages:</p> <p>@CMGR: <stat>,<da>[,<toda>,<fo>,<pid>,<dcs>,,<sca>,<tosca>,<length>]<CR><LF><text></p> <p>Output format for message delivery confirm:</p> <p>@CMGR: <stat>,<fo>,<mr>,,,<scts>,<dt>,<st></p> <p>where:</p> <ul style="list-style-type: none"> <stat> - status of the message "REC UNREAD" - new received message unread "REC READ" - received message read "STO UNSENT" - message stored not yet sent "STO SENT" - message stored already sent <fo> - first octet of the message PDU <mr> - message reference number <scts> - arrival time of the message to the SC <dt> - sending time of the message <st> - message status as coded in the PDU <pid> - Protocol Identifier <dcs> - Data Coding Scheme <oa> - Originator address, string type represented in the currently selected character set (see +CSCS) <da> - Destination address, string type represented in the currently selected character set (see +CSCS) <sca> - Service Centre number <tooa>,<toda>,<tosca> - type of number <oa>,<da>,<sca> 129 - number in national format 145 - number in international format (contains the "+") <length> - text length <text> - message text <p>Note: the command differs from the +CMGR because after the message <pdu> or <text> a <CR><LF> is put before the OK result code.</p> <p>Note: in both cases if status of the message is 'received unread', status in</p>	



@CMGR - Read Message Improved		SELINT 1
	the storage changes to 'received read'.	
	Note: an error result code is sent on empty record <index>.	
AT@CMGR=?	Test command has no effect; the answer is OK	
Reference	GSM 27.005	

3.5.5.4. Message Sending And Writing

3.5.5.4.1. Send Message - +CMGS

+CMGS - Send Message		SELINT 0 / 1
<i>(PDU Mode)</i> AT+CMGS= <length>	<p style="text-align: center;">(PDU Mode)</p> <p>Execution command sends to the network a message.</p> <p>Parameter: <length> - length of the PDU to be sent in bytes (excluding the SMSC address octets). 7..164</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt: <CR><LF><greater_than><space> (IRA 13, 10, 62, 32)</p> <p>and waits for the specified number of bytes.</p> <p>Note: the DCD signal shall be in ON state while PDU is given.</p> <p>Note: the echoing of given characters back from the TA is controlled by echo command E</p>	



+CMGS - Send Message	SELINT 0 / 1
	<p>Note: the PDU shall be hexadecimal format (each octet of the PDU is given as two IRA character long hexadecimal number) and given in one line.</p> <p>Note: when the length octet of the SMSC address (given in the PDU) equals zero, the SMSC address set with command +CSCA is used; in this case the SMSC Type-of-Address octet shall not be present in the PDU.</p> <p>To send the message issue Ctrl-Z char (0x1A hex). To exit without sending the message issue ESC char (0x1B hex).</p> <p>If message is successfully sent to the network, then the result is sent in the format:</p> <p>+CMGS: <mr></p> <p>where <mr> - message reference number.</p> <p>Note: if message sending fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, which may take several seconds, no other SIM interacting commands are issued.</p>
<p><i>(Text Mode)</i> AT+CMGS=<da> [,<toda>]</p>	<p style="text-align: center;">(Text Mode)</p> <p>Execution command sends to the network a message.</p> <p>Parameters: <da> - destination address, string type. <toda> - type of destination address 129 - number in national format 145 - number in international format (contains the "+")</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt:</p> <p><CR><LF><greater_than><space> (IRA 13, 10, 62, 32)</p> <p>After this prompt text can be entered; the entered text should be formatted as follows:</p> <p>- if current <dcs> (see +CSMP) indicates that GSM03.38 default alphabet is</p>



+CMGS - Send Message	SELINT 0 / 1
	<p>used and current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set, then ME/TA converts the entered text into GSM alphabet, according to GSM 27.005, Annex A; backspace can be used to delete last character and carriage returns can be used.</p> <p>- if current <dcs> (see +CSMP) indicates that 8-bit or UCS2 data coding scheme is used or current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set, the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. the 'asterisk' will be entered as 2A (IRA50 and IRA65) and this will be converted to an octet with integer value 0x2A)</p> <p>Note: the DCD signal shall be in ON state while text is entered.</p> <p>Note: the echoing of entered characters back from the TA is controlled by echo command E</p> <p>To send the message issue Ctrl-Z char (0x1A hex). To exit without sending the message issue ESC char (0x1B hex).</p> <p>If message is successfully sent to the network, then the result is sent in the format:</p> <p>+CMGS: <mr> where <mr> - message reference number.</p> <p>Note: if message sending fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, which may take several seconds, no other SIM interacting commands are issued.</p> <p>Note: it is possible to send a concatenation of at most 10 SMs; the maximum number of chars depends on the <dcs>: 1530 chars if 3GPP TS 23.038 default alphabet is used, 1340 chars if 8-bit is used, 670 chars if UCS2 is used</p>
Note	To avoid malfunctions is suggested to wait for the +CMGS: <mr> or +CMS ERROR: <err> response before issuing further commands.
Reference	GSM 27.005

+CMGS - Send Message	SELINT 2
-----------------------------	-----------------



+CMGS - Send Message		SELINT 2
<p><i>Note: the behaviour of command +CMGS differs depending on whether or not the improved SMS commands operation mode has been enabled (see #SMSMODE)</i></p>		
<p>[#SMSMODE=0]</p>		
<p># S M S M O D E = 0</p> <p># S M S M O D E = 0</p> <p># S M S M O D E = 0</p>	<p><i>(PDU Mode)</i></p> <p>AT+CMGS= <length></p>	<p style="text-align: center;">(PDU Mode)</p> <p>Execution command sends to the network a message.</p> <p>Parameter: <length> - length of the PDU to be sent in bytes (excluding the SMSC address octets). 7..164</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt: <CR><LF><greater_than><space> (IRA 13, 10, 62, 32)</p> <p>and waits for the specified number of bytes.</p> <p>Note: the DCD signal shall be in ON state while PDU is given.</p> <p>Note: the echoing of given characters back from the TA is controlled by echo command E</p> <p>Note: the PDU shall be hexadecimal format (each octet of the PDU is given as two IRA character long hexadecimal number) and given in one line.</p> <p>Note: when the length octet of the SMSC address (given in the PDU) equals zero, the SMSC address set with command +CSCA is used; in this case the SMSC Type-of-Address octet shall not be present in the PDU.</p> <p>To send the message issue Ctrl-Z char (0x1A hex). To exit without sending the message issue ESC char (0x1B hex).</p> <p>If message is successfully sent to the network, then the result is sent in the format:</p> <p>+CMGS: <mr></p>



+CMGS - Send Message		SELINT 2
# S M S M O D E = 0		<p>where <mr> - message reference number; 3GPP TS 23.040 TP-Message-Reference in integer format.</p> <p>Note: if message sending fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, which may take several seconds, no other SIM interacting commands are issued.</p>
# S M S M O D E = 0	<p><i>(Text Mode)</i> AT+CMGS=<da> [,<toda>]</p>	<p style="text-align: center;">(Text Mode)</p> <p>Execution command sends to the network a message.</p> <p>Parameters: <da> - destination address, string type represented in the currently selected character set (see +CSCS). <toda> - type of destination address 129 - number in national format 145 - number in international format (contains the "+")</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt: <CR><LF><greater_than><space> (IRA 13, 10, 62, 32)</p> <p>After this prompt text can be entered; the entered text should be formatted as follows:</p> <ul style="list-style-type: none"> - if current <dcs> (see +CSMP) indicates that GSM03.38 default alphabet is used and current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set, then ME/TA converts the entered text into GSM alphabet, according to GSM 27.005, Annex A; backspace can be used to delete last character and carriage returns can be used. - if current <dcs> (see +CSMP) indicates that 8-bit or UCS2 data coding scheme is used or current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set, the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. the 'asterisk' will be entered as 2A (IRA50 and IRA65) and this will be converted to an octet with integer value 0x2A)
# S M S M O D E = 0		



+CMGS - Send Message		SELINT 2
# S M S M O D E = 0		<p>Note: the DCD signal shall be in ON state while text is entered.</p> <p>Note: the echoing of entered characters back from the TA is controlled by echo command E</p> <p>To send the message issue Ctrl-Z char (0x1A hex). To exit without sending the message issue ESC char (0x1B hex).</p> <p>If message is successfully sent to the network, then the result is sent in the format:</p> <p>+CMGS: <mr></p> <p>where <mr> - message reference number; 3GPP TS 23.040 TP-Message-Reference in integer format.</p> <p>Note: if message sending fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, which may take several seconds, no other SIM interacting commands are issued.</p> <p>Note: it is possible to send a concatenation of at most 10 SMs; the maximum number of chars depends on the <dcs>: 1530 chars if 3GPP TS 23.038 default alphabet is used, 1340 chars if 8-bit is used, 670 chars if UCS2 is used.</p>
	AT+CMGS=?	Test command returns the OK result code.
	Note	To avoid malfunctions is suggested to wait for the +CMGS: <mr> or +CMS ERROR: <err> response before issuing further commands.
	Reference	GSM 27.005
#SMSMODE=1		
# S M S M O D E	<i>(PDU Mode)</i> AT+CMGS= <length>	(PDU Mode) Execution command sends to the network a message. Parameter: <length> - length of the PDU to be sent in bytes (excluding the SMSC address octets). 7..164



+CMGS - Send Message		SELINT 2
1 # S M S M O D E = 1 # S M S M O D E = 1 # S M S M O D E = 1	[,<tda>]	<p>Parameters:</p> <p><da> - destination address, string type represented in the currently selected character set (see +CSCS).</p> <p><tda> - type of destination address 129 - number in national format 145 - number in international format (contains the "+")</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt:</p> <p><CR><LF><greater_than><space> (IRA 13, 10, 62, 32)</p> <p>After this prompt text can be entered; the entered text should be formatted as follows:</p> <ul style="list-style-type: none"> - if current <dcs> (see +CSMP) indicates that GSM03.38 default alphabet is used and current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set, then ME/TA converts the entered text into GSM alphabet, according to GSM 27.005, Annex A; backspace can be used to delete last character and carriage returns can be used; after every <CR> entered by the user the sequence <CR><LF><greater_than><space> is sent to the TE. - if current <dcs> (see +CSMP) indicates that 8-bit or UCS2 data coding scheme is used or current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set, the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. the 'asterisk' will be entered as 2A (IRA50 and IRA65) and this will be converted to an octet with integer value 0x2A) <p>Note: the DCD signal shall be in ON state while text is entered.</p> <p>Note: the echoing of entered characters back from the TA is controlled by echo command E</p> <p>To send the message issue Ctrl-Z char (0x1A hex). To exit without sending the message issue ESC char (0x1B hex).</p> <p>If message is successfully sent to the network, then the result is sent in the format:</p>



+CMGS - Send Message		SELINT 2
# S M S M O D E = 1		<p>+CMGS: <mr></p> <p>where <mr> - message reference number; 3GPP TS 23.040 TP-Message-Reference in integer format.</p> <p>Note: if message sending fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, which may take several seconds, no other SIM interacting commands are issued.</p> <p>Note: it is possible to send a concatenation of at most 10 SMs; the maximum number of chars depends on the <dcs>: 1520 chars if 3GPP TS 23.038 default alphabet is used, 1330 chars if 8-bit is used, 660 chars if UCS2 is used. If entered text is longer than this maximum value an error is raised</p>
	AT+CMGS=?	Test command returns the OK result code.
	Note	To avoid malfunctions is suggested to wait for the +CMGS: <mr> or +CMS ERROR: <err> response before issuing further commands.
	Reference	GSM 27.005

3.5.5.4.2. Send Message From Storage - +CMSS

+CMSS - Send Message From Storage		SELINT 0 / 1
AT+CMSS= <index>[,<da> [,<toda>]]		<p>Execution command sends to the network a message which is already stored in the <memw> storage (see +CPMS) at the location <index>.</p> <p>Parameters:</p> <p><index> - location value in the message storage <memw> of the message to send</p> <p><da> - destination address, string type represented in the currently selected character set (see +CSCS); if it is given it shall be used instead of the one stored with the message.</p> <p><toda> - type of destination address 129 - number in national format 145 - number in international format (contains the "+")</p> <p>If message is successfully sent to the network then the result is sent in the</p>



+CMSS - Send Message From Storage		SELINT 0 / 1
	<p>format:</p> <p>+CMSS: <mr> where: <mr> - message reference number.</p> <p>If message sending fails for some reason, an error code is reported:</p> <p>+CMS ERROR:<err></p> <p>Note: to store a message in the <memw> storage see command +CMGW.</p> <p>Note: care must be taken to ensure that during the command execution, which may take several seconds, no other SIM interacting commands are issued.</p>	
Note	To avoid malfunctions is suggested to wait for the +CMSS: <mr> or +CMS ERROR: <err> response before issuing further commands.	
Reference	GSM 27.005	

+CMSS - Send Message From Storage		SELINT 2
<p>AT+CMSS= <index>[,<da> [,<toda>]]</p>	<p>Execution command sends to the network a message which is already stored in the <memw> storage (see +CPMS) at the location <index>.</p> <p>Parameters:</p> <p><index> - location value in the message storage <memw> of the message to send</p> <p><da> - destination address, string type represented in the currently selected character set (see +CSCS); if it is given it shall be used instead of the one stored with the message.</p> <p><toda> - type of destination address 129 - number in national format 145 - number in international format (contains the "+")</p> <p>If message is successfully sent to the network then the result is sent in the format:</p> <p>+CMSS: <mr> where: <mr> - message reference number.</p> <p>If message sending fails for some reason, an error code is reported:</p>	



+CMSS - Send Message From Storage		SELINT 2
	+CMS ERROR:<err> Note: to store a message in the <memw> storage see command +CMGW . Note: care must be taken to ensure that during the command execution, which may take several seconds, no other SIM interacting commands are issued.	
AT+CMSS=?	Test command returns the OK result code.	
Note	To avoid malfunctions is suggested to wait for the +CMSS: <mr> or +CMS ERROR: <err> response before issuing further commands.	
Reference	GSM 27.005	

3.5.5.4.3. Write Message To Memory - +CMGW

+CMGW - Write Message To Memory		SELINT 0 / 1
<i>(PDU Mode)</i> AT+CMGW= <length> [,<stat>]	(PDU Mode) Execution command writes in the <memw> memory storage a new message. Parameter: <length> - length in bytes of the PDU to be written. 7..164 <stat> - message status. 0 - new message 1 - read message 2 - stored message not yet sent (default) 3 - stored message already sent The device responds to the command with the prompt '>' and waits for the specified number of bytes. To write the message issue Ctrl-Z char (0x1A hex).	



+CMGW - Write Message To Memory	SELINT 0 / 1
	<p>To exit without writing the message issue ESC char (0x1B hex).</p> <p>If message is successfully written in the memory, then the result is sent in the format:</p> <p>+CMGW: <index> where: <index> - message location index in the memory <memw>.</p> <p>If message storing fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, no other SIM interacting commands are issued.</p>
<p><i>(Text Mode)</i> AT+CMGW[=<da>[,<todo>[,<stat>]]]</p>	<p style="text-align: center;">(Text Mode)</p> <p>Execution command writes in the <memw> memory storage a new message.</p> <p>Parameters:</p> <p><da> - destination address, string type represented in the currently selected character set (see +CSCS).</p> <p><todo> - type of destination address. 129 - number in national format 145 - number in international format (contains the "+")</p> <p><stat> - message status. "REC UNREAD" - new received message unread "REC READ" - received message read "STO UNSENT" - message stored not yet sent (default) "STO SENT" - message stored already sent</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt:</p> <p><CR><LF><greater_than><space> (IRA 13, 10, 62, 32)</p> <p>After this prompt text can be entered; the entered text should be formatted as follows:</p> <p>- if current <dcs> (see +CSMP) indicates that GSM03.38 default alphabet is used and current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set, then ME/TA converts the entered text into GSM alphabet, according to GSM 27.005, Annex A; backspace can be used to delete last character and carriage returns can be used.</p>



+CMGW - Write Message To Memory		SELINT 0 / 1
	<p>- if current <dcs> (see +CSMP) indicates that 8-bit or UCS2 data coding scheme is used or current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set, the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. the 'asterisk' will be entered as 2A (IRA50 and IRA65) and this will be converted to an octet with integer value 0x2A)</p> <p>Note: the DCD signal shall be in ON state while text is entered.</p> <p>Note: the echoing of entered characters back from the TA is controlled by echo command E</p> <p>To write the message issue Ctrl-Z char (0x1A hex). To exit without writing the message issue ESC char (0x1B hex).</p> <p>If message is successfully written in the memory, then the result is sent in the format:</p> <p>+CMGW: <index> where: <index> - message location index in the memory <memw>.</p> <p>If message storing fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, no other SIM interacting commands are issued.</p> <p>Note: it is possible to save a concatenation of at most 10 SMS; the maximum number of chars depends on the <dcs>: 1530 chars if 3GPP TS 23.038 default alphabet is used, 1340 chars if 8-bit is used, 670 chars if UCS2 is used</p>	
Reference	GSM 27.005	
Note	To avoid malfunctions is suggested to wait for the +CMGW: <index> or +CMS ERROR: <err> response before issuing further commands.	

+CMGW - Write Message To Memory		SELINT 2
<p><i>Note: the behaviour of command +CMGW differs depending on whether or not the improved SMS commands operation mode has been enabled (see #SMSMODE).</i></p>		
(#SMSMODE=0)		
#	<i>(PDU Mode)</i>	<i>(PDU Mode)</i>



+CMGW - Write Message To Memory		SELINT 2
S M S M O D E = 0 # S M S M O D E = 0 # S M S M O D E = 0 # S M	AT+CMGW= <length> [,<stat>]	<p>Execution command writes in the <memw> memory storage a new message.</p> <p>Parameter: <length> - length in bytes of the PDU to be written. 7..164 <stat> - message status. 0 - new message 1 - read message 2 - stored message not yet sent (default) 3 - stored message already sent</p> <p>The device responds to the command with the prompt '>' and waits for the specified number of bytes.</p> <p>To write the message issue Ctrl-Z char (0x1A hex). To exit without writing the message issue ESC char (0x1B hex).</p> <p>If message is successfully written in the memory, then the result is sent in the format:</p> <p>+CMGW: <index></p> <p>where: <index> - message location index in the memory <memw>.</p> <p>If message storing fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, no other SIM interacting commands are issued.</p>
# S M	<i>(Text Mode)</i> AT+CMGW[=<da> [,<toda> [,<stat>]]]	<p style="text-align: center;">(Text Mode)</p> <p>Execution command writes in the <memw> memory storage a new message.</p> <p>Parameters: <da> - destination address, string type represented in the currently selected character set (see +CSCS). <toda> - type of destination address. 129 - number in national format 145 - number in international format (contains the "+")</p>



+CMGW - Write Message To Memory		SELINT 2
S M O D E = 0		<p><stat> - message status. "REC UNREAD" - new received message unread "REC READ" - received message read "STO UNSENT" - message stored not yet sent (default) "STO SENT" - message stored already sent</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt:</p> <p><CR><LF><greater_than><space> (IRA 13, 10, 62, 32)</p> <p>After this prompt text can be entered; the entered text should be formatted as follows:</p> <ul style="list-style-type: none"> - if current <dcs> (see +CSMP) indicates that GSM03.38 default alphabet is used and current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set, then ME/TA converts the entered text into GSM alphabet, according to GSM 27.005, Annex A; backspace can be used to delete last character and carriage returns can be used. - if current <dcs> (see +CSMP) indicates that 8-bit or UCS2 data coding scheme is used or current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set, the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. the 'asterisk' will be entered as 2A (IRA50 and IRA65) and this will be converted to an octet with integer value 0x2A) <p>Note: the DCD signal shall be in ON state while text is entered.</p> <p>Note: the echoing of entered characters back from the TA is controlled by echo command E</p> <p>To write the message issue Ctrl-Z char (0x1A hex).</p> <p>To exit without writing the message issue ESC char (0x1B hex).</p> <p>If message is successfully written in the memory, then the result is sent in the format:</p> <p>+CMGW: <index> where:</p>
# S M S M O D E = 0		
# S M S M O		



+CMGW - Write Message To Memory		SELINT 2
D E = 0		<p><index> - message location index in the memory <memw>.</p> <p>If message storing fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, no other SIM interacting commands are issued.</p> <p>Note: it is possible to save a concatenation of at most 10 SMS; the maximum number of chars depends on the <dcs>: 1530 chars if 3GPP TS 23.038 default alphabet is used, 1340 chars if 8-bit is used, 670 chars if UCS2 is used.</p>
	AT+CMGW=?	Test command returns the OK result code.
	Reference	GSM 27.005
	Note	To avoid malfunctions is suggested to wait for the +CMGW: <index> or +CMS ERROR: <err> response before issuing further commands.
#SMSMODE=1		
# S M S M O D E = 1	(PDU Mode) AT+CMGW= <length> [,<stat>]	<p style="text-align: center;">(PDU Mode)</p> <p>Execution command writes in the <memw> memory storage a new message.</p> <p>Parameter:</p> <p><length> - length in bytes of the PDU to be written. 7..164</p> <p><stat> - message status.</p> <p>0 - new message (received unread message; default for DELIVER messages (3GPP TS 23.040 SMS-DELIVER messages))</p> <p>1 - read message</p> <p>2 - stored message not yet sent (default for SUBMIT messages(3GPP TS 23.040 SMS-SUBMIT messages))</p> <p>3 - stored message already sent</p> <p>The device responds to the command with the prompt '>' and waits for the specified number of bytes.</p> <p>To write the message issue Ctrl-Z char (0x1A hex). To exit without writing the message issue ESC char (0x1B hex).</p> <p>If message is successfully written in the memory, then the result is sent in the format:</p>
# S M S M O D E = 1		



+CMGW - Write Message To Memory		SELINT 2
# S M S M O D E = 1		<p>+CMGW: <index></p> <p>where: <index> - message location index in the memory <memw>.</p> <p>If message storing fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, no other SIM interacting commands are issued.</p> <p>Note: in PDU mode, not only SUBMIT messages can be stored in SIM as per #SMSMODE=0, but also DELIVER and STATUS REPORT messages (3GPP TS 23.040 SMS-STATUS-REPORT messages). SUBMIT messages can only be stored with status 2 or 3; DELIVER and STATUS REPORT messages can only be stored with status 0 or 1.</p>
# S M S M O D E = 1	<p><i>(Text Mode)</i> AT+CMGW[=<da> [,<tda> [,<stat>]]]</p>	<p style="text-align: center;">(Text Mode)</p> <p>Execution command writes in the <memw> memory storage a new message.</p> <p>Parameters: <da> - destination address, string type represented in the currently selected character set (see +CSCS). <tda> - type of destination address. 129 - number in national format 145 - number in international format (contains the "+") <stat> - message status. "REC UNREAD" - new received message unread (default for DELIVER messages) "REC READ" - received message read "STO UNSENT" - message stored not yet sent (default for SUBMIT messages) "STO SENT" - message stored already sent</p> <p>After command line is terminated with <CR>, the device responds sending a four character sequence prompt:</p> <p><CR><LF><greater_than><space> (IRA 13, 10, 62, 32)</p> <p>After this prompt text can be entered; the entered text should be formatted as follows:</p>
# S M S M O D E = 1		



+CMGW - Write Message To Memory		SELINT 2
# S M S M O D E = 1 # S M S M O D E = 1	<p>- if current <dcs> (see +CSMP) indicates that GSM03.38 default alphabet is used and current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set, then ME/TA converts the entered text into GSM alphabet, according to GSM 27.005, Annex A; backspace can be used to delete last character and carriage returns can be used; after every <CR> entered by the user the sequence <CR><LF><greater_than><space> is sent to the TE.</p> <p>- if current <dcs> (see +CSMP) indicates that 8-bit or UCS2 data coding scheme is used or current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set, the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. the 'asterisk' will be entered as 2A (IRA50 and IRA65) and this will be converted to an octet with integer value 0x2A)</p> <p>Note: the DCD signal shall be in ON state while text is entered.</p> <p>Note: the echoing of entered characters back from the TA is controlled by echo command E</p> <p>To write the message issue Ctrl-Z char (0x1A hex).</p> <p>To exit without writing the message issue ESC char (0x1B hex).</p> <p>If message is successfully written in the memory, then the result is sent in the format:</p> <p>+CMGW: <index> where: <index> - message location index in the memory <memw>.</p> <p>If message storing fails for some reason, an error code is reported.</p> <p>Note: care must be taken to ensure that during the command execution, no other SIM interacting commands are issued.</p> <p>Note: it is possible to save a concatenation of at most 10 SMs; the maximum number of chars depends on the <dcs>: 1530 chars if 3GPP TS 23.038 default alphabet is used, 1340 chars if 8-bit is used, 670 chars if UCS2 is used. If entered text is longer than this maximum</p>	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

+CMGD - Delete Message		SELINT 0 / 1
	<p>mobile originated messages, leaving unread messages untouched 4 - delete all messages from <memr> storage.</p> <p>Note: if <delflag> is present and not set to 0 then <index> is ignored and ME shall follow the rules for <delflag> shown above.</p> <p>Note: if the location to be deleted is empty, an error message is reported.</p>	
AT+CMGD=?	<p>Test command shows the valid memory locations and optionally the supported values of <delflag>.</p> <p>+CMGD: (list of supported <index>s)[,(list of supported <delflag>s)]</p>	
Example	<p>AT+CMGD=? +CMGD: (1,2,3,6,7,17,18,19,20,37,38,39,47),(0-4) OK</p>	
Reference	GSM 27.005	

+CMGD - Delete Message		SELINT 2
<p><i>Note: the behaviour of command +CMGD differs depending on whether or not the improved SMS commands operation mode has been enabled (see #SMSMODE).</i></p>		
(#SMSMODE=0)		
<p># S M S M O D E = 0</p> <p># S M S M O D</p>	<p>AT+CMGD= <index> [,<delflag>]</p>	<p>Execution command deletes from memory <memr> the message(s).</p> <p>Parameter:</p> <p><index> - message index in the selected storage <memr> that can have values form 1 to N, where N depends on the available space (see +CPMS)</p> <p><delflag> - an integer indicating multiple message deletion request.</p> <p>0 (or omitted) - delete message specified in <index></p> <p>1 - delete all read messages from <memr> storage, leaving unread messages and stored mobile originated messages (whether sent or not) untouched</p> <p>2 - delete all read messages from <memr> storage and sent mobile originated messages, leaving unread messages and unsent mobile originated messages untouched</p> <p>3 - delete all read messages from <memr> storage, sent and unsent mobile originated messages, leaving unread messages untouched</p> <p>4 - delete all messages from <memr> storage.</p> <p>Note: if <delflag> is present and not set to 0 then, if <index> is greater than 0, <index> is ignored and ME shall follow the rules for <delflag></p>



+CMGD - Delete Message		SELINT 2
E = 0		shown above. Note: if the location to be deleted is empty, an error message is reported.
	AT+CMGD=?	Test command shows the valid memory locations and optionally the supported values of <delflag> . +CMGD: (supported <index>s list)[,(supported <delflag>s list)]
	Example	AT+CMGD=? +CMGD: (1,2,3,6,7,17,18,19,20,37,38,39,47) ,(0-4) OK
	Reference	GSM 27.005
[#SMSMODE=1]		
# S M S M O D E = 1	AT+CMGD= <index> [,<delflag>]	Execution command deletes from memory <memr> the message(s). Parameter: <index> - message index in the selected storage <memr> that can have values form 1 to N, where N depends on the available space (see +CPMS) <delflag> - an integer indicating multiple message deletion request. 0 (or omitted) - delete message specified in <index> 1 - delete all read messages from <memr> storage, leaving unread messages and stored mobile originated messages (whether sent or not) untouched 2 - delete all read messages from <memr> storage and sent mobile originated messages, leaving unread messages and unsent mobile originated messages untouched 3 - delete all read messages from <memr> storage, sent and unsent mobile originated messages, leaving unread messages untouched 4 - delete all messages from <memr> storage. Note: if <delflag> is present and not set to 0 then, if <index> is greater than 0, <index> is ignored and ME shall follow the rules for <delflag> shown above.
# S M S M O D E = 1	AT+CMGD=?	Test command shows the valid memory locations and optionally the supported values of <delflag> . +CMGD: (supported <index>s list)[,(supported <delflag>s list)]
	Example	AT+CMGD=? +CMGD: (1,2,3,6,7,17,18,19,20,37,38,39,47) ,(0-4)



+CMGD - Delete Message		SELINT 2
		OK
Reference		GSM 27.005

3.5.5.4.5. Select service for MO SMS messages - +CGSMS

+CGSMS - Select service for MO SMS messages		SELINT 2
AT+CGSMS= [<service>]	<p>The set command is used to specify the service or service preference that the MT will use to send MO SMS messages.</p> <p><service>: a numeric parameter which indicates the service or service preference to be used</p> <p>0 - GPRS 1 - circuit switched (default) 2 - GPRS preferred (use circuit switched if GPRS not available) 3 - circuit switched preferred (use GPRS if circuit switched not available)</p> <p>Note: the <service> value is saved on NVM as global parameter</p>	
AT+CGSMS?	<p>The read command returns the currently selected service or service preference in the form:</p> <p>+CGSMS: <service></p>	
AT+CGSMS=?	<p>Test command reports the supported list of currently available <service>s.</p>	



FAX Class 1 AT Commands

3.5.5.5. General Configuration

3.5.5.5.1. Manufacturer ID - +FMI

+FMI - Manufacturer ID		SELINT 0
AT+FMI?	Read command reports the manufacturer ID. The output depends on the choice made through #SELINT command.	
Example	AT+FMI? Telit_Mobile_Terminals OK	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

+FMI - Manufacturer ID		SELINT 1 / 2
AT+FMI?	Read command reports the manufacturer ID. The output depends on the choice made through #SELINT command.	
Example	AT+FMI? Telit OK	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.5.5.2. Model ID - +FMM

+FMM - Model ID		SELINT 0 / 1 / 2
AT+FMM?	Read command reports the model ID	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.5.5.3. Revision ID - +FMR

+FMR - Revision ID		SELINT 0 / 1 / 2
AT+FMR?	Read command reports the software revision ID	
Reference	ITU T.31 and TIA/EIA-578-A specifications	



3.5.5.6. Transmission/Reception Control

3.5.5.6.1. Stop Transmission And Pause - +FTS

+FTS - Stop Transmission And Pause		SELINT 0 / 1 / 2
AT+FTS=<time>	<p>Execution command causes the modem to terminate a transmission and wait for <time> 10ms intervals before responding with OK result.</p> <p>Parameter: <time> - duration of the pause, expressed in 10ms intervals. 0..255</p>	
AT+FTS=?	<p>Test command returns all supported values of the parameter <time>.</p> <p>Note: test command result is without command echo</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.5.6.2. Wait For Receive Silence - +FRS

+FRS - Wait For Receive Silence		SELINT 0 / 1 / 2
AT+FRS=<time>	<p>Execution command causes the modem to listen and report OK when silence has been detected for the specified period of time. This command will terminate when the required silence period is detected or when the DTE sends another character other than XON or XOFF.</p> <p>Parameter: <time> - amount of time, expressed in 10ms intervals. ..0..255</p>	
AT+FRS=?	<p>Test command returns all supported values of the parameter <time>.</p> <p>Note: test command result is without command echo.</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	



3.5.5.6.3. Transmit Data Modulation - +FTM

+FTM - Transmit Data Modulation		SELINT 0 / 1
AT+FTM=<mod>	<p>Execution command causes the module to transmit facsimile data using the modulation defined by the parameter <mod>.</p> <p>Parameter: <mod> - carrier modulation 24 - V27ter/2400 bps 48 - V27ter/4800 bps 72 - V29/7200 bps 96 - V29/9600 bps</p>	
AT+FTM=?	<p>Test command returns all supported values of the parameter <mod>.</p> <p>Note: the output is not bracketed and without command echo.</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

+FTM - Transmit Data		SELINT 2
AT+FTM=<mod>	<p>Execution command causes the module to transmit facsimile data using the modulation defined by the parameter <mod>.</p> <p>Parameter: <mod> - carrier modulation 24 - V27ter/2400 bps 48 - V27ter/4800 bps 72 - V29/7200 bps 96 - V29/9600 bps</p>	
AT+FTM=?	<p>Test command returns all supported values of the parameter <mod>.</p> <p>Note: test command result is without command echo.</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	



3.5.5.6.4. Receive Data Modulation - +FRM

+FRM - Receive Data Modulation		SELINT 0 / 1
AT+FRM=<mod>	<p>Execution command causes the module to receive facsimile data using the modulation defined by the parameter <mod>.</p> <p>Parameter: <mod> - carrier modulation 24 - V27ter/2400 bps 48 - V27ter/4800 bps 72 - V29/7200 bps 96 - V29/9600 bps</p>	
AT+FRM=?	<p>Test command returns all supported values of the parameter <mod>.</p> <p>Note: the output is not bracketed and without command echo.</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

+FRM - Receive Data Modulation		SELINT 2
AT+FRM=<mod>	<p>Execution command causes the module to receive facsimile data using the modulation defined by the parameter <mod>.</p> <p>Parameter: <mod> - carrier modulation 24 - V27ter/2400 bps 48 - V27ter/4800 bps 72 - V29/7200 bps 96 - V29/9600 bps</p>	
AT+FRM=?	<p>Test command returns all supported values of the parameter <mod>.</p> <p>Note: test command result is without command echo.</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.5.6.5. Transmit Data With HDLC Framing - +FTH

+FTH - Transmit Data With HDLC Framing		SELINT 0 / 1 / 2
AT+FTH=<mod>	<p>Execution command causes the module to transmit facsimile data using HDLC protocol and the modulation defined by the parameter <mod>.</p> <p>Parameter: <mod> - carrier modulation 3 - V21/300 bps</p>	
AT+FTH=?	<p>Test command returns all supported values of the parameter <mod>.</p>	



+FTH - Transmit Data With HDLC Framing		SELINT 0 / 1 / 2
	Note: test command result is without command echo.	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.5.6.6. Receive Data With HDLC Framing - +FRH

+FRH - Receive Data With HDLC Framing		SELINT 0 / 1 / 2
AT+FRH=<mod>	<p>Execution command causes the module to receive facsimile data using HDLC protocol and the modulation defined by the parameter <mod>.</p> <p>Parameter: <mod> - carrier modulation 3 - V21/300 bps</p>	
AT+FRH=?	<p>Test command returns all supported values of the parameter <mod>.</p> <p>Note: test command result is without command echo.</p>	
Reference	ITU T.31 and TIA/EIA-578-A specifications	



+FPR - Select Serial Port Rate		SELINT 0 / 1 / 2
	Note: test command result is without command echo.	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.5.7.3. Double Escape Character Replacement - +FDD

+FDD - Double Escape Character Replacement Control		SELINT 0 / 1 / 2
AT+FDD=<mode>	Set command concerns the use of the <DLE><SUB> pair to encode consecutive escape characters (<10h><10h>) in user data. Parameter <mode> 0 - currently the only available value. The DCE decode of <DLE><SUB> is either <DLE><DLE> or discard. The DCE encode of <10h><10h> is <DLE><DLE><DLE><DLE>	
AT+FDD?	Read command returns the current value of parameter <mode>	
AT+FDD=?	Test command returns all supported values of parameter <mode>. Note: test command result is without command echo.	
Reference	ITU T.31 and TIA/EIA-578-A specifications	

3.5.6. Custom AT Commands

3.5.6.1. General Configuration AT Commands

3.5.6.1.1. Network Selection Menu Availability - +PACSP

+PACSP - Network Selection Menu Availability		SELINT 2
AT+PACSP?	Read command returns the current value of the <mode> parameter in the format: +PACSP<mode> where: <mode> - PLMN mode bit (in CSP file on the SIM) 0 - restriction of menu option for manual PLMN selection. 1 - no restriction of menu option for Manual PLMN selection.	
AT+PACSP=?	Test command returns the OK result code.	
Note	The command is available only if the ENS functionality has been previously enabled (see #ENS)	



3.5.6.1.2. Manufacturer Identification - #CGMI

#CGMI - Manufacturer Identification		SELINT 0 / 1
AT#CGMI	Execution command returns the device manufacturer identification code with command echo. The output depends on the choice made through #SELINT command.	
AT#CGMI?	Read command has the same effect as the Execution command	

#CGMI - Manufacturer Identification		SELINT 2
AT#CGMI	Execution command returns the device manufacturer identification code with command echo. The output depends on the choice made through #SELINT command.	
AT#CGMI=?	Test command returns the OK result code.	

3.5.6.1.3. Model Identification - #CGMM

#CGMM - Model Identification		SELINT 0 / 1
AT#CGMM	Execution command returns the device model identification code with command echo.	
AT#CGMM?	Read command has the same effect as the Execution command	

#CGMM - Model Identification		SELINT 2
AT#CGMM	Execution command returns the device model identification code with command echo.	
AT#CGMM=?	Test command returns the OK result code.	

3.5.6.1.4. Revision Identification - #CGMR

#CGMR - Revision Identification		SELINT 0 / 1
AT#CGMR	Execution command returns device software revision number with command echo.	
AT#CGMR?	Read command has the same effect as the Execution command	

#CGMR - Revision Identification		SELINT 2
AT#CGMR	Execution command returns device software revision number with command echo.	
AT#CGMR=?	Test command returns the OK result code.	

3.5.6.1.5. Product Serial Number Identification - #CGSN

#CGSN - Product Serial Number Identification		SELINT 0 / 1
--	--	--------------



#CGSN - Product Serial Number Identification		SELINT 0 / 1
AT#CGSN	Execution command returns the product serial number, identified as the IMEI of the mobile, with command echo.	
AT#CGSN?	Read command has the same effect as the Execution command	

#CGSN - Product Serial Number Identification		SELINT 2
AT#CGSN	Execution command returns the product serial number, identified as the IME of the mobile, with command echo.	
AT#CGSN=?	Test command returns the OK result code.	

3.5.6.1.6. International Mobile Subscriber Identity (IMSI) - #CIMI

#CIMI - International Mobile Subscriber Identity (IMSI)		SELINT 0 / 1
AT#CIMI	Execution command returns the international mobile subscriber identity, identified as the IMSI number, with command echo.	
AT#CIMI?	Read command has the same effect as the Execution command	

#CIMI - International Mobile Subscriber Identity (IMSI)		SELINT 2
AT#CIMI	Execution command returns the international mobile subscriber identity, identified as the IMSI number, with command echo.	
AT#CIMI=?	Test command returns the OK result code.	

3.5.6.1.7. Read ICCID (Integrated Circuit Card Identification) - #CCID

#CCID - Read ICCID		SELINT 2
AT#CCID	Execution command reads on SIM the ICCID (card identification number that provides a unique identification number for the SIM)	
AT#CCID=?	Test command returns the OK result code.	

3.5.6.1.8. Service Provider Name - #SPN

#SPN - Service Provider Name		SELINT 2
AT#SPN	<p>Execution command returns the service provider string contained in the SIM field SPN, in the format:</p> <p>#SPN: <spn></p> <p>where:</p> <p><spn> - service provider string contained in the SIM field SPN, represented in the currently selected character set (see +CSCS).</p> <p>Note: if the SIM field SPN is empty, the command returns just the OK result</p>	



#SPN - Service Provider Name	SELINT 2
	code.
AT#SPN=?	Test command returns the OK result code.

3.5.6.1.9. Extended Numeric Error report - #CEER

#CEER - Extended numeric error report	SELINT 2																																		
AT#CEER	<p>Execution command causes the TA to return a numeric code in the format</p> <p>#CEER: <code></p> <p>which should offer the user of the TA a report of the reason for</p> <ul style="list-style-type: none"> • the failure in the last unsuccessful call setup (originating or answering); • the last call release; • the last unsuccessful GPRS attach or unsuccessful PDP context activation; • the last GPRS detach or PDP context deactivation. <p>Note: if none of the previous conditions has occurred since power up then 0 is reported (i.e. No error, see below)</p> <p><code> values as follows</p> <table border="1"> <thead> <tr> <th>Value</th> <th>Diagnostic</th> </tr> </thead> <tbody> <tr><td>0</td><td>No error</td></tr> <tr><td>1</td><td>Unassigned (unallocated) number</td></tr> <tr><td>3</td><td>No route to destination</td></tr> <tr><td>6</td><td>Channel unacceptable</td></tr> <tr><td>8</td><td>Operator determined barring</td></tr> <tr><td>16</td><td>Normal call clearing</td></tr> <tr><td>17</td><td>User busy</td></tr> <tr><td>18</td><td>No user responding</td></tr> <tr><td>19</td><td>User alerting, no answer</td></tr> <tr><td>21</td><td>Call rejected</td></tr> <tr><td>22</td><td>Number changed</td></tr> <tr><td>26</td><td>Non selected user clearing</td></tr> <tr><td>27</td><td>Destination out of order</td></tr> <tr><td>28</td><td>Invalid number format (incomplete number)</td></tr> <tr><td>29</td><td>Facility rejected</td></tr> <tr><td>30</td><td>Response to STATUS ENQUIRY</td></tr> </tbody> </table>	Value	Diagnostic	0	No error	1	Unassigned (unallocated) number	3	No route to destination	6	Channel unacceptable	8	Operator determined barring	16	Normal call clearing	17	User busy	18	No user responding	19	User alerting, no answer	21	Call rejected	22	Number changed	26	Non selected user clearing	27	Destination out of order	28	Invalid number format (incomplete number)	29	Facility rejected	30	Response to STATUS ENQUIRY
Value	Diagnostic																																		
0	No error																																		
1	Unassigned (unallocated) number																																		
3	No route to destination																																		
6	Channel unacceptable																																		
8	Operator determined barring																																		
16	Normal call clearing																																		
17	User busy																																		
18	No user responding																																		
19	User alerting, no answer																																		
21	Call rejected																																		
22	Number changed																																		
26	Non selected user clearing																																		
27	Destination out of order																																		
28	Invalid number format (incomplete number)																																		
29	Facility rejected																																		
30	Response to STATUS ENQUIRY																																		



#CEER – Extended numeric error report		SELINT 2
31	Normal, unspecified	
34	No circuit/channel available	
38	Network out of order	
41	Temporary failure	
42	Switching equipment congestion	
43	Access information discarded	
44	Requested circuit/channel not available	
47	Resources unavailable, unspecified	
49	Quality of service unavailable	
50	Requested facility not subscribed	
55	Incoming calls barred with in the CUG	
57	Bearer capability not authorized	
58	Bearer capability not presently available	
63	Service or option not available, unspecified	
65	Bearer service not implemented	
68	ACM equal to or greater than ACMmax	
69	Requested facility not implemented	
70	Only restricted digital information bearer capability is available	
79	Service or option not implemented, unspecified	
81	Invalid transaction identifier value	
87	User not member of CUG	
88	Incompatible destination	
91	Invalid transit network selection	
95	Semantically incorrect message	
96	Invalid mandatory information	
97	Message type non-existent or not implemented	
98	Message type not compatible with protocol state	
99	Information element non-existent or not implemented	
100	Conditional IE error	
101	Message not compatible with protocol state	
102	Recovery on timer expiry	
111	Protocol error, unspecified	
127	Interworking, unspecified	
GPRS related errors		
224	MS requested detach	
225	NWK requested detach	
226	Unsuccessful attach cause NO SERVICE	
227	Unsuccessful attach cause NO ACCESS	
228	Unsuccessful attach cause GPRS SERVICE REFUSED	



#CEER – Extended numeric error report		SELINT 2
229	PDP deactivation requested by NWK	
230	PDP deactivation cause LLC link activation Failed	
231	PDP deactivation cause NWK reactivation with same TI	
232	PDP deactivation cause GMM abort	
233	PDP deactivation cause LLC or SNDCP failure	
234	PDP unsuccessful activation cause GMM error	
235	PDP unsuccessful activation cause NWK reject	
236	PDP unsuccessful activation cause NO NSAPI available	
237	PDP unsuccessful activation cause SM refuse	
238	PDP unsuccessful activation cause MMI ignore	
239	PDP unsuccessful activation cause Nb Max Session Reach	
256	PDP unsuccessful activation cause wrong APN	
257	PDP unsuccessful activation cause unknown PDP address or type	
258	PDP unsuccessful activation cause service not supported	
259	PDP unsuccessful activation cause QOS not accepted	
260	PDP unsuccessful activation cause socket error	
<i>Other custom values</i>		
240	FDN is active and number is not in FDN	
241	Call operation not allowed	
252	Call barring on outgoing calls	
253	Call barring on incoming calls	
254	Call impossible	
255	Lower layer failure	
AT#CEER=?	Test command returns OK result code.	
Reference	GSM 04.08	

3.5.6.1.10. Extended error report for Network Reject cause - #CEERNET

#CEERNET – Ext error report for Network reject cause	SELINT 2
AT#CEERNET	<p>Execution command causes the TA to return a numeric code in the format</p> <p>#CEERNET: <code></p> <p>which should offer the user of the TA a report for the last mobility management(MM) or session management(SM) procedure not accepted by the network and a report of detach or deactivation causes from network.</p>



#CEERNET – Ext error report for Network reject cause		SELINT 2
	<code> values as follows	
Value	Diagnostic	
2	IMSI UNKNOWN IN HLR	
3	ILLEGAL MS	
4	IMSI UNKNOWN IN VISITOR LR	
5	IMEI NOT ACCEPTED	
6	ILLEGAL ME	
7	GPRS NOT ALLOWED	
8	GPRS AND NON GPRS NOT ALLOWED	
9	MS IDENTITY CANNOT BE DERIVED BY NETWORK	
10	IMPLICITLY DETACHED	
11	PLMN NOT ALLOWED	
12	LA NOT ALLOWED	
13	ROAMING NOT ALLOWED	
14	GPRS NOT ALLOWED IN THIS PLMN	
15	NO SUITABLE CELLS IN LA	
16	MSC TEMP NOT REACHABLE	
17	NETWORK FAILURE	
22	CONGESTION	
25	LLC OR SNDTCP FAILURE	
26	INSUFFICIENT RESOURCES	
27	MISSING OR UNKNOWN APN	
28	UNKNOWN PDP ADDRESS OR PDP TYPE	
29	USER AUTHENTICATION FAILED	
30	ACTIVATION REJECTED BY GGSN	
31	ACTIVATION REJECTED UNSPECIFIED	
32	SERVICE OPTION NOT SUPPORTED	
33	REQ. SERVICE OPTION NOT SUBSCRIBED	
34	SERV.OPTION TEMPORARILY OUT OF ORDER	
35	NSAPI ALREADY USED	
36	REGULAR DEACTIVATION	
37	QOS NOT ACCEPTED	
38	SMN NETWORK FAILURE	
39	REACTIVATION REQUIRED	
40	FEATURE NOT SUPPORTED	
41	SEM ERROR IN TPF	
42	SYNT ERROR IN TPF	
43	UNKNOWN PDP CNTXT	
44	SEM ERR IN PKT FILTER	
45	SYNT ERR IN PKT FILTER	
46	PDP CNTXT WITHOUT TPF ACT	
48	RETRY ON NEW CELL ENTRY	
81	INVALID TRANSACTION IDENTIFIER	
95	SEMANTICALLY INCORRECT MESSAGE	
96	INVALID MANDATORY INFORMATION	
97	MSG TYPE NON EXISTENT OR NOT IMPLEMENTED	
98	MSG TYPE NOT COMPATIBLE WITH PROTOCOL STATE	



#CEERNET – Ext error report for Network reject cause		SELINT 2
	99	IE NON_EXISTENT OR NOT IMPLEMENTED
	100	CONDITIONAL IE ERROR
	101	MSG NOT COMPATIBLE WITH PROTOCOL STATE
	111	PROTOCOL ERROR UNSPECIFIED
	Note: causes 15, 41 to 46 are not considered for R98 products(GSM 04.08).	
AT#CEERNET=?	Test command returns OK result code.	
Reference	GSM 24.008 for REL4 and GSM 04.08 for R98	

3.5.6.1.11. Change Audio Path - #CAP

#CAP - Change Audio Path	SELINT 0 / 1
AT#CAP[=<n>]	<p>Set command switches the active audio path depending on parameter <n></p> <p>Parameter: <n> - audio path 0 - audio path follows the AXE input (factory default):</p> <ul style="list-style-type: none"> • if AXE is low, handsfree is enabled; • if AXE is high, internal path is enabled <p>1 - enables handsfree external mic/ear audio path 2 - enables internal mic/ear audio path</p> <p>Note: The audio path are mutually exclusive, enabling one disables the other.</p> <p>Note: when changing the audio path, the volume level is set at the previously stored value for that audio path (see +CLVL).</p> <p>Note: issuing AT#CAP<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#CAP=<CR> is the same as issuing the command AT#CAP=0<CR>.</p>
AT#CAP?	<p>Read command reports the active audio path in the format:</p> <p>#CAP: <n>.</p>
AT#CAP=?	Test command reports the supported values for the parameter <n>.

#CAP - Change Audio Path	SELINT2
AT#CAP=<n>	Set command switches the active audio path depending on parameter <n>



#CAP - Change Audio Path	SELINT2
	<p>Parameter: <n> - audio path 0 - audio path follows the AXE input (factory default): <ul style="list-style-type: none"> • if AXE is low, handsfree is enabled; • if AXE is high, internal path is enabled 1 - enables handsfree external mic/ear audio path 2 - enables internal mic/ear audio path</p> <p>Note: The audio path are mutually exclusive, enabling one disables the other.</p> <p>Note: when changing the audio path, the volume level is set at the previously stored value for that audio path (see +CLVL).</p>
AT#CAP?	<p>Read command reports the active audio path in the format:</p> <p>#CAP: <n>.</p>
AT#CAP=?	<p>Test command reports the supported values for the parameter <n>.</p>

3.5.6.1.12. Select Ringer Sound - #SRS

#SRS - Select Ringer Sound	SELINT 0 / 1
<p>AT#SRS[= <n>,<tout>]</p>	<p>Set command sets the ringer sound.</p> <p>Parameters: <n> - ringing tone 0 - current ringing tone 1..<i>max</i> - ringing tone number, where <i>max</i> can be read by issuing the Test command AT#SRS=?. <tout> - ringing tone playing time-out in seconds. 0 - ringer is stopped (if present) and current ringer sound is set. 1..60 - ringer sound playing for <tout> seconds and, if <n> > 0, ringer sound <n> is set as default ringer sound.</p> <p>Note: when the command is issued with <n> > 0 and <tout> > 0, the <n> ringing tone is played for <tout> seconds and stored as default ringing tone.</p> <p>Note: if command is issued with <n> > 0 and <tout> = 0, the playing of the ringing is stopped (if present) and <n> ringing tone is set as current.</p>



#SRS - Select Ringer Sound	SELINT 0 / 1
	<p>Note: if command is issued with <n> = 0 and <tout> > 0 then the current ringing tone is played.</p> <p>Note: if both <n> and <tout> are 0 then the default ringing tone is set as current and ringing is stopped.</p> <p>Note: If all parameters are omitted then the behaviour of Set command is the same as Read command</p>
AT#SRS?	<p>Read command reports current selected ringing and its status in the form:</p> <p>#SRS: <n>,<status></p> <p>where:</p> <p><n> - ringing tone number 1..<i>max</i></p> <p><status> - ringing status 0 - selected but not playing 1 - currently playing</p>
AT#SRS=?	<p>Test command reports the supported values for the parameters <n> and <tout></p>

#SRS - Select Ringer Sound	SELINT 2
AT#SRS= [<n>,<tout>]	<p>Set command sets the ringer sound.</p> <p>Parameters:</p> <p><n> - ringing tone 0 - current ringing tone 1..<i>max</i> - ringing tone number, where <i>max</i> can be read by issuing the Test command AT#SRS=?.</p> <p><tout> - ringing tone playing timer in units of seconds. 0 - ringer is stopped (if present) and current ringer sound is set. 1..60 - ringer sound playing for <tout> seconds and, if <n> > 0, ringer sound <n> is set as default ringer sound.</p> <p>Note: when the command is issued with <n> > 0 and <tout> > 0, the <n> ringing tone is played for <tout> seconds and stored as default ringing tone.</p> <p>Note: if command is issued with <n> > 0 and <tout> = 0, the playing of the ringing is stopped (if present) and <n> ringing tone is set as current.</p> <p>Note: if command is issued with <n> = 0 and <tout> > 0 then the current</p>



#SRS - Select Ringer Sound	SELINT 2
	<p>ringing tone is played for <tout> seconds.</p> <p>Note: if both <n> and <tout> are 0 then the default ringing tone is set as current and ringing is stopped.</p> <p>Note: If all parameters are omitted then the behaviour of Set command is the same as Read command</p>
AT#SRS?	<p>Read command reports current selected ringing and its status in the form:</p> <p>#SRS: <n>,<status></p> <p>where:</p> <p><n> - ringing tone number 1..<i>max</i></p> <p><status> - ringing status 0 - selected but not playing 1 - currently playing</p>
AT#SRS=?	<p>Test command reports the supported values for the parameters <n> and <tout></p>

3.5.6.1.13. Select Ringer Path - #SRP

#SRP - Select Ringer Path	SELINT 0 / 1
AT#SRP[=[<n>]]	<p>Set command selects the ringer path towards whom sending ringer sounds and all signalling tones.</p> <p>Parameter:</p> <p><n> - ringer path number 0 - sound output towards current selected audio path (see command #CAP) 1 - sound output towards handsfree 2 - sound output towards handset 3 - sound output towards Buzzer Output pin GPIO7</p> <p>Note: In order to use the Buzzer Output an external circuitry must be added to drive it properly from the GPIO7 pin, furthermore the GPIO7 pin direction must be set to Buzzer output (Alternate function); see command #GPIO.</p>



#SRP - Select Ringer Path		SELINT 0 / 1
	<p>Note: issuing AT#SRP<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#SRP=<CR> is the same as issuing the command AT#SRP=0<CR>.</p>	
AT#SRP?	<p>Read command reports the selected ringer path in the format:</p> <p>#SRP: <n>.</p>	
AT#SRP=?	<p>Test command reports the supported values for the parameter <n>.</p>	
Example	<pre>AT#SRP=? #SRP: (0-3) OK AT#SRP=3 OK</pre>	

#SRP - Select Ringer Path		SELINT 2
AT#SRP=<n>	<p>Set command selects the ringer path towards whom sending ringer sounds and all signalling tones.</p> <p>Parameter: <n> - ringer path number 0 - sound output towards current selected audio path (see command #CAP) 1 - sound output towards handsfree 2 - sound output towards handset 3 - sound output towards Buzzer Output pin GPIO7</p> <p>Note: In order to use the Buzzer Output an external circuitry must be added to drive it properly from the GPIO7 pin, furthermore the GPIO7 pin direction must be set to Buzzer output (Alternate function); see command #GPIO.</p>	
AT#SRP?	<p>Read command reports the selected ringer path in the format:</p> <p>#SRP: <n>.</p>	
AT#SRP=?	<p>Test command reports the supported values for the parameter <n>.</p>	
Example	<pre>AT#SRP=? #SRP: (0-3) OK AT#SRP=3 OK</pre>	

3.5.6.1.14. Signaling Tones Mode - #STM



#TONEEXT – Extended tone generation		SELINT 2
<toneld>,<act>	<p>tone, standard busy tone and a set of user defined tones for a infinite time, or stop the running tone</p> <p>Parameters:</p> <p>< toneld > - ASCII characters in the set (0-9), #,*,(A-D),(G-L),Y,Z ;</p> <ul style="list-style-type: none"> - (0-9), #,*,(A-D) : DTMF tone - (G-L) : User Defined Tones²². - y : free tone - z: busy tone <p>< act > - Action to be performed.</p> <ul style="list-style-type: none"> - 0: Stop the <toneld> if running. - 1: Start the <toneld>. 	
AT#TONEEXT=?	Test command returns the range of supported values for parameter <toneld>,<act>.	

3.5.6.1.20. Tone Classes Volume - #TSVOL

#TSVOL – Tone Classes Volume		SELINT 2
AT#TSVOL= <class>, <mode> [,<volume>]	<p>Set command is used to select the volume mode for one or more tone classes.</p> <p>Parameters:</p> <p><class> -sum of integers each representing a class of tones which the command refers to</p> <ul style="list-style-type: none"> 1 - GSM tones 2 - ringer tones 4 - alarm tones 8 - signalling tones 16 - DTMF tones 32 - SIM Toolkit tones 64 - user defined tones 128 – Dial tones 255 - all classes <p><mode> - it indicates which volume is used for the classes of tones represented by <class></p> <ul style="list-style-type: none"> 0 - default volume is used 1 - the volume <volume> is used 	

²² See also AT#UDTSET, AT#UDTRST and AT#UDTSAV command description following in this document.



#TSVOL – Tone Classes Volume	SELINT 2
	<p><volume> - volume to be applied to the set of classes of tones represented by <class>; it is mandatory if <mode> is 1. 0..<i>max</i> - the value of <i>max</i> can be read issuing the Test command AT#TSVOL=?</p> <p>Note: The class DTMF Tones (<class>=16) refers only to the volume for locally generated DTMF tones. It doesn't affect the level of the DTMF generated by the network as result of AT+VTS command</p>
AT#TSVOL?	<p>Read command returns for each class of tones the last setting of <mode> and, if <mode> is not 0, of <volume> too, in the format:</p> <pre>#TSVOL: 1,<mode1>[,<volume1>]<CR><LF> ... #TSVOL:128,<mode128>[,<volume128>]</pre>
AT#TSVOL=?	<p>Test command returns the supported range of values of parameters <class>, <mode> and <volume>.</p>
Example	<pre>AT#TSVOL=64,1,5 OK AT#TSVOL? #TSVOL:1,0 #TSVOL:2,0 #TSVOL:4,1,5 #TSVOL:8,0 #TSVOL:16,1,5 #TSVOL:32,0 #TSVOL:64,1,5 #TSVOL:128,0 OK</pre>
Note:	<p>GSM Tones: BusyTonelId CongestionTonelId RadioPathTonelId CallWaitingTonelId</p> <p>Ringer Tone: RingingToneMOId RingingToneMTId AutoRedialConnTonelId</p> <p>Alarm Tones:</p>



#TSVOL – Tone Classes Volume	SELINT 2
	<p>AlarmToneld BatteryLowToneld SMSToneld MMSToneld PowerOnToneld PowerOffToneld NoUnitsLeftToneld</p> <p>Signaling Tones: classzeroToneld NetworkIndToneld NoServiceToneld SignallingErrToneld AutoRedialToneld ErrorToneld CallDroppedToneld</p> <p>DTMF Tones Local ADTMF</p> <p>SIM Toolkit Tones SIMTDialToneld SIMTBusyToneld SIMTCongestionToneld SIMTRadioPathToneld SIMTCallDroppedToneld SIMTErrorToneld SIMTCallWaitingToneld SIMTRingingToneMTId</p> <p>User Defined Tones: Tone defined with AT#UDTSET</p> <p>Dial tones: DialToneld</p>

3.5.6.1.21. Select Registration Operation Mode - #REGMODE

#REGMODE – Select Registration Operation Mode	SELINT 2
AT#REGMODE= <mode>	<p>There are situations in which the presentation of the URCs controlled by either +CREG and +CGREG are slightly different from ETSI specifications. We identified this behaviour and decided to maintain it as default for backward compatibility issues, while we're offering a more formal 'Enhanced Operation Mode' through #REGMODE.</p>



#PLMNMODE - PLMN List Selection		SELINT 0 / 1 / 2
AT#PLMNMODE= [<plmnlst>]	<p>Set command selects the list of PLMN names to be used currently</p> <p>Parameter: <plmnlst> - list of PLMN names 0 - PLMN names list, currently used in commands like +COPS or #MONI, is fixed and depends upon currently selected interface (see #SELINT) (default for all products, except GE865-QUAD and GE864-DUAL V2) 1 - PLMN names list is not fixed and can be updated in newer software versions (default for GE865-QUAD and GE864-DUAL V2)</p> <p>Note: <plmnlst> parameter is saved in NVM</p>	
AT#PLMNMODE?	<p>Read command reports whether the currently used list of PLMN names is fixed or not, in the format:</p> <p>#PLMNMODE: <plmnlst> (<plmnlst> described above)</p>	
AT#PLMNMODE=?	<p>Test command returns the supported range of values for parameter <plmnlst>.</p>	

3.5.6.1.24. Display PIN Counter - #PCT

#PCT - Display PIN Counter		SELINT 0 / 1
AT#PCT	<p>Execution command reports the PIN/PUK or PIN2/PUK2 input remaining attempts, depending on +CPIN requested password in the format:</p> <p>#PCT: <n> where: <n> - remaining attempts 0 - the SIM is blocked. 1..3 - if the device is waiting either SIM PIN or SIM PIN2 to be given. 1..10 - if the device is waiting either SIM PUK or SIM PUK2 to be given.</p>	
AT#PCT?	<p>Read command has the same behaviour as Execution command.</p>	

#PCT - Display PIN Counter		SELINT 2
AT#PCT	<p>Execution command reports the PIN/PUK or PIN2/PUK2 input remaining attempts, depending on +CPIN requested password in the format:</p> <p>#PCT: <n> where: <n> - remaining attempts</p>	



3.5.6.1.27. Periodic Reset - #ENHRST

#ENHRST – Periodic ReSeT	SELINT 2
AT#ENHRST=<mod>[,<delay>]	<p>Set command enables/disables the unit reset after <delay> minutes.</p> <p>Parameters:</p> <p><mod></p> <ul style="list-style-type: none"> 0 – disables the unit reset (factory default) 1 – enables the unit reset only for one time 2 – enables the periodic unit reset <p><delay> - time interval after that the unit reboots; numeric value in minutes</p> <p>Note: the settings are saved automatically in NVM only if old or new mod is 2. Any change from 0 to 1 or from 1 to 0 is not stored in NVM</p>
AT#ENHRST?	<p>Read command reports the current parameter settings for #ENHRST command in the format:</p> <p>#ENHRST: < mod >[,<delay>,<remainTime>]</p> <p><remainTime> - time remaining before next reset</p>
AT#ENHRST=?	<p>Test command reports supported range of values for parameters <mod> and <delay>.</p>
Examples	<p>AT#ENHRST=1,60</p> <p>... Module reboots after 60 minutes ...</p> <p>AT#ENHRST=1,0</p> <p>... Module reboots now ...</p> <p>AT#ENHRST=2,60</p> <p>... Module reboots after 60 minutes and indefinitely after every following power on ...</p>

3.5.6.1.28. Wake From Alarm Mode - #WAKE

#WAKE - Wake From Alarm Mode	SELINT 0 / 1
------------------------------	--------------



#WAKE - Wake From Alarm Mode		SELINT 0 / 1
AT#WAKE[= <opmode>]	<p>Execution command stops any eventually present alarm activity and, if the module is in alarm mode, it exits the alarm mode and enters the normal operating mode.</p> <p>Parameter: <opmode> - operating mode; any input is possible: no control is made on the <opmode> value, although it is mandatory to have it; the module exits the alarm mode, enters the normal operating mode, any alarm activity is stopped (e.g. alarm tone playing) and an OK result code is returned.</p> <p>Note: if parameter is omitted, the command returns the operating status of the device in the format:</p> <p>#WAKE: <status></p> <p>where: <status> 0 - normal operating mode 1 - alarm mode or normal operating mode with some alarm activity.</p> <p>Note: the alarm mode is indicated by status ON of hardware pin CTS and by status ON of pin DSR, the power saving status is indicated by a CTS - OFF and DSR - OFF status; the normal operating status is indicated by DSR - ON.</p> <p>Note: during the alarm mode the device will not make any network scan and will not register to any network and therefore is not able to dial or receive any call or SM, the only commands that can be issued to the MODULE in this state are the #WAKE and #SHDN, every other command must not be issued during this state.</p>	
AT#WAKE?	Read command has the same effect as Execution command when parameter is omitted.	
AT#WAKE=?	Test command returns OK result code.	

#WAKE - Wake From Alarm Mode		SELINT 2
AT#WAKE= [<opmode>]	<p>Execution command stops any eventually present alarm activity and, if the module is in alarm mode, it exits the alarm mode and enters the normal operating mode.</p> <p>Parameter: <opmode> - operating mode</p>	



#QTEMP - Query Temperature Overflow		SELINT 0 / 1
	1 - the device temperature is out of the <i>working range</i> Note: typical <i>temperature working range</i> is (-10°C..+55°C); anyway you are strongly recommended to consult the "Hardware User Guide" to verify the real temperature working range of your module	
#QTEMP=?	Test command reports supported range of values for parameter <mode>.	
Note	The device should not be operated out of its <i>temperature working range</i> ; if temperature is out of range proper functioning of the device is not ensured.	

#QTEMP - Query Temperature Overflow		SELINT 2
AT#QTEMP=[<mode>]	Set command has currently no effect. The interpretation of parameter <mode> is currently not implemented: any value assigned to it will simply have no effect.	
AT#QTEMP?	Read command queries the device internal temperature sensor for over temperature and reports the result in the format: #QTEMP: <temp> where <temp> - over temperature indicator 0 - the device temperature is in the <i>working range</i> 1 - the device temperature is out of the <i>working range</i> Note: typical <i>temperature working range</i> is (-10°C..+55°C); anyway you are strongly recommended to consult the "Hardware User Guide" to verify the real temperature working range of your module	
#QTEMP=?	Test command reports supported range of values for parameter <mode>.	
Note	The device should not be operated out of its <i>temperature working range</i> , elsewhere proper functioning of the device is not ensured.	

3.5.6.1.30. Temperature Monitor - #TEMPMON

#TEMPMON - Temperature Monitor		SELINT 2
AT#TEMPMON= <mod> [,<urcmode> [,<action> [,<hyst_time>	Set command sets the behaviour of the module internal temperature monitor. Parameters: <mod>	



<p>[,<GPIO>]]]]</p>	<p>0 - sets the command parameters. 1 - triggers the measurement of the module internal temperature, reporting the result in the format:</p> <p>#TEMPMEAS: <level>,<value></p> <p>where: <level> - threshold level -2 - extreme temperature lower bound (see Note) -1 - operating temperature lower bound (see Note) 0 - normal temperature 1 - operating temperature upper bound (see Note) 2 - extreme temperature upper bound (see Note)</p> <p><value> - actual temperature expressed in Celsius degrees.</p> <p><i>Setting of the following optional parameters has meaning only if <mod>=0</i></p> <p><urcmode> - URC presentation mode. 0 - it disables the presentation of the temperature monitor URC 1 - it enables the presentation of the temperature monitor URC, whenever the module internal temperature reaches either operating or extreme levels; the unsolicited message is in the format:</p> <p>#TEMPMEAS: <level>,<value></p> <p>where: <level> and <value> are as before</p> <p><action> - sum of integers, each representing an action to be done whenever the module internal temperature reaches either operating or extreme levels (default is 0). If <action> is not zero, it is mandatory to set the <hyst_time> parameter too.</p> <p>0..7 - as a sum of: 0 - no action 1 - automatic shut-down when the temperature is beyond the extreme bounds 2 - RF TX circuits automatically disabled (using +CFUN=2) when operating temperature bounds are reached. When the temperature is back to normal the module is brought back to the previous state, before RF TX disabled. 4 - the output pin <GPIO> is tied HIGH when operating temperature</p>
---------------------------	---



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p>bounds are reached; when the temperature is back to normal the output pin <GPIO> is tied LOW. If this <action> is required, it is mandatory to set the <GPIO> parameter too.</p> <p><hyst_time> - hysteresis time: all the actions happen only if the extreme or operating bounds are maintained at least for this period. This parameter is needed and required if <action> is not zero. 0..255 - time in seconds</p> <p><GPIO> - GPIO number. valid range is "any output pin" (see "Hardware User's Guide"). This parameter is needed and required only if <action>=4 is required.</p> <p>Note: the URC presentation mode <urcmode> is related to the current AT instance only (see +cmux); last <urcmode> settings are saved for every instance as extended profile parameters, thus it is possible to restore them either if the multiplexer control channel is released and set up, back and forth.</p> <p>Note: last <action>, <hyst_time> and <GPIO> settings are saved in NVM too, but they are not related to the current CMUX instance only (see +cmux).</p>										
AT#TEMPMON?	<p>Read command reports the current parameter settings for #TEMPMON command in the format:</p> <p>#TEMPMON: <urcmode>,<action>[,<hyst_time>[,<GPIO>]]</p>										
AT#TEMPMON=?	<p>Test command reports the supported range of values for parameters <mod>, <urcmode>, <action>, <hyst_time> and <GPIO></p>										
Note	<p>In the following table typical temperature bounds are represented; anyway you are strongly recommended to consult the "Hardware User Guide" to verify the real temperature bounds for your module.</p> <table border="1" data-bbox="491 1576 1326 1850"> <tr> <td>Extreme Temperature Lower Bound^(*)</td> <td>T_{ext_low}</td> </tr> <tr> <td>Operating Temperature Lower Bound^(*)</td> <td>T_{op_low}</td> </tr> <tr> <td>Operating Temperature</td> <td></td> </tr> <tr> <td>Operating Temperature Upper Bound^(*)</td> <td>T_{op_up}</td> </tr> <tr> <td>Extreme Temperature Upper Bound^(*)</td> <td>T_{ext_up}</td> </tr> </table>	Extreme Temperature Lower Bound ^(*)	T _{ext_low}	Operating Temperature Lower Bound ^(*)	T _{op_low}	Operating Temperature		Operating Temperature Upper Bound ^(*)	T _{op_up}	Extreme Temperature Upper Bound ^(*)	T _{ext_up}
Extreme Temperature Lower Bound ^(*)	T _{ext_low}										
Operating Temperature Lower Bound ^(*)	T _{op_low}										
Operating Temperature											
Operating Temperature Upper Bound ^(*)	T _{op_up}										
Extreme Temperature Upper Bound ^(*)	T _{ext_up}										



#E2SMSRI - SMS Ring Indicator		SELINT 0 / 1
	Note: issuing AT#E2SMSRI=<CR> returns the OK result code.	
AT#E2SMSRI?	Read command reports the duration in ms of the pulse generated on receipt of an incoming SM, in the format: #E2SMSRI: <n> Note: as seen before, the value <n>=0 means that the RI pin response to an incoming SM is disabled.	
AT#E2SMSRI=?	Reports the range of supported values for parameter <n>	

#E2SMSRI - SMS Ring Indicator		SELINT 2
AT#E2SMSRI= [<n>]	Set command enables/disables the Ring Indicator pin response to an incoming SMS message. If enabled, a negative going pulse is generated on receipt of an incoming SMS message. The duration of this pulse is determined by the value of <n> . Parameter: <n> - RI enabling 0 - disables RI pin response for incoming SMS messages (factory default) 50..1150 - enables RI pin response for incoming SMS messages. The value of <n> is the duration in ms of the pulse generated on receipt of an incoming SM. Note: if +CNMI=3,1 command is issued and the module is in a GPRS connection, a 100 ms break signal is sent and a 1 sec. pulse is generated on RI pin, no matter if the RI pin response is either enabled or not.	
AT#E2SMSRI?	Read command reports the duration in ms of the pulse generated on receipt of an incoming SM, in the format: #E2SMSRI: <n> Note: as seen before, the value <n>=0 means that the RI pin response to an incoming SM is disabled.	
AT#E2SMSRI=?	Reports the range of supported values for parameter <n>	

3.5.6.1.38. Analog/Digital Converter Input - #ADC

#ADC - Analog/Digital Converter Input		SELINT 0 / 1
AT#ADC[= <adc>,<mode>	Execution command reads pin<adc> voltage, converted by ADC, and outputs it in the format:	



#ADC - Analog/Digital Converter Input	SELINT 0 / 1
[,<dir>]]	<p>#ADC: <value></p> <p>where: <value> - pin<adc> voltage, expressed in mV</p> <p>Parameters: <adc> - index of pin For the number of available ADCs see HW User Guide</p> <p><mode> - required action 2 - query ADC value <dir> - direction; its interpretation is currently not implemented 0 - no effect.</p> <p>If all parameters are omitted the command reports all pins voltage, converted by ADC, in the format:</p> <p>#ADC: <value>[<CR><LF>#ADC: <value>[...]]</p> <p>Note: The command returns the last valid measure.</p>
AT#ADC?	Read command has the same effect as Execution command when all parameters are omitted.
AT#ADC=?	Test command reports the supported range of values of the command parameters <adc> , <mode> and <dir> .

#ADC - Read Analog/Digital Converter input	SELINT 2
AT#ADC= [<adc>,<mode> [,<dir>]]	<p>Execution command reads pin<adc> voltage, converted by ADC, and outputs it in the format:</p> <p>#ADC: <value></p> <p>where: <value> - pin<adc> voltage, expressed in mV</p> <p>Parameters: <adc> - index of pin For the number of available ADCs see HW User Guide</p> <p><mode> - required action 2 - query ADC value <dir> - direction; its interpretation is currently not implemented</p>



#ADC - Read Analog/Digital Converter input	SELINT 2
	0 - no effect. Note: The command returns the last valid measure.
AT#ADC?	Read command reports all pins voltage, converted by ADC, in the format: #ADC: <value>[<CR><LF>#ADC: <value>[...]]
AT#ADC=?	Test command reports the supported range of values of the command parameters <adc>, <mode> and <dir>.

3.5.6.1.39. Digital/Analog Converter Control - #DAC

#DAC - Digital/Analog Converter Control	SELINT 0 / 1
AT#DAC[= <enable> [,<value>]]	Set command enables/disables the DAC_OUT pin. Parameters: <enable> - enables/disables DAC output. 0 - disables pin; it is in high impedance status (factory default) 1 - enables pin; the corresponding output is driven <value> - scale factor of the integrated output voltage; it must be present if <enable>=1 0..1023 - 10 bit precision Note: integrated output voltage = MAX_VOLTAGE * value / 1023 Note: if all parameters are omitted then the behaviour of Set command is the same as the Read command.
AT#DAC?	Read command reports whether the DAC_OUT pin is currently enabled or not, along with the integrated output voltage scale factor, in the format: #DAC: <enable>,<value>
AT#DAC=?	Test command reports the range for the parameters <enable> and <value>.
Example	Enable the DAC out and set its integrated output to the 50% of the max value: AT#DAC=1 , 511 OK Disable the DAC out: AT#DAC=0 OK
Note	With this command the DAC frequency is selected internally. D/A converter must not be used during POWERSAVING. DAC_OUT line must be integrated (for example with a low band pass filter)



#DAC - Digital/Analog Converter Control		SELINT 0 / 1
	in order to obtain an analog voltage. For a more in depth description of the integration filter refer to the hardware user guide.	
#DAC - Digital/Analog Converter Control		SELINT 2
AT#DAC= [<enable> [,<value>]]	Set command enables/disables the DAC_OUT pin. Parameters: <enable> - enables/disables DAC output. 0 - disables pin; it is in high impedance status (factory default) 1 - enables pin; the corresponding output is driven <value> - scale factor of the integrated output voltage; it must be present if <enable>=1 0..1023 - 10 bit precision Note: integrated output voltage = MAX_VOLTAGE * value / 1023	
AT#DAC?	Read command reports whether the DAC_OUT pin is currently enabled or not, along with the integrated output voltage scale factor, in the format: #DAC: <enable>,<value>	
AT#DAC=?	Test command reports the range for the parameters <enable> and <value>.	
Example	<i>Enable the DAC out and set its integrated output to the 50% of the max value:</i> AT#DAC=1,511 OK <i>Disable the DAC out:</i> AT#DAC=0 OK	
Note	With this command the DAC frequency is selected internally. D/A converter must not be used during POWERSAVING. DAC_OUT line must be integrated (for example with a low band pass filter) in order to obtain an analog voltage. For a more in depth description of the integration filter refer to the hardware user guide.	

3.5.6.1.40. Auxiliary Voltage Output Control - #VAUX



#VAUX- Auxiliary Voltage Output Control		SELINT 0 / 1
AT#VAUX[=<n>, <stat>]	<p>Set command enables/disables the Auxiliary Voltage pins output.</p> <p>Parameters: <n> - VAUX pin index 1 - there is currently just one VAUX pin <stat> 0 - output off 1 - output on 2 - query current value of VAUX pin</p> <p>Note: when <stat>=2 and command is successful, it returns:</p> <p>#VAUX: <value></p> <p>where: <value> - power output status 0 - output off 1 - output on</p> <p>Note: If all parameters are omitted the command has the same behaviour as Read command.</p> <p>Note: for the GPS product (GE863-GPS): if the Auxiliary Voltage pin output is disabled while GPS is powered on they'll both also be turned off.</p> <p>Note: for the GPS products, at commands \$GPSP, \$GPSPS, \$GPSWK control VAUX and can interfere with AT# command.</p>	
AT#VAUX?	<p>Read command reports whether the Auxiliary Voltage pin output is currently enabled or not, in the format:</p> <p>#VAUX: <value></p>	
AT#VAUX=?	<p>Test command reports the supported range of values for parameters <n>, <stat>.</p>	
NOTE:	<p>Command available only on GE864-QUAD and GC864-QUAD with SW 10.00.xxx</p>	

#VAUX- Auxiliary Voltage Output Control		SELINT 2
AT#VAUX=[<n>,<stat>]	<p>Set command enables/disables the Auxiliary Voltage pins output.</p> <p>Parameters: <n> - VAUX pin index 1 - there is currently just one VAUX pin</p>	



#V24MODE - V24 Output Pins Mode	SELINT 2
<p><mode>, <when></p>	<p>Parameters: <port> - serial port: 0 – ASC0 (AT command port) 1 – ASC1 (trace port) <mode> - AT commands serial port interface hardware pins mode: 0 – Tx and Rx pins are set in push/pull function during power saving. (default) 1 – Tx and Rx pins are set in open drain function during power saving. 2 – Reserved <when> - When the command is applied: 0 – Always (default) 1 – In power saving only</p>
<p>AT#V24MODE?</p>	<p>Read command returns actual functioning <mode> for all ports in the format:</p> <p>#V24MODE: 0,<mode_port0>,<when0>[<CR><LF> #V24MODE: 1,<mode_port1>,<when1> [<CR><LF></p> <p>Where: < mode_port0> - mode of the serial port 0, < mode_port1> - mode of the serial port 1, <when0> - when setting for serial port 0, <when1> - when setting for serial port 1</p>
<p>AT#V24MODE=?</p>	<p>Test command reports supported range of values for parameters <port>, <mode> and <when>.</p>



#V24 - V24 Output Pins Control	SELINT 2
	<p>1 - CTS (Clear To Send) 2 - RI (Ring Indicator) 3 - DSR (Data Set Ready) 4 - DTR (Data Terminal Ready). This is not an output pin: we maintain this value only for backward compatibility, but trying to set its state raises the result code "ERROR" 5 - RTS (Request To Send). This is not an output pin: we maintain this value only for backward compatibility, but trying to set its state raises the result code "ERROR"</p> <p><state> - State of AT commands serial port interface output hardware pins(0, 1, 2, 3) when pin is in GPIO mode (see #V24CFG): 0 - Low 1 - High</p> <p>Note: if <state> is omitted the command returns the actual state of the pin <pin>.</p>
AT#V24?	<p>Read command returns actual state for all the pins (either output and input) in the format:</p> <p>#V24: <pin1>,<state1>[<CR><LF> #V24: <pin2>,<state2>[...]]</p> <p>where <pin<i>n</i>> - AT command serial port interface HW pin <state<i>n</i>> - AT commands serial port interface hardware pin state</p>
AT#V24=?	<p>Test command reports supported range of values for parameters <pin> and <state>.</p>

3.5.6.1.45. AXE Pin Reading - #AXE

#AXE - AXE Pin Reading	SELINT 2
AT#AXE	<p>Execution command causes the ME to return the current state of AXE pin in the format:</p> <p>#AXE: <state></p> <p>where: <state> 0 - Low</p>



#AXE - AXE Pin Reading	SELINT 2
	..1 - High
AT#AXE=?	Test command returns the OK result code.
NOTE:	This command is not available for GE865 modules

3.5.6.1.46. RF Transmission Monitor Mode - #TXMONMODE

#TXMONMODE- RF Transmission Monitor Mode	SELINT 2
AT#TXMONMODE= <mode>	<p>Set TXMON pin behaviour.</p> <p>Parameter: <mode></p> <p>0 - TXMON pin goes high when a call is started and it drops down when the call is ended. It also goes high when a location update starts, and it drops down when the location update procedure stops. Finally it goes high during SMS transmission and receiving. Even if the TXMON in this case is set as GPIO in output, the read command AT#GPIO=5,2 returns #GPIO:2,0, as the GPIO is in alternate mode.</p> <p>1 - TXMON is set in alternate mode and the Timer unit controls its state. TXMON goes high 200µs before TXEN goes high. Then power ramps start raising and there is the burst transmission. Finally TXMON drops down 47µs after power ramps stop falling down. This behaviour is repeated for every transmission burst.</p> <p>Note: if user sets GPIO 5 as input or output the TXMON does not follow the above behaviour.</p> <p>Note: if <mode> is change during a call from 1 to 0, TXMON goes down. If it is restored to 1, TXMON behaves as usual, following the bursts.</p> <p>Note: this command is not supported in GM862 product family.</p>
AT#TXMONMODE?	<p>Read command reports the <mode> parameter set value, in the format:</p> <p>#TXMONMODE: <mode></p>
AT#TXMONMODE=?	Test command reports the supported values for <mode> parameter.

3.5.6.1.47. Battery And Charger Status - #CBC



#CBC- Battery And Charger Status		SELINT 0 / 1
AT#CBC	<p>Execution command returns the current Battery and Charger state in the format:</p> <p>#CBC: <ChargerState>,<BatteryVoltage></p> <p>where:</p> <p><ChargerState> - battery charger state 0 - charger not connected 1 - charger connected and charging 2 - charger connected and charge completed</p> <p><BatteryVoltage> - battery voltage in units of ten millivolts: it is the real battery voltage only if charger is not connected; if the charger is connected this value depends on the charger voltage.</p>	
AT#CBC?	Read command has the same meaning as Execution command.	
AT#CBC=?	Test command returns the OK result code.	

#CBC- Battery And Charger Status		SELINT 2
AT#CBC	<p>Execution command returns the current Battery and Charger state in the format:</p> <p>#CBC: <ChargerState>,<BatteryVoltage></p> <p>where:</p> <p><ChargerState> - battery charger state 0 - charger not connected 1 - charger connected and charging 2 - charger connected and charge completed</p> <p><BatteryVoltage> - battery voltage in units of ten millivolts: it is the real battery voltage only if charger is not connected; if the charger is connected this value depends on the charger voltage.</p>	
AT#CBC=?	Test command returns the OK result code.	

3.5.6.1.48. GPRS Auto-Attach Property - #AUTOATT

#AUTOATT - Auto-Attach Property		SELINT 0 / 1
AT#AUTOATT [=<auto>]	<p>Set command enables/disables the TE GPRS auto-attach property.</p> <p>Parameter:</p> <p><auto> 0 - disables GPRS auto-attach property 1 - enables GPRS auto-attach property (factory default): after the</p>	



#MSCLASS - Multislot Class Control		SELINT 0 / 1
	Note: if all parameters are omitted the behaviour of set command is the same as read command.	
AT#MSCLASS?	Read command reports the current value of the multislot class in the format: #MSCLASS: <class>	
AT#MSCLASS=?	Test command reports the range of available values for parameter <class>.	

#MSCLASS - Multislot Class Control		SELINT 2
AT#MSCLASS= [<class>, <autoattach>]	Set command sets the multislot class Parameters: <class> - multislot class; take care: class 7 is not supported. 1..6 - GPRS class 8..10 - GPRS class <autoattach> 0 - the new multislot class is enabled only at the next detach/attach or after a reboot. 1 - the new multislot class is enabled immediately, automatically forcing a detach / attach procedure.	
AT#MSCLASS?	Read command reports the current value of the multislot class in the format: #MSCLASS: <class>	
AT#MSCLASS=?	Test command reports the range of available values for both parameters <class> and <autoattach>.	

3.5.6.1.50. Cell Monitor - #MONI

#MONI - Cell Monitor		SELINT 0 / 1
AT#MONI[= [<number>]]	#MONI is both a set and an execution command. Set command sets one cell out of seven, in the neighbour list of the serving cell including it, from which we extract GSM-related information. Parameter: <number> 0..6 - it is the ordinal number of a cell, in the neighbour list of the serving	



#MONI - Cell Monitor	SELINT 0 / 1
	<p>cell (default 0, serving cell). 7 - it is a special request to obtain GSM-related informations from the whole set of seven cells in the neighbour list of the serving cell.</p> <p>Note: issuing AT#MONI<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#MONI=<CR> is the same as issuing the command AT#MONI=0<CR>.</p>
<p>AT#MONI?</p>	<p>Execution command reports GSM-related informations for selected cell and dedicated channel (if exists).</p> <p>a)When extracting data for the serving cell and the network name is known the format is: #MONI: <netname> BSIC:<bsic> RxQual:<qual> LAC:<lac> Id:<id> ARFCN:<arfcn> PWR:<dBm> dBm TA: <timadv></p> <p>b)When the network name is unknown, the format is: #MONI: Cc:<cc> Nc:<nc> BSIC:<bsic> RxQual:<qual> LAC:<lac> Id:<id> ARFCN:<arfcn> PWR:<dBm> dBm TA: <timadv></p> <p>c)When extracting data for an adjacent cell, the format is: #MONI: Adj Cell<n> [LAC:<lac> Id:<id>] ARFCN:<arfcn> PWR:<dBm> dBm</p> <p>where: <netname> - name of network operator <cc> - country code <nc> - network operator code <n> - progressive number of adjacent cell <bsic> - base station identification code <qual> - quality of reception 0..7 <lac> - localization area code <id> - cell identifier <arfcn> - assigned radio channel <dBm> - received signal strength in dBm <timadv> - timing advance</p> <p>Note: TA: <timadv> is reported only for the serving cell.</p> <p>1. If the last setting done by #MONI is 7, the execution command</p>



#MONI - Cell Monitor	SELINT 0 / 1
	<p>neighbour list of the serving cell and including it, from which we can extract GSM-related informations, along with the ordinal number of the current selected cell, in the format:</p> <p>#MONI: (<MaxCellNo>,<CellSet>)</p> <p>where:</p> <p><MaxCellNo> - maximum number of cells, in the neighbour list of the serving cell and including it, from which we can extract GSM-related informations. This value is always 7.</p> <p><CellSet> - the last setting done with command #MONI.</p> <p>Note: The serving cell is the current serving cell or the last available serving cell, if the module loses coverage.</p>
Example	<p><i>Set command selects the cell 0</i></p> <pre>at#moni=0 OK</pre> <p><i>Execution command reports GSM-related information for cell 0</i></p> <pre>at#moni #MONI: I WIND BSIC:70 RxQual:0 LAC:55FA Id:1D23 ARFCN:736 PWR:-83dbm TA:1 OK</pre> <p><i>Set command selects the special request to obtain GSM-related information from the whole set of seven cells in the neighbour list of the serving cell</i></p> <pre>at#moni=7 OK</pre> <p><i>Execution command reports the requested information in table-like format</i></p> <pre>at#moni #MONI: Cell BSIC LAC CellId ARFCN Power C1 C2 TA RxQual PLMN #MONI: S 70 55FA 1D23 736 -83dbm 19 33 1 0 I WIND #MONI: N1 75 55FA 1297 983 -78dbm 26 20 #MONI: N2 72 55FA 1289 976 -82dbm 22 16 #MONI: N3 70 55FA 1D15 749 -92dbm 10 18 #MONI: N4 72 55FA 1D0D 751 -92dbm 10 18 #MONI: N5 75 55FA 1296 978 -95dbm 9 3 #MONI: N6 70 55FA 1D77 756 -99dbm 3 11 OK</pre>
Note	<p>The refresh time of the measures is preset to 3 sec.</p> <p>The timing advance value is meaningful only during calls or GPRS transfers active.</p>



#MONI - Cell Monitor	SELINT 0 / 1
Note	The serving cell is the current serving cell or the last available serving cell, if the module loses coverage.

#MONI - Cell Monitor	SELINT 2
AT#MONI=[[<number>]]	<p>#MONI is both a set and an execution command.</p> <p>Set command sets one cell out of seven, in a the neighbour list of the serving cell including it, from which extract GSM-related information.</p> <p>Parameter: <number> 0..6 - it is the ordinal number of the cell, in a the neighbour list of the serving cell (default 0, serving cell). 7 - it is a special request to obtain GSM-related information from the whole set of seven cells in the neighbour list of the serving cell.</p> <p>Execution command (AT#MONI<CR>) reports GSM-related information for selected cell and dedicated channel (if exists).</p> <p>2. If the last setting done by #MONI is in the range [0..6], the output format is as follows:</p> <p>d) When extracting data for the serving cell and the network name is known the format is: #MONI: <netname> BSIC:<bsic> RxQual:<qual> LAC:<lac> Id:<id> ARFCN:<arfcn> PWR:<dBm> dBm TA: <timadv></p> <p>e) When the network name is unknown, the format is: #MONI: Cc:<cc> Nc:<nc> BSIC:<bsic> RxQual:<qual> LAC:<lac> Id:<id> ARFCN:<arfcn> PWR:<dBm> dBm TA: <timadv></p> <p>f) When extracting data for an adjacent cell, the format is: #MONI: Adj Cell<n> [LAC:<lac> Id:<id>] ARFCN:<arfcn> PWR:<dBm> dBm</p> <p>where: <netname> - name of network operator <cc> - country code <nc> - network operator code <n> - progressive number of adjacent cell</p>



#MONI - Cell Monitor	SELINT 2
	<p> <bsic> - base station identification code <qual> - quality of reception 0..7 <lac> - localization area code <id> - cell identifier <arfcn> - assigned radio channel <dBm> - received signal strength in dBm <timadv> - timing advance </p> <p>Note: TA: <timadv> is reported only for the serving cell.</p> <p>3. If the last setting done by #MONI is 7, the execution command produces a table-like formatted output, as follows:</p> <p>a. First row reports the identifying name of the 'columns'</p> <p>#MONI: Cell BSIC LAC CellId ARFCN Power C1 C2 TA RxQual PL MN<CR><LF></p> <p>b. Second row reports a complete set of GSM-related information for the serving cell:</p> <p>#MONI: S: <bsic> <lac> <id> <arfcn> <dBm> <C1value> <C2value> <timadv> <qual> <netname><CR><LF></p> <p>c. 3rd to 8th rows report a reduced set of GSM-related information for the cells in the neighbours:</p> <p>#MONI: N<n> <bsic> <lac> <id> <arfcn> <dBm> <C1value> <C2value> ><CR><LF></p> <p>where: <C1value> - C1 reselection parameter <C2value> - C2 reselection parameter <i>other parameters as before</i></p>
AT#MONI=?	<p>Test command reports the maximum number of cells, in the neighbour list of the serving cell excluding it, from which we can extract GSM-related informations, along with the ordinal number of the current selected cell, in the format:</p> <p>#MONI: (<MaxCellNo>,<CellSet>)</p>



#MONI - Cell Monitor	SELINT 2
	<p>where:</p> <p><MaxCellNo> - maximum number of cells, in the neighbour list of the serving cell and excluding it, from which we can extract GSM-related informations. This value is always 6.</p> <p><CellSet> - the last setting done with command #MONI.</p>
Example	<p><i>Set command selects the cell 0</i></p> <pre>at#moni=0 OK</pre> <p><i>Execution command reports GSM-related information for cell 0</i></p> <pre>at#moni #MONI: I WIND BSIC:70 RxQual:0 LAC:55FA Id:1D23 ARFCN:736 PWR:-83dbm TA:1 OK</pre> <p><i>Set command selects the special request to obtain GSM-related information from the whole set of seven cells in the neighbour list of the serving cell</i></p> <pre>at#moni=7 OK</pre> <p><i>Execution command reports the requested information in table-like format</i></p> <pre>at#moni #MONI: Cell BSIC LAC CellId ARFCN Power C1 C2 TA RxQual PLMN I #MONI: S 70 55FA 1D23 736 -83dbm 19 33 1 0 I WIND #MONI: N1 75 55FA 1297 983 -78dbm 26 20 #MONI: N2 72 55FA 1289 976 -82dbm 22 16 #MONI: N3 70 55FA 1D15 749 -92dbm 10 18 #MONI: N4 72 55FA 1D0D 751 -92dbm 10 18 #MONI: N5 75 55FA 1296 978 -95dbm 9 3 #MONI: N6 70 55FA 1D77 756 -99dbm 3 11 OK</pre>
Note	<p>The refresh time of the measures is preset to 3 sec.</p> <p>The timing advance value is meaningful only during calls or GPRS transfers active.</p>
Note	<p>The serving cell is the current serving cell or the last available serving cell, if the module loses coverage.</p>

3.5.6.1.51. Serving Cell Information - #SERVINFORM

#SERVINFORM - Serving Cell Information	SELINT 0 / 1
AT#SERVINFORM	Execution command reports information about serving cell, in the format:



#SERVINFO - Serving Cell Information	SELINT 2
	<p> <dBM> - received signal strength in dBm <NetNameAsc> - operator name, quoted string type <NetCode> - country code and operator code, hexadecimal representation <BSIC> - Base Station Identification Code <LAC> - Localization Area Code <TA> - Time Advance: it's available only if a GSM or GPRS is running <GPRS> - GPRS supported in the cell 0 - not supported 1 - supported </p> <p>The following information will be present only if GPRS is supported in the cell</p> <p> <PB-ARFCN> - PBCCH ARFCN of the serving cell; it'll be printed only if PBCCH is supported by the cell, otherwise the label "hopping" will be printed <NOM> - Network Operation Mode .."I" "II" .."III" <RAC> - Routing Area Colour Code <PAT> - Priority Access Threshold ..0 ..3..6 </p>

3.5.6.1.52. +COPS Mode - #COPSMODE

#COPSMODE - +COPS Mode	SELINT 0 / 1
<p>AT#COPSMODE [=<mode>]</p>	<p>Set command sets the behaviour of +COPS command (<i>see</i> +COPS).</p> <p>Parameter: <mode> 0 - +COPS behaviour like former GM862 family products (default) 1 - +COPS behaviour compliant with ETSI format</p> <p>Note: The setting is saved in NVM (and available on following reboot).</p> <p>Note: if parameter <mode> is omitted the behaviour of Set command is the same as Read command.</p>



#COPSMODE - +COPS Mode		SELINT 0 / 1
AT#COPSMODE?	<p>Read command returns the current behaviour of +COPS command, in the format:</p> <p>#COPSMODE: <mode></p> <p>where <mode> - +COPS behaviour as seen before.</p>	
AT#COPSMODE=?	Test command returns the range of available values for parameter <mode> .	
Note	It's suggested to reboot the module after every #COPSMODE setting.	

3.5.6.1.53. Query SIM Status - #QSS

#QSS - Query SIM Status		SELINT 0 / 1
AT#QSS[= [<mode>]]	<p>Set command enables/disables the Query SIM Status unsolicited indication in the ME.</p> <p>Parameter: <mode> - type of notification 0 - disabled (factory default); it's possible only to query the current SIM status through Read command AT#QSS? 1 - enabled; the ME informs at every SIM status change through the following unsolicited indication:</p> <p>#QSS: <status></p> <p>where: <status> - current SIM status 0 - SIM NOT INSERTED 1 - SIM INSERTED</p> <p>Note: issuing AT#QSS<CR> is the same as issuing the Read command.</p>	
AT#QSS?	<p>Read command reports whether the unsolicited indication #QSS is currently enabled or not, along with the SIM status, in the format:</p> <p>#QSS: <mode>,<status> (<mode> and <status> are described above)</p>	
AT#QSS=?	Test command returns the supported range of values for parameter <mode> .	



#QSS - Query SIM Status	SELINT 2
<p>AT#QSS= [<mode>]</p>	<p>Set command enables/disables the Query SIM Status unsolicited indication in the ME.</p> <p>Parameter: <mode> - type of notification 0 - disabled (factory default); it's possible only to query the current SIM status through Read command AT#QSS? 1 - enabled; the ME informs at every SIM status change through the following basic unsolicited indication:</p> <p style="text-align: center;">#QSS: <status></p> <p>where: <status> - current SIM status 0 - SIM NOT INSERTED 1 - SIM INSERTED</p> <p>2 - enabled; the ME informs at every SIM status change through the following unsolicited indication:</p> <p style="text-align: center;">#QSS: <status></p> <p>where: <status> - current SIM status 0 - SIM NOT INSERTED 1 - SIM INSERTED 2 - SIM INSERTED and PIN UNLOCKED 3 - SIM INSERTED and READY (SMS and Phonebook access are possible).</p> <p>Note: the command reports the SIM status change after the <mode> has been set to 2. We suggest to set <mode>=2 and save the value in the user profile, then power off the module. The proper SIM status will be available at the next power on.</p>
<p>AT#QSS?</p>	<p>Read command reports whether the unsolicited indication #QSS is currently enabled or not, along with the SIM status, in the format:</p> <p style="text-align: center;">#QSS: <mode>,<status> (<mode> and <status> are described above)</p>
<p>AT#QSS=?</p>	<p>Test command returns the supported range of values for parameter <mode>.</p>



3.5.6.1.54. ATD Dialing Mode - #DIALMODE

#DIALMODE - ATD Dialing Mode	SELINT 0 / 1
<p>AT#DIALMODE[= <mode>]</p>	<p>Set command sets ATD modality.</p> <p>Parameter: <mode></p> <ul style="list-style-type: none"> 0 - (voice call only) OK result code is received as soon as it starts remotely ringing (factory default) 1 - (voice call only) OK result code is received only after the called party answers. Any character typed aborts the call and NO CARRIER result code is received. 2 - (voice call and data call) the following custom result codes are received, monitoring step by step the call status: <ul style="list-style-type: none"> DIALING (MO in progress) RINGING (remote ring) CONNECTED (remote call accepted) RELEASED (after ATH) DISCONNECTED (remote hang-up) <p>Note: The setting is saved in NVM and available on following reboot.</p> <p>Note: In case a BUSY tone is received and at the same time ATX0 is enabled ATD will return NO CARRIER instead of DISCONNECTED.</p> <p>Note: if parameter <mode> is omitted the behaviour of Set command is the same as Read command.</p>
<p>AT#DIALMODE?</p>	<p>Read command returns current ATD dialing mode in the format:</p> <p>#DIALMODE: <mode></p>
<p>AT#DIALMODE=?</p>	<p>Test command returns the range of values for parameter <mode></p>

#DIALMODE - Dialing Mode	SELINT 2
<p>AT#DIALMODE= [<mode>]</p>	<p>Set command sets dialing modality.</p> <p>Parameter: <mode></p> <ul style="list-style-type: none"> 0 - (voice call only) OK result code is received as soon as it starts remotely ringing (factory default) 1 - (voice call only) OK result code is received only after the called party answers. Any character typed aborts the call and OK result code is received. 2 - (voice call and data call) the following custom result codes are



#DIALMODE - Dialing Mode	SELINT 2
	<p>received, monitoring step by step the call status: DIALING (MO in progress) RINGING (remote ring) CONNECTED (remote call accepted) RELEASED (after ATH) DISCONNECTED (remote hang-up)</p> <p>Note: In case a BUSY tone is received and at the same time ATX0 is enabled ATD will return NO CARRIER instead of DISCONNECTED.</p> <p>Note: The setting is saved in NVM and available on following reboot.</p>
AT#DIALMODE?	<p>Read command returns current ATD dialing mode in the format:</p> <p>#DIALMODE: <mode></p>
AT#DIALMODE=?	<p>Test command returns the range of values for parameter <mode></p>

3.5.6.1.55. Automatic Call - #ACAL

#ACAL - Automatic Call	SELINT 0 / 1
AT#ACAL[= [<mode>]]	<p>Set command enables/disables the automatic call function.</p> <p>Parameter: <mode> 0 - disables the automatic call function (factory default) 1 - enables the automatic call function. If enabled (and &D2 has been issued), the transition OFF/ON of DTR causes an automatic call to the first number (position 0) stored in the internal phonebook.</p> <p>Note: type of call depends on the last issue of command +FCLASS.</p> <p>Note: issuing AT#ACAL<CR> is the same as issuing the Read command.</p>
AT#ACAL?	<p>Read command reports whether the automatic call function is currently enabled or not, in the format:</p> <p>#ACAL: <mode></p>
AT#ACAL=?	<p>Test command returns the supported range of values for parameter <mode>.</p>
Note	<p>See &Z to write and &N to read the number on module internal phonebook.</p>



#ACAL - Automatic Call		SELINT 2
AT#ACAL= [<mode>]	<p>Set command enables/disables the automatic call function.</p> <p>Parameter: <mode> 0 - disables the automatic call function (factory default) 1 - enables the automatic call function. If enabled (and &D2 has been issued), the transition OFF/ON of DTR causes an automatic call to the first number (position 0) stored in the internal phonebook.</p> <p>Note: type of call depends on the last issue of command +FCLASS.</p>	
AT#ACAL?	<p>Read command reports whether the automatic call function is currently enabled or not, in the format:</p> <p>#ACAL: <mode></p> <p>Note: as a consequence of the introduction of the command #ACALEXT (Extended Automatic Call) it is possible that the Read Command returns a value supported by #ACALEXT but NOT supported by #ACAL.</p> <p>AT#ACAL? #ACAL : 2</p> <p>OK</p> <p>Due to this possible situation it is strongly recommended not to use contemporaneously both commands.</p>	
AT#ACAL=?	<p>Test command returns the supported range of values for parameter <mode>.</p>	
Note	<p>See &Z to write and &N to read the number on module internal phonebook.</p>	

3.5.6.1.56. Extended Automatic Call - #ACALEXT

#ACALEXT - Extended Automatic Call		SELINT 0 / 1 / 2
AT#ACALEXT= <mode>,<index>	<p>Set command enables/disables the extended automatic call function.</p> <p>Parameters: <mode> 0 - disables the automatic call function (factory default)</p>	



#ECAM - Extended Call Monitoring	SELINT 0 / 1
	<p><ccstatus> - call status 0 - idle 1 - calling (MO) 2 - connecting (MO) 3 - active 4 - hold 5 - waiting (MT) 6 - alerting (MT) 7 - busy</p> <p><calltype> - call type 1 - voice 2 - data</p> <p><number> - called number (valid only for <ccstatus>=1)</p> <p><type> - type of <number> 129 - national number 145 - international number</p> <p>Note: the unsolicited indication is sent along with usual codes (OK, NO CARRIER, BUSY...).</p> <p>Note: issuing AT#ECAM<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#ECAM=<CR> returns the OK result code.</p>
AT#ECAM?	<p>Read command reports whether the extended call monitoring function is currently enabled or not, in the format:</p> <p>#ECAM: <onoff></p>
AT#ECAM=?	<p>Test command returns the list of supported values for <onoff></p>

#ECAM - Extended Call Monitoring	SELINT 2
AT#ECAM=[<onoff>]	<p>This command enables/disables the call monitoring function in the ME.</p> <p>Parameter: <onoff> 0 - disables call monitoring function (factory default) 1 - enables call monitoring function; the ME informs about call events, such as incoming call, connected, hang up etc. using the following unsolicited indication:</p> <p>#ECAM: <ccid>,<ccstatus>,<calltype>,,,[<number>,<type>]</p>



#ECAM - Extended Call Monitoring	SELINT 2
	<p>where</p> <p><ccid> - call ID</p> <p><ccstatus> - call status</p> <p>0 - idle</p> <p>1 - calling (MO)</p> <p>2 - connecting (MO)</p> <p>3 - active</p> <p>4 - hold</p> <p>5 - waiting (MT)</p> <p>6 - alerting (MT)</p> <p>7 - busy</p> <p><calltype> - call type</p> <p>1 - voice</p> <p>2 - data</p> <p><number> - called number (valid only for <ccstatus>=1)</p> <p><type> - type of <number></p> <p>129 - national number</p> <p>145 - international number</p> <p>Note: the unsolicited indication is sent along with usual codes (OK, NO CARRIER, BUSY...).</p>
AT#ECAM?	<p>Read command reports whether the extended call monitoring function is currently enabled or not, in the format:</p> <p>#ECAM: <onoff></p>
AT#ECAM=?	<p>Test command returns the list of supported values for <onoff></p>

3.5.6.1.58. SMS Overflow - #SMOV

#SMOV - SMS Overflow	SELINT 0 / 1
AT#SMOV[= [<mode>]]	<p>Set command enables/disables the SMS overflow signalling function.</p> <p>Parameter:</p> <p><mode></p> <p>0 - disables SMS overflow signalling function(factory default)</p> <p>1 - enables SMS overflow signalling function; when the maximum storage capacity has been reached, the following notification is sent:</p> <p>#SMOV: <memo></p>



#SMOV - SMS Overflow		SELINT 0 / 1
	<p>where <memo> is a string indicating the SMS storage that has reached maximum capacity: "SM" – SIM Memory</p> <p>Note: issuing AT#SMOV<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#SMOV=<CR> is the same as issuing the command AT#SMOV=0<CR>.</p>	
AT#SMOV?	<p>Read command reports whether the SMS overflow signalling function is currently enabled or not, in the format:</p> <p>#SMOV: <mode></p>	
AT#SMOV=?	<p>Test command returns the supported range of values of parameter <mode>.</p>	

#SMOV - SMS Overflow		SELINT 2
AT#SMOV= [<mode>]	<p>Set command enables/disables the SMS overflow signalling function.</p> <p>Parameter: <mode></p> <p>0 - disables SMS overflow signalling function (factory default) 1 - enables SMS overflow signalling function; when the maximum storage capacity has been reached, the following network initiated notification is sent:</p> <p>#SMOV: <memo></p> <p>where <memo> is a string indicating the SMS storage that has reached maximum capacity: "SM" – SIM Memory</p>	
AT#SMOV?	<p>Read command reports whether the SMS overflow signalling function is currently enabled or not, in the format:</p> <p>#SMOV: <mode></p>	
AT#SMOV=?	<p>Test command returns the supported range of values of parameter <mode>.</p>	

3.5.6.1.59. Mailbox Numbers - #MBN

#MBN - Mailbox Numbers	SELINT 2
------------------------	----------



#MWI - Message Waiting Indication	SELINT 2
	<p>#MWI: <status>,<indicator>[,<count>]</p> <p>where:</p> <p><status> 0 - clear: it has been deleted one of the messages related to the indicator <indicator>. 1 - set: there's a new waiting message related to the indicator <indicator></p> <p><indicator> 1 - either Line 1 (CPHS context) or Voice (3GPP context) 2 - Line 2 (CPHS context only) 3 - Fax 4 - E-mail 5 - Other</p> <p><count> - message counter: network information reporting the number of pending messages related to the message waiting indicator <indicator>.</p> <p>The presentation at startup of the message waiting indicators status, as they are currently stored on SIM, is as follows:</p> <p>#MWI: <status>[,<indicator>[,<count>]][<CR><LF> #MWI: <status>,<indicator>[,<count>][...]]</p> <p>where:</p> <p><status> 0 - no waiting message indicator is currently set: if this the case no other information is reported 1 - there are waiting messages related to the message waiting indicator <indicator>.</p> <p><indicator> 1 - either Line 1 (CPHS context) or Voice (3GPP context) 2 - Line 2 (CPHS context) 3 - Fax 4 - E-mail 5 - Other</p> <p><count> - message counter: number of pending messages related to the message waiting indicator <indicator> as it is stored on SIM.</p>
<p>AT#MWI?</p>	<p>Read command reports wheter the presentation of the message waiting indicator URC is currently enabled or not, and the current status of the message waiting indicators as they are currently stored on SIM. The</p>



#CODEC - Audio Codec		SELINT 2
AT#CODEC= [<codec>]	<p>Set command sets the audio codec mode.</p> <p>Parameter: <codec> 0 - all the codec modes are enabled (factory default) 1..31 - sum of integers each representing a specific codec mode:</p> <ul style="list-style-type: none"> 1 - FR, full rate mode enabled 2 - EFR, enhanced full rate mode enabled 4 - HR, half rate mode enabled 8 - AMR-FR, AMR full rate mode enabled 16 - AMR-HR, AMR half rate mode enabled <p>Note: the full rate mode is added by default to any setting in the SETUP message (as specified in ETSI 04.08).</p> <p>Note: the setting 0 is equivalent to the setting 31.</p> <p>Note: The codec setting is saved in the profile parameters.</p>	
AT#CODEC?	<p>Read command returns current audio codec mode in the format:</p> <p>#CODEC: <codec></p>	
AT#CODEC=?	<p>Test command returns the range of available values for parameter <codec></p>	
Example	<p>AT#CODEC=14 OK</p> <p><i>sets the codec modes HR (4), EFR (2) and AMR-FR (8)</i></p>	

3.5.6.1.62. Handsfree Echo Canceller - #SHFEC

#SHFEC - Handsfree Echo Canceller		SELINT 0 / 1
AT#SHFEC[= [<mode>]]	<p>Set command enables/disables the echo canceller function on audio handsfree output.</p> <p>Parameter: <mode> 0 - disables echo canceller for handsfree mode (factory default) 1 - enables echo canceller for handsfree mode</p>	



#SHFEC - Handsfree Echo Cancellor		SELINT 0 / 1
	<p>Note: This setting returns to default after power off.</p> <p>Note: issuing AT#SHFEC<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#SHFEC=<CR> is the same as issuing the command AT#SHFEC=0<CR>.</p>	
AT#SHFEC?	<p>Read command reports whether the echo canceller function on audio handsfree output is currently enabled or not, in the format:</p> <p>#SHFEC: <mode></p>	
AT#SHFEC=?	<p>Test command returns the supported range of values of parameter <mode>.</p>	

#SHFEC - Handsfree Echo Cancellor		SELINT 2
AT#SHFEC=[<mode>]	<p>Set command enables/disables the echo canceller function on audio handsfree output.</p> <p>Parameter: <mode> 0 - disables echo canceller for handsfree mode (factory default) 1 - enables echo canceller for handsfree mode</p> <p>Note: This setting returns to default after power off.</p>	
AT#SHFEC?	<p>Read command reports whether the echo canceller function on audio handsfree output is currently enabled or not, in the format:</p> <p>#SHFEC: <mode></p>	
AT#SHFEC=?	<p>Test command returns the supported range of values of parameter <mode>.</p>	

3.5.6.1.63. Handsfree Microphone Gain - #HFMICG

#HFMICG - Handsfree Microphone Gain		SELINT 0 / 1
AT#HFMICG=[<level>]	<p>Set command sets the handsfree microphone input gain</p> <p>Parameter: <level>: handsfree microphone input gain 0..7 - handsfree microphone gain (+6dB/step, factory default = 4)</p>	



#HFMICG - Handsfree Microphone Gain		SELINT 0 / 1
	<p>Note: issuing AT#HFMICG<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#HFMICG=<CR> returns the OK result code.</p>	
AT#HFMICG?	<p>Read command returns the current handsfree microphone input gain, in the format:</p> <p>#HFMICG: <level></p>	
AT#HFMICG=?	<p>Test command returns the supported range of values of parameter <level>.</p>	

#HFMICG - Handsfree Microphone Gain		SELINT 2
AT#HFMICG=[<level>]	<p>Set command sets the handsfree microphone input gain</p> <p>Parameter: <level>: handsfree microphone input gain 0..7 - handsfree microphone gain (+6dB/step, factory default = 4)</p>	
AT#HFMICG?	<p>Read command returns the current handsfree microphone input gain, in the format:</p> <p>#HFMICG: <level></p>	
AT#HFMICG=?	<p>Test command returns the supported range of values of parameter <level>.</p>	

3.5.6.1.64. Handset Microphone Gain - #HSMICG

#HSMICG - Handset Microphone Gain		SELINT 0 / 1
AT#HSMICG=[<level>]	<p>Set command sets the handset microphone input gain</p> <p>Parameter: <level>: handset microphone input gain 0..7 - handset microphone gain (+6dB/step, factory default = 0)</p> <p>Note: issuing AT#HSMICG<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#HSMICG=<CR> returns the OK result code.</p>	
AT#HSMICG?	<p>Read command returns the current handset microphone input gain, in the format:</p>	



#HSMICG - Handset Microphone Gain		SELINT 0 / 1
	#HSMICG: <level>	
AT#HSMICG=?	Test command returns the supported range of values of parameter <level>.	

#HSMICG - Handset Microphone Gain		SELINT 2
AT#HSMICG=[<level>]	Set command sets the handset microphone input gain Parameter: <level>: handset microphone input gain 0..7 - handset microphone gain (+6dB/step, factory default = 0)	
AT#HSMICG?	Read command returns the current handset microphone input gain, in the format: #HSMICG: <level>	
AT#HSMICG=?	Test command returns the supported range of values of parameter <level>.	

3.5.6.1.65. Set Headset Sidetone - #SHFSD

#SHFSD - Set Headset Sidetone		SELINT 0 / 1
AT#SHFSD=[<mode>]	Set command enables/disables the sidetone on headset audio output. Parameter: <mode> 0 - disables the headset sidetone (factory default) 1 - enables the headset sidetone. Note: This setting returns to default after power off. Note: issuing AT#SHFSD<CR> is the same as issuing the Read command. Note: issuing AT#SHFSD=<CR> is the same as issuing the command AT#SHFSD=0<CR> .	
AT#SHFSD?	Read command reports whether the headset sidetone is currently enabled or not, in the format: #SHFSD: <mode>	
AT#SHFSD=?	Test command returns the supported range of values of parameter <mode>.	

#SHFSD - Set Headset Sidetone	SELINT 2
--------------------------------------	-----------------



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p><level>: handsfree analogue output gain 0..6 - handsfree analogue output (-3dB/step, factory default = 0)</p> <p><i>Note: This parameter is saved in NVM issuing AT&W command.</i></p>
AT#HFRECG?	<p>Read command returns the current handsfree analog output gain, in the format:</p> <p>#HFRECG: <level></p>
AT#HFRECG =?	<p>Test command returns the supported range of values of parameter <level>.</p>

3.5.6.1.68. Handset Receiver Gain - #HSRECG

#HSRECG - Handset Receiver Gain		SELINT 2
AT#HSRECG=<level>	<p>Set command sets the handset analogue output gain</p> <p>Parameter: <level>: handset analogue output gain 0..6 - handset analogue output (-3dB/step, default value = 0)</p> <p><i>Note: This parameter is saved in NVM issuing AT&W command.</i></p>	
AT#HSRECG?	<p>Read command returns the current handset analog output gain, in the format:</p> <p>#HSRECG: <level></p>	
AT#HSRECG =?	<p>Test command returns the supported range of values of parameter <level>.</p>	

3.5.6.1.69. Audio Profile Factory Configuration - #PRST

#PRST - Audio Profile Factory Configuration		SELINT 2
AT#PRST	<p>Execution command resets the actual audio parameters in the NVM of the device to the default set. It is not allowed if active audio profile is 0. The audio parameters to reset are:</p> <p style="padding-left: 40px;">- microphone line gain</p>	



#PRST - Audio Profile Factory Configuration		SELINT 2
	<ul style="list-style-type: none"> - earpiece line gain - side tone gain - LMS adaptation speed (step size) - LMS filter length (number of coefficients) - speaker to micro signal power relation - noise reduction max attenuation - noise reduction weighting factor (band 300-500Hz) - noise reduction weighting factor (band 500-4000Hz) - AGC Additional attenuation - AGC minimal attenuation - AGC maximal attenuation 	
AT#PRST=?	Test command returns the OK result code.	
Example	AT#PRST OK <i>Current audio profile is reset</i>	

3.5.6.1.70. Audio Profile Configuration Save - #PSAV

#PSAV - Audio Profile Configuration Save		SELINT 2
AT#PSAV	<p>Execution command saves the actual audio parameters in the NVM of the device. It is not allowed if active audio profile is 0.</p> <p>The audio parameters to store are:</p> <ul style="list-style-type: none"> - microphone line gain - earpiece line gain - side tone gain - LMS adaptation speed - LMS filter length (number of coefficients) - speaker to micro signal power relation - noise reduction max attenuation - noise reduction weighting factor (band 300-500Hz) - noise reduction weighting factor (band 500-4000Hz) - AGC Additional attenuation - AGC minimal attenuation - AGC maximal attenuation - Uplink path biquad filters - Downlink path biquad filters 	
AT#PSAV=?	Test command returns the OK result code.	
Example	AT#PSAV	



#PSET - Audio Profile Setting		SELINT 2
	<p>#PSET:<scal_in>,<scal_out>,<side_tone_atten>,<adaption_speed>,<filter_length>,<rxtxrelation>,<nr_atten>,<nr_w_0>,<nr_w_1>,<add_atten>,<min_atten>,<max_atten></p> <p>It is not allowed if active audio profile is 0.</p>	
AT#PSET=?	Test command returns the supported range of values for the audio parameters.	

3.5.6.1.73. Handsfree Automatic Gain Control - #SHFAGC

#SHFAGC - Handsfree Automatic Gain Control		SELINT 2
AT# SHFAGC = <mode>	<p>Set command enables/disables the automatic gain control function on audio handsfree input.</p> <p>Parameter: <mode> 0 - disables automatic gain control for handsfree mode (default) 1 - enables automatic gain control for handsfree mode</p> <p><i>Note: This parameter is saved in NVM issuing AT&W command.</i></p>	
AT# SHFAGC?	<p>Read command reports whether the automatic gain control function on audio handsfree input is currently enabled or not, in the format:</p> <p>#SHFAGC: <mode></p>	
AT# SHFAGC =?	Test command returns the supported range of values of parameter <mode> .	

3.5.6.1.74. Handsfree Noise Reduction - #SHFNR

#SHFNR - Handsfree Noise Reduction		SELINT 2
AT#SHFNR = <mode>	<p>Set command enables/disables the noise reduction function on audio handsfree input.</p> <p>Parameter: <mode> 0 - disables noise reduction for handsfree mode (default) 1 - enables noise reduction for handsfree mode</p> <p><i>Note: This parameter is saved in NVM issuing AT&W command.</i></p>	
AT#SHFNR?	Read command reports whether the noise reduction function on audio	



#SHFNR - Handsfree Noise Reduction		SELINT 2
	handsfree input is currently enabled or not, in the format: #SHFNR: <mode>	
AT#SHFNR=?	Test command returns the supported range of values of parameter <mode>.	

3.5.6.1.75. Handset Automatic Gain Control - #SHSAGC

#SHSAGC - Handset Automatic Gain Control		SELINT 2
AT#SHSAGC = <mode>	Set command enables/disables the automatic gain control function on audio handset input. Parameter: #SHSAGC: <mode> 0 - disables automatic gain control for handset mode (default) 1 - enables automatic gain control for handset mode <i>Note: This parameter is saved in NVM issuing AT&W command.</i>	
AT#SHSAGC?	Read command reports whether the automatic gain control function on audio handset input is currently enabled or not, in the format: #SHSAGC: <mode>	
AT#SHSAGC=?	Test command returns the supported range of values of parameter <mode>.	

3.5.6.1.76. Handset Echo Canceller - #SHSEC

#SHSEC - Handset Echo Canceller		SELINT 2
AT#SHSEC = <mode>	Set command enables/disables the echo canceller function on audio handset output. Parameter: #SHSEC: <mode> 0 - disables echo canceller for handset mode (default) 1 - enables echo canceller for handset mode <i>Note: This parameter is saved in NVM issuing AT&W command.</i>	
AT#SHSEC?	Read command reports whether the echo canceller function on audio handset output is currently enabled or not, in the format: #SHSEC: <mode>	



#SHSEC - Handset Echo Celler		SELINT 2
AT#SHSEC =?	Test command returns the supported range of values of parameter <mode>.	

3.5.6.1.77. Handset Noise Reduction - #SHSNR

#SHSNR - Handset Noise Reduction		SELINT 2
AT# SHSNR = <mode>	Set command enables/disables the noise reduction function on audio handset input. Parameter: <mode> 0 - disables noise reduction for handset mode (default) 1 - enables noise reduction for handset mode <i>Note: This parameter is saved in NVM issuing AT&W command.</i>	
AT# SHSNR?	Read command reports whether the noise reduction function on audio handset input is currently enabled or not, in the format: # SHSNR: <mode>	
AT# SHSNR =?	Test command returns the supported range of values of parameter <mode>.	

3.5.6.1.78. Set Handset Sidetone - #SHSSD

#SHSSD - Set Handset Sidetone		SELINT 2
AT#SHSSD= <mode>	Set command enables/disables the sidetone on handset audio output. Parameter: <mode> 0 - disables the handset sidetone 1 - enables the handset sidetone (factory default) <i>Note: This parameter is saved in NVM issuing AT&W command.</i>	
AT#SHSSD?	Read command reports whether the headset sidetone is currently enabled or not, in the format: #SHSSD: <mode>	
AT#SHSSD=?	Test command returns the supported range of values of parameter <mode>.	

3.5.6.1.79. PCM Play and Receive - #SPCM



#SPCM - PCM Play And Receive	SELINT 2												
<p>AT#SPCM=<mode>[,dir]</p>	<p>Execution command allows user either to send speech sample coming from microphone and/or downlink audio channel to serial port, or to reproduce a PCM coming from serial port to speaker and/or uplink audio channel; both modes are also available during speech calls.</p> <p>Parameters:</p> <p><mode>: action to be execute; 1 - reproduce PCM stream from serial to selected path. 2 - send speech from selected path to serial.</p> <p><dir>: Select the audio path. 0 - send/receive to/from analog front end 1 - send/receive to/from audio channel 2 - send/receive to/from both analog front end and audio channel</p> <p>Note: Execution command switches module in online mode, with flow control set by &Kx. Module moves back to command mode either afer entering the escape sequence +++ or as a consequence of a DTR transition.</p> <p>Note: PCM stream format must be 8 bit, 8KHz sampling, Mono.</p> <p>The following table summarizes the status of audio path during a speech call for different configurations and with sidetone disabled:</p> <table border="1" data-bbox="448 1305 1444 1648"> <thead> <tr> <th></th> <th>mode = 1</th> <th>mode = 2</th> </tr> </thead> <tbody> <tr> <td>dir = 0</td> <td>Uplink off / Downlink on PCM stream on speaker</td> <td>Uplink off / Downlink off PCM stream from microphone</td> </tr> <tr> <td>dir = 1</td> <td>Uplink on / Downlink off PCM stream on Uplink</td> <td>Uplink off / Downlink off PCM stream from Downlink</td> </tr> <tr> <td>dir = 2</td> <td>Uplink on / Downlink on PCM stream on both speaker and Uplink</td> <td>Uplink off / Downlink off PCM stream from both microphone and Downlink</td> </tr> </tbody> </table> <p>Sidetone is active during a voice call (HF path default configuration).</p>		mode = 1	mode = 2	dir = 0	Uplink off / Downlink on PCM stream on speaker	Uplink off / Downlink off PCM stream from microphone	dir = 1	Uplink on / Downlink off PCM stream on Uplink	Uplink off / Downlink off PCM stream from Downlink	dir = 2	Uplink on / Downlink on PCM stream on both speaker and Uplink	Uplink off / Downlink off PCM stream from both microphone and Downlink
	mode = 1	mode = 2											
dir = 0	Uplink off / Downlink on PCM stream on speaker	Uplink off / Downlink off PCM stream from microphone											
dir = 1	Uplink on / Downlink off PCM stream on Uplink	Uplink off / Downlink off PCM stream from Downlink											
dir = 2	Uplink on / Downlink on PCM stream on both speaker and Uplink	Uplink off / Downlink off PCM stream from both microphone and Downlink											
<p>AT#SPCM=?</p>	<p>Test command returns the supported range of values for parameters <mode> and <dir>.</p> <p>#SPCM: <mode>,<dir></p>												
<p>Example</p>	<p>AT#SPCM=1,0 CONNECT</p>												



	<pre>+++ NO CARRIER</pre> <p>Note: after the CONNECT, PCM stream has to be sent to serial port</p> <pre>AT#SPCM=2,0 CONNECT +++ NO CARRIER</pre> <p>Note: after the CONNECT, PCM stream can be read from serial port</p>
--	--

3.5.6.1.80. Open Audio Loop - #OAP

#OAP - Open Audio Loop		SELINT 2
AT#OAP=<mode>	Set command sets Open Audio Path. Parameter: 0 - disables Open Audio Path (default) 1 - enables Open Audio Path Note: the audio Loop will be activated on line select by the AXE pin or #CAP command.	
AT#OAP?	Read command reports whether the Open Audio Path is currently enabled or not, in the format: #OAP: <mode>	
AT#OAP=?	Test command returns the supported range of values of parameter <mode> .	
Note	The audio loop will be established between microphone and speaker using sidetone scaling value.	

3.5.6.1.81. Network Timezone - #NITZ

#NITZ - Network Timezone		SELINT 0 / 1
AT#NITZ[= <val> [,<mode>]]	Set command enables/disables automatic date/time updating and Network Timezone unsolicited indication. Date and time information can be sent by the network after GSM	



#NITZ - Network Timezone	SELINT 0 / 1
	<p>registration or after GPRS attach.</p> <p>Parameters: <val> 0 - disables automatic set (factory default) 1 - enables automatic set <mode> 0 - disables unsolicited message (factory default) 1 - enables unsolicited message; after date and time updating the following unsolicited indication is sent:</p> <p>#NITZ: "yy/MM/dd,hh:mm:ss"</p> <p>where: yy - year MM - month (in digits) dd - day hh - hour mm - minute ss - second</p> <p>Note: issuing AT#NITZ<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#NITZ=<CR> is the same as issuing the command AT#NITZ=0<CR>.</p>
AT#NITZ?	<p>Read command reports whether automatic date/time updating is currently enabled or not, and whether Network Timezone unsolicited indication is enabled or not, in the format:</p> <p>#NITZ: <val>,<mode></p>
AT#NITZ=?	<p>Test command returns supported values of parameters <val> and <mode>.</p>

#NITZ - Network Timezone	SELINT 2
AT#NITZ= [<val> [,<mode>]]	<p>Set command enables/disables (a) automatic date/time updating, (b) Full Network Name applying and (c) #NITZ URC; moreover it permits to change the #NITZ URC format.</p> <p>Date and time information can be sent by the network after GSM registration or after GPRS attach.</p> <p>Parameters: <val></p>



#NITZ - Network Timezone	SELINT 2
	<p>0 - disables (a) automatic data/time updating, (b) Full Network Name applying and (c) #NITZ URC; moreover it sets the #NITZ URC <i>'basic'</i> format (see <datetime> below) (factory default for all products except GE865-QUAD and GE864-DUAL V2)</p> <p>1..15 - as a sum of:</p> <ul style="list-style-type: none"> 1 - enables automatic date/time updating 2 - enables Full Network Name applying 4 - it sets the #NITZ URC <i>'extended'</i> format (see <datetime> below) 8 - it sets the #NITZ URC <i>'extended'</i> format with Daylight Saving Time (DST) support (see <datetime> below) (default for GE865-QUAD and GE864-DUAL V2: 7) <p><mode></p> <p>0 - disables #NITZ URC (factory default)</p> <p>1 - enables #NITZ URC; after date and time updating the following unsolicited indication is sent:</p> <p>#NITZ: <datetime></p> <p>where:</p> <p><datetime> - string whose format depends on subparameter <val></p> <p>“yy/MM/dd, hh:mm:ss” - <i>'basic'</i> format, if <val> is in (0..3)</p> <p>“yy/MM/dd, hh:mm:ss±zz” - <i>'extended'</i> format, if <val> is in (4..7)</p> <p>“yy/MM/dd, hh:mm:ss±zz,d” - <i>'extended'</i> format with DST support, if <val> is in (8..15)</p> <p>where:</p> <ul style="list-style-type: none"> yy - year MM - month (in digits) dd - day hh - hour mm - minute ss - second zz - time zone (indicates the difference, expressed in quarter of an hour, between the local time and GMT; two last digits are mandatory, range is -47..+48) d - number of hours added to the local TZ because of Daylight Saving Time (summertime) adjustment; range is 0-3. <p>Note: If the DST information isn't sent by the network, then the <datetime> parameter has the format “yy/MM/dd, hh:mm:ss±zz”</p>
AT#NITZ?	Read command reports whether (a) automatic date/time updating, (b) Full Network Name applying, (c) #NITZ URC (as well as its format) are currently



#NITZ - Network Timezone	SELINT 2
	enabled or not, in the format: #NITZ: <val>,<mode>
AT#NITZ=?	Test command returns supported values of parameters <val> and <mode>.

3.5.6.1.82. Clock management - #CCLK

#CCLK - Clock Management	SELINT 2
AT#CCLK=<time>	<p>Set command sets the real-time clock of the ME.</p> <p>Parameter: <time> - current time as quoted string in the format: "yy/MM/dd,hh:mm:ss±zz,d" yy - year (two last digits are mandatory), range is 00..99 MM - month (two last digits are mandatory), range is 01..12 dd - day (two last digits are mandatory) The range for dd(day) depends either on the month and on the year it refers to. Available ranges are: (01..28) (01..29) (01..30) (01..31) Trying to enter an out of range value will raise an error</p> <p>hh - hour (two last digits are mandatory), range is 00..23 mm - minute (two last digits are mandatory), range is 00..59 ss - seconds (two last digits are mandatory), range is 00..59 ±zz - time zone (indicates the difference, expressed in quarter of an hour, between the local time and GMT; two last digits are mandatory), range is -47..+48 d - number of hours added to the local TZ because of Daylight Saving Time (summertime) adjustment; range is 0-2.</p>
AT#CCLK?	<p>Read command returns the current setting of the real-time clock, in the format <time>.</p> <p>Note: if the time is set by the network but the DST information is missing, or the time is set by +CCLK command, then the <time> format is: "yy/MM/dd,hh:mm:ss±zz"</p>
AT#CCLK=?	Test command returns the OK result code.
Example	AT#CCLK="02/09/07,22:30:00+04,1" OK AT#CCLK?



#CCLK - Clock Management	SELINT 2
#CCLK: 02/09/07,22:30:25+04,1	
OK	

3.5.6.1.83. Enhanced Network Selection - #ENS

#ENS - Enhanced Network Selection	SELINT 2
AT#ENS=[<mode>]	<p>Set command is used to activate the ENS functionality.</p> <p>Parameter: <mode> 0 - disable ENS functionality (default) 1 - enable ENS functionality; if AT#ENS=1 has been issued, the following values will be automatically set:</p> <ul style="list-style-type: none"> ➤ at every next power-up <ul style="list-style-type: none"> a Band GSM 850 and PCS enabled (AT#BND=3) b SIM Application Toolkit enabled on user interface 0 if not previously enabled on a different user interface (AT#STIA=2) ➤ just at first next power-up <ul style="list-style-type: none"> a Automatic Band Selection enabled (AT#AUTOBND=1) only if the previous setting was different from AT#AUTOBND=2 b PLMN list not fixed (AT#PLMNMODE=1). <p>Note: the new setting will be available just at first next power-up.</p> <p>Note: If 'Four Band' Automatic Band Selection has been activated (AT#AUTOBND=2), at power-up the value returned by AT#BND? could be different from 3 when ENS functionality is enabled.</p>
AT#ENS?	<p>Read command reports whether the ENS functionality is currently enabled or not, in the format:</p> <p>#ENS: <mode> where: <mode> as above</p>
AT#ENS=?	Test command reports the available range of values for parameter <mode> .
Reference	Cingular Wireless LLC Requirement



3.5.6.1.84. Select Band - #BND

#BND - Select Band		SELINT 0 / 1
AT#BND[= [<band>]]	<p>Set command selects the current band.</p> <p>Parameter <band>:</p> <ul style="list-style-type: none"> 0 - GSM 900MHz + DCS 1800MHz 1 - GSM 900MHz + PCS 1900MHz 2 - GSM 850MHz + DCS 1800MHz (available only on quadri-band modules) 3 - GSM 850MHz + PCS 1900MHz (available only on quadri-band modules) <p>Note: This setting is maintained even after power off.</p> <p>Note: issuing AT#BND<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#BND=<CR> is the same as issuing the command AT#BND=0<CR>.</p>	
AT#BND?	<p>Read command returns the current selected band in the format:</p> <p>#BND: <band></p>	
AT#BND=?	<p>Test command returns the supported range of values of parameter <band>.</p> <p>Note: the range of values differs between triband modules and quadric-band modules</p>	
Note:	Not available for GC864-DUAL, GC864-DUAL V2 and GE864-DUAL V2	

#BND - Select Band		SELINT 2
AT#BND= [<band>]	<p>Set command selects the current band.</p> <p>Parameter <band>:</p> <ul style="list-style-type: none"> 0 - GSM 900MHz + DCS 1800MHz 1 - GSM 900MHz + PCS 1900MHz; this value is not available if the ENS functionality has been activated (see #ENS) 2 - GSM 850MHz + DCS 1800MHz (available only on quadri-band modules); this value is not available if the ENS functionality has been activated (see #ENS) 3 - GSM 850MHz + PCS 1900MHz (available only on quadri-band modules) 	



#BND - Select Band	SELINT 2
	<p>Note: This setting is maintained even after power off.</p> <p>Note: if the normal automatic band selection is enabled (AT#AUTOBND=1) then the last #BND settings can automatically change at power-up; then you can normally use the command.</p> <p>Note: if the 'four bands' automatic band selection is enabled (AT#AUTOBND=2) then you can issue AT#BND=<band> but it will have no functional effect; nevertheless every following read command AT#BND? will report that setting.</p>
AT#BND?	<p>Read command returns the current selected band in the format:</p> <p>#BND: <band></p>
AT#BND=?	<p>Test command returns the supported range of values of parameter <band>.</p> <p>Note: the range of values differs between tri-band modules and quadri-band modules</p>
Note:	Not available for GC864-DUAL, GC864-DUAL V2 and GE864-DUAL V2

3.5.6.1.85. Automatic Band Selection - #AUTOBND

#AUTOBND - Automatic Band Selection	SELINT 0 / 1
AT#AUTOBND[=<value>]	<p>Set command enables/disables the automatic band selection at power-on.</p> <p>Parameter: <value>:</p> <ul style="list-style-type: none"> 0 - disables automatic band selection at power-on (default for all products) 1 - enables automatic band selection at power-on; +COPS=0 is necessary condition to effectively have automatic band selection at next power-on; the automatic band selection stops as soon as a GSM cell is found. <p>Note: if automatic band selection is enabled the band changes every about 90 seconds through available bands until a GSM cell is found.</p> <p>Note: if parameter <value> is omitted the behaviour of Set command is the same as Read command.</p>
AT#AUTOBND?	<p>Read command returns whether the automatic band selection is enabled or not in the format:</p>



#AUTOBND - Automatic Band Selection		SELINT 0 / 1
	#AUTOBND: <value>	
AT#AUTOBND=?	Test command returns the range of supported values for parameter <value>.	
Note:	Not available for GC864-DUAL, GC864-DUAL V2 and GE864-DUAL V2	

#AUTOBND - Automatic Band Selection		SELINT 2
AT#AUTOBND=[<value>]	<p>Set command enables/disables the automatic band selection at power-on.</p> <p>Parameter: <value>: 0 - disables automatic band selection at <i>next</i> power-up (default for all products, except GE865-QUAD) 1 - enables automatic band selection at <i>next</i> power-up; the automatic band selection stops as soon as a GSM cell is found. 2 – (default for GE865-QUAD) enables automatic band selection in four bands (at 850/1900 and 900/1800); differently from previous settings it takes <i>immediate</i> effect</p> <p>Note: necessary condition to <i>effectively</i> have automatic band selection at next power-up (due to either AT#AUTOBND=1 or AT#AUTOBND=2) is that AT+COPS=0 has to be previously issued</p> <p>Note: if automatic band selection is enabled (AT#AUTOBND=1) the band changes every about 90 seconds through available bands until a GSM cell is found.</p> <p>Note: if the current setting is different from AT#AUTOBND=2 and we're issuing AT#ENS=1, at <i>first next</i> power-up after the ENS functionality has been activated (see #ENS) the automatic band selection (AT#AUTOBND=1) is enabled.</p>	
AT#AUTOBND?	<p>Read command returns whether the automatic band selection is enabled or not in the form:</p> <p>#AUTOBND: <value></p>	
AT#AUTOBND=?	Test command returns the range of supported values for parameter <value>.	
Note:	Not available for GC864-DUAL, GC864-DUAL V2 and GE864-DUAL V2	



3.5.6.1.86. Skip Escape Sequence - #SKIPESC

#SKIPESC - Skip Escape Sequence		SELINT 0 / 1
AT#SKIPESC[= [<mode>]]	<p>Set command enables/disables skipping the escape sequence +++ while transmitting during a data connection.</p> <p>Parameter: <mode> 0 - doesn't skip the escape sequence; its transmission is enabled (factory default). 1 - skips the escape sequence; its transmission is not enabled.</p> <p>Note: in case of an FTP connection, the escape sequence is not transmitted, regardless of the command setting.</p> <p>Note: issuing AT#SKIPESC<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#SKIPESC=<CR> is the same as issuing the command AT#SKIPESC=0<CR>.</p>	
AT#SKIPESC?	<p>Read command reports whether escape sequence skipping is currently enabled or not, in the format:</p> <p>#SKIPESC: <mode></p>	
AT#SKIPESC=?	Test command reports supported range of values for parameter <mode> .	

#SKIPESC - Skip Escape Sequence		SELINT 2
AT#SKIPESC= [<mode>]	<p>Set command enables/disables skipping the escape sequence +++ while transmitting during a data connection.</p> <p>Parameter: <mode> 0 - doesn't skip the escape sequence; its transmission is enabled (factory default). 1 - skips the escape sequence; its transmission is not enabled.</p> <p>Note: in case of an FTP connection, the escape sequence is not transmitted, regardless of the command setting.</p>	



#SKIPESC - Skip Escape Sequence		SELINT 2
AT#SKIPESC?	Read command reports whether escape sequence skipping is currently enabled or not, in the format: #SKIPESC: <mode>	
AT#SKIPESC=?	Test command reports supported range of values for parameter <mode>.	

3.5.6.1.87. Escape Sequence Guard Time - #E2ESC

#E2ESC - Escape Sequence Guard Time		SELINT 0 / 1
AT#E2ESC=[<gt;]]	Set command sets a guard time in seconds for the escape sequence in GPRS to be considered a valid one (and return to on-line command mode). Parameter: <gt; 0 - guard time defined by command S12 (factory default) 1..10 - guard time in seconds Note: if the Escape Sequence Guard Time is set to a value different from zero, it overrides the one set with S12 . Note: issuing AT#E2ESC<CR> is the same as issuing the Read command. Note: issuing AT#E2ESC=<CR> returns the OK result code.	
AT#E2ESC?	Read command returns current value of the escape sequence guard time, in the format: #E2ESC: <gt;	
AT#E2ESC=?	Test command returns the OK result code.	

#E2ESC - Escape Sequence Guard Time		SELINT 2
AT#E2ESC=[<gt;]	Set command sets a guard time in seconds for the escape sequence in GPRS to be considered a valid one (and return to on-line command mode). Parameter: <gt; 0 - guard time defined by command S12 (factory default) 1..10 - guard time in seconds Note: if the Escape Sequence Guard Time is set to a value different from zero, it overrides the one set with S12 .	
AT#E2ESC?	Read command returns current value of the escape sequence guard time, in the format:	



#E2ESC - Escape Sequence Guard Time		SELINT 2
	#E2ESC: <gt>	
AT#E2ESC=?	Test command returns the range of supported values for parameter <gt>.	
AT#E2ESC= [<gt>]	Set command sets a guard time in seconds for the escape sequence in GPRS to be considered a valid one (and return to on-line command mode). Parameter: <gt> 0 - guard time defined by command S12 (factory default) 1..10 - guard time in seconds Note: if the Escape Sequence Guard Time is set to a value different from zero, it overrides the one set with S12.	

3.5.6.1.88. PPP-GPRS Connection Authentication Type - #GAUTH

#GAUTH - PPP-GPRS Connection Authentication Type		SELINT 0 / 1
AT#GAUTH[= <type>]	Set command sets the authentication type either for PPP-GPRS and PPP-GSM connections. Parameter <type> 0 - no authentication 1 - PAP authentication (factory default) 2 - CHAP authentication Note: if parameter <type> is omitted the behaviour of Set command is the same as Read command.	
AT#GAUTH?	Read command reports the current PPP-GPRS connection authentication type, in the format: #GAUTH: <type>	
AT#GAUTH=?	Test command returns the range of supported values for parameter <type>.	

#GAUTH - PPP-GPRS Connection Authentication Type	SELINT 2
--	----------



#GAUTH - PPP-GPRS Connection Authentication Type		SELINT 2
AT#GAUTH= [<type>]	<p>Set command sets the authentication type either for PPP-GPRS and PPP-GSM connections.</p> <p>Parameter <type> 0 - no authentication 1 - PAP authentication (factory default) 2 - CHAP authentication 3 - automatic (PAP and CHAP)</p>	
AT#GAUTH?	<p>Read command reports the current PPP-GPRS connection authentication type, in the format:</p> <p>#GAUTH: <type></p>	
AT#GAUTH=?	<p>Test command returns the range of supported values for parameter <type>.</p>	

3.5.6.1.89. PPP-GPRS Parameters Configuration - #GPPPCFG

#GPPPCFG - PPP-GPRS Parameters Configuration		SELINT 2
AT#GPPPCFG= <hostIPAddress> [,<LCPTimeout> [,<PPPmode>]]	<p>Set command sets three parameters for a PPP-GPRS connection.</p> <p>Parameters: <hostIPAddress> - Host IP Address that is assigned to the PPP server side (the host application); Sstring type, it can be any valid IP address in the format: xxx.xxx.xxx.xxx. <LCPTimeout> - LCP response timeout value in 100ms units 10..600 - hundreds of ms (factory default is 25) <PPPmode> - PPP mode 0 - passive mode (default), the module waits the first message coming from the remote application (e.g. LCP Conf Req) before starting the LCP negotiation 1 - active mode, the module starts autonomously the LCP negotiation immediately after the CONNECT message 2 - passive mode (default), the module waits the first message coming from the remote application (e.g. LCP Conf Req) before starting the LCP negotiation; LCP termination is performed by the module</p>	



#GPPPCFG - PPP-GPRS Parameters Configuration		SELINT 2
	<p>3 - active mode, the module starts autonomously the LCP negotiation immediately after the CONNECT message; LCP termination is performed by the module</p> <p>Note: if <hostIPAddress>="0.0.0.0" (factory default) the Host IP Address assigned to the host application is the previous remote IP Address obtained by the Network.</p>	
AT# GPPPCFG?	<p>Read command reports the current PPP-GPRS connection parameters in the format:</p> <p>#GPPPCFG: <hostIPAddress>,<LCPTimeout>,<PPPmode></p>	
AT# GPPPCFG=?	<p>Test command returns the range of supported values for parameter <LCPTimeout> and <PPPmode>, in the format:</p> <p>#GPPPCFG: (10-600),(0-3)</p>	

3.5.6.1.90. RTC Status - #RTCSTAT

#RTCSTAT - RTC Status		SELINT 0 / 1
AT#RTCSTAT[=<status>]	<p>Set command resets the RTC status flag.</p> <p>Parameter: <status> 0 - Set RTC Status to RTC HW OK</p> <p>Note: the initial value of RTC status flag is RTC HW Error and it doesn't change until a command AT#RTCSTAT=0 is issued.</p> <p>Note: if a power failure occurs and the buffer battery is down the RTC status flag is set to 1. It doesn't change until command AT#RTCSTAT=0 is issued.</p> <p>Note: if parameter <status> is omitted the behaviour of Set command is the same as Read command.</p>	
AT#RTCSTAT?	<p>Read command reports the current value of RTC status flag, in the format:</p> <p>#RTCSTAT: <status></p>	
AT#RTCSTAT=?	<p>Test command returns the range of supported values for parameter <status></p>	



#RTCSTAT - RTC Status		SELINT 2
AT#RTCSTAT= [<status>]	<p>Set command resets the RTC status flag.</p> <p>Parameter: <status> 0 - Set RTC Status to RTC HW OK</p> <p>Note: the initial value of RTC status flag is RTC HW Error and it doesn't change until a command AT#RTCSTAT=0 is issued.</p> <p>Note: if a power failure occurs and the buffer battery is down the RTC status flag is set to 1. It doesn't change until command AT#RTCSTAT=0 is issued.</p>	
AT#RTCSTAT?	<p>Read command reports the current value of RTC status flag, in the format:</p> <p>#RTCSTAT: <status></p>	
AT#RTCSTAT=?	<p>Test command returns the range of supported values for parameter <status></p>	

3.5.6.1.91. GSM Antenna Detection - #GSMAD

#GSMAD - GSM Antenna Detection		SELINT 2
AT#GSMAD= <mod>, [<urcmode> [,<interval> [,<detGPIO> [,<repGPIO>]]]]	<p>Set command sets the behaviour of antenna detection algorithm</p> <p>Parameters: <mod> 0 - antenna detection algorithm not active 1 - periodic activation of the antenna detection algorithm; detection is started every <interval> period, using <detGPIO> for detection; if the algorithm detects a change in the antenna status the module is notified by URC #GSMAD (see format below) 2 - instantaneous activation of the antenna detection algorithm; if the algorithm detects a change in the antenna status the module is notified by URC #GSMAD (see format below); this instantaneous activation doesn't affect a periodic activation eventually started before. This modality is obsolete and is maintained only for backward compatibility. We suggest to use the modality 3</p> <p>URC format:</p>	



	<p>#GSMAD: <presence></p> <p>where:</p> <p><presence></p> <ul style="list-style-type: none"> 0 - antenna connected. 1 - antenna connector short circuited to ground. 2 - antenna connector short circuited to power. 3 - antenna not detected (open). <p>3 - instantaneous activation of the antenna detection algorithm as modality 2 but in this case the command doesn't return until the algorithm ended. The returned value is the antenna <presence> status just detected. Format:</p> <pre>AT#GSMAD=3 #GSMAD: <presence></pre> <p>OK</p> <p>This instantaneous activation doesn't affect a periodic activation eventually started before, then the output format would be:</p> <pre>AT#GSMAD=3 #GSMAD: <presence></pre> <p>OK</p> <pre>#GSMAD: <presence> // URC resulting of previous #GSMAD=1</pre> <p><urcmode> - URC presentation mode. It has meaning and can be set only if <mod> is 1.</p> <ul style="list-style-type: none"> 0 - it disables the presentation of the antenna detection URC 1 - it enables the presentation of the antenna detection URC, whenever the antenna detection algorithm detects a change in the antenna status; the unsolicited message is in the format: <pre>#GSMAD: <presence></pre> <p>where:</p> <p><presence> is as before</p> <p><interval> - duration in seconds of the interval between two consecutive antenna detection algorithm runs (default is 120). It has</p>
--	---



	<p>meaning and can be set only if <mod> is 1. ..1..3600 - seconds</p> <p><detGPIO> - defines which GPIO shall be used as input by the Antenna Detection algorithm. For the <detGPIO> actual range see Test Command</p> <p><repGPIO> - defines which GPIO shall be used by the Antenna Detection algorithm to report antenna condition. It has meaning only if <mod> is 1. For the <repGPIO> actual range see Test Command.</p> <p>Note: the URC presentation mode <urcmode> is related to the current AT instance only (see +cmux); last <urcmode> settings are saved for every instance as extended profile parameters, thus it is possible to restore them either if the multiplexer control channel is released and set up, back and forth.</p> <p>Note: GPIO is set to LOW when antenna is connected. Set to HIGH otherwise</p> <p>Note: #GSMAD parameters, excluding <urcmode>, are saved in NVM.</p>
AT#GSMAD?	<p>Read command returns the current parameter settings for #GSMAD command in the format:</p> <p>#GSMAD: <mod>,<urcmode>,<interval>,<detGPIO>,<repGPIO></p>
AT#GSMAD=?	<p>Test command reports the supported range of values for parameters <mod>, <urcmode>, <interval>, <detGPIO> and <repGPIO>.</p>

3.5.6.1.92. SIM Detection Mode - #SIMDET

#SIMDET - SIM Detection Mode		SELINT 2
AT#SIMDET= <mode>	<p>Set command specifies the SIM Detection mode</p> <p>Parameter: <mode> - SIM Detection mode 0 - ignore SIMIN pin and simulate the status 'SIM Not Inserted' 1 - ignore SIMIN pin and simulate the status 'SIM Inserted' 2 - automatic SIM detection through SIMIN Pin (default)</p>	
AT#SIMDET?	<p>Read command returns the currently selected Sim Detection Mode in the format:</p>	



	<p>#SIMDET: <mode>,<simin></p> <p>where: <mode> - SIM Detection mode, as before <simin> - SIMIN pin real status 0 - SIM not inserted 1 - SIM inserted</p>
AT#SIMDET=?	Test command reports the supported range of values for parameter <mode>

3.5.6.1.93. SIM Enhanced Speed - #ENHSIM

#ENHSIM - SIM Enhanced Speed	SELINT 2
AT#ENHSIM= <mod>	<p>Set command activates or deactivates the Sim Enhanced Speed Functionality.</p> <p>Parameter: <mod> 0 - Not Active (default for all products, except GE865-QUAD and GE864-DUAL V2) 1 - BRF is (F=512 D=8) (default for GE865-QUAD and GE864-DUAL V2)</p> <p><i>(For BRF definition refer to ISO-7816-3)</i></p> <p>Note: value <mod> is saved in NVM and will be used since next module startup or new SIM insertion.</p> <p>Note: module will use the slowest speed between the one programmed and the one supported by the SIM.</p>
AT#ENHSIM?	<p>Read command returns whether the Sim Enhanced Speed Functionality is currently activated or not, in the format:</p> <p>#ENHSIM: <mod></p>
AT#ENHSIM=?	Test command reports the supported range of values for parameter <mod>.
Reference	GSM 11.11, ISO-7816-3
Note	It is strongly suggested to verify which is the maximum speed supported by the final application

3.5.6.1.94. Subscriber number - #SNUM



#SNUM – Subscriber Number	SELINT 2
<p>AT#SNUM= <index>,<number>[, <alpha>]</p>	<p>Set command writes the MSISDN information related to the subscriber (own number) in the EFmsisdn SIM file.</p> <p>Parameter:</p> <p><index> - record number The number of record in the EFmsisdn depends on the SIM. If the ENS functionality has not been previously enabled (see #ENS), <index>=1 is the only value admitted. If only <index> value is given, then delete the EFmsisdn record in location <index> is deleted.</p> <p><number> - string containing the phone number The string could be written between quotes. If the ENS functionality has been previously enabled (see #ENS) "+" at start only is also admitted (international numbering scheme).</p> <p><alpha> - alphanumeric string associated to <number>. Default value is empty string (""), otherwise the used character set should be the one selected with +CSCS. The string could be written between quotes, the number of characters depends on the SIM. If empty string is given (""), the corresponding <alpha> will be an empty string.</p> <p>Note: the command return ERROR if EFmsisdn file is not present in the SIM or if MSISDN service is not allocated and activated in the SIM Service Table (see 3GPP TS 11.11).</p>
<p>AT#SNUM=?</p>	<p>Test command returns the OK result code</p>

3.5.6.1.95. SIM Answer to Reset - #SIMATR

#SIMATR – SIM Answer To Reset	SELINT 2
<p>AT#SIMATR</p>	<p>This command returns the characters collected from the Reset/ATR procedure.</p> <p>Note: The ATR is the information presented by the SIM to the ME at the beginning of the card session and gives operational requirements (ISO/IEC 7816-3).</p>



3.5.6.1.96. TeleType Writer - #TTY

#TTY - TeleType Writer		SELINT 2
AT#TTY=<support>	Set command enables/disables the TTY functionality. Parameter: <support> 0 - disable TTY functionality 1 - enable TTY functionality	
AT#TTY?	Read command returns whether the TTY functionality is currently enabled or not, in the format: #TTY: <support>	
AT#TTY=?	Test command reports the supported range of values for parameter <support> .	

3.5.6.1.97. CPU Clock Mode - #CPUMODE

#CPUMODE - CPU Clock Mode		SELINT 2
AT#CPUMODE= <mode>	Set command specifies the CPU clock mode Parameter: <mode> 0 - normal CPU clock 1 - fast CPU clock 2 - fast CPU clock, during GPRS TX/RX only Note: using <mode>=1 , the power consumption will increase	
AT#CPUMODE?	Read command returns the currently selected CPU clock mode in the format: #CPUMODE: <mode>	
AT#CPUMODE=?	Test command reports the supported range of values for parameter <mode> .	

3.5.6.1.98. GSM Context Definition - #GSMCONT

#GSMCONT - GSM Context Definition		SELINT 2
AT#GSMCONT= <cid>[,<P_type>]	Set command specifies context parameter values for the only GSM context, identified by the (local) context identification parameter 0.	



<CSD_num>]	<p>Parameters:</p> <p><cid> - context Identifier; numeric parameter which specifies the only GSM context</p> <p>0</p> <p><P_type> - protocol type; a string parameter which specifies the type of protocol</p> <p>"IP" - Internet Protocol</p> <p><CSD_num> - phone number of the internet service provider</p> <p>Note: issuing #GSMCONT=0 causes the values for context number 0 to become undefined.</p>
AT#GSMCONT?	<p>Read command returns the current settings for the GSM context, if defined, in the format:</p> <p>+GSMCONT: <cid>,<P_type>,<CSD_num></p>
AT#GSMCONT=?	<p>Test command returns the supported range of values for all the parameters.</p>

3.5.6.1.99. IPEGSM configurations - #GSMCONTCFG

#GSMCONTCFG - IPEGSM configurations	SELINT 2
<p>AT#GSMCONTCFG= <actTo>[,<unused_A > [,<unused_B >[,<unused_C>]]]]</p>	<p>Set command sets the IPEGSM configuration.</p> <p>Parameters:</p> <p><actTo> - activation timer value</p> <p>0 – no timer (default)</p> <p>50..65535 – timeout value in hundreds of milliseconds</p> <p>Note: this timeout starts as soon as the PPP activation starts (refer to EasyGPRS User Guide). It does not include the time for the CSD call to be established.</p> <p>Note: the value set by command is directly stored in NVM and doesn't depend on the specific AT instance.</p>
AT#GSMCONTCFG?	<p>Read command returns the current configuration parameters value:</p> <p>#GSMCONTCFG:<actTo>,0,0,0<CR><LF></p>



AT#GSMCONTCFG=?	Test command returns the range of supported values for all the subparameters.
-----------------	---

3.5.6.1.100. Show Address - #CGPADDR

#CGPADDR - Show Address	SELINT 2
<p>AT#CGPADDR= [<cid>[,<cid> [,...]]]</p>	<p>Execution command returns either the IP address for the GSM context (if specified) and/or a list of PDP addresses for the specified PDP context identifiers</p> <p>Parameters: <cid> - context identifier 0 - specifies the GSM context (see +GSMCONT). 1..5 - numeric parameter which specifies a particular PDP context definition (see +CGDCONT command).</p> <p>Note: if no <cid> is specified, the addresses for all defined contexts are returned.</p> <p>Note: issuing the command with more than 6 parameters raises an error.</p> <p>Note: the command returns only one row of information for every specified <cid>, even if the same <cid> is present more than once.</p> <p>The command returns a row of information for every specified <cid> whose context has been already defined. No row is returned for a <cid> whose context has not been defined yet. Response format is:</p> <p>#CGPADDR: <cid>,<address>[<CR><LF> #CGPADDR: <cid>,<address>[...]]</p> <p>where: <cid> - context identifier, as before <address> - its meaning depends on the value of <cid> a) if <cid> is the (only) GSM context identifier (<cid>=0) it is the dynamic address assigned during the GSM context</p>



	<p>activation.</p> <p>b) if <cid> is a PDP context identifier (<cid> in (1..5)) it is a string that identifies the terminal in the address space applicable to the PDP. The address may be static or dynamic. For a static address, it will be the one set by the +CGDCONT command when the context was defined. For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid>.</p> <p>Note: if no address is available the empty string ("") is represented as <address>.</p>
AT#CGPADDR=?	Test command returns a list of defined <cid> s.
Example	<pre>AT#SGACT=0,1 #SGACT: xxx.yyy.zzz.www OK AT#CGPADDR=0 #CGPADDR: 0,"xxx.yyy.zzz.www" OK AT#CGPADDR=? #CGPADDR: (0) OK</pre>

3.5.6.1.101. Network Scan Timer - #NWSCANTMR

#NWSCANTMR - Network Scan Timer		SELINT 2
AT#NWSCANTMR=<tmr>	<p>Set command sets the Network Scan Timer that is used by the module to schedule the next network search when it is without network coverage (no signal).</p> <p>Parameter: <tmr> - timer value in units of seconds 5 3600 - time in seconds (default 5 secs.)</p>	
AT#NWSCANTMR	<p>Execution command reports time, in seconds, when the next scan activity will be executed. The format is:</p> <p>#NWSCANTMREXP: <time></p> <p>Note: if <time> is zero it means that the timer is not running</p>	
AT#NWSCANTMR?	Read command reports the current parameter setting for #NWSCANTMR	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	It is not allowed if active audio profile is 0.
AT# BIQUADIN=?	Test command returns the supported range of values for parameters $\langle a_{F0} \rangle$, $\langle a_{F1} \rangle$, $\langle a_{F2} \rangle$, $\langle b_{F1} \rangle$, $\langle b_{F2} \rangle$, $\langle a_{S0} \rangle$, $\langle a_{S1} \rangle$, $\langle a_{S2} \rangle$, $\langle b_{S1} \rangle$, $\langle b_{S2} \rangle$

3.5.6.1.103. Cascaded filters - #BIQUADOUT

#BIQUADOUT - Downlink Path Biquad Filters		SELINT 2
AT# BIQUADOUT= $\langle a_{F0} \rangle$ [, $\langle a_{F1} \rangle$ [, $\langle a_{F2} \rangle$ [, $\langle b_{F1} \rangle$ [, $\langle b_{F2} \rangle$ [, $\langle a_{S0} \rangle$ [, $\langle a_{S1} \rangle$ [, $\langle a_{S2} \rangle$ [, $\langle b_{S1} \rangle$ [, $\langle b_{S2} \rangle$]]]]]]]]]	<p>Set command allows configuring the parameters of the two cascaded digital biquad filters $H_{First}(z) \cdot H_{Second}(z)$ in Downlink path (receiving). It is not allowed if active audio profile is 0.</p> <p>Parameters: $\langle a_{Fn} \rangle$, $\langle b_{Fn} \rangle$, $\langle a_{Sn} \rangle$, $\langle b_{Sn} \rangle$ - they all are specific parameters for the calculation of digital biquad filters as follows:</p> $H_F(z) = \frac{a_{F0} + 2 \cdot a_{F1} \cdot z^{-1} + a_{F2} \cdot z^{-2}}{1 + 2 \cdot b_{F1} \cdot z^{-1} + b_{F2} \cdot z^{-2}}$ $H_S(z) = \frac{a_{S0} + 2 \cdot a_{S1} \cdot z^{-1} + a_{S2} \cdot z^{-2}}{1 + 2 \cdot b_{S1} \cdot z^{-1} + b_{S2} \cdot z^{-2}}$ <p>-32768..32767 - each value has to be interpreted as signed fixed point number in two's complement format with 15 fractional bits in a 16 bit word (Q15)</p> <p>Note: in the above formulas pay attention to the multiplier (2) for parameters $\langle a_{F1} \rangle$, $\langle a_{S1} \rangle$, $\langle b_{F1} \rangle$ and $\langle b_{S1} \rangle$ Parameters can be saved in NVM using AT#PSAV command and are available for audio profiles 1,2,3. For audio profile 0 the values are fixed.</p>	
AT# BIQUADOUT?	<p>Read command returns the parameters for the active profile in the format:</p> <p># BIQUADOUT: $\langle a_{F0} \rangle$, $\langle a_{F1} \rangle$, $\langle a_{F2} \rangle$, $\langle b_{F1} \rangle$, $\langle b_{F2} \rangle$, $\langle a_{S0} \rangle$, $\langle a_{S1} \rangle$, $\langle a_{S2} \rangle$, $\langle b_{S1} \rangle$, $\langle b_{S2} \rangle$ It is not allowed if active audio profile is 0.</p>	
AT# BIQUADOUT=?	<p>Test command returns the supported range of values for parameters $\langle a_{F0} \rangle$, $\langle a_{F1} \rangle$, $\langle a_{F2} \rangle$, $\langle b_{F1} \rangle$, $\langle b_{F2} \rangle$, $\langle a_{S0} \rangle$, $\langle a_{S1} \rangle$, $\langle a_{S2} \rangle$, $\langle b_{S1} \rangle$, $\langle b_{S2} \rangle$</p>	



#BIQUADOUT - Downlink Path Biquad Filters	SELINT 2

3.5.6.1.104. Call Establishment Lock - #CESTHLCK

#CESTHLCK - Call establishment lock	SELINT 2
AT#CESTHLCK= [<closure_type >]	<p>This command can be used to disable call abort before the DCE enters connected state.</p> <p>< closure_type >:</p> <p>0 - Aborting the call setup by reception of a character is generally possible at any time before the DCE enters connected state (default)</p> <p>1 - Aborting the call setup is disabled until the DCE enters connected state</p>
AT#CESTHLCK?	<p>Read command returns the current setting of <closure_type> parameter in the format:</p> <p>#CESTHLCK: <closure_type></p>
AT#CESTHLCK=?	<p>Test command returns the supported range of values for the <closure_type> parameter</p>

3.5.6.1.105. Phone Activity Status - #CPASMODE

#CPASMODE - AT+CPAS answer mode	SELINT 2
AT#CPASMODE=<mode>	<p>Set command enables/disables a modified AT+CPAS command response when the command is issued before an incoming call starts ringing (RING unsolicited code sent to the TE). If <mode> is 0, AT+CPAS response will be +CPAS: 4 otherwise the response will be +CPAS: 3</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p>Parameter: <mode> - AT+CPAS response selection 0 – standard AT+CPAS response (factory default) 1 – modified AT+CPAS response.</p> <p>Note: the value set by command is directly stored in NVM and doesn't depend on the specific AT instance</p>
AT#CPASMODE?	<p>Read command reports the currently selected <mode> in the format: #CPASMODE: <mode></p>
AT#CPASMODE=?	<p>Test command reports the supported range of values for parameter <mode></p>

3.5.6.1.106. ICCID SIM file reading mode - #FASTCCID

#FASTCCID – Set ICCID SIM file reading mode		SELINT 2
AT#FASTCCID= [<fast>]	<p>The set command is used to specify the ICCID reading mode.</p> <p><fast>: a numeric parameter which indicates the reading mode</p> <p>0 – the ICCID value is read from the SIM card each time the AT#CCID command is issued and not during SIM card initialization (default) 1 – the ICCID value is read from the SIM card during SIM card initialization</p> <p>Note: the value is saved in NVM and has effect only at the next power cycle.</p>	
AT#FASTCCID?	<p>The read command returns the currently selected reading mode in the form:</p> <p>#FASTCCID: <fast></p>	
AT#FASTCCID=?	<p>Test command reports the supported list of currently available <fast>s.</p>	

3.5.6.1.107. I2C data via GPIO - #I2CWR

#I2CWrite – Write to I2C		SELINT 2
AT#I2CWR= <sdaPin> , <sclPin> ,	<p>This command is used to Send Data to an I2C peripheral connected to module GPIOs</p>	



#I2CWrite – Write to I2C	SELINT 2
<p><deviceld>, <registerld>, <len></p>	<p><sdaPin >: GPIO number for SDA . Valid range is “any input/output pin” (see Test Command.)</p> <p><sclPin>: GPIO number to be used for SCL. Valid range is “any output pin” (see Test Command).</p> <p><deviceld>: address of the I2C device, without the LSB used for read\write command, 10 bit addressing supported. Value has to be written in hexadecimal form (without 0x).</p> <p><registerld>: Register to write data to , range 0..255. Value has to be written in hexadecimal form (without 0x).</p> <p><len>: number of data to send. Valid range is 1-254.</p> <p>The module responds to the command with the prompt '>' and awaits for the data to send. To complete the operation send Ctrl-Z char (0x1A hex); to exit without writing the message send ESC char (0x1B hex).</p> <p>Data shall be written in Hexadecimal Form.</p> <p>If data are successfully sent, then the response is OK.</p> <p>If data sending fails for some reason, an error code is reported. Example if CheckAck is set and no Ack signal was received on the I2C bus</p> <p>E.g. AT#I2CWR=2,3,20,10,14 > 00112233445566778899AABBCCDD<ctrl-z> OK Set GPIO2 as SDA, GPIO3 as SCL; Device I2C address is 0x20; 0x10 is the address of the first register where to write I2C data; 14 data bytes will be written since register 0x10</p> <p>NOTE: At the end of the execution GPIO will be restored to the original setting (check AT#GPIO Command)</p> <p>NOTE: device address, register address where to read from\ write to, and data bytes have to be written in hexadecimal form without 0x.</p>
<p>AT#I2CWR=?</p>	<p>Test command reports the supported list of currently available <service>s.</p>



3.5.6.1.108. I2C data from GPIO - #I2CRD

#I2CRD – Read to I2C	SELINT 2
<p>AT#I2CRD= <sdaPin>, <sclPin>, <devicId>, <registerId>, <len></p>	<p>This command is used to Send Data to an I2C peripheral connected to module GPIOs</p> <p><sdaPin >: GPIO number for SDA . Valid range is “any input/output pin” (see Test Command.)</p> <p><sclPin>: GPIO number to be used for SCL. Valid range is “any output pin” (see Command Test).</p> <p><devicId>: address of the I2C device, without the LSB used for read\write command, 10 bit addressing supported. Value has to be written in hexadecimal form (without 0x before).</p> <p><registerId>: Register to read data from, range 0..255. Value has to be written in hexadecimal form (without 0x before).</p> <p><len>: number of data to receive. Valid range is 1-254.</p> <p>Data Read from I2C will be dumped in Hex:</p> <p>E.g. AT#I2CRD=2,3,20,10,12 #I2CRD: 00112233445566778899AABBCC OK</p> <p>NOTE: If data requested are more than data available in the device, dummy data (normally 0x00 or 0xff) will be dumped.</p> <p>NOTE: At the end of the execution GPIO will be restored to the original setting (check AT#GPIO Command)</p> <p>NOTE: device address, register address where to read from\ write to, and date bytes have to be written in hexadecimal form without 0x.</p>
AT#I2CRD=?	Test command reports the supported list of currently available <service>s.

3.5.6.1.109. Power saving mode ring - #PSMRI

#PSMRI – Power Saving Mode Ring	SELINT 2
---------------------------------	----------



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

AT#PSMRI= <x>	<p>Set command enables/disables the Ring Indicator pin response to an URC message while modem is in power saving mode. If enabled, a negative going pulse is generated, when URC message for specific event is invoked.</p> <p>The duration of this pulse is determined by the value of <x>.</p> <p>Parameter: <x> - RI enabling 0 - disables RI pin response for URC message(factory default) 50-1150 - enables RI pin response for URC messages.</p> <p>Note: when RING signal from incoming call/SMS/socket listen is enabled, the behaviour for #PSMRI will be ignored.</p> <p>Note: to avoid missing of URC messages while modem is in power saving mode flow control has to be enabled in command mode (AT#CFLO=1)</p> <p>Note: the behavior for #PSMRI is invoked, only when modem is in sleep mode (AT+CFUN=5 and DTR Off on Main UART)</p> <p>Note: the value set by command is stored in the profile extended section and doesn't depend on the specific AT instance</p>
AT#PSMRI?	<p>Read command reports the duration in ms of the pulse generated, in the format: #PSMRI: <x></p>
AT#PSMRI=?	<p>Test command reports the supported range of values for parameter <x></p>

3.5.6.1.110. Software level selection - #SWLEVEL

#SWLEVEL – SW Level selection	SELINT 2
AT#SWLEVEL=<level>	<p>Set command enables 2 enhanced features:</p> <ol style="list-style-type: none"> 1) It permits to get a faster indication of SIM status when the PIN is not required (see command #QSS) 2) DTMF duration (see AT+VTS;AT+VTD) can be controlled even for values shorter than 300mS. <p>Parameters: <level> - SW level 0 - disable SW level (default for for all products, except GE865-QUAD and GE864-DUAL V2)</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p>1 - enable SW level (default for GE865-QUAD and GE864-DUAL V2)</p> <p>Note1: the value of <level> parameter is directly stored in NVM and doesn't depend on the specific AT instance.</p> <p>Note2: please remember that DTMFs are generated at network level, and the real duration can be operator dependant.</p>
AT#SWLEVEL?	<p>Read command reports the currently selected <level> in the format:</p> <p>#SWLEVEL: <level></p>
AT#SWLEVEL=?	<p>Test command reports the supported range of values for parameter <level></p>

3.5.6.1.111. Control Command Flow - #CFLO

#CFLO – Command Flow Control		SELINT 2
AT#CFLO=<enable>	<p>Set command enables/disables the flow control in command mode. If enabled, current flow control is applied to both data mode and command mode.</p> <p>Parameter: <enable> - 0 – disable flow control in command mode <default value> 1 – enable flow control in command mode</p> <p>Note: setting value is saved in the profile</p>	
AT#CFLO?	<p>Read command returns current setting value in the format</p> <p>#CFLO: <enable></p>	
AT#CFLO=?	<p>Test command returns the range of supported values for parameter <enable></p>	

3.5.6.1.112. Report concatenated SMS indexes - #CMGLCONCINDEX

#CMGLCONCINDEX – Report concatenated SMS indexes		SELINT 2
AT#CMGLCONCINDEX	<p>The command will report a line for each concatenated SMS containing:</p> <p>#CMGLCONCINDEX: N,i,j,k,...</p>	



#CMGLCONCINDEX – Report concatenated SMS indexes		SELINT 2
	<p>where N is the number of segments that form the whole concatenated SMS i,j,k are the SMS indexes of each SMS segment , 0 if segment has not been received</p> <p>If no concatenated SMS is present on the SIM, only OK result code will be returned.</p>	
AT#CMGLCONCINDEX=?	Test command returns OK result code.	
Example	<pre>at#cmglconcinde #CMGLCONCINDEX: 3,0,2,3 #CMGLCONCINDEX: 5,4,5,6,0,8</pre> <p>OK</p>	

3.5.6.1.113. Codec Information - #CODECINFO

#CODECINFO – Codec Information	SELINT 2
<p>AT#CODECINFO[=<format>[, <mode>]]</p>	<p>This command is both a set and an execution command.</p> <p>Set command enables/disables codec information reports depending on the parameter <mode>, in the specified <format>.</p> <p>Parameters:</p> <p><format> 0 – numeric format (default) 1 – textual format</p> <p><mode> 0 - disable codec information unsolicited report (default) 1 - enable codec information unsolicited report only if the codec changes 2 - enable short codec information unsolicited report only if the codec changes</p> <p>If <mode>=1 the unsolicited channel mode information is reported in the following format:</p> <p>(if <format>=0) #CODECINFO: <codec_used>,<codec_set></p>



#CODECINFO – Codec Information	SELINT 2
	<p>(if <format>=1) #CODECINFO: <codec_used>,<codec_set1> [,<codec_set2>[..,<codec_setn>]]]</p> <p>If <mode>=2 the unsolicited codec information is reported in the following format:</p> <p>#CODECINFO: <codec_used></p> <p>The reported values are described below.</p> <p>Execution command reports codec information in the specified <format>.</p> <p>(if <format>=0) #CODECINFO: <codec_used>,<codec_set></p> <p>(if <format>=1) #CODECINFO: <codec_used>,<codec_set1> [,<codec_set2>[..,<codec_setn>]]]</p> <p>The reported values are:</p> <p>(if <format>=0) <codec_used> - one of the following channel modes: 0 - no TCH 1 - full rate speech 1 on TCH 2 - full rate speech 2 on TCH 4 - half rate speech 1 on TCH 8 - full rate speech 3 – AMR on TCH 16 - half rate speech 3 – AMR on TCH 128 – full data 9.6 129 – full data 4.8 130 – full data 2.4 131 – half data 4.8 132 – half data 2.4 133 – full data 14.4</p> <p><codec_set> 1..31 - sum of integers each representing a specific codec mode: 1 - FR, full rate mode enabled 2 - EFR, enhanced full rate mode enabled</p>



#CODECINFO – Codec Information	SELINT 2
	<p>4 - HR, half rate mode enabled 8 - FAMR, AMR full rate mode enabled 16 - HAMR, AMR half rate mode enabled</p> <p>(if <format>=1) <codec_used> - one of the following channel modes: None - no TCH FR - full rate speech 1 on TCH EFR - full rate speech 2 on TCH HR - half rate speech 1 on TCH FAMR - full rate speech 3 - AMR on TCH HAMR - half rate speech 3 - AMR on TCH FD96 - full data 9.6 FD48 - full data 4.8 FD24 - full data 2.4 HD48 - half data 4.8 HD24 - half data 2.4 FD144 - full data 14.4</p> <p><codec_set/n> FR - full rate mode enabled EFR - enhanced full rate mode enabled HR - half rate mode enabled FAMR - AMR full rate mode enabled HAMR - AMR half rate mode enabled</p> <p>Note: The command refers to codec information in speech call and to channel mode in data/fax call.</p> <p>Note: if AT#CODEC is 0, the reported codec set for <format>=0 is 31 (all codec).</p>
AT#CODECINFO?	<p>Read command reports <format> and <mode> parameter values in the format:</p> <p>#CODECINFO: <format>,<mode></p>
AT#CODECINFO=?	<p>Test command returns the range of supported <format> and <mode>.</p>

3.5.6.1.114. Second Interface Instance - #SII



#SII – Second Interface Instance	SELINT 2
<p>AT#SII=<inst>[,<rate>[,<format>[,<parity>]]]</p>	<p>This command activates one of the three AT instances available, and assigns it to the ASC1 serial port at a particular speed and format.</p> <p>Parameters:</p> <p><inst>: is a number that identifies the instance that will be activated on ASC1. The parameter is mandatory and can be 0, 1 or 2: 0 – disables the other AT instance and restores the trace service; 1 – enables instance 1; 2 – enables instance 2;</p> <p><rate>: Set command specifies the DTE speed at which the device accepts commands during command mode operations; it may be used to fix the DTE-DCE interface speed. The default value is 115200. It has sense only if <inst> parameter has value either 1 or 2. Parameter: 300 1200 2400 4800 9600 19200 38400 57600 115200</p> <p><format>: determines the number of bits in the data bits, the presence of a parity bit, and the number of stop bits in the start-stop frame. The default value is 3,0, (N81) format. It has sense only if <inst> parameter has value either 1 or 2. Parameter: 1 - 8 Data, 2 Stop 2 - 8 Data, 1 Parity, 1 Stop 3 - 8 Data, 1 Stop 5 - 7 Data, 1 Parity, 1 Stop</p> <p><parity>: determines how the parity bit is generated and checked, if present. It has a meaning only if <format> parameter has value either 2 or 5</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p>and only if <inst> parameter has value either 1 or 2.</p> <p>Parameter: 0 - Odd 1 - Even</p> <p>Note: the value set by command is directly stored in NVM and doesn't depend on the specific AT instance.</p> <p>Note: two sets of <rate>, <format> and <parity> parameters values are stored in NVM: one for instance 1 (<inst> = 1) and the other for instance 2 (<inst> = 2). The <rate>, <format> and <parity> parameters values are ignored when <inst> parameter has value 0.</p> <p>Note: ASC1 port doesn't support hardware flow control.</p>
AT#SII?	<p>Read command reports the currently active parameters settings in the format:</p> <p>#SII: <inst>[,<rate>,<format>,<parity>]</p> <p>Note: the <rate>, <format> and <parity> parameters values are showed only if <inst> parameter has value either 1 or 2.</p>
AT#SII=?	<p>Test command reports the supported range of values for parameter <inst>, <rate>, <format> and <parity></p>

3.5.6.2. General Configuration AT Commands - Special Issues

The following commands are available only for specific subsets of products, as it appears in the 'Note'

3.5.6.2.1. External 32kHz Oscillator

#OSC32KHZ - External 32kHz Oscillator		SELINT 2
AT#OSC32KHZ	<p>Execution command reports the presence of an external 32kHz oscillator, in the format:</p> <p>#OSC32KHZ: <stat></p> <p>where: <stat> 0 - external 32kHz oscillator is not present</p>	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p>1 - external 32kHz oscillator is present</p> <p>Note: if the external oscillator is removed while the module is on, the software will take up to 9 seconds to realize its absence.</p> <p>Note: if the external oscillator is connected to the module while it is on, the software will take less than 1 second to realize its presence.</p>
AT#OSC32KHZ=?	Test command returns the OK result code.
Note	This command is currently available only for the product GE864-QUAD Automotive

3.5.6.2.2. Select language - #LANG

#LANG - select language		SELINT 2
AT#LANG=<lan>	<p>Set command selects the currently used language for displaying different messages</p> <p>Parameter: <lan> - selected language "en" – English (factory default) "it" – Italian</p>	
AT#LANG?	Read command reports the currently selected <lan> in the format: #LANG: <lan>	
AT#LANG=?	Test command reports the supported range of values for parameter <lan>	
Note	This command is currently available only for software 10.00.xxx.	

3.5.6.2.3. Postpone alarm - +CAPD

+CAPD - postpone or dismiss an alarm		SELINT 2
AT+CAPD=[<sec>]	<p>Set command postpones or dismisses a currently active alarm.</p> <p>Parameters: <sec>: integer type value indicating the number of seconds to postpone the alarm (maximum 60 seconds). If <sec> is set to 0 (default), the alarm is dismissed.</p>	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

AT+CAPD=?	Test command reports the supported range of values for parameter <sec>
Note	This command is currently available only for software 10.00.xxx.

3.5.6.2.4. Call meter maximum event - +CCWE

+CCWE – Call Meter maximum event		SELINT 2
AT+CCWE=<mode>	<p>Set command is used to enable/disable sending of an unsolicited result code +CCWV shortly before the ACM (Accumulated Call Meter) maximum value is reached. The warning is issued approximately when 30 seconds call time remains. It is also issued when starting a call if less than 30 seconds call time remains.</p> <p>Parameters: <mode>: 0 Disable the call meter warning event (default) 1 Enable the call meter warning event</p> <p>Note: the set command will respond with an error if the Accumulated Call Meter service is not active in SIM</p>	
AT+CCWE?	<p>Read command reports the currently selected <mode> in the format:</p> <p>+CCWE: <mode></p>	
AT+CCWE=?	Test command reports the supported range of values for parameter <mode>	
Note	This command is currently available only for software 10.00.xxx.	

3.5.6.2.5. Setting date format - +CSDF

+CSDF – setting date format		SELINT 2
AT+CSDF=[<mode> [,<auxmode>]]	<p>This command sets the date format of the date information presented to the user, which is specified by use of the <mode> parameter. The <mode> affects the date format on the phone display and doesn't affect the date format of the AT command serial interface, so it not used.</p> <p>The command also sets the date format of the TE-TA interface, which is specified by use of the <auxmode> parameter (i.e., the <auxmode> affects the <time> of AT+CCLK and AT+CALA). If the parameters are omitted then this sets the default value of <mode>.</p>	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p>Parameters:</p> <p><mode>:</p> <p>1 DD-MMM-YYYY (default)</p> <p>2 DD-MM-YY</p> <p>3 MM/DD/YY</p> <p>4 DD/MM/YY</p> <p>5 DD.MM.YY</p> <p>6 YYMMDD</p> <p>7 YY-MM-DD</p> <p><auxmode>:</p> <p>1 yy/MM/dd (default)</p> <p>2 yyyy/MM/dd</p> <p>Note: The <time> format of +CCLK and +CALA is "yy/MM/dd, hh:mm:ss+zz" when <auxmode>=1 and it is "yyyy/MM/dd, hh:mm:ss+zz" when <auxmode>=2.</p>
AT+CSDF?	Read command reports the currently selected <mode> and <auxmode> in the format: +CSDF: <mode>, <auxmode>
AT+CSDF=?	Test command reports the supported range of values for parameters <mode> and <auxmode>
Note	This command is currently available only for software 10.00.xxx.

3.5.6.2.6. Silence command - +CSIL

+CSIL - silence command		SELINT 2
AT+CSIL=[<mode>]	<p>This command enables/disables the silent mode. When the phone is in silent mode, all signalling tones from MT are suppressed.</p> <p>Parameters:</p> <p><mode>:</p> <p>0 Silent mode off (default)</p> <p>1 Silent mode on</p>	
AT+CSIL?	Read command reports the currently selected <mode> in the	



	format: +CSIL: <mode>
AT+CSIL=?	Test command reports the supported range of values for parameter <mode>
Note	This command is currently available only for software 10.00.xxx.

3.5.6.2.7. Setting time format

+CSTF – setting time format		SELINT 2
AT+CSTF=[<mode>]	This command sets the time format of the time information presented to the user, which is specified by use of the <mode> parameter. The <mode> affects the time format on the phone display and doesn't affect the time format of the AT command serial interface, so it not actually not used. Parameters: <mode> : 1 HH:MM (24 hour clock; default) 2 HH:MM a.m./p.m.	
AT+CSTF?	Read command reports the currently selected <mode> in the format: +CSTF: <mode>	
AT+CSTF=?	Test command reports the supported range of values for parameter <mode>	
Note	This command is currently available only for software 10.00.xxx.	

3.5.6.2.8. Call deflection

+CTFR – Call deflection		SELINT 2
AT+CTFR=<number>[,<type>]	Set command is used to request a service that causes an incoming alerting call to be forwarded to a specified number. This is based on the GSM/UMTS supplementary service CD (Call Deflection; refer 3GPP TS 22.072). Parameters: <number> : string type phone number of format specified by <type>	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p><type>: type of address octet in integer format; default 145 when dialling string includes international access code character "+", otherwise 129</p> <p>Note: Call Deflection is only applicable to an incoming voice call</p>
AT+CTFR=?	Test command tests for command existence
Note	This command is currently available only for software 10.00.xxx.

3.5.6.2.9. Time Zone reporting

+CTZR – Time Zone reporting		SELINT 2
AT+CTZR=<onoff>	<p>This command enables and disables the time zone change event reporting. If the reporting is enabled the MT returns the unsolicited result code +CTZV: <tz> whenever the time zone is changed.</p> <p>Parameters: <onoff>: 0 Disable time zone change event reporting (default) 1 Enable time zone change event reporting</p>	
AT+CTZR?	<p>Read command reports the currently selected <onoff> in the format: +CTZR: <onoff></p>	
AT+CTZR=?	Test command reports the supported range of values for parameter <onoff>	
Note	This command is currently available only for software 10.00.xxx.	

3.5.6.2.10. Automatic Time Zone update

+CTZU – automatic Time Zone update		SELINT 2
AT+CTZU=<onoff>	<p>This command enables and disables automatic time zone update via NITZ.</p> <p>Parameters: <onoff>: 0 Disable automatic time zone update via NITZ (default) 1 Enable automatic time zone update via NITZ</p>	



AT+CTZU?	Read command reports the currently selected <onoff> in the format: +CTZU: <onoff>
AT+CTZU=?	Test command reports the supported range of values for parameter <onoff>
Note	This command is currently available only for software 10.00.xxx.

3.5.6.3. AT Run Commands

3.5.6.3.1. Enable SMS Run AT Service - #SMSATRUN

#SMSATRUN – Enable SMS AT Run service		SELINT 2
AT#SMSATRUN= <mod>	<p>Set command enables/disables the SMS AT RUN service.</p> <p>Parameter: < mod ></p> <ul style="list-style-type: none"> 0: Service Disabled 1: Service Enabled <p>Note1: When the service is active on a specific AT instance (see AT#SMSATRUNCFG), that instance cannot be used for any other scope, except for OTA service that has the highest priority. For example in the multiplexer request to establish the Instance, the request will be rejected.</p> <p>Note2: the current settings are stored in NVM.</p>	
AT#SMSATRUN?	<p>Read command returns the current settings of <mode> and the value of <stat> in the format:</p> <p># SMSATRUN: <mod>,<stat></p> <p>where: <stat> - service status</p> <ul style="list-style-type: none"> 0 – not active 1 - active 	
AT#SMSATRUN =?	Test command returns the supported values for the SMSATRUN parameters	



#SMSATRUN – Enable SMS AT Run service SELINT 2

Notes:

- By default the SMS ATRUN service is disabled
- If the module receives the following SMS:

Offset	Size	Value	Description
0	3	0xD2D2D2	SMSATRUN activation
3	1	0..255	Transaction ID
4	1	0x11	Segment 1 of 1
5	1		Session Id
6	64		RSA Digest

- where the RSA is calculated using the RSA algorithm with the RSA private key on the string SMSATRUN ACTIVATION concatenated with an optional phone number
- the module decodes the digest using the RSA public key and, if the result is the default string expected, the message is accepted and
 - activates the SMSATRUN service
 - inserts in the white list (which has 8 positions) the phone number if present, in position 7
 - inserts in the white list a default password in position 8: as for OTA service, the password is imei+last imei digit (16 digits)
- answers to server sending a SMS to the sender number:

Offset	Size	Value	Description
0	3	0xD3D3D3	SMSATRUN activation Response
3	1	0..255	Transaction ID
4	1	0x11	Segment 1 of 1
5	1		Session Id
6	64		RSA Digest
70	1+1		Command response

- where:
 - session Id is the same of SMSATRUN activation SMS
 - the 64 bytes long RSA digest is calculated applying the RSA algorithm with the RSA public key on the string SMSATRUN ACTIVATION concatenated with the module IMEI.
- If the SMSATRUN activation SMS is received and the SMSATRUN is already active, the SMS is ignored and handled as a normal SMS



#SMSATRAN – Enable SMS AT Run service	SELINT 2
	<ul style="list-style-type: none"> If the SMSATRAN activation SMS is received after that the SMSATRAN has been activated and deactivated, the module activates the service and overwrites in white list positions 7 and 8 the possibly present elements. Based on the fact that only 2 passwords are admitted at maximum, if there are already 2, one of them is erased because the default password is inserted in position 8

3.5.6.3.2. Set SMS Run AT Service parameters - #SMSATRANCFG

#SMSATRANCFG – Set SMS AT Run Parameters	
<p>AT#SMSATRANCFG= <instance> [,<urcmmod> [,<timeout>]]</p>	<p>Set command configures the SMS AT RUN service.</p> <p>Parameter:</p> <p><instance>: AT instance that will be used by the service to run the AT Command. Range 2 - 3, default 3.</p> <p><urcmmod>: 0 – disable unsolicited message 1 - enable an unsolicited message when an AT command is requested via SMS (default).</p> <p>When unsolicited is enabled, the AT Command requested via SMS is indicated to TE with unsolicited result code:</p> <p>#SMSATRAN: <Text></p> <p>e.g.: #SMSATRAN: AT+CGMR;+CGSN;+GSN;+CCLK</p> <p>Unsolicited is dumped on the instance that requested the service activation.</p> <p><timeout>: It defines in minutes the maximum time for a command execution. If timeout expires the module will be rebooted. Range 1 – 60, default 5.</p> <p>Note 1: the current settings are stored in NVM.</p>



#SMSATRUNCFG – Set SMS AT Run Parameters	
	<p>Note 2: the instance used for the SMS AT RUN service is the same used for the EvMoni service. Therefore, when the #SMSATRUNCFG sets the <instance> parameter, the change is reflected also in the <instance> parameter of the #ENAEVMONICFG command, and viceversa.</p> <p>Note 3: the set command returns ERROR if the command AT#ENAEVMONI? returns 1 as <mod> parameter or the command AT#SMSATRUN? returns 1 as <mod> parameter</p>
AT#SMSATRUNCFG?	<p>Read command returns the current settings of parameters in the format:</p> <p>#SMSATRUNCFG:<instance>,<urcmo>,<timeo></p>
AT#SMSATRUNCFG=?	<p>Test command returns the supported values for the SMSATRUNCFG parameters</p>

3.5.6.3.3. SMS AT Run White List - #SMSATWL

#SMSATWL – SMS AT Run White List	SELINT 2
<p>AT#SMSATWL= <action> ,<index> [,<entryType> [,<string>]]</p>	<p>Set command to handle the white list.</p> <p><action >:</p> <ul style="list-style-type: none"> 0 – Add an element to the WhiteList 1 – Delete an element from the WhiteList 2 – Print and element of the WhiteList <p>< index >: Index of the WhiteList. Range 1-8</p> <p>< entryType >:</p> <ul style="list-style-type: none"> 0 – Phone Number 1 – Password <p>NOTE: A maximum of two Password Entry can be present at same time in the white List</p> <p><string>: string parameter enclosed between double quotes containing or</p>



#SMSATWL – SMS AT Run White List		SELINT 2
	<p>the phone number or the password</p> <p>Phone number shall contain numerical characters and/or the character “+” at the beginning of the string and/or the character “*” at the end of the string. Password shall be 16 characters length</p> <p>NOTE: When the character “*” is used, it means that all the numbers that begin with the defined digit are part of the white list.</p> <p>E.g. “+39*” All Italian users can ask to run AT Command via SMS “+39349*” All vodafone users can ask to run AT Command via SMS.</p>	
AT#SMSATWL?	<p>Read command returns the list elements in the format:</p> <p>#SMSATWL: [<entryType>,<string>]</p>	
AT#SMSATWL=?	<p>Test command returns the supported values for the parameter <action>, <index> and <entryType></p>	

3.5.6.3.4. Set TCP Run AT Service parameter - #TCPATRUNCFG

#TCPATRUNCFG– Set TCP AT Run Service Parameters	
<p>AT#TCPATRUNCFG= <connId> ,<instance> ,<tcpPort> ,<tcpHostPort> ,<tcpHost> [,<urcmMod> [,<timeout> [,<authMode> [,<retryCnt> [,<retryDelay>]]]]]</p>	<p>Set command configures the TCP AT RUN service Parameters:</p> <p><connId> socket connection identifier. Default 1.</p> <p>Range 1..6. This parameter is mandatory.</p> <p><instance>: AT instance that will be used by the service to run the AT Command. Default 2. Range 2 - 3. This parameter is mandatory.</p> <p><tcpPort> Tcp Listen port for the connection to the service in server mode. Default 1024. Range 1...65535. This parameter is mandatory.</p> <p><tcpHostPort> Tcp remote port of the Host to connect to, in client mode. Default 1024. Range 1...65535. This parameter is mandatory.</p>



#TCPATRUNCFG– Set TCP AT Run Service Parameters

<tcpHost>

IP address of the Host, string type.

This parameter can be either:

- any valid IP address in the format: "xxx.xxx.xxx.xxx"
- any host name to be solved with a DNS query

This parameter is mandatory. Default "".

<urcmo>:

0 – disable unsolicited messages

1 - enable an unsolicited message when the TCP socket is connected or disconnect (default).

When unsolicited is enabled, an asynchronous TCP Socket connection is indicated to TE with unsolicited result code:

#TCPATRUN: <iphostaddress>

When unsolicited is enabled, the TCP socket disconnection is indicated to TE with unsolicited result code:

#TCPATRUN: <DISCONNECT>

Unsolicited is dumped on the instance that requested the service activation.

<timeout>:

Define in minutes the maximum time for a command execution. If timeout expires the module will be rebooted. The default value is 5 minutes. Range 1...5.

<authMode>:

determines the authentication procedure in server mode:

0 – (default) when connection is up, username and password (in this order and each of them followed by a Carriage Return) have to be sent to the module before the first AT command.

1 – when connection is up, the user receives a request for username and, if username is correct, a request for password. Then a message of "Login successfull" will close authentication phase.

Note: if username and/or password are not allowed (see AT#TCPATRUNAUTH) the connection will close immediately.



#TCPATRUNCFG– Set TCP AT Run Service Parameters	
	<p><retryCnt>: in client mode, at boot or after a socket disconnection, this parameter represents the number of attempts that are made in order to re-connect to the Host. Default: 0. Range 0...5.</p> <p><retryDelay>: in client mode, delay between one attempt and the other. In minutes. Default: 2. Range 1...3600.</p> <p>Note2: the current settings are stored in NVM.</p> <p>Note3: to start automatically the service when the module is powered-on, the automatic PDP context activation has to be set (see AT#SGACTCFG command).</p>
AT#TCPATRUNCFG?	<p>Read command returns the current settings of parameters in the format:</p> <p>#TCPATRUNCFG: <connId>,<instance>,<tcpPort>,<tcpHostPort>,<tcpHost>,<urcmod>,<timeout>,<authMode>,<retryCnt>,<retryDelay></p>
AT#TCPATRUNCFG=?	Test command returns the supported values for the TCPATRUNCFG parameters

3.5.6.3.5. TCP Run AT Service in listen (server) mode - #TCPATRUNL

#TCPATRUNL– Enables TCP AT Run Service in listen (server) mode	SELINT 2
<p>AT#TCPATRUNL= <mod></p>	<p>Set command enables/disables the TCP AT RUN service in server mode. When this service is enabled, the module tries to put itself in TCP listen state.</p> <p>Parameter: < mod > 0: Service Disabled 1: Service Enabled</p> <p>Note1: If SMSATRUN is active on the same instance (see AT#TCPATRUNCFG) the command will return ERROR.</p>



#TCPATRNL – Enables TCP AT Run Service in listen (server) mode	SELINT 2
	<p>Note2: when the service is active it is on a specific AT instance (see AT#TCPATRUNCFG), that instance cannot be used for any other scope. For example, if the multiplexer requests to establish the Instance, the request will be rejected.</p> <p>Note3: the current settings are stored in NVM.</p> <p>Note4: to start automatically the service when the module is powered-on, the automatic PDP context activation has to be set (see AT#SGACTCFG command).</p>
AT#TCPATRNL?	<p>Read command returns the current settings of <mode> and the value of <stat> in the format:</p> <p>#TCPATRNL: <mod>,<stat></p> <p>where:</p> <ul style="list-style-type: none"> <stat> - connection status 0 - not in listen 1 - in listen or active
AT#TCPATRNL =?	<p>Test command returns the supported values for the TCPATRNL parameters</p>

3.5.6.3.6. TCP AT Run Firewall List - #TCPATRUNFRWL

# TCPATRUNFRWL – TCP AT Run Firewall List	SELINT 2
AT#TCPATRUNFRWL = <action>, <ip_addr>, <net_mask>	<p>Set command controls the internal firewall settings for the TCPATRNL connection.</p> <p>Parameters:</p> <ul style="list-style-type: none"> <action> - command action 0 - remove selected chain 1 - add an ACCEPT chain 2 - remove all chains (DROP everything); <ip_addr> and <net_mask> has no meaning in this case. <ip_addr> - remote address to be added into the ACCEPT chain; string type, it can be any valid IP address in the format: xxx.xxx.xxx.xxx



# TCPATRUNFRWL – TCP AT Run Firewall List	SELINT 2
	<p><net_mask> - mask to be applied on the <ip_addr>; string type, it can be any valid IP address mask in the format: xxx.xxx.xxx.xxx</p> <p>Command returns OK result code if successful.</p> <p>Firewall general policy is DROP, therefore all packets that are not included into an ACCEPT chain rule will be silently discarded.</p> <p>When a packet comes from the IP address incoming_IP, the firewall chain rules will be scanned for matching with the following criteria:</p> <p>incoming_IP & <net_mask> = <ip_addr> & <net_mask></p> <p>If criteria is matched, then the packet is accepted and the rule scan is finished; if criteria is not matched for any chain the packet is silently dropped.</p> <p>Note1: A maximum of 5 firewall can be present at same time in the List.</p> <p>Note2: the firewall list is saved in NVM</p>
AT# TCPATRUNFRWL?	<p>Read command reports the list of all ACCEPT chain rules registered in the Firewall settings in the format:</p> <p>#TCPATRUNFRWL: <ip_addr>,<net_mask> #TCPATRUNFRWL: <ip_addr>,<net_mask> ... OK</p>
AT#TCPATRUNFRWL=?	Test command returns the allowed values for parameter <action> .

3.5.6.3.7. TCP AT Run Authentication Parameters List - #TCPATRUNAATH

# TCPATRUNAATH – TCP AT Run Authentication Parameters List	SELINT 2
AT# TCPATRUNAATH= <action>, <userid>, <passw>	<p>Execution command controls the authentication parameters for the TCPATRUN connection.</p> <p>Parameters:</p>



# TCPATRUNAATH – TCP AT Run Authentication Parameters List	SELINT 2
	<p><action> - command action 0 - remove selected chain 1 - add an ACCEPT chain 2 - remove all chains (DROP everything); < userid > and < passw > has no meaning in this case.</p> <p>< userid > - user to be added into the ACCEPT chain; string type, maximum length 50 < passw > - password of the user on the < userid >; string type, maximum length 50</p> <p>Command returns OK result code if successful.</p> <p>Note1: A maximum of 3 entry (password and userid) can be present at same time in the List.</p> <p>Note2: the Authentication Parameters List is saved in NVM.</p>
AT#TCPATRUNAATH?	<p>Read command reports the list of all ACCEPT chain rules registered in the Authentication settings in the format:</p> <pre>#TCPATRUNAATH: <user_id>,<passw> #TCPATRUNAATH: <user_id>,<passw> OK</pre>
AT#TCPATRUNAATH=?	<p>Test command returns the allowed values for parameter <action>.</p>

3.5.6.3.8. TCP AT Run in dial (client) mode - #TCPATRUND

#TCPATRUND – Enables TCP Run AT Service in dial (client) mode	SELINT 2
AT#TCPATRUND=<mod>	<p>Set command enables/disables the TCP AT RUN service in client mode. When this service is enabled, the module tries to open a connection to the Host (the Host is specified in AT#TCPATRUNCFG).</p> <p>Parameter: < mod > 0: Service Disabled 1: Service Enabled</p>



#TCPATRUND – Enables TCP Run AT Service in dial (client) mode	SELINT 2
	<p>Note1: If SMSATRUND is active on the same instance (see AT#TCPATRUNCFG) the command will return ERROR.</p> <p>Note2: when the service is active it is on a specific AT instance (see AT#TCPATRUNCFG), that instance cannot be used for any other scope. For example if the multiplexer request to establish the Instance, the request will be rejected.</p> <p>Note3: the current setting are stored in NVM</p> <p>Note4: to start automatically the service when the module is powered-on, the automatic PDP context activation has to be set (see AT#SGACTCFG command).</p> <p>Note5: if the connection closes or at boot, if service is enabled and context is active, the module will try to reconnect for the number of attempts specified in AT#TCPATRUNCFG; also the delay between one attempt and the other will be the one specified in AT#TCPATRUNCFG.</p>
AT# TCPATRUND?	<p>Read command returns the current settings of <mode> and the value of <stat> in the format:</p> <p>#TCPATRUND: <mod>,<stat></p> <p>where:</p> <ul style="list-style-type: none"> <stat> - connection status 0 - not connected 1 – connected or connecting at socket level 2 - not connected but still trying to connect, attempting every delay time (specified in AT#TCPATRUNCFG)
AT#TCPATRUND =?	Test command returns the supported values for the TCPATRUND parameters

3.5.6.3.9. Closing TCP Run AT Socket - #TCPATRUNCLOSE

#TCPATRUNCLOSE – Closes TCP Run AT Socket	SELINT 2
AT#TCPATRUNCLOSE	<p>Closes the socket used by TCP ATRUN service.</p> <p>Note: TCP ATRUN status is still enabled after this command, so the service re-starts automatically.</p>



#TCPATRUNCLOSE – Closes TCP Run AT Socket		SELINT 2
AT#TCPATRUNCLOSE =?	Test command returns OK	

3.5.6.3.10. TCP AT Run Command Sequence - #TCPATCMDSEQ

#TCPATCMDSEQ – For TCP Run AT Service, allows the user to give AT commands in sequence		SELINT 2
AT#TCPATCMDSEQ= <mod>	Set command enable/disable, for TCP Run AT service, a feature that allows giving more than one AT command without waiting for responses. It does not work with commands that uses the prompt '>' to receive the message body text (e.g. "at+cmgs", "at#semail") Parameter: < mod > 0: Service Disabled (default) 1: Service Enabled	
AT# TCPATCMDSEQ?	Read command returns the current settings of parameters in the format: #TCPATCMDSEQ: <mod>	
AT# TCPATCMDSEQ =?	Test command returns the supported values for the TCPATCMDSEQ parameters	

3.5.6.3.11. TCP Run AT service to a serial port - #TCPATCONSER

#TCPATCONSER – Connects the TCP Run AT service to a serial port		SELINT 2
AT#TCPATCONSER= <port>,<rate>	Set command sets the TCP Run AT in transparent mode, in order to have direct access to the serial port specified. Data will be transferred directly, without being elaborated, between the TCP Run AT service and the serial port specified. If the CMUX protocol is running the command will return ERROR. Parameter: < port > 0 – 1. Serial port to connect to. < rate > baud rate for data transfer. Allowed values are 300,1200,2400,4800,9600,19200,38400,57600,115200. Note1: the command has to be issued from the TCP ATRUN instance	



#TCPATCONSER – Connects the TCP Run AT service to a serial port		SELINT 2
	<p>Note2: After this command has been issued, if no error has occurred, then a "CONNECT" will be returned by the module to advise that the TCP ATRUN instance is in <i>online mode</i> and connected to the port specified.</p> <p>Note3: To exit from online mode and close the connection, the escape sequence (+++) has to be sent on the TCP ATRUN instance</p>	
AT# TCPATCONSER =?	Test command returns the supported values for the TCPATCONSER parameters	

3.5.6.3.12. Run AT command execution - #ATRUNDELAY

#ATRUNDELAY – Set the delay on Run AT command execution		SELINT 2
AT#ATRUNDELAY= <srv>,<delay>	<p>Set command enables the use of a delay before the execution of AT command received by Run AT service (TCP and SMS). It affects just AT commands given through Run AT service.</p> <p><srv></p> <ul style="list-style-type: none"> 0 – TCP Run AT service 1 - SMS Run AT service <p><delay> Value of the delay, in seconds. Range 0..30. Default value 0 for both services (TCP and SMS).</p> <p>Note1 - The use of the delay is recommended to execute some AT commands that require network interaction or switch between GSM and GPRS services. For more details see the RUN AT User Guide.</p> <p>Note2: The delay is valid till a new AT#ATRUNDELAY is set.</p>	
AT# ATRUNDELAY?	<p>Read command returns the current settings of parameters in the format:</p> <p>#ATRUNDELAY: 0, <dealyTCP> #ATRUNDELAY: 1, <dealySMS> OK</p>	
AT#ATRUNDELAY =?	Test command returns the supported values for the ATRUNDELAY parameters	



3.5.6.3.13. Enable EvMoni Service - #ENAEVMONI

#ENAEVMONI – Enable EvMoni Service		SELINT 2
AT#ENAEVMONI= <mod>	<p>Set command enables/disables the EvMoni service.</p> <p>Parameter: < mod ></p> <p>0: Service Disabled (default) 1: Service Enabled</p> <p>Note1: When the service is active on a specific AT instance, that instance cannot be used for any other scope, except for OTA service that has the highest priority. For example in the multiplexer request to establish the Instance, the request will be rejected.</p> <p>Note2: the current settings are stored in NVM.</p>	
AT#ENAEVMONI?	<p>Read command returns the current settings of <mode> and the value of <stat> in the format:</p> <p># ENAEVMONI: <mod>,<stat></p> <p>where: <stat> - service status 0 - not active (default) 1 - active</p>	
AT#ENAEVMONI =?	<p>Test command returns the supported values for the ENAEVMONI parameters</p>	

3.5.6.3.14. EvMoni Service parameter - #ENAEVMONICFG

#ENAEVMONICFG – Set EvMoni Service Parameters		SELINT 2
AT#ENAEVMONICFG=<i nstance> [,<urcmod> [,<timeout>]]	<p>Set command configures the EvMoni service.</p> <p>Parameter: <instance>: AT instance that will be used by the service to run the AT Command. Range 2 - 3. (Default: 3)</p> <p><urcmod>: 0 – disable unsolicited message 1 - enable an unsolicited message when an AT command is executed after an event is occurred (default)</p>	



#ENAEVMONICFG – Set EvMoni Service Parameters	SELINT 2
	<p>When unsolicited is enabled, the AT Command is indicated to TE with unsolicited result code:</p> <p>#EVMONI: <Text></p> <p>e.g.: #EVMONI: AT+CGMR;+CGSN;+GSN;+CCLK</p> <p>Unsolicited is dumped on the instance that requested the service activation.</p> <p><timeout>: It defines in minutes the maximum time for a command execution. If timeout expires the module will be rebooted. (Default: 5)</p> <p>Note 1: the current settings are stored in NVM.</p> <p>Note 2: the instance used for the EvMoni service is the same used for the SMS AT RUN service. Therefore, when the #ENAEVMONICFG sets the <instance> parameter, the change is reflected also in the <instance> parameter of the #SMSATRUNCFG command, and viceversa.</p> <p>Note 3: the set command returns ERROR if the command AT#ENAEVMONI? returns 1 as <mod> parameter or the command AT#SMSATRUNCFG returns 1 as <mod> parameter</p>
AT#ENAEVMONICFG?	<p>Read command returns the current settings of parameters in the format:</p> <p>#ENAEVMONICFG:<instance>,<urcmmod>,<timeout></p>
AT# ENAEVMONICFG =?	<p>Test command returns the supported values for the ENAEVMONICFG parameters</p>

3.5.6.3.15. Event Monitoring - #EVMONI

#EVMONI – Set the single Event Monitoring	SELINT 2
AT#EVMONI= <label>, <mode>, [,<paramType >	<p>Set command enables/disables the single event monitoring, configures the related parameter and associates the AT command</p> <p><label>: string parameter (that has to be enclosed between double quotes)</p>



#EVMONI – Set the single Event Monitoring	SELINT 2
<p>,<param>]</p>	<p>indicating the event under monitoring. It can assume the following values:</p> <ul style="list-style-type: none"> • VBATT - battery voltage monitoring • DTR - DTR monitoring • ROAM - roaming monitoring • CONTDEACT - context deactivation monitoring • RING - call ringing monitoring • STARTUP – module start-up monitoring • REGISTERED – network registration monitoring • GPIO1 – monitoring on a selected GPIO in the GPIO range • GPIO2 – monitoring on a selected GPIO in the GPIO range • GPIO3 – monitoring on a selected GPIO in the GPIO range • GPIO4 – monitoring on a selected GPIO in the GPIO range • GPIO5 – monitoring on a selected GPIO in the GPIO range • ADCH1 – ADC High Voltage monitoring • ADCL1 – ADC Low Voltage monitoring <p><mode>:</p> <ul style="list-style-type: none"> 0 – disable the single event monitoring (default) 1 – enable the single event monitoring <p>< paramType >: numeric parameter indicating the type of parameter contained in <param>. The 0 value indicates that <param> contains the AT command string to execute when the related event has occurred. Other values depend from the type of event.</p> <p><param>: it can be a numeric or string value depending on the value of <paramType> and on the type of event.</p> <p>If <paramType> is 0, then <param> is a string containing the AT command:</p> <ul style="list-style-type: none"> • It has to be enclosed between double quotes • It has to start with the 2 chars AT (or at) • If the string contains the character ", then it has to be replaced with the 3 characters \22 • the max string length is 96 characters • if it is an empty string, then the AT command is erased <ul style="list-style-type: none"> • If <label> is VBATT, <paramType> can assume values in the range 0 - 2. <ul style="list-style-type: none"> ○ if <paramType> = 1, <param> indicates the battery voltage threshold in the range 0 – 500, where one unit corresponds to 10 mV (therefore 500 corresponds to 5 V). (Default: 0) ○ if <paramType> = 2, <param> indicates the time interval in



#EVMONI – Set the single Event Monitoring	SELINT 2
	<p>seconds after that the voltage battery under the value specified with <paramType> = 1 causes the event. The range is 0 – 255. (Default: 0)</p> <ul style="list-style-type: none"> • If <label> is DTR, <paramType> can assume values in the range 0 - 2. <ul style="list-style-type: none"> ○ if <paramType> = 1, <param> indicates the status high or low under monitoring. The values are 0 (low) and 1 (high). (Default: 0) ○ if <paramType> = 2, <param> indicates the time interval in seconds after that the DTR in the status specified with <paramType> = 1 causes the event. The range is 0 – 255. (Default: 0) • If <label> is ROAM, <paramType> can assume only the value 0. The event under monitoring is the roaming state. • If <label> is CONTDEACT, <paramType> can assume only the value 0. The event under monitoring is the context deactivation. • If <label> is RING, <paramType> can assume values in the range 0 - 1. <ul style="list-style-type: none"> ○ if <paramType> = 1, <param> indicates the numbers of call rings after that the event occurs. The range is 1-50. (Default: 1) • If <label> is STARTUP, <paramType> can assume only the value 0. The event under monitoring is the module start-up. • If <label> is REGISTERED, <paramType> can assume only the value 0. The event under monitoring is the network registration (to home network or in roaming) after the start-up and the SMS ordering. • If <label> is GPIOX, <paramType> can assume values in the range 0 - 3. <ul style="list-style-type: none"> ○ if <paramType> = 1, <param> indicates the GPIO pin number; supported range is from 1 to a value that depends on the hardware. (Default: 1) ○ if <paramType> = 2, <param> indicates the status high or low under monitoring. The values are 0 (low) and 1 (high) . (Default: 0) ○ if <paramType> = 3, <param> indicates the time interval in seconds after that the selected GPIO pin in the status specified with <paramType> = 1 causes the event. The range is 0 – 255. (Default: 0) • If <label> is ADCH1, <paramType> can assume values in the range 0 - 3. <ul style="list-style-type: none"> ○ if <paramType> = 1, <param> indicates the ADC pin number; supported range is from 1 to a value that depends on the



AT Commands Reference Guide 80000ST10025a Rev. 9 – 2010-10-04

#EVMONI – Set the single Event Monitoring	SELINT 2
AT# EVMONI?	Read command returns the current settings for each event in the format: #EVMONI: <label>,<mode>,<param0>[,<param1>,<param2>,<param3>]] Where <param0>, <param1>, <param2> and <param3> are defined as before for <param> depending on <label> value
AT#EVMONI=?	Test command returns values supported as a compound value

3.5.6.3.16. Send Message - #CMGS

#CMGS - Send Message	SELINT 2
<i>(PDU Mode)</i> AT#CMGS= <length>,<pdu>	<p style="text-align: center;"><i>(PDU Mode)</i></p> Execution command sends to the network a message. Parameter: <length> - length of the PDU to be sent in bytes (excluding the SMSC address octets). 7..164 <pdu> - PDU in hexadecimal format (each octet of the PDU is given as two IRA character long hexadecimal number) and given in one



#CMGS - Send Message	SELINT 2
	<p>line.</p> <p>Note: when the length octet of the SMSC address (given in the <pdu>) equals zero, the SMSC address set with command +CSCA is used; in this case the SMSC Type-of-Address octet shall not be present in the <pdu>.</p> <p>If message is successfully sent to the network, then the result is sent in the format:</p> <p>#CMGS: <mr></p> <p>where <mr> - message reference number; 3GPP TS 23.040 TP-Message-Reference in integer format.</p> <p>Note: if message sending fails for some reason, an error code is reported.</p>
<p><i>(Text Mode)</i> AT#CMGS=<da> ,<text></p>	<p>(Text Mode)</p> <p>Execution command sends to the network a message.</p> <p>Parameters: <da> - destination address, string type represented in the currently selected character set (see +CSCS). <text> - text to send</p> <p>The entered text should be enclosed between double quotes and formatted as follows:</p> <ul style="list-style-type: none"> - if current <dcs> (see +CSMP) indicates that GSM03.38 default alphabet is used and current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set, then ME/TA converts the entered text into GSM alphabet, according to GSM 27.005, Annex A. - if current <dcs> (see +CSMP) indicates that 8-bit or UCS2 data coding scheme is used or current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set, the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. the 'asterisk' will be entered as 2A (IRA50 and IRA65) and this will be converted to an octet with integer value 0x2A)



#CMGS - Send Message	SELINT 2
	<p>If message is successfully sent to the network, then the result is sent in the format:</p> <p>#CMGS: <mr></p> <p>where <mr> - message reference number; 3GPP TS 23.040 TP-Message-Reference in integer format.</p> <p>Note: if message sending fails for some reason, an error code is reported.</p>
AT#CMGS=?	Test command returns the OK result code.
Note	To avoid malfunctions is suggested to wait for the #CMGS: <mr> or #CMS ERROR: <err> response before issuing further commands.
Reference	GSM 27.005

3.5.6.3.17. Write Message To Memory - #CMGW

#CMGW - Write Message To Memory	SELINT 2
<p><i>(PDU Mode)</i> AT#CMGW= <length>,<pdu></p>	<p style="text-align: center;">(PDU Mode)</p> <p>Execution command writes in the <memw> memory storage a new message.</p> <p>Parameter: <length> - length in bytes of the PDU to be written. 7..164 <pdu> - PDU in hexadecimal format (each octet of the PDU is given as two IRA character long hexadecimal number) and given in one line.</p> <p>If message is successfully written in the memory, then the result is sent in the format:</p> <p>#CMGW: <index></p> <p>where: <index> - message location index in the memory <memw>.</p>



#CMGW - Write Message To Memory	SELINT 2
	If message storing fails for some reason, an error code is reported.
<p><i>(Text Mode)</i> AT#CMGW=<da> ,<text></p>	<p>(Text Mode) Execution command writes in the <memw> memory storage a new message.</p> <p>Parameters: <da> - destination address, string type represented in the currently selected character set (see +CSCS). <text> - text to write</p> <p>The entered text should be enclosed between double quotes and formatted as follows:</p> <ul style="list-style-type: none"> - if current <dcs> (see +CSMP) indicates that GSM03.38 default alphabet is used and current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is not set, then ME/TA converts the entered text into GSM alphabet, according to GSM 27.005, Annex A. - if current <dcs> (see +CSMP) indicates that 8-bit or UCS2 data coding scheme is used or current <fo> (see +CSMP) indicates that 3GPP TS 23.040 TP-User-Data-Header-Indication is set, the entered text should consist of two IRA character long hexadecimal numbers which ME/TA converts into 8-bit octet (e.g. the 'asterisk' will be entered as 2A (IRA50 and IRA65) and this will be converted to an octet with integer value 0x2A) <p>If message is successfully written in the memory, then the result is sent in the format:</p> <p>#CMGW: <index> where: <index> - message location index in the memory <memw>.</p> <p>If message storing fails for some reason, an error code is reported.</p>
AT#CMGW=?	Test command returns the OK result code.
Reference	GSM 27.005
Note	To avoid malfunctions is suggested to wait for the #CMGW: <index> or +CMS ERROR: <err> response before issuing further commands.



3.5.6.4. FOTA Commands

3.5.6.4.1. OTA Set Network Access Point - #OTASNAP

#OTASNAP – OTA Set Network Access Point	SELINT 0/1
<p>AT#OTASNAP= <addr>[,<company_name>]</p>	<p>Set command specifies the SMS number that the module has to use to send the Remote Registration SM. If the current IMSI hasn't been yet registered, the Remote Registration SM is automatically sent.</p> <p>Parameters: <addr> - string parameter which specifies the phone number <company_name> - string parameter containing a client identifier</p> <p>Note1: a special form of the Set command, #OTASNAP="", causes the deletion of the SMS number</p> <p>Note2: the value of <addr> parameter can be overwritten from the OTA server by the Provisioning SMS</p> <p>Note3: a change of the value of <company_name> parameter causes a new FOTA Registration procedure</p> <p>Note4: if the <company_name> is an empty string, an ERROR is returned</p> <p>Note5: the setting is saved in NVM</p>
<p>AT#OTASNAP?</p>	<p>Read command reports the current settings in the format:</p> <p>#OTASNAP: <addr>[,<company_name>]</p>
<p>AT#OTASNAP</p>	<p>Execution command has the same effect as the Read command</p>
<p>AT#OTASNAP=?</p>	<p>Test command returns the maximum length of <addr> field and maximum length of <company_name> field. The format is:</p> <p>#OTASNAP: <nlength>,<tlength></p> <p>where: <nlength> - integer type value indicating the maximum length of field <addr> <tlength> - integer type value indicating the maximum length of field <company_name></p>



#OTASNAP – OTA Set Network Access Point		SELINT 0/1
Example	<pre>AT#OTASNAP="SMS Number","Client Alpha" OK AT#OTASNAP? #OTASNAP:"SMS Number","Client Alpha" OK AT#OTASNAP=? #OTASNAP: 21,15 OK</pre>	

#OTASNAP – OTA Set Network Access Point		SELINT 2
AT#OTASNAP= <addr>[,<company_name>]	<p>Set command specifies the SMS number that the module has to use to send the Remote Registration SM. If the current IMSI hasn't been yet registered, the Remote Registration SM is automatically sent.</p> <p>Parameters: <addr> - string parameter which specifies the phone number <company_name> - string parameter containing a client identifier</p> <p>Note1: a special form of the Set command, #OTASNAP="", causes the deletion of the SMS number</p> <p>Note2: the value of <addr> parameter can be overwritten from the OTA server by the Provisioning SMS</p> <p>Note3: a change of the value of <company_name> parameter causes a new FOTA Registration procedure</p> <p>Note4: if the <company_name> is an empty string, an ERROR is returned</p> <p>Note5: the setting is saved in NVM</p>	
AT#OTASNAP?	<p>Read command reports the current settings in the format:</p> <p>#OTASNAP: <addr>[,<company_name>]</p>	
AT#OTASNAP=?	<p>Test command returns the maximum length of <addr> field and maximum length of <company_name> field. The format is:</p> <p>#OTASNAP: <nlength>,<tlength></p> <p>where: <nlength> - integer type value indicating the maximum length of field <addr> <tlength> - integer type value indicating the maximum length of field</p>	



#OTASNAP – OTA Set Network Access Point	SELINT 2
	<company_name>
Example	<pre>AT#OTASNAP="SMS Number","Client Alpha" OK AT#OTASNAP? #OTASNAP:"SMS Number","Client Alpha" OK AT#OTASNAP=? #OTASNAP: 21,15 OK</pre>

3.5.6.4.2. OTA Set User Answer - #OTASUAN

#OTASUAN – OTA Set User Answer	SELINT 0/1
AT#OTASUAN= <response>[,<mode >[,<bfr>]]	<p>Set command:</p> <ol style="list-style-type: none"> enables or disables sending of unsolicited result code #OTAEV that asks the TE to accept or reject the Management Server request to download a firmware allows the TE to accept or reject the request <p>Parameters:</p> <p><response> - numeric parameter used to accept or reject the download request</p> <ul style="list-style-type: none"> 0 – the request is rejected 1 – the request is accepted 2 – the request is delayed indefinitely: the URC is prompted indefinitely until the request is accepted or reject <p><mode> - numeric parameter that controls the processing of unsolicited result code #OTAEV</p> <ul style="list-style-type: none"> 0 –buffer unsolicited result codes in the MT; if MT result code buffers is full, the oldest ones can be discarded. No codes are forwarded to the TE. 1 –discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE 2 –buffer unsolicited result codes in the MT when MT-TE link is reserved (e.g. in on-line data mode) and flush them to the TE when MT-TE link becomes available; otherwise forward them directly to the TE <p><bfr> - numeric parameter that controls the effect on buffered codes when <mode> 1 or 2 is entered</p> <ul style="list-style-type: none"> 0 – MT buffer of unsolicited result codes #OTAEV is cleared when <mode>



#OTASUAN – OTA Set User Answer	SELINT 0/1
	<p>1 or 2 is entered 1 – MT buffer of unsolicited result codes #OTAEV is flushed to TE when <mode> 1 or 2 is entered</p> <p>Note: the following unsolicited result codes and the corresponding events are defined:</p> <p>#OTAEV: Do you want to upgrade the firmware? A management server request to start the firmware upgrade. The user answer is expected</p> <p>#OTAEV: User Answer Timeout Expected User Answer not received within server defined time interval</p> <p>#OTAEV: Automatic Fw Upgrade Requested An automatic Fw Upgrade procedure has started</p> <p>#OTAEV: Start Fw Download The firmware download is started</p> <p>#OTAEV: Fw Download Complete The firmware download is finished</p> <p>#OTAEV: OTA Fw Upgrade Failed The Fw upgrade has failed</p> <p>#OTAEV: Module Upgraded To New Fw The Fw upgrade is successfully finished</p> <p>#OTAEV: Server notified about successfull FW Upgrade The final SMS has been sent to the server notifying the successful FW upgrade</p> <p>"#OTAEV: Registered" The module has registered itself to a server</p> <p>"#OTAEV: Not registered" The registration procedure has failed</p> <p>"#OTAEV: Company Name Registered" The company name is registered</p>



#OTASUAN – OTA Set User Answer	SELINT 0/1
	<p>"#OTAEV: Company Name not registered" The company name is not registered</p> <p>"#OTAEV: Provisioned" A server has provisioned the module</p> <p>"#OTAEV: Notified" A server has notified the module</p>
AT# OTASUAN?	<p>Read command reports the current settings in the format:</p> <p>#OTASUAN: ,<mode>,<bfr></p>
AT#OTASUAN	Execution command has the same effect as the Read command
AT#OTASUAN =?	Test command returns values supported as a compound value
Example	<pre>AT#OTASUAN= , 2 , 1 OK AT#OTASUAN? #OTASUAN: , 2 , 1 OK AT#OTASUAN =? #OTASUAN: (0-2) , (0-2) , (0 , 1) OK</pre>

#OTASUAN – OTA Set User Answer	SELINT 2
<p>AT#OTASUAN= <response>[,<mode>] >[,<bfr>]]</p>	<p>Set command:</p> <ul style="list-style-type: none"> a) enables or disables sending of unsolicited result code #OTAEV that asks the TE to accept or reject the Management Server request to download a firmware b) allows the TE to accept or reject the request <p>Parameters:</p> <p><response> - numeric parameter used to accept or reject the download request</p> <ul style="list-style-type: none"> 0 – the request is rejected 1 – the request is accepted 2 – the request is delayed indefinitely: the URC is prompted indefinitely until the request is accepted or reject <p><mode> - numeric parameter that controls the processing of unsolicited result code #OTAEV</p> <ul style="list-style-type: none"> 0 –buffer unsolicited result codes in the MT; if MT result code buffers is



#OTASUAN – OTA Set User Answer	SELINT 2
	<p>full, the oldest ones can be discarded. No codes are forwarded to the TE.</p> <p>1 –discard unsolicited result codes when MT-TE link is reserved (e.g. in on-line data mode); otherwise forward them directly to the TE</p> <p>2 –buffer unsolicited result codes in the MT when MT-TE link is reserved (e.g. in on-line data mode) and flush them to the TE when MT-TE link becomes available; otherwise forward them directly to the TE</p> <p><bfr> - numeric parameter that controls the effect on buffered codes when <mode> 1 or 2 is entered</p> <p>0 – MT buffer of unsolicited result codes #OTAEV is cleared when <mode> 1 or 2 is entered</p> <p>1 – MT buffer of unsolicited result codes #OTAEV is flushed to TE when <mode> 1 or 2 is entered</p> <p>Note: the following unsolicited result codes and the corresponding events are defined:</p> <p>#OTAEV: Do you want to upgrade the firmware? A management server request to start the firmware upgrade. The user answer is expected</p> <p>#OTAEV: User Answer Timeout Expected User Answer not received within server defined time interval</p> <p>#OTAEV: Automatic Fw Upgrade Requested An automatic Fw Upgrade procedure has started</p> <p>#OTAEV: Start Fw Download The firmware download is started</p> <p>#OTAEV: Fw Download Complete The firmware download is finished</p> <p>#OTAEV: OTA Fw Upgrade Failed The Fw upgrade has failed</p> <p>#OTAEV: Module Upgraded To New Fw The Fw upgrade is successfully finished</p> <p>#OTAEV: Server notified about successful FW Upgrade The final SMS has been sent to the server notifying the successful FW upgrade</p>



#OTASUAN – OTA Set User Answer	SELINT 2
	<p>"#OTAEV: Registered" The module has registered itself to a server</p> <p>"#OTAEV: Not registered" The registration procedure has failed</p> <p>"#OTAEV: Company Name Registered" The company name is registered</p> <p>"#OTAEV: Company Name not registered" The company name is not registered</p> <p>"#OTAEV: Provisioned" A server has provisioned the module</p> <p>"#OTAEV: Notified" A server has notified the module</p>
AT# OTASUAN?	<p>Read command reports the current settings in the format:</p> <p>#OTASUAN: ,<mode>,<bfr></p>
AT#OTASUAN =?	<p>Test command returns values supported as a compound value</p>
Example	<pre>AT#OTASUAN= , 2 , 1 OK AT#OTASUAN? #OTASUAN: , 2 , 1 OK AT#OTASUAN =? #OTASUAN: (0-2) , (0-2) , (0 , 1) OK</pre>

3.5.6.4.3. OTA Set Ring Indicator - #OTASETRI

#OTASETRI - OTA Set Ring Indicator	SELINT 0/1
------------------------------------	------------



#OTASETRI - OTA Set Ring Indicator		SELINT 0/1
AT#OTASETRI= [<n>]	<p>Set command enables/disables the Ring Indicator pin response to a manual OTA server request to start the firmware upgrade. If enabled, a negative going pulse is generated when the URC “#OTAEV: Do you want to upgrade the firmware?” is prompted (see AT#OTASUAN command). The duration of this pulse is determined by the value of <n>.</p> <p>Parameter: <n> - RI enabling 0 - disables RI pin response when the URC “#OTAEV: Do you want to upgrade the firmware?” is prompted (factory default) 50..1150 - enables RI pin response. The value of <n> is the duration in ms of the pulse generated when the URC “#OTAEV: Do you want to upgrade the firmware?” is prompted.</p> <p>Note: if the <response> parameter of the AT#OTASUAN command has the value 2, then the URC is prompted indefinitely until the Fw update request is accepted or reject and, for every URC, a pulse is generated.</p> <p>Note: the setting is saved in the profile parameters</p>	
AT#OTASETRI?	<p>Read command reports the duration in ms of the pulse generated when the URC “#OTAEV: Do you want to upgrade the firmware?” is prompted, in the format:</p> <p>#OTASETRI: <n></p> <p>Note: as seen before, the value <n>=0 means that the RI pin response to the URC is disabled.</p>	
AT#OTASETRI	Execution command has the same effect as the Read command	
AT#OTASETRI=?	Reports the range of supported values for parameter <n>	

#OTASETRI - OTA Set Ring Indicator		SELINT 2
AT#OTASETRI= [<n>]	<p>Set command enables/disables the Ring Indicator pin response to a manual OTA server request to start the firmware upgrade. If enabled, a negative going pulse is generated when the URC “#OTAEV: Do you want to upgrade the firmware?” is prompted (see AT#OTASUAN command). The duration of this pulse is determined by the value of <n>.</p> <p>Parameter: <n> - RI enabling 0 - disables RI pin response when the URC “#OTAEV: Do you want to</p>	



#OTASETRI - OTA Set Ring Indicator		SELINT 2
	<p><i>upgrade the firmware?</i> is prompted (factory default) 50..1150 - enables RI pin response. The value of <n> is the duration in ms of the pulse generated when the URC "<i>#OTAEV: Do you want to upgrade the firmware?</i>" is prompted.</p> <p>Note: if the <response> parameter of the AT#OTASUAN command has the value 2, then the URC is prompted indefinitely until the Fw update request is accepted or reject and, for every URC, a pulse is generated.</p> <p>Note: the setting is saved in the profile parameters</p>	
AT#OTASETRI?	<p>Read command reports the duration in ms of the pulse generated when the URC "<i>#OTAEV: Do you want to upgrade the firmware?</i>" is prompted, in the format:</p> <p>#OTASETRI: <n></p> <p>Note: as seen before, the value <n>=0 means that the RI pin response to the URC is disabled.</p>	
AT#OTASETRI=?	Reports the range of supported values for parameter <n>	

3.5.6.5. Multisocket AT Commands

3.5.6.5.1. Socket Status - #SS

#SS - Socket Status	SELINT 2
AT#SS[=<connId>]	<p>Execution command reports the current status of the socket:</p> <p>Parameters: <connId> - socket connection identifier 1..6</p> <p>The response format is:</p> <p>#SS: <connId>,<state>,<locIP>,<locPort>,<remIP>,<remPort></p> <p>where: <connId> - socket connection identifier, as before <state> - actual state of the socket: 0 - Socket Closed. 1 - Socket with an active data transfer connection. 2 - Socket suspended.</p>



#SS - Socket Status	SELINT 2
	<p>3 - Socket suspended with pending data. 4 - Socket listening. 5 - Socket with an incoming connection. Waiting for the user accept or shutdown command.</p> <p><locIP> - IP address associated by the context activation to the socket. <locPort> - two meanings: - the listening port if we put the socket in listen mode. - the local port for the connection if we use the socket to connect to a remote machine.</p> <p><remIP> - when we are connected to a remote machine this is the remote IP address. <remPort> - it is the port we are connected to on the remote machine.</p> <p>Note: issuing #SS<CR> causes getting information about status of all the sockets; the response format is:</p> <p>#SS: <connId1>,<state1>,<locIP1>,<locPort1>,<remIP1>,<remPort1> <CR><LF></p> <p>...</p> <p>#SS: <connId6>,<state6>,<locIP6>,<locPort6>,<remIP6>,<remPort6></p>
AT#SS=?	Test command reports the range for parameter <connId>.
Example	<pre>AT#SS #SS: 1,3,91.80.90.162,61119,88.37.127.146,10510 #SS: 2,4,91.80.90.162,1000 #SS: 3,0 #SS: 4,0 #SS: 5,3,91.80.73.70,61120,88.37.127.146,10509 #SS: 6,0 OK Socket 1: opened from local IP 91.80.90.162/local port 61119 to remote IP 88.37.127.146/remote port 10510 is suspended with pending data Socket 2: listening on local IP 91.80.90.162/local port 1000 Socket 5: opened from local IP 91.80.73.70/local port 61120 to remote IP 88.37.127.146/remote port 10509 is suspended with pending data AT#SS=2</pre>



#SS - Socket Status	SELINT 2
	<p>#SS: 2,4,91.80.90.162,1000</p> <p>OK</p> <p>We have information only about socket number 2</p>

3.5.6.5.2. Socket Info - #SI

#SI - Socket Info	SELINT 2
<p>AT#SI[=<connId>]</p>	<p>Execution command is used to get information about socket data traffic.</p> <p>Parameters: <connId> - socket connection identifier 1..6</p> <p>The response format is:</p> <p>#SI: <connId>,<sent>,<received>,<buff_in>,<ack_waiting></p> <p>where:</p> <ul style="list-style-type: none"> <connId> - socket connection identifier, as before <sent> - total amount (in bytes) of sent data since the last time the socket connection identified by <connId> has been opened <received> - total amount (in bytes) of received data since the last time the socket connection identified by <connId> has been opened <buff_in> - total amount (in bytes) of data just arrived through the socket connection identified by <connId> and currently buffered, not



#SI - Socket Info	SELINT 2
	<p>yet read</p> <p><ack_waiting> - total amount (in bytes) of sent and not yet acknowledged data since the last time the socket connection identified by <connId> has been opened</p> <p>Note: not yet acknowledged data are available only for TCP connections; the value <ack_waiting> is always 0 for UDP connections.</p> <p>Note: issuing #SI<CR> causes getting information about data traffic of all the sockets; the response format is:</p> <p>#SI: <connId1>,<sent1>,<received1>,<buff_in1>,<ack_waiting1> <CR><LF></p> <p>...</p> <p>#SI: <connId6>,<sent6>,<received6>,<buff_in6>,<ack_waiting6></p>
AT#SI=?	Test command reports the range for parameter <connId> .
Example	<pre>AT#SI #SI: 1,123,400,10,50 #SI: 2,0,100,0,0 #SI: 3,589,100,10,100 #SI: 4,0,0,0,0 #SI: 5,0,0,0,0 #SI: 6,0,98,60,0 OK <i>Sockets 1,2,3,6 are opened with some data traffic. For example socket 1 has 123 bytes sent, 400 bytes received, 10 byte waiting to be read and 50 bytes waiting to be acknowledged from the remote side.</i> AT#SI=1 #SI: 1,123,400,10,50 OK <i>We have information only about socket number 1</i></pre>

3.5.6.5.3. Context Activation - #SGACT

#SGACT - Context Activation	SELINT 2
AT#SGACT=<cid>,<stat>[,<userId>,<pwd>]	Execution command is used to activate or deactivate either the GSM context or the specified PDP context.



#SGACT - Context Activation	SELINT 2
	<p>Parameters:</p> <p><cid> - PDP context identifier 0 - specifies the GSM context 1..5 - numeric parameter which specifies a particular PDP context definition</p> <p><stat> 0 - deactivate the context 1 - activate the context</p> <p><userId> - string type, used only if the context requires it</p> <p><pwd> - string type, used only if the context requires it</p> <p>Note: context activation/deactivation returns ERROR if there is not any socket associated to it (see AT#SCFG).</p> <p>Note: after the GSM context has been activated, you can use either Multisocket, or FTP or Email AT commands to send/receive TCP/IP packets via GSM.</p> <p>Note: to deactivate the GSM context, AT#SGACT=0,0 has to be issued on the same serial port used when the context was activated.</p> <p>Note: GSM context activation is affected by AT+CBST command. In particular, GSM context activation is just allowed with "non transparent" data calls.</p> <p>Note: activating a GSM context while a PDP context is already activated causes the PDP context to be suspended.</p> <p>Note: if GSM context is active, it is not allowed any PDP context activation.</p>
<p>AT#SGACT?</p>	<p>Returns the state of all the contexts that have been defined through the commands +CGDCONT or #GSMCONT</p> <p>#SGACT: <cid1>,<Stat1><CR><LF> ... #SGACT: <cid5>,<Stat5></p> <p>where: <cid<i>n</i>> - as <cid> before <stat<i>n</i>> - context status 0 - context deactivated 1 - context activated</p>
<p>AT#SGACT=?</p>	<p>Test command reports the range for the parameters <cid> and <stat></p>



#SGACT - Context Activation		SELINT 2
Note	It is strongly recommended to use the same command (e.g. #SGACT) to activate the context, deactivate it and interrogate about its status.	

3.5.6.5.4. Socket Shutdown - #SH

#SH - Socket Shutdown		SELINT 2
AT#SH=<connId>	This command is used to close a socket. Parameter: <connId> - socket connection identifier 1..6	
AT#SH=?	Test command reports the range for parameter <connId>.	

3.5.6.5.5. Socket Configuration - #SCFG

#SCFG - Socket Configuration		SELINT 2
AT#SCFG= <connId>,<cid>, <pktSz>,<maxTo>, <connTo>,<txTo>	Set command sets the socket configuration parameters. Parameters: <connId> - socket connection identifier 1..6 <cid> - PDP context identifier 0 - specifies the GSM context 1..5 - numeric parameter which specifies a particular PDP context definition <pktSz> - packet size to be used by the TCP/UDP/IP stack for data sending. 0 - select automatically default value(300). 1..1500 - packet size in bytes. <maxTo> - exchange timeout (or socket inactivity timeout); if there's no data exchange within this timeout period the connection is closed. 0 - no timeout 1..65535 - timeout value in seconds (default 90 s.) <connTo> - connection timeout; if we can't establish a connection to the remote within this timeout period, an error is raised. 10..1200 - timeout value in hundreds of milliseconds (default 600) <txTo> - data sending timeout; after this period data are sent also if they're less than max packet size. 0 - no timeout 1..255 - timeout value in hundreds of milliseconds (default 50)	



#SCFG - Socket Configuration		SELINT 2
	Note: these values are automatically saved in NVM.	
AT#SCFG?	Read command returns the current socket configuration parameters values for all the six sockets, in the format: #SCFG: <connId1>,<cid1>,<pktsz1>,<maxTo1>,<connTo1>,<txTo1> <CR><LF> ... #SCFG: <connId6>,<cid6>,<pktsz6>,<maxTo6>,<connTo6>,<txTo6> <CR><LF>	
AT#SCFG=?	Test command returns the range of supported values for all the subparameters.	
Example	<pre>at#scfg? #SCFG: 1,1,300,90,600,50 #SCFG: 2,2,300,90,600,50 #SCFG: 3,2,250,90,600,50 #SCFG: 4,1,300,90,600,50 #SCFG: 5,1,300,90,600,50 #SCFG: 6,1,300,90,600,50 OK</pre>	

3.5.6.5.6. Socket Configuration Extended - #SCFGEXT

#SCFGEXT - Socket Configuration Extended		SELINT 2
AT#SCFGEXT= <conned>,<srMode>, <recvDataMode>, <keepalive>, [, <ListenAutoRsp> [, <sendDataMode>]]	Set command sets the socket configuration extended parameters. Parameters: <connId> - socket connection identifier 1..6 <srMode> - SRing unsolicited mode 0 - Normal (default): SRING : <connId> where <connId> is the socket connection identifier 1 - Data amount: SRING : <connId>,<recData> where <recData> is the amount of data received on the socket connection number <connId> 2 - Data view: SRING : <connId>,<recData>,<data> same as before and	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p><data> is data received displayed following <dataMode> value</p> <p><recvDataMode> - data view mode for received data in command mode(AT#SRECV or <srMode> = 2) 0- text mode (default) 1- hexadecimal mode</p> <p><keepalive> - Set the TCP Keepalive value in minutes 0 – Deactivated (default) 1 – 240 – Keepalive time in minutes</p> <p><ListenAutoRsp> - Set the listen auto-response mode, that affects the commands AT#SL and AT#SLUDP 0 - Deactivated (default) 1 – Activated</p> <p><sendDataMode> - data mode for sending data in command mode(AT#SEND) 0 - data represented as text (default) 1 - data represented as sequence of hexadecimal numbers (from 00 to FF) Each octet of the data is given as two IRA character long hexadecimal number</p> <p>Note: these values are automatically saved in NVM. Note: Keepalive is available only on TCP connections.</p> <p>Note: for the behaviour of AT#SL and AT#SLUDP in case of auto-response mode or in case of no auto-response mode, see the description of the two commands.</p>
<p>AT#SCFGEXT?</p>	<p>Read command returns the current socket extended configuration parameters values for all the six sockets, in the format:</p> <p>#SCFGEXT:<connId1>,<srMode1>,<dataMode1>,<keepalive1>,<ListenAutoRsp1>,0<CR><LF></p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<pre>... #SCFGEXT:<connId6>, <srMode6>,<dataMode6>,<keepalive6>, <ListenAutoRsp6>,0<CR><LF></pre>
AT#SCFGEXT=?	Test command returns the range of supported values for all the subparameters.
Example	<p>Socket 1 set with data view string, text data mode, a keepalive time of 30 minutes and listen auto-response set.</p> <p>Socket 3 set with data amount string, hex rcv data mode, no keepalive and listen auto-response not set.</p> <p>Socket 4 set with hex rcv and send data mode</p> <pre>at#scfgext? #SCFGEXT: 1,2,0,30,1,0 #SCFGEXT: 2,0,0,0,0,0 #SCFGEXT: 3,1,1,0,0,0 #SCFGEXT: 4,0,1,0,0,1 #SCFGEXT: 5,0,0,0,0,0 #SCFGEXT: 6,0,0,0,0,0 OK</pre>

3.5.6.5.7. Socket configuration Extended 2 - #SCFGEXT2

#SCFGEXT2 - Socket Configuration Extended	
AT#SCFGEXT2= <connId>,<bufferStart> [,<abortConnAttempt> [,<unused_B > [,<unused_C >[,<unused_D>]]]]	<p>Set command sets the socket configuration extended parameters for features not included in #SCFGEXT command.</p> <p>Parameters:</p> <p><connId> - socket connection identifier 1..6</p> <p><bufferStart> - Set the sending timeout method based on new data received from the serial port. (<txTo> timeout value is set by #SCFG command) Restart of transmission timer will be done when new data are received from the serial port.</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p>0 - old behaviour for transmission timer (#SCFG command 6th parameter old behaviour, start only first time if new data are received from the serial port) 1 - new behaviour for transmission timer: restart at each new byte received from the serial port</p> <p>Note: is necessary to avoid overlapping of the two methods. Enabling new method, the old method for transmission timer(#SCFG) is automatically disabled to avoid overlapping.</p> <p><abortConnAttempt> - Enable connection attempt(#SD/#SKTD/#SKTOP) abort before CONNECT(online mode) or OK(command mode)</p> <p>0 – Not possible to interrupt connection attempt 1 – It is possible to interrupt the connection attempt (<connTo> set by #SCFG or DNS resolution running if required)</p> <p>and give back control to AT interface by reception of a character. As soon as the control has been given to the AT interface the ERROR message will be received on the interface itself.</p> <p>Note: values are automatically saved in NVM.</p>
<p>AT#SCFGEXT2?</p>	<p>Read command returns the current socket extended configuration parameters values for all the six sockets, in the format:</p> <p>#SCFGEXT2:<connId1>,<bufferStart1>,0,0,0,0<CR><LF> ... #SCFGEXT2:<connId6>,<bufferStart6>,0,0,0,0<CR><LF></p>
<p>AT#SCFGEXT2=?</p>	<p>Test command returns the range of supported values for all the subparameters.</p>
<p>Example</p>	<p>AT#SCFGEXT2=1,1 OK</p> <p>AT#SCFGEXT2=2,1 OK</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<pre> AT#SCFGEXT2? #SCFGEXT2: 1,1,0,0,0,0 #SCFGEXT2: 2,1,0,0,0,0 #SCFGEXT2: 3,0,0,0,0,0 #SCFGEXT2: 4,0,0,0,0,0 #SCFGEXT2: 5,0,0,0,0,0 #SCFGEXT2: 6,0,0,0,0,0 OK AT#SCFG? #SCFG: 1,1,300,90,600,50 #SCFG: 2,1,300,90,600,50 #SCFG: 3,1,300,90,600,50 #SCFG: 4,2,300,90,600,50 #SCFG: 5,2,300,90,600,50 #SCFG: 6,2,300,90,600,50 OK AT#SCFG=1,1,300,90,600,30 OK Current configuration: socket with connId 1 and 2 are configured with new transmission timer behaviour. <txTo> corresponding value has been changed(#SCFG) for connId 1, for connId 2 has been left to default value. </pre>
--	--

3.5.6.5.8. Socket Dial - #SD

#SD - Socket Dial	SELINT 2
<pre> AT#SD=<connId>, <txProt>,<rPort>, <lPaddr> [,<closureType> [,<lPort> [,<connMode>]]] </pre>	<p>Execution command opens a remote connection via socket.</p> <p>Parameters:</p> <p><connId> - socket connection identifier 1..6</p> <p><txProt> - transmission protocol 0 - TCP 1 - UDP</p>



#SD - Socket Dial	SELINT 2
	<p><rPort> - remote host port to contact 1..65535</p> <p><IPaddr> - address of the remote host, string type. This parameter can be either:</p> <ul style="list-style-type: none"> - any valid IP address in the format: "xxx.xxx.xxx.xxx" - any host name to be solved with a DNS query <p><closureType> - socket closure behaviour for TCP 0 - local host closes immediately when remote host has closed (default) 255 - local host closes after an escape sequence (+++)</p> <p><lPort> - UDP connections local port 1..65535</p> <p><connMode> - Connection mode 0 - online mode connection (default) 1 - command mode connection</p> <p>Note: <closureType> parameter is valid for TCP connections only and has no effect (if used) for UDP connections.</p> <p>Note: <lPort> parameter is valid for UDP connections only and has no effect (if used) for TCP connections.</p> <p>Note: if we set <connMode> to online mode connection and the command is successful we enter in online data mode and we see the intermediate result code CONNECT. After the CONNECT we can suspend the direct interface to the socket connection (nb the socket stays open) using the escape sequence (+++): the module moves back to command mode and we receive the final result code OK after the suspension. After such a suspension, it's possible to resume it in every moment (unless the socket inactivity timer timeouts, see #SCFG) by using the #SO command with the corresponding <connId>.</p> <p>Note: if we set <connMode> to command mode connection and the command is successful, the socket is opened and we remain in command mode and we see the result code OK.</p> <p>Note: if there are input data arrived through a connected socket and not yet read because the module entered command mode before reading them (after an escape sequence or after #SD has been issued with <connMode> set to command mode connection), these data are buffered and we receive the SRING URC (SRING presentation format depends on the last #SCFGEXT setting); it's possible to read these data afterwards issuing #SRECV. Under the same hypotheses it's possible to send data</p>



#SD - Socket Dial	SELINT 2
	<p>while in command mode issuing #SEND</p> <p>Note: resume of the socket(#SO) after suspension or closure(#SH) has to be done on the same instance on which the socket was opened through #SD. In fact, suspension has been done on the instance itself.</p>
AT#SD=?	Test command reports the range of values for all the parameters.
Example	<p><i>Open socket 1 in online mode</i></p> <pre>AT#SD=1,0,80,"www.google.com",0,0,0 CONNECT ...</pre> <p><i>Open socket 1 in command mode</i></p> <pre>AT#SD=1,0,80,"www.google.com",0,0,1 OK</pre>

3.5.6.5.9. Socket Restore - #SO

#SO - Socket Restore	SELINT 2
AT#SO=<connId>	<p>Execution command resumes the direct interface to a socket connection which has been suspended by the escape sequence.</p> <p>Parameter: <connId> - socket connection identifier 1..6</p>
AT#SO=?	Test command reports the range of values for <connId> parameter.

3.5.6.5.10. Socket Listen - #SL

#SL - Socket Listen	SELINT 2
AT#SL=<connId>,<listenState>,<listenPort>>[,<closure type>]	<p>This command opens/closes a socket listening for an incoming TCP connection on a specified port.</p> <p>Parameters: <connId> - socket connection identifier 1..6 <listenState> - 0 - closes socket listening 1 - starts socket listening <listenPort> - local listening port</p>



#SL - Socket Listen	SELINT 2
	<p>1..65535</p> <p><closure type> - socket closure behaviour for TCP 0 - local host closes immediately when remote host has closed (default) 255 - local host closes after an escape sequence (+++)</p> <p>Note: if successful, the command returns a final result code OK. If the ListenAutoRsp flag has not been set through the command AT#SCFGEXT (for the specific conId), then, when a TCP connection request comes on the input port, if the sender is not filtered by internal firewall (see #FRWL), an URC is received:</p> <p>+SRING : <conId></p> <p>Afterwards we can use #SA to accept the connection or #SH to refuse it.</p> <p>If the ListenAutoRsp flag has been set, then, when a TCP connection request comes on the input port, if the sender is not filtered by the internal firewall (see command #FRWL), the connection is automatically accepted: the CONNECT indication is given and the modem goes into online data mode.</p> <p>If the socket is closed by the network the following URC is received:</p> <p>#SL: ABORTED</p> <p>Note: when closing the listening socket <listenPort> is a don't care parameter</p>
AT#SL?	Read command returns all the actual listening TCP sockets.
AT#SL=?	Test command returns the range of supported values for all the subparameters.
Example	<p><i>Next command opens a socket listening for TCP on port 3500 without.</i></p> <p>AT#SL=1,1,3500 OK</p>

3.5.6.5.11. Socket Listen UDP - #SLUDP

#SLUDP - Socket Listen UDP	SELINT 2
AT#SLUDP=<conId>	This command opens/closes a socket listening for an incoming UDP



#SLUDP - Socket Listen UDP	SELINT 2
<p>>, <listenState>, <listenPort></p>	<p>connection on a specified port.</p> <p>Parameters: <connId> - socket connection identifier 1..6 <listenState> - 0 - closes socket listening 1 - starts socket listening <listenPort> - local listening port 1..65535</p> <p>Note: if successful, the command returns a final result code OK. If the ListenAutoRsp flag has not been set through the command AT#SCFGEXT (for the specific connId), then, when an UDP connection request comes on the input port, if the sender is not filtered by internal firewall (see #FRWL), an URC is received:</p> <p>+SRING : <connId></p> <p>Afterwards we can use #SA to accept the connection or #SH to refuse it.</p> <p>If the ListenAutoRsp flag has been set, then, when an UDP connection request comes on the input port, if the sender is not filtered by the internal firewall (see command #FRWL), the connection is automatically accepted: the CONNECT indication is given and the modem goes into online data mode.</p> <p>If the socket is closed by the network the following URC is received:</p> <p>#SLUDP: ABORTED</p> <p>Note: when closing the listening socket <listenPort> is a don't care parameter</p>
AT#SLUDP?	Read command returns all the actual listening UDP sockets.
AT#SLUDP=?	Test command returns the range of supported values for all the subparameters.
Example	<p><i>Next command opens a socket listening for UDP on port 3500.</i></p> <p>AT#SLUDP=1,1,3500 OK</p>



#SLUDP - Socket Listen UDP	SELINT 2

3.5.6.5.12. Socket Accept - #SA

#SA - Socket Accept	SELINT 2
AT#SA=<connId> [,<connMode>]	<p>Execution command accepts an incoming socket connection after an URC SRING: <connId></p> <p>Parameter: <connId> - socket connection identifier 1..6 <connMode> - Connection mode, as for command #SD. 0 - online mode connection (default) 1 - command mode connection</p> <p>Note: the SRING URC has to be a consequence of a #SL issue.</p> <p>Note: setting the command before to having received a SRING will result in an ERROR indication, giving the information that a connection request has not yet been received</p>
AT#SA=?	Test command reports the range of values for all the parameters.

3.5.6.5.13. Receive Data In Command Mode - #SRECV

#SRECV - Receive Data In Command Mode	SELINT 2
AT#SRECV= <connId>, <maxByte>	<p>Execution command permits the user to read data arrived through a connected socket, but buffered and not yet read because the module entered command mode before reading them; the module is notified of these data by a SRING URC, whose presentation format depends on the last #SCFGEXT setting.</p> <p>Parameters: <connId> - socket connection identifier 1..6 <maxByte> - max number of bytes to read 1..1500</p> <p>Note: issuing #SRECV when there's no buffered data raises an error.</p>



#SRECV - Receive Data In Command Mode	SELINT 2
AT#SRECV=?	Test command returns the range of supported values for parameters < connId > and < maxByte >
Example	<p>SRING URC (<srMode> be 0, <dataMode> be 0) telling data have just come through connected socket identified by <connId>=1 and are now buffered SRING: 1</p> <p><i>Read in text format the buffered data</i> AT#SRECV=1,15 #SRECV: 1,15 stringa di test</p> <p>OK</p> <p>SRING URC (<srMode> be 1, <dataMode> be 1) telling 15 bytes data have just come through connected socket identified by <connId>=2 and are now buffered SRING: 2,15</p> <p><i>Read in hexadecimal format the buffered data</i> AT#SRECV=2,15 #SRECV: 2,15 737472696e67612064692074657374</p> <p>OK</p> <p>SRING URC (<srMode> be 2, <dataMode> be 0) displaying (in text format) 15 bytes data that have just come through connected socket identified by <connId>=3; it's no necessary to issue #SRECV to read the data; no data remain in the buffer after this URC SRING: 3,15, stringa di test</p>

3.5.6.5.14. Send Data In Command Mode - #SEND

#SEND - Send Data In Command Mode	SELINT 2
AT#SEND= <connId>	<p>Execution command permits, while the module is in command mode, to send data through a connected socket.</p> <p>Parameters: <connId> - socket connection identifier 1..6</p> <p>The device responds to the command with the prompt '>' and waits for the data to send. To complete the operation send Ctrl-Z char (0x1A hex); to exit without</p>



#SSEND - Send Data In Command Mode	SELINT 2
	<p>writing the message send ESC char (0x1B hex).</p> <p>If data are successfully sent, then the response is OK. If data sending fails for some reason, an error code is reported</p> <p>Note: the maximum number of bytes to send is 1024; trying to send more data will cause the surplus to be discarded and lost.</p> <p>If <sendDataMode> has been set to 1 by AT#SCFGEXT, then the #SSEND support the Hex data mode representation. The data shall be hexadecimal format (each octet of the data is given as two IRA character long hexadecimal number) and given in one line.</p> <p>Note: it's possible to use #SSEND only if the connection was opened by #SD, else the ME is raising an error.</p> <p>Note: a byte corresponding to BS char(0x08) is treated with its corresponding meaning; therefore previous byte will be cancelled(and BS char itself will not be sent)</p>
AT#SSEND=?	Test command returns the range of supported values for parameter < connId >
Example	<p><i>Send data through socket number 2</i></p> <pre>AT#SSEND=2 >Test<CTRL-Z> OK</pre>

3.5.6.5.15. Send data in Command Mode extended - #SENDEXT

#SENDEXT - Send Data In Command Mode extended	SELINT 2
AT#SENDEXT= <connId>, <bytestosend>	<p>Execution command permits, while the module is in command mode, to send data through a connected socket including all possible octets (from 0x00 to 0xFF).</p> <p>Parameters: <connId> - socket connection identifier 1..6</p>



#SENDEXT - Send Data In Command Mode extended	SELINT 2
	<p>< bytestosend > - number of bytes to be sent Please refer to test command for range</p> <p>The device responds to the command with the prompt '>' and waits for the data to send. When <bytestosend> bytes have been sent, operation is automatically completed. If data are successfully sent, then the response is OK. If data sending fails for some reason, an error code is reported.</p> <p>Note: it's possible to use #SENDEXT only if the connection was opened by #SD, else the ME is raising an error.</p> <p>Note: all special characters are sent like a generic byte. (For instance: 0x08 is simply sent through the socket and don't behave like a BS, i.e. previous character is not deleted)</p>
<p>AT#SEND=?</p>	<p>Test command returns the range of supported values for parameters < connd > and <bytestosend></p>
<p>Example</p>	<p>Open the socket in command mode: at#sd=1,0,<port>,"IP address",0,0,1 OK</p> <p>Give the command specifying total number of bytes as second parameter: at#ssendext=1,256 > ; // Terminal echo of bytes sent is displayed here OK</p> <p>All possible bytes(from 0x00 to 0xFF) are sent on the socket as generic bytes.</p>



#SENDEXT - Send Data In Command Mode extended	SELINT 2
---	----------

3.5.6.5.16. Easy GPRS Authentication Type - #SGACTAUTH

#SGACTAUTH – Easy GRPS Authentication Type		SELINT 2
AT#SGACTAUTH= <type>	<p>Set command sets the authentication type for Easy GPRS This command has effect on the authentication mode used on AT#SGACT or AT#GPRS commands.</p> <p>Parameter <type> 0 - no authentication 1 - PAP authentication (factory default) 2 - CHAP authentication</p> <p>Note: the parameter is not saved in NWM</p>	
AT#SGACTAUTH?	<p>Read command reports the current Easy GPRS authentication type, in the format:</p> <p>#SGACTAUTH: <type></p>	
AT#SGACTAUTH=?	<p>Test command returns the range of supported values for parameter <type>.</p>	

3.5.6.5.17. Context activation and configuration - #SGACTCFG

#SGACTCFG - Context Activation and Configuration		SELINT 2
AT#SGACTCFG= <cid>, <retry>, [,<delay > [,<urcmode >]]	<p>Execution command is used to enable or disable the automatic activation/reactivation of the context for the specified PDP context, to set the maximum number of attempts and to set the delay between an attempt and the next one. The context is activated automatically after every GPRS Attach or after a NW PDP CONTEXT deactivation if at least one IPEasy socket is configured to this context (see AT#SCFG).</p> <p>Parameters:</p> <p><cid> - PDP context identifier (see +CGDCONT command) 1..5 - numeric parameter which specifies a particular PDP context definition</p>	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p><retry> - numeric parameter which specifies the maximum number of context activation attempts in case of activation failure. The value belongs to the following range: 0 - 15 0 - disable the automatic activation/reactivation of the context (default)</p> <p><delay> - numeric parameter which specifies the delay in seconds between an attempt and the next one. The value belongs to the following range: 180 - 3600</p> <p>< urcmode > - URC presentation mode 0 - disable unsolicited result code (default) 1 - enable unsolicited result code, after an automatic activation/reactivation, of the local IP address obtained from the network. It has meaning only if <auto>=1. The unsolicited message is in the format:</p> <p>#SGACT: <ip_address></p> <p>reporting the local IP address obtained from the network.</p> <p>Note: the URC presentation mode <urcmode> is related to the current AT instance only. Last <urcmode> setting is saved for every instance as extended profile parameter, thus it is possible to restore it even if the multiplexer control channel is released and set up, back and forth.</p> <p>Note: < retry > and <delay> setting are global parameter saved in NVM</p> <p>Note: if the automatic activation is enabled on a context, then it is not allowed to modify by the command AT#SCFG the association between the context itself and the socket connection identifier; all the other parameters of command AT#SCFG are modifiable while the socket is not connected</p>
<p>AT#SGACTCFG?</p>	<p>Read command reports the state of all the five contexts, in the format:</p> <p>#SGACTCFG: <cid1>,<retry1>,<delay1>, < urcmode >CR><LF></p> <p>...</p>



	<p>#SGACTCFG: <cid5>,<retry5>,<delay5>,< urcmode ></p> <p>where:</p> <p><cid n> - as <cid> before</p> <p><retry n> - as <retry> before</p> <p><delay n> - as <delay> before</p> <p>< urcmode > - as < urcmode > before</p>
AT#SGACTCFG=?	Test command reports supported range of values for parameters <cid> >,<retry>,<delay> and < urcmode >

3.5.6.5.18. Context activation and configuration extended - #SGACTCFGEXT

#SGACTCFGEXT - context activation configuration extended	SELINT 2
<p>AT#SGACTCFGEXT= <cid>,<abortAttemptEnable> [,<unused> [,<unused> [,<unused>]]]</p>	<p>Execution command is used to enable new features related to context activation.</p> <p>Parameters:</p> <p><cid> - PDP context identifier (see +CGDCONT command) 1..5 - numeric parameter which specifies a particular PDP context definition</p> <p>< abortAttemptEnable > 0 – old behaviour: no abort possible while attempting context activation</p> <p>1 – abort during context activation attempt is possible by sending a byte on the serial port.</p> <p>It takes effect on successive GPRS context activation attempt through #SGACT command in the following manner. While waiting for AT#SGACT=<cid>,1 response(up to 150 s) is possible to abort attempt by sending a byte and get back AT interface control(NO CARRIER indication).</p> <p>Note: If we receive delayed CTXT ACTIVATION ACCEPT after abort, network will be automatically informed of our aborted attempt through relative protocol messages(SM STATUS) and will also close on its side. Otherwise, if no ACCEPT is received after abort, network will be informed later of our PDP state through other protocol messages (routing area update for instance).</p>



<p>AT# SGACTIONTEXT?</p>	<p>Read command reports the state of all the five contexts, in the format:</p> <p>#SGACTIONTEXT: <cid1>,< abortAttemptEnable1 >,0,0,0<CR><LF> ... #SGACTIONTEXT: <cid5>,< abortAttemptEnable5 >,0,0,0<CR><LF></p> <p>where: <cid<i>n</i>> - as <cid> before < abortAttemptEnable <i>n</i>> - as < abortAttemptEnable > before</p> <p>Note: values are automatically saved in NVM.</p>
<p>AT#SGACTIONTEXT=?</p>	<p>Test command reports supported range of values for all parameters</p>

3.5.6.5.19. PAD command features - #PADCMD

<p>#PADCMD – PAD command features SELINT 2</p>	
<p>AT#PADCMD=<mode></p>	<p>This command sets features of the pending data flush to socket, opened with AT#SD command.</p> <p>Parameters: <mode>: Bit 1: 1 - enable forwarding; 0 – disable forwarding; Other bits reserved;</p> <p>Note: forwarding depends on character defined by AT#PADFWD</p>
<p>AT#PADCMD?</p>	<p>Read command reports the currently selected <mode> in the format: #PADCMD: mode</p>
<p>AT#PADCMD=?</p>	<p>Test command reports the supported range of values for parameter <mode>.</p>

3.5.6.5.20. PAD forward character - #PADFWD

<p>#PADFWD – PAD forward character SELINT 2</p>	
<p>AT#PADFWD=<char> [,<mode>]</p>	<p>This command sets the char that immediately flushes pending data to socket, opened with AT#SD command.</p> <p>Parameters: <char>:</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p>a number, from 0 to 255, that specifies the ascii code of the char used to flush data</p> <p><mode>: flush mode, 0 – normal mode (default); 1 – reserved;</p> <p>Note: use AT#PADCMD to enable the socket char-flush activity.</p>
AT#PADFWD?	<p>Read command reports the currently selected <char> and <mode> in the format: #PADFWD: <char>,mode</p>
AT#PADFWD=?	<p>Test command reports the supported range of values for parameters <char> and <mode>.</p>

3.5.6.5.21. Base64 encoding/decoding of data sent/received on a socket - #BASE64

#BASE64 – Base64 encoding/decoding of data sent/received on a skt	SELINT 2
<p>AT#BASE64= <connId>,<enc>,<dec> [,<unused_B > [,<unused_C >]]</p>	<p>Set command enables base64 encoding and/or decoding of data sent/received to/from the socket in online or in command mode.</p> <p>Parameters: <connId> - socket connection identifier 1..6</p> <p><enc> 0 – no encoding of data received from serial port. 1 - MIME RFC2045 base64 encoding of data received from serial port that have to be sent to <connId> socket.</p> <p>Note: as indicated from RFC2045 the encoded output stream is represented in lines of no more than 76 characters each. Lines are defined as sequences of octets separated by a CRLF sequence.</p> <p>2 - RFC 3548 base64 encoding of data received from serial port that have to be sent to <connId> socket. Note: as indicated from RFC3548 CRLF have not to be added.</p> <p><dec> 0 – no decoding of data received from socket <connId>. 1 - MIME RFC2045 base64 decoding of data received from socket</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

	<p><connId> and sent to serial port. (Same rule as for <enc> regarding line feeds in the received file that has to be decoded) 2 - RFC3548 base64 decoding of data received from socket <connId> and sent to serial port. (Same rule as for <enc> regarding line feeds in the received file that has to be decoded)</p> <p>Note: it is possible to use command to change current <enc>/<dec> settings for a socket already opened in command mode or in online mode after suspending it. (In this last case obviously it is necessary to set AT#SKIPESC=1).</p> <p>Note: to use #BASE64 in command mode, if data to send exceed maximum value for #SENDEXT command, they have to be divided in multiple parts. These parts have to be a multiple of 57 bytes, except for the last one, to distinguish EOF condition. (Base64 encoding rules) For the same reason if #SRECV command is used by the application to receive data, a multiple of 78 bytes has to be considered.</p> <p>Note: to use #SRECV to receive data with <dec> enabled, it is necessary to consider that: reading <maxByte> bytes from socket, user will get less due to decoding that is performed.</p> <p>Note: on version 10.0x.xx3 only <connId> 1 is available.</p> <p>Note: values are automatically saved in NVM.</p>
<p>AT# BASE64?</p>	<p>Read command returns the current <enc>/<dec> settings for all the six sockets, in the format:</p> <p># BASE64:<connId1><enc1>,<dec1>,0,0<CR><LF> ... # BASE64:<connId6>,<enc6>,<dec6>,0,0<CR><LF></p>
<p>AT# BASE64=?</p>	<p>Test command returns the range of supported values for all the subparameters.</p>



<p>Example</p>	<pre> AT#SKIPESC=1 OK AT#SD=<connId>,<txProt>,<rPort>,<IPaddr> CONNECT //Data sent without modifications(default) +++ (suspension) OK at#base64=<connId>,1,0 OK AT#SO=<connId> CONNECT // Data received from serial port are encoded // base64 before to be sent on the socket +++ (suspension) OK at#base64=<connId>,0,1 OK AT#SO=<connId> CONNECT // Data received from socket are decoded // base64 before to be sent on the serial port +++ (suspension) </pre>
----------------	--

3.5.6.6. FTP AT Commands

3.5.6.6.1. FTP Time-Out - #FTPTO

#FTPTO - FTP Time-Out	SELINT 0 / 1
<p>AT#FTPTO[= <tout>]</p>	<p>Set command sets the time-out used when opening either the FTP control channel or the FTP traffic channel.</p> <p>Parameter: <tout> - time-out in 100 ms units 100..5000 - hundreds of ms (factory default is 100)</p>



#FTPTO - FTP Time-Out		SELINT 0 / 1
	<p>Note: The parameter is not saved in NVM.</p> <p>Note: if parameter <tout> is omitted the behaviour of Set command is the same as Read command.</p>	
AT#FTPTO?	<p>Read command returns the current FTP operations time-out, in the format:</p> <p>#FTPTO: <tout></p>	
AT#FTPTO=?	<p>Test command returns the range of supported values for parameter <tout></p>	

#FTPTO - FTP Time-Out		SELINT 2
AT#FTPTO= [<tout>]	<p>Set command sets the time-out used when opening either the FTP control channel or the FTP traffic channel.</p> <p>Parameter: <tout> - time-out in 100 ms units 100..5000 - hundreds of ms (factory default is 100)</p> <p>Note: The parameter is not saved in NVM.</p>	
AT#FTPTO?	<p>Read command returns the current FTP operations time-out, in the format:</p> <p>#FTPTO: <tout></p>	
AT#FTPTO=?	<p>Test command returns the range of supported values for parameter <tout></p>	

3.5.6.6.2. FTP Open - #FTPOPEN

#FTPOPEN - FTP Open		SELINT 0 / 1
AT#FTPOPEN= <server:port>, <username>, <password>[, <mode>]	<p>Execution command opens an FTP connection toward the FTP server.</p> <p>Parameters: <server:port> - string type, address and port of FTP server (factory default port 21). <username> - string type, authentication user identification string for FTP. <password> - string type, authentication password for FTP. <mode></p>	



#FTPOPEN - FTP Open	SELINT 0 / 1
<p>0 - active mode (default) 1 - passive mode</p> <p>Note: Before opening an FTP connection the GPRS context must have been activated by AT#GPRS=1</p>	

#FTPOPEN - FTP Open	SELINT 2
<p>AT#FTPOPEN= [<server:port>, <username>, <password>[, <mode>]]</p> <p>Execution command opens an FTP connection toward the FTP server.</p> <p>Parameters: <server:port> - string type, address and port of FTP server (factory default port 21). <username> - string type, authentication user identification string for FTP. <password> - string type, authentication password for FTP. <mode> 0 - active mode (factory default) 1 - passive mode</p> <p>Note: Before opening an FTP connection either the GSM context must have been activated by AT#SGACT=0,1 or the PDP context #1 must have been activated by AT#SGACT=1,1 or by AT#GPRS=1</p>	
AT#FTPOPEN=?	Test command returns the OK result code.

3.5.6.6.3. FTP Close - #FTPCLOSE

#FTPCLOSE - FTP Close	SELINT 0 / 1
AT#FTPCLOSE	Execution command closes an FTP connection.
AT#FTPCLOSE?	Read command behavior is the same as Execution command.

#FTPCLOSE - FTP Close	SELINT 2
AT#FTPCLOSE	Execution command closes an FTP connection.
AT#FTPCLOSE=?	Test command returns the OK result code.

3.5.6.6.4. FTP Put - #FTPPUT

#FTPPUT - FTP Put	SELINT 0 / 1
<p>AT#FTPPUT= <filename></p> <p>Execution command, issued during an FTP connection, opens a data connection and starts sending <filename> file to the FTP server.</p> <p>If the data connection succeeds, a CONNECT indication is sent,</p>	



#FTPPUT - FTP Put	SELINT 0 / 1
	<p>afterward a NO CARRIER indication is sent when the socket is closed.</p> <p>Parameter: <filename> - string type, name of the file (maximum length 200 characters)</p> <p>Note: use the escape sequence +++ to close the data connection.</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p>
AT#FTPPUT=?	Test command returns the OK result code.

#FTPPUT - FTP Put	SELINT 2
AT#FTPPUT= [<filename>]	<p>Execution command, issued during an FTP connection, opens a data connection and starts sending <filename> file to the FTP server.</p> <p>If the data connection succeeds, a CONNECT indication is sent. afterward a NO CARRIER indication is sent when the socket is closed.</p> <p>Parameter: <filename> - string type, name of the file (maximum length 200 characters)</p> <p>Note: use the escape sequence +++ to close the data connection.</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p>
AT#FTPPUT=?	Test command returns the OK result code.

3.5.6.6.5. FTP Get - #FTPGET

#FTPGET - FTP Get	SELINT 0 / 1
AT#FTPGET= <filename>	<p>Execution command, issued during an FTP connection, opens a data connection and starts getting a file from the FTP server.</p> <p>If the data connection succeeds a CONNECT indication is sent, otherwise a NO CARRIER indication is sent.</p> <p>The file is received on the serial port.</p> <p>Parameter:</p>



#FTPGET - FTP Get	SELINT 0 / 1
	<p><filename> - file name, string type.</p> <p>Note: The command causes an ERROR result code to be returned in case no FTP connection has been opened yet.</p> <p>Note: Command closure should always be handled by application. In order to avoid download stall situations a timeout should be implemented by the application.</p>

#FTPGET - FTP Get	SELINT 2
<p>AT#FTPGET= [<filename>]</p>	<p>Execution command, issued during an FTP connection, opens a data connection and starts getting a file from the FTP server. If the data connection succeeds a CONNECT indication is sent. The file is received on the serial port.</p> <p>Parameter: <filename> - file name, string type.</p> <p>Note: The command causes an ERROR result code to be returned in case no FTP connection has been opened yet.</p> <p>Note: Command closure should always be handled by application. In order to avoid download stall situations a timeout should be implemented by the application.</p>
AT#FTPGET=?	Test command returns the OK result code.

3.5.6.6.6. FTP GET in command mode - #FTPGETPKT

#FTPGETPKT - FTP Get in command mode	SELINT 2
<p>AT#FTPGETPKT= <filename> [,<viewMode>]</p>	<p>Execution command, issued during an FTP connection, opens a data connection and starts getting a file from the FTP server while remaining in command mode.</p> <p>The data port is opened and we remain in command mode and we see the result code OK. Retrieval from FTP server of "remotefile" is started, but data are only buffered in the module. It's possible to read data afterwards issuing #FTPGET command</p> <p>Parameters:</p>



#FTPGETPKT - FTP Get in command mode	SELINT 2
	<p><filename> - file name, string type. <viewMode> - permit to choose view mode (text format or Hexadecimal)</p> <p>Note: The command causes an ERROR result code to be returned in case no FTP connection has been opened yet.</p> <p>Note: Command closure should always be handled by application. In order to avoid download stall situations a timeout should be implemented by the application.</p>
AT#FTPGETPKT?	<p>Read command reports current download state for <filename> with <viewMode> chosen, in the format:</p> <p>#FTPGETPKT: <remotefile>,<viewMode>,<eof> <eof> 0 = file currently being transferred 1 = complete file has been transferred to FTP client</p>
AT#FTPGETPKT=?	Test command returns the OK result code.

3.5.6.6.7. FTP Type - #FTPTYPE

#FTPTYPE - FTP Type	SELINT 0 / 1
AT#FTPTYPE[=<type>]	<p>Set command, issued during an FTP connection, sets the file transfer type.</p> <p>Parameter: <type> - file transfer type: 0 - binary 1 - ascii</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p> <p>Note: If the parameter is omitted then the behaviour of Set command is the same of Read command.</p>
#FTPTYPE?	<p>Read command returns the current file transfer type, in the format:</p> <p>#FTPTYPE: <type></p>
#FTPTYPE=?	<p>Test command returns the range of available values for parameter <type>:</p> <p>#FTPTYPE: (0,1)</p>



#FTPTYPE - FTP Type		SELINT 2
AT#FTPTYPE= [<type>]	Set command, issued during an FTP connection, sets the file transfer type. Parameter: <type> - file transfer type: 0 - binary 1 - ascii Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.	
#FTPTYPE?	Read command returns the current file transfer type, in the format: #FTPTYPE: <type>	
#FTPTYPE=?	Test command returns the range of available values for parameter <type>: #FTPTYPE: (0,1)	

3.5.6.6.8. FTP Read Message - #FTPMSG

#FTPMSG - FTP Read Message		SELINT 0 / 1
AT#FTPMSG	Execution command returns the last response from the server.	
AT#FTPMSG?	Read command behaviour is the same as Execution command.	

#FTPMSG - FTP Read Message		SELINT 2
AT#FTPMSG	Execution command returns the last response from the server.	
AT#FTPMSG=?	Test command returns the OK result code.	

3.5.6.6.9. FTP Delete - #FTPDELE

#FTPDELE - FTP Delete		SELINT 0 / 1
AT#FTPDELE= <filename>	Execution command, issued during an FTP connection, deletes a file from the remote working directory. Parameter: <filename> - string type, it's the name of the file to delete. Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.	



#FTPDELE - FTP Delete	SELINT 0 / 1
	Note: In case of delayed server response, it is necessary to check if ERROR indication is temporary due to timing out while waiting. In this case #FTPMSG response will result temporary empty. (Checking later #FTPMSG response will match with delayed server response)

#FTPDELE - FTP Delete	SELINT 2
AT#FTPDELE= [<filename>]	Execution command, issued during an FTP connection, deletes a file from the remote working directory. Parameter: <filename> - string type, it's the name of the file to delete. Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet. Note: In case of delayed server response, it is necessary to check if ERROR indication is temporary due to timing out while waiting. In this case #FTPMSG response will result temporary empty. (Checking later #FTPMSG response will match with delayed server response)
AT#FTPDELE=?	Test command returns the OK result code.

3.5.6.6.10. FTP Print Working Directory - #FTPPWD

#FTPPWD - FTP Print Working Directory	SELINT 0 / 1
AT#FTPPWD	Execution command, issued during an FTP connection, shows the current working directory on FTP server. Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.

#FTPPWD - FTP Print Working Directory	SELINT 2
AT#FTPPWD	Execution command, issued during an FTP connection, shows the current working directory on FTP server. Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.



#FTPPWD - FTP Print Working Directory		SELINT 2
AT#FTPPWD=?	Test command returns the OK result code.	

3.5.6.6.11. FTP Change Working Directory - #FTPCWD

#FTPCWD - FTP Change Working Directory		SELINT 0 / 1
AT#FTPCWD= <dirname>	<p>Execution command, issued during an FTP connection, changes the working directory on FTP server.</p> <p>Parameter: <dirname> - string type, it's the name of the new working directory.</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p>	

#FTPCWD - FTP Change Working Directory		SELINT 2
AT#FTPCWD= [<dirname>]	<p>Execution command, issued during an FTP connection, changes the working directory on FTP server.</p> <p>Parameter: <dirname> - string type, it's the name of the new working directory.</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p>	
AT#FTPCWD=?	Test command returns the OK result code.	

3.5.6.6.12. FTP List - #FTPLIST

#FTPLIST - FTP List	SELINT 0 / 1
----------------------------	---------------------



#FTPLIST - FTP List		SELINT 0 / 1
AT#FTPLIST[= <name>]	<p>Execution command, issued during an FTP connection, opens a data connection and starts getting from the server the list of contents of the specified directory or the properties of the specified file.</p> <p>Parameter: <name> - string type, it's the name of the directory or file.</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p> <p>Note: issuing AT#FTPLIST<CR> opens a data connection and starts getting from the server the list of contents of the working directory.</p>	

#FTPLIST - FTP List		SELINT 2
AT#FTPLIST[= [<name>]]	<p>Execution command, issued during an FTP connection, opens a data connection and starts getting from the server the list of contents of the specified directory or the properties of the specified file.</p> <p>Parameter: <name> - string type, it's the name of the directory or file.</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p> <p>Note: issuing AT#FTPLIST<CR> opens a data connection and starts getting from the server the list of contents of the working directory.</p>	
AT#FTPLIST=?	Test command returns the OK result code.	

3.5.6.6.13. Get file size - #FTPFSIZE

#FTPFSIZE – Get file size from FTP server		SELINT 2
AT#FTPFSIZE= <filename>	<p>Execution command, issued during an FTP connection, permits to get file size of <filename> file.</p> <p>Note: FTPTYPE=0 command has to be issued before FTPFSIZE command, to set file transfer type to binary mode.</p>	
AT# FTPFSIZE=?	Test command returns the OK result code.	



3.5.6.6.14. FTP Append - #FTPAPP

#FTPAPP - FTP Append	SELINT 2
<p>AT#FTPAPP= [<filename>]</p>	<p>Execution command, issued during an FTP connection, opens a data connection and append data to existing <filename> file.</p> <p>If the data connection succeeds, a CONNECT indication is sent, afterward a NO CARRIER indication is sent when the socket is closed.</p> <p>Parameter: <filename> - string type, name of the file.</p> <p>Note: use the escape sequence +++ to close the data connection.</p> <p>Note: The command causes an ERROR result code to be returned if no FTP connection has been opened yet.</p>
<p>AT#FTPAPP=?</p>	<p>Test command returns the OK result code.</p>

3.5.6.6.15. Set restart position - # FTPREST

#FTPREST - Set restart position for FTP GET	SELINT 2
<p>AT#FTPREST= <restartposition></p>	<p>Set command sets the restart position for successive FTPGET (or FTPGETPKT) command.</p> <p>It permits to restart a previously interrupted FTP download from the selected position in byte.</p> <p>Parameter: <restartposition> position in byte of restarting for successive FTPGET (or FTPGETPKT)</p> <p>Note: It's necessary to issue FTPTYPE=0 before successive FTPGET (or FTPGETPKT command) to set binary file transfer type.</p> <p>Note: Setting <restartposition> has effect on successive FTP download. After successive successfully initiated FTPGET(or FTPGETPKT) command</p>



#FTPREST – Set restart position for FTP GET	SELINT 2
	<p><restartposition> is automatically reset.</p> <p>Note: value set for <restartposition> has effect on next data transfer(data port opened by FTPGET or FTPGETPKT). Then <restartposition> value is automatically assigned to 0 for next download.</p>
AT# FTPREST?	<p>Read command returns the current <restartposition></p> <p>#FTPREST: <restartposition></p>
AT# FTPREST=?	Test command returns the OK result code.

3.5.6.6.16. Receive Data In Command Mode - #FTP_RECV

#FTP_RECV – Receive Data In Command Mode	SELINT 2
AT#FTP_RECV=<blocksize>	<p>Execution command permits the user to transfer at most <blocksize> bytes of remote file, provided that retrieving from the FTP server has been started with a previous #FTPGETPKT command, onto the serial port.</p> <p>This number is limited to the current number of bytes of the remote file which have been transferred from the FTP server.</p> <p>Parameters: < blocksize > - max number of bytes to read 1..3000</p> <p>Note: it's necessary to have previously opened FTP data port and started download and buffering of remote file through #FTPGETPKT command</p> <p>Note: issuing #FTP_RECV when there's no FTP data port opened</p>



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

#FTP_RECV – Receive Data In Command Mode	SELINT 2
	<p>raises an error.</p> <p>Note: data port will stay opened if socket is temporary waiting to receive data(FTP_RECV returns 0 and FTP_GETPKT gives a EOF 0 indication).</p>
AT# FTP_RECV?	<p>Read command reports the number of bytes currently received from FTP server, in the format:</p> <p>#FTP_RECV: <available></p>
AT# FTP_RECV=?	<p>Test command returns the range of supported values for <blocksize> parameter.</p>
Example	<pre> AT#FTP_RECV? #FTP_RECV: 3000 OK Read required part of the buffered data: AT#FTP_RECV=400 #FTP_RECV: 400 Text row number 1 * 11111111111111111111111111111111 * Text row number 2 * 22222222222222222222222222222222 * Text row number 3 * 33333333333333333333333333333333 * Text row number 4 * 44444444444444444444444444444444 * Text row number 5 * 55555555555555555555555555555555 * Text row number 6 * 66666666666666666666666666666666 * Text row number 7 * 77777777777777777777777777777777 * Text row number 8 * 88888888888888888888888888888888 OK AT#FTP_RECV =200 #FTP_RECV: 200 88888 *</pre>



#FTPRECV - Receive Data In Command Mode	SELINT 2
<pre>Text row number 9 * 999999999999999999999999 * Text row number 10 * AAAAAAAAAAAAAAAAAAAAAAAAAA * Text row number 12 *BBBBBBBBBBBBBBBBBBBBBBBB * Text row number 13 *CCCCCCCCCCCCCCCC</pre>	
OK	
Note: to check when you have received complete file it's possible to use AT#FTPGETPKT read command:	
AT#FTPGETPKT? #FTPGETPKT: sample.txt,0,1	
OK	
(you will get <eof> set to 1)	

3.5.6.7. Enhanced Easy GPRS® Extension AT Commands

3.5.6.7.1. Authentication User ID - #USERID

#USERID - Authentication User ID	SELINT 0 / 1
AT#USERID [=<user>]	Set command sets the user identification string to be used during the authentication step. Parameter: <user> - string type, it's the authentication User Id; the max length for this value is the output of Test command, AT#USERID=? (factory default is the empty string ""). Note: If parameter is omitted then the behaviour of Set command is the same of Read command.
AT#USERID?	Read command reports the current user identification string, in the format: #USERID: <user> .
AT#USERID=?	Test command returns the maximum allowed length of the string



#USERID - Authentication User ID		SELINT 0 / 1
	parameter <user> .	
Example	AT#USERID="myName" OK AT#USERID? #USERID: "myName" OK	

#USERID - Authentication User ID		SELINT 2
AT#USERID= [<user>]	Set command sets the user identification string to be used during the authentication step. Parameter: <user> - string type, it's the authentication User Id; the max length for this value is the output of Test command, AT#USERID=? (factory default is the empty string ""). Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).	
AT#USERID?	Read command reports the current user identification string, in the format: #USERID: <user>	
AT#USERID=?	Test command returns the maximum allowed length of the string parameter <user> .	
Example	AT#USERID="myName" OK AT#USERID? #USERID: "myName" OK	

3.5.6.7.2. Authentication Password - #PASSW

#PASSW - Authentication Password		SELINT 0/1
AT#PASSW= <pwd>	Set command sets the user password string to be used during the authentication step. Parameter: <pwd> - string type, it's the authentication password; the max length for this value is the output of Test command, AT#PASSW=? (factory default is the empty string "").	
AT#PASSW=?	Test command returns the maximum allowed length of the string parameter <pwd> .	
Example	AT#PASSW="myPassword" OK	



#PASSW - Authentication Password		SELINT 2
AT#PASSW=[<pwd>]	<p>Set command sets the user password string to be used during the authentication step.</p> <p>Parameter: <pwd> - string type, it's the authentication password; the max length for this value is the output of Test command, AT#PASSW=? (factory default is the empty string "").</p> <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>	
AT#PASSW=?	Test command returns the maximum allowed length of the string parameter <pwd>.	
Example	AT#PASSW="myPassword" OK	

3.5.6.7.3. Packet Size - #PKTSZ

#PKTSZ - Packet Size		SELINT 0 / 1
AT#PKTSZ[=<size>]	<p>Set command sets the default packet size to be used by the TCP/UDP/IP stack for data sending.</p> <p>Parameter: <size> - packet size in bytes 0 - automatically chosen by the device 1..512 - packet size in bytes (factory default is 300)</p> <p>Note: issuing AT#PKTSZ<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#PKTSZ=<CR> is the same as issuing the command AT#PKTSZ=0<CR>.</p>	
AT#PKTSZ?	<p>Read command reports the current packet size value.</p> <p>Note: after issuing command AT#PKTSZ=0, the Read command reports the value automatically chosen by the device.</p>	
AT#PKTSZ=?	Test command returns the allowed values for the parameter <size>.	
Example	<pre>AT#PKTSZ=100 OK AT#PKTSZ? #PKTSZ: 100 OK AT#PKTSZ=0 OK</pre>	



#PKTSZ - Packet Size	SELINT 0 / 1
<p>AT#PKTSZ?</p> <p>#PKTSZ: 300 ->value automatically chosen by device</p> <p>OK</p>	

#PKTSZ - Packet Size	SELINT 2
<p>AT#PKTSZ=[<size>]</p> <p>Set command sets the default packet size to be used by the TCP/UDP/IP stack for data sending.</p> <p>Parameter: <size> - packet size in bytes 0 - automatically chosen by the device 1..1500 - packet size in bytes (factory default is 300)</p> <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>	
<p>AT#PKTSZ?</p> <p>Read command reports the current packet size value.</p> <p>Note: after issuing command AT#PKTSZ=0, the Read command reports the value automatically chosen by the device.</p>	
<p>AT#PKTSZ=?</p> <p>Test command returns the allowed values for the parameter <size>.</p>	
<p>Example</p> <p>AT#PKTSZ=100 OK AT#PKTSZ? #PKTSZ: 100</p> <p>OK AT#PKTSZ=0 OK AT#PKTSZ? #PKTSZ: 300 ->value automatically chosen by device</p> <p>OK</p>	

3.5.6.7.4. Data Sending Time-Out - #DSTO

#DSTO - Data Sending Time-Out	SELINT 0 / 1
<p>AT#DSTO=[<tout>]</p> <p>Set command sets the maximum time that the module awaits before sending anyway a packet whose size is less than the default one.</p> <p>Parameter: <tout> - packet sending time-out in 100ms units (factory default is 50) 0 - no time-out, wait forever for packets to be completed before send. 1..255 hundreds of ms</p>	



#DSTO - Data Sending Time-Out		SELINT 0 / 1
	<p>Note: In order to avoid low performance issues, it is suggested to set the data sending time-out to a value greater than 5.</p> <p>Note: this time-out applies to data whose size is less than packet size and whose sending would have been delayed for an undefined time until new data to be sent had been received and full packet size reached.</p> <p>Note: issuing AT#DSTO<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#DSTO=<CR> is the same as issuing the command AT#DSTO=0<CR>.</p>	
AT#DSTO?	Read command reports the current data sending time-out value.	
AT#DSTO=?	Test command returns the allowed values for the parameter <tout> .	
Example	<pre>AT#DSTO=10 ->1 sec. time-out OK AT#DSTO? #DSTO: 10 OK</pre>	

#DSTO -Data Sending Time-Out		SELINT 2
AT#DSTO= [<tout>]	<p>Set command sets the maximum time that the module awaits before sending anyway a packet whose size is less than the default one.</p> <p>Parameter: <tout> - packet sending time-out in 100ms units (factory default is 50) 0 - no time-out, wait forever for packets to be completed before send. 1..255 hundreds of ms</p> <p>Note: In order to avoid low performance issues, it is suggested to set the data sending time-out to a value greater than 5.</p> <p>Note: this time-out applies to data whose size is less than packet size and whose sending would have been delayed for an undefined time until new data to be sent had been received and full packet size reached.</p> <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>	
AT#DSTO?	Read command reports the current data sending time-out value.	
AT#DSTO=?	Test command returns the allowed values for the parameter <tout> .	
Example	<pre>AT#DSTO=10 ->1 sec. time-out OK AT#DSTO? #DSTO: 10</pre>	



#DSTO -Data Sending Time-Out	SELINT 2
OK	

3.5.6.7.5. Socket Inactivity Time-Out - #SKTTO

#SKTTO - Socket Inactivity Time-Out	SELINT 0 / 1
AT#SKTTO=[<tout>]	<p>Set command sets the maximum time with no data exchanging on the socket that the module awaits before closing the socket and deactivating the GPRS context.</p> <p>Parameter: <tout> - socket inactivity time-out in seconds units 0 - no time-out. 1..65535 - time-out in sec. units (factory default is 90).</p> <p>Note: this time-out applies when no data is exchanged through the socket for a long time and therefore the socket connection has to be automatically closed; the GPRS context is deactivated only if it has been activated issuing #SKTOP; if it has been activated issuing #SKTD, now it stays activated.</p> <p>Note: issuing AT#SKTTO<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT+#SKTTO=<CR> is the same as issuing the command AT+#SKTTO=0<CR>.</p>
AT#SKTTO?	Read command reports the current socket inactivity time-out value.
AT#SKTTO=?	Test command returns the allowed values for parameter <tout> .
Example	<pre>AT#SKTTO=30 ->{30 sec. time-out} OK AT#SKTTO? #SKTTO: 30 OK</pre>

#SKTTO - Socket Inactivity Time-Out	SELINT 2
AT#SKTTO=[<tout>]	<p>Set command sets the maximum time with no data exchanging on the socket that the module awaits before closing the socket and deactivating the GPRS context.</p> <p>Parameter: <tout> - socket inactivity time-out in seconds units 0 - no time-out. 1..65535 - time-out in sec. units (factory default is 90).</p>



#SKTTO - Socket Inactivity Time-Out	SELINT 2
	<p>Note: this time-out applies when no data is exchanged in the socket for a long time and therefore the socket connection has to be automatically closed; the GPRS context is deactivated only if it has been activated issuing #SKTOP; if it has been activated issuing #SKTD, now it stays activated.</p> <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>
AT#SKTTO?	Read command reports the current socket inactivity time-out value.
AT#SKTTO=?	Test command returns the allowed values for parameter <tout> .
Example	<pre>AT#SKTTO=30 ->(30 sec. time-out) OK AT#SKTTO? #SKTTO: 30 OK</pre>

3.5.6.7.6. Socket Definition - #SKTSET

#SKTSET - Socket Definition	SELINT 0 / 1
AT#SKTSET[= <socket type>, <remote port>, <remote addr>, [<closure type>], [<local port>]]	<p>Set command sets the socket parameters values.</p> <p>Parameters:</p> <p><socket type> - socket protocol type 0 - TCP (factory default) 1 - UDP</p> <p><remote port> - remote host port to be opened 0..65535 - port number (factory default is 3333)</p> <p><remote addr> - address of the remote host, string type. This parameter can be either:</p> <ul style="list-style-type: none"> - any valid IP address in the format: xxx.xxx.xxx.xxx - any host name to be solved with a DNS query in the format: <host name> (factory default is the empty string "") <p><closure type> - socket closure behaviour for TCP 0 - local host closes immediately when remote host has closed (default) 255 - local host closes after an escape sequence (+++) or after an abortive disconnect from remote.</p> <p><local port> - local host port to be used on UDP socket 0..65535 - port number</p> <p>Note: <closure type> parameter is valid only for TCP socket type, for UDP sockets shall be left unused.</p>



#SKTSET - Socket Definition	SELINT 0 / 1
	<p>Note: <local port> parameter is valid only for UDP socket type, for TCP sockets shall be left unused.</p> <p>Note: The resolution of the host name is done when opening the socket, therefore if an invalid host name is given to the #SKTSET command, then error message will be issued.</p> <p>Note: the DNS Query to be successful requests that:</p> <ul style="list-style-type: none"> - the GPRS context 1 is correctly set with +CGDCONT - the authentication parameters are set (#USERID, #PASSW) - the GPRS coverage is enough to permit a connection. <p>Note: If all parameters are omitted then the behaviour of Set command is the same as Read command.</p>
AT#SKTSET?	<p>Read command reports the socket parameters values, in the format:</p> <p>AT#SKTSET: <socket type>, <remote port>, <remote addr>, <closure type>, <local port></p>
AT#SKTSET=?	Test command returns the allowed values for the parameters.
Example	<pre>AT#SKTSET=0,1024,"123.255.020.001" OK AT#SKTSET=0,1024,"www.telit.net" OK</pre>
Note	Issuing command #QDNS will overwrite <remote addr> setting.

#SKTSET - Socket Definition	SELINT 2
<p>AT#SKTSET= [<socket type>, <remote port>, <remote addr>, [<closure type>], [<local port>]</p>	<p>Set command sets the socket parameters values.</p> <p>Parameters:</p> <p><socket type> - socket protocol type</p> <p>0 - TCP (factory default)</p> <p>1 - UDP</p> <p><remote port> - remote host port to be opened</p> <p>0..65535 - port number (factory default is 3333)</p> <p><remote addr> - address of the remote host, string type. This parameter can be either:</p> <ul style="list-style-type: none"> - any valid IP address in the format: xxx.xxx.xxx.xxx - any host name to be solved with a DNS query in the format: <host name> (factory default is the empty string "") <p><closure type> - socket closure behaviour for TCP</p> <p>0 - local host closes immediately when remote host has closed (default)</p> <p>255 - local host closes after an escape sequence (+++) or after an abortive</p>



#SKTSET - Socket Definition	SELINT 2
	<p>disconnect from remote.</p> <p><local port> - local host port to be used on UDP socket 0..65535 - port number</p> <p>Note: <closure type> parameter is valid only for TCP socket type, for UDP sockets shall be left unused.</p> <p>Note: <local port> parameter is valid only for UDP socket type, for TCP sockets shall be left unused.</p> <p>Note: The resolution of the host name is done when opening the socket, therefore if an invalid host name is given to the #SKTSET command, then an error message will be issued.</p> <p>Note: the DNS Query to be successful requests that:</p> <ul style="list-style-type: none"> - the GPRS context 1 is correctly set with +CGDCONT - the authentication parameters are set (#USERID, #PASSW) - the GPRS coverage is enough to permit a connection. <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>
AT#SKTSET?	Read command reports the socket parameters values, in the format: AT#SKTSET: <socket type>, <remote port>, <remote addr>, <closure type>, <local port>
AT#SKTSET=?	Test command returns the allowed values for the parameters.
Example	<pre>AT#SKTSET=0,1024,"123.255.020.001" OK AT#SKTSET=0,1024,"www.telit.net" OK</pre>
Note	Issuing command #QDNS will overwrite <remote addr> setting.

3.5.6.7.7. Socket Open - #SKTOP

#SKTOP - Socket Open	SELINT 0 / 1
AT#SKTOP	<p>Execution command activates the context number 1, proceeds with the authentication with the user ID and password previously set by #USERID and #PASSW commands, and opens a socket connection with the host specified in the #SKTSET command. Eventually, before opening the socket connection, it issues automatically a DNS query to solve the IP address of the host name.</p> <p>If the connection succeeds a CONNECT indication is sent, otherwise a NO</p>



#QDNS - Query DNS		SELINT 0 / 1
	<p><IP address> - string type, in the format “xxx.xxx.xxx.xxx”</p> <p>Note: the command has to activate the GPRS context if it was not previously activated. In this case the context is deactivated after the DNS query.</p>	
Note	This command requires that the authentication parameters are correctly set and that the GPRS network is present.	
Note	Issuing command #QDNS will overwrite <remote addr> setting for command #SKTSET .	

#QDNS - Query DNS		SELINT 2
<p>AT#QDNS= [<host name>]</p>	<p>Execution command executes a DNS query to solve the host name into an IP address.</p> <p>Parameter: <host name> - host name, string type.</p> <p>If the DNS query is successful then the IP address will be reported in the result code, as follows:</p> <p>#QDNS: <host name>,<IP address></p> <p>where <host name> - string type <IP address> - string type, in the format “xxx.xxx.xxx.xxx”</p> <p>Note: the command has to activate the GPRS context if it was not previously activated. In this case the context is deactivated after the DNS query. It also works with GSM context, but the GSM context has to be activated before.</p>	
AT#QDNS=?	Test command returns the OK result code.	
Note	This command requires that the authentication parameters are correctly set and that the GPRS network is present (or GSM, if GSM context is used).	
Note	Issuing command #QDNS will overwrite <remote addr> setting for command #SKTSET .	

3.5.6.7.9. DNS Response Caching - #CACHEDNS

#CACHEDNS - DNS Response Caching		SELINT 2
<p>AT#CACHEDNS= [<mode>]</p>	<p>Set command enables caching a mapping of domain names to IP addresses, as does a resolver library.</p>	



#CACHEDNS – DNS Response Caching	SELINT 2
	<p>Parameter: <mode> 0 - caching disabled; it cleans the cache too 1 - caching enabled</p> <p>Note: the validity period of each cached entry (i.e. how long a DNS response remains valid) is determined by a value called the Time To Live (TTL), set by the administrator of the DNS server handing out the response.</p> <p>Note: it is recommended to clean the cache, if command +CCLK has been issued while the DNS Response Caching was enabled.</p>
AT#CACHEDNS?	<p>Read command reports whether the DNS Response Caching is currently enabled or not, in the format:</p> <p>#CACHEDNS: <mode></p>
AT#CACHEDNS=?	<p>Test command returns the currently cached mapping along with the range of available values for parameter <mode>, in the format:</p> <p>#CACHEDNS: [<hostn 1>,<IPaddr 1>,[...,<hostn n>,<IPaddr n>,,]](0,1)</p> <p>where: <hostn n> - hostname, string type <IPaddr n> - IP address, string type, in the format “xxx.xxx.xxx.xxx”</p>

3.5.6.7.10. Manual DNS Selection - #DNS

#DNS – Manual DNS Selection	SELINT 2
AT#DNS=<cid>,<primary>,<secondary>	<p>Set command allows to manually set primary and secondary DNS servers either for a PDP context defined by +CGDCONT or for a GSM context defined by #GSMCONT</p> <p>Parameters: <cid> - context identifier 0 - specifies the GSM context 1..5 - numeric parameter which specifies a particular PDP context definition <primary> - manual primary DNS server, string type, in the format “xxx.xxx.xxx.xxx” used for the specified cid; we’re using this</p>



#DNS – Manual DNS Selection	SELINT 2
	<p>value instead of the primary DNS server come from the network (default is “0.0.0.0”)</p> <p><secondary> - manual secondary DNS server, string type, in the format “xxx.xxx.xxx.xxx” used for the specified cid; we’re using this value instead of the secondary DNS server come from the network (default is “0.0.0.0”).</p> <p>Note: if <primary> is “0.0.0.0” and <secondary> is not “0.0.0.0”, then issuing AT#DNS=... raises an error.</p> <p>Note: if <primary> is “0.0.0.0” we’re using the primary DNS server come from the network as consequence of a context activation.</p> <p>Note: if <primary> is not “0.0.0.0” and <secondary> is “0.0.0.0”, then we’re using only the manual primary DNS server.</p> <p>Note: the context identified by <cid> has to be previously defined, elsewhere issuing AT#DNS=... raises an error.</p> <p>Note: the context identified by <cid> has to be not activated yet, elsewhere issuing AT#DNS=... raises an error.</p>
AT#DNS?	<p>Read command returns the manual DNS servers set either for every defined PDP context and for the single GSM context (only if defined), in the format:</p> <p>[#DNS: <cid>,<primary>,<secondary>[<CR><LF> #DNS: <cid>,<primary>,<secondary>]]</p>
AT#DNS=?	<p>Test command reports the supported range of values for the <cid> parameter, only, in the format:</p> <p>#DNS: {0,5},,</p>

3.5.6.7.11. Socket TCP Connection Time-Out - #SKTCT

#SKTCT - Socket TCP Connection Time-Out	SELINT 0 / 1
AT#SKTCT[=<tout>]	Set command sets the TCP connection time-out for the first CONNECT answer from the TCP peer to be received.



#SKTCT - Socket TCP Connection Time-Out	SELINT 0 / 1
	<p>Parameter: <tout> - TCP first CONNECT answer time-out in 100ms units 10..1200 - hundreds of ms (factory default value is 600).</p> <p>Note: this time-out applies only to the time that the TCP stack waits for the CONNECT answer to its connection request.</p> <p>Note: The time for activate the GPRS and resolving the name with the DNS query (if the peer was specified by name and not by address) is not counted in this time-out.</p> <p>Note: if parameter is omitted then the behaviour of Set command is the same as Read command.</p>
AT#SKTCT?	Read command reports the current TCP connection time-out.
AT#SKTCT=?	Test command returns the allowed values for parameter <tout> .
Example	<pre>AT#SKTCT=600 OK socket first connection answer time-out has been set to 60 s.</pre>

#SKTCT - Socket TCP Connection Time-Out	SELINT 2
AT#SKTCT= [<tout>]	<p>Set command sets the TCP connection time-out for the first CONNECT answer from the TCP peer to be received.</p> <p>Parameter: <tout> - TCP first CONNECT answer time-out in 100ms units 10..1200 - hundreds of ms (factory default value is 600).</p> <p>Note: this time-out applies only to the time that the TCP stack waits for the CONNECT answer to its connection request.</p> <p>Note: The time for activate the GPRS and resolving the name with the DNS query (if the peer was specified by name and not by address) is not counted in this time-out.</p> <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>
AT#SKTCT?	Read command reports the current TCP connection time-out.
AT#SKTCT=?	Test command returns the allowed values for parameter <tout> .
Example	<pre>AT#SKTCT=600 OK socket first connection answer time-out has been set to 60 s.</pre>



3.5.6.7.12. Socket Parameters Save - #SKTSAV

#SKTSAV - Socket Parameters Save		SELINT 0 / 1
AT#SKTSAV	<p>Execution command stores the current socket parameters in the NVM of the device.</p> <p>The socket parameters to store are:</p> <ul style="list-style-type: none"> - User ID - Password - Packet Size - Socket Inactivity Time-Out - Data Sending Time-Out - Socket Type (UDP/TCP) - Remote Port - Remote Address - TCP Connection Time-Out 	
Example	<pre>AT#SKTSAV OK socket parameters have been saved in NVM</pre>	
Note	If some parameters are not previously specified then a default value will be stored.	

#SKTSAV - Socket Parameters Save		SELINT 2
AT#SKTSAV	<p>Execution command stores the current socket parameters in the NVM of the device.</p> <p>The socket parameters to store are:</p> <ul style="list-style-type: none"> - User ID - Password - Packet Size - Socket Inactivity Time-Out - Data Sending Time-Out - Socket Type (UDP/TCP) - Remote Port - Remote Address - TCP Connection Time-Out <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>	
AT#SKTSAV=?	Test command returns the OK result code.	
Example	<pre>AT#SKTSAV OK socket parameters have been saved in NVM</pre>	
Note	If some parameters have not been previously specified then a default value	



#SKTSAV - Socket Parameters Save	SELINT 2
will be stored.	

3.5.6.7.13. Socket Parameters Reset - #SKTRST

#SKTRST - Socket Parameters Reset	SELINT 0 / 1
AT#SKTRST	<p>Execution command resets the socket parameters to the “factory default” configuration and stores them in the NVM of the device.</p> <p>The socket parameters to reset are:</p> <ul style="list-style-type: none"> - User ID - Password - Packet Size - Socket Inactivity Time-Out - Data Sending Time-Out - Socket Type - Remote Port - Remote Address - TCP Connection Time-Out
Example	<pre>AT#SKTRST OK socket parameters have been reset</pre>

#SKTRST - Socket Parameters Reset	SELINT 2
AT#SKTRST	<p>Execution command resets the socket parameters to the “factory default” configuration and stores them in the NVM of the device.</p> <p>The socket parameters to reset are:</p> <ul style="list-style-type: none"> - User ID - Password - Packet Size - Socket Inactivity Time-Out - Data Sending Time-Out - Socket Type - Remote Port - Remote Address - TCP Connection Time-Out
AT#SKTRST=?	Test command returns the OK result code.
Example	<pre>AT#SKTRST OK socket parameters have been reset</pre>



3.5.6.7.14. GPRS Context Activation - #GPRS

#GPRS - GPRS Context Activation	SELINT 0 / 1
<p>AT#GPRS[= [<mode>]]</p>	<p>Execution command deactivates/activates the GPRS context, eventually proceeding with the authentication with the parameters given with #PASSW and #USERID.</p> <p>Parameter: <mode> - GPRS context activation mode 0 - GPRS context deactivation request 1 - GPRS context activation request</p> <p>In the case that the GPRS context has been activated, the result code OK is preceded by the intermediate result code:</p> <p>+IP: <ip_address_obtained></p> <p>reporting the local IP address obtained from the network.</p> <p>Note: issuing AT#GPRS<CR> reports the current status of the GPRS context, in the format:</p> <p>#GPRS: <status></p> <p>where: <status> 0 - GPRS context deactivated 1 - GPRS context activated 2 - GPRS context activation pending.</p> <p>Note: issuing AT#GPRS=<CR> is the same as issuing the command AT#GPRS=0<CR>.</p> <p>Note: if you request a GPRS context deactivation during a call issuing either AT#GPRS=0 or AT#EMAILACT=0 and then, after the call termination, you want to request a GPRS context activation through #GPRS, you need to issue the following sequence of three commands</p> <pre> AT#GPRS=1 OK AT#GPRS=0 OK AT#GPRS=1 </pre>



#GPRS - GPRS Context Activation		SELINT 0 / 1
	OK	
AT#GPRS?	Read command has the same effect as the Execution command AT#GPRS<CR> .	
AT#GPRS=?	Test command returns the allowed values for parameter <mode> .	
Example	<pre>AT#GPRS=1 +IP: 129.137.1.1 OK Now GPRS Context has been activated and our IP is 129.137.1.1</pre> <pre>AT#GPRS=0 OK Now GPRS context has been deactivated, IP is lost.</pre>	
Note	It is strongly recommended to use the same command (e.g. #GPRS) to activate the context, deactivate it and interrogate about its status.	

#GPRS - GPRS Context Activation		SELINT 2
AT#GPRS= [<mode>]	<p>Execution command deactivates/activates the PDP context #1, eventually proceeding with the authentication with the parameters given with #PASSW and #USERID.</p> <p>Parameter: <mode> - PDP context activation mode 0 - PDP context #1 deactivation request 1 - PDP context #1 activation request</p> <p>In the case that the PDP context #1 has been activated, the result code OK is preceded by the intermediate result code:</p> <p>+IP: <ip_address_obtained></p> <p>reporting the local IP address obtained from the network.</p> <p>Note: at least a socket identifier needs to be associated with PDP context #1 in order to every #GPRS action be effective; by default the PDP context #1 is associated with socket identifiers 1, 2 and 3, but it is possible to modify these associations through #SCFG. Trying to issue a #GPRS action when no socket identifier is associated with PDP context #1 raises an error.</p> <p>Note: if the PDP context #1 has been activated issuing AT#GPRS=1, then</p> <ul style="list-style-type: none"> if you request to deactivate the PDP context #1 issuing AT#EMAILACT=0 an ERROR is raised and nothing happens 	



#SKTD - Socket Dial	SELINT 0 / 1
<p>[=<socket type>, <remote port>, <remote addr>, [<closure type>], [<local port>]]</p>	<p>parameters.</p> <p>Parameters:</p> <p><socket type> - socket protocol type 0 - TCP (factory default) 1 - UDP</p> <p><remote port> - remote host port to be opened 0..65535 - port number (factory default is 0)</p> <p><remote addr> - address of the remote host, string type. This parameter can be either:</p> <ul style="list-style-type: none"> - any valid IP address in the format: xxx.xxx.xxx.xxx - any host name to be solved with a DNS query in the format: <host name> (factory default is the empty string "") <p><closure type> - socket closure behaviour for TCP 0 - local host closes immediately when remote host has closed (default) 255 - local host closes after an escape sequence (+++) or after an abortive disconnect from remote.</p> <p><local port> - local host port to be used on UDP socket 0..65535 - port number</p> <p>Note: <closure type> parameter is valid only for TCP socket type, for UDP sockets shall be left unused.</p> <p>Note: <local port> parameter is valid only for UDP socket type, for TCP sockets shall be left unused.</p> <p>Note: the resolution of the host name is done when opening the socket, therefore if an invalid host name is given to the #SKTD command, then an error message will be issued.</p> <p>Note: the command to be successful requests that:</p> <ul style="list-style-type: none"> - the GPRS context 1 is correctly set with +CGDCONT - the authentication parameters are set (#USERID, #PASSW) the GPRS coverage is enough to permit a connection - the GPRS has been activated with AT#GPRS=1 <p>Note: If all parameters are omitted then the behaviour of Set command is the same as Read command.</p>
<p>AT#SKTD?</p>	<p>Read command reports the socket dial parameters values, in the format:</p> <p>AT#SKTD: <socket type>,<remote port>,<remote addr>,</p>



#SKTD - Socket Dial	SELINT 2
	<p>Note: <local port> parameter is valid only for UDP socket type, for TCP sockets shall be left unused.</p> <p>Note: the resolution of the host name is done when opening the socket, therefore if an invalid host name is given to the #SKTD command, then an error message will be issued.</p> <p>Note: the command to be successful requests that:</p> <ul style="list-style-type: none"> - the GPRS context 1 is correctly set with +CGDCONT - the authentication parameters are set (#USERID, #PASSW) the GPRS coverage is enough to permit a connection - the GPRS has been activated with AT#GPRS=1 <p>Note: this command is not allowed for sockets associated to a GSM context (see #SCFG).</p>
AT#SKTD?	<p>Read command reports the socket dial parameters values, in the format:</p> <p>AT#SKTD: <socket type>, <remote port>, <remote addr>, <closure type>, <local port></p>
AT#SKTD=?	<p>Test command returns the allowed values for the parameters.</p>
Example	<pre>AT#SKTD=0,1024,"123.255.020.001",255 CONNECT AT#SKTD=1,1024,"123.255.020.001",,1025 CONNECT <i>In this way my local port 1025 is opened to the remote port 1024</i> AT#SKTD=0,1024,"www.telit.net",255 CONNECT</pre>
Note	<p>The main difference between this command and #SKTOP is that this command does not interact with the GPRS context status, leaving it ON or OFF according to the #GPRS setting, therefore when the connection made with #SKTD is closed the context (and hence the local IP address) is maintained.</p>

3.5.6.7.16. Socket Listen - #SKTL

#SKTL - Socket Listen	SELINT 0 / 1
AT#SKTL [=<mode>, <socket type>, <input port>,	<p>Execution command opens/closes the socket listening for connection requests.</p> <p>Parameters:</p>



#SKTL - Socket Listen	SELINT 0 / 1
<p>[<closure type>]]</p>	<p><mode> - socket mode 0 - closes socket listening 1 - starts socket listening <socket type> - socket protocol type 0 - TCP <input port> - local host input port to be listened 0..65535 - port number <closure type> - socket closure behaviour for TCP 0 - local host closes immediately when remote host has closed (default) 255 - local host closes after an escape sequence (+++) or after an abortive disconnect from remote.</p> <p>Command returns the OK result code if successful.</p> <p>Note: the command to be successful requests that:</p> <ul style="list-style-type: none"> - the GPRS context 1 is correctly set with +CGDCONT - the authentication parameters are set (#USERID, #PASSW) - the GPRS coverage is enough to permit a connection - the GPRS has been activated with AT#GPRS=1 <p>When a connection request comes on the input port, if the sender is not filtered by the internal firewall (see command #FRWL), an unsolicited code is reported:</p> <p>+CONN FROM: <remote addr></p> <p>Where: <remote addr> - host address of the remote machine that contacted the device.</p> <p>When the connection is established the CONNECT indication is given and the modem goes into data transfer mode.</p> <p>On connection close or when context is closed with #GPRS=0 the socket is closed and no listen is anymore active.</p> <p>If the context is closed by the network while in listening, the socket is closed, no listen is anymore active and an unsolicited code is reported:</p> <p>#SKTL: ABORTED</p> <p>Note: if all parameters are omitted the command returns the current</p>



#SKTL - Socket Listen	SELINT 0 / 1
	<p>socket listening status and the last settings of parameters <input port> and <closure type>, in the format:</p> <p>#SKTL: <status>,<input port>,<closure type></p> <p>where</p> <p><status> - socket listening status</p> <p>0 - socket not listening</p> <p>1 - socket listening</p>
AT#SKTL?	Read command has the same effect as Execution command when parameters are omitted.
AT#SKTL=?	Test command returns the allowed values for parameters <mode> , <input port> and <closure type> .
Example	<p><i>Activate GPRS</i></p> <p>AT#GPRS=1 +IP: ###.###.###.###</p> <p>OK</p> <p><i>Start listening</i></p> <p>AT#SKTL=1,0,1024</p> <p>OK</p> <p>or</p> <p>AT#SKTL=1,0,1024,255</p> <p>OK</p> <p><i>Receive connection requests</i></p> <p>+CONN FROM: 192.164.2.1 CONNECT</p> <p><i>exchange data with the remote host</i></p> <p><i>send escape sequence</i></p> <p>+++ NO CARRIER</p> <p><i>Now listen is not anymore active</i></p> <p><i>to stop listening</i></p> <p>AT#SKTL=0,0,1024, 255</p> <p>OK</p>
Note	<p>The main difference between this command and the #SKTD is that #SKTL does not contact any peer, nor does any interaction with the GPRS context status, leaving it ON or OFF according to the #GPRS setting, therefore when the connection made with #SKTL is closed the context (and hence the local IP address) is maintained.</p> <p>The improving command @SKTL has been defined.</p>



#SKTL - Socket Listen	SELINT 2
<p>AT#SKTL =[<mode>, <socket type>, <input port>, [<closure type>]]</p>	<p>Execution command opens/closes the socket listening for connection requests.</p> <p>Parameters:</p> <p><mode> - socket mode 0 - closes socket listening 1 - starts socket listening</p> <p><socket type> - socket protocol type 0 -TCP (default) 1- UDP</p> <p><input port> - local host input port to be listened 1..65535 - port number</p> <p><closure type> - socket closure behaviour for TCP 0 - local host closes immediately when remote host has closed (default) 255 - local host closes after an escape sequence (+++)</p> <p>Command returns the OK result code if successful.</p> <p>Note: the command to be successful requests that:</p> <ul style="list-style-type: none"> - the GPRS context 1 is correctly set with +CGDCONT - the authentication parameters are set (#USERID, #PASSW) - the GPRS coverage is enough to permit a connection - the GPRS has been activated with AT#GPRS=1 <p>When a connection request comes on the input port, if the sender is not filtered by the internal firewall (see command #FRWL), an unsolicited code is reported:</p> <p style="padding-left: 40px;">+CONN FROM: <remote addr></p> <p>Where:</p> <p style="padding-left: 40px;"><remote addr> - host address of the remote machine that contacted the device.</p> <p>When the connection is established the CONNECT indication is given and the modem goes into data transfer mode.</p> <p>On connection close or when context is closed with #GPRS=0 the socket is closed and no listen is anymore active.</p> <p>If the context is closed by the network while in listening, the socket is</p>



#SKTL - Socket Listen	SELINT 2
	<p>closed, no listen is anymore active and an unsolicited code is reported:</p> <p>#SKTL: ABORTED</p> <p>Note: when closing the listening socket <input port> is a don't care parameter</p>
<p>AT#SKTL?</p>	<p>Read command returns the current socket listening status and the last settings of parameters <input port> and <closure type>, in the format:</p> <p>#SKTL: <status>, <socket type>, <input port>, <closure type></p> <p>Where</p> <ul style="list-style-type: none"> <status> - socket listening status 0 - socket not listening 1 - socket listening
<p>AT#SKTL=?</p>	<p>Test command returns the allowed values for parameters <mode>, <socket type>, <input port> and <closure type>.</p>
<p>Example</p>	<p><i>Activate GPRS</i> AT#GPRS=1 +IP: ###.###.###.###</p> <p>OK</p> <p><i>Start TCP listening</i> AT#SKTL=1, 0, 1024 OK</p> <p>or AT#SKTL=1, 0, 1024, 255 OK</p> <p><i>Receive TCP connection requests</i> +CONN FROM: 192.164.2.1 CONNECT</p> <p><i>exchange data with the remote host</i></p> <p><i>send escape sequence</i> +++ NO CARRIER <i>Now listen is not anymore active</i></p> <p><i>to stop listening</i> AT#SKTL=0, 0, 1024, 255 OK</p>
<p>Note</p>	<p>The main difference between this command and #SKTD is that #SKTL does not contact any peer, nor does any interaction with the GPRS context status,</p>



#SKTL - Socket Listen	SELINT 2
	<p>leaving it ON or OFF according to the #GPRS setting, therefore when the connection made with #SKTL is closed the context (and hence the local IP address) is maintained.</p>

3.5.6.7.17. Socket Listen Improved - @SKTL

@SKTL - Socket Listen Improved	SELINT 0 / 1
<p>AT@SKTL [=<mode>, <socket type>, <input port>, [<closure type>]]</p>	<p>Execution command opens/closes the socket listening for connection requests.</p> <p>Parameters:</p> <p><mode> - socket mode 0 - closes socket listening 1 - starts socket listening</p> <p><socket type> - socket protocol type 0 - TCP</p> <p><input port> - local host input port to be listened 0..65535 - port number</p> <p><closure type> - socket closure behaviour for TCP 0 - local host closes immediately when remote host has closed (default) 255 - local host closes after an escape sequence (+++) or after an abortive disconnect from remote.</p> <p>Command returns the OK result code if successful.</p> <p>Note: the command to be successful requests that:</p> <ul style="list-style-type: none"> - the GPRS context 1 is correctly set with +CGDCONT - the authentication parameters are set (#USERID, #PASSW) - the GPRS coverage is enough to permit a connection - the GPRS has been activated with AT#GPRS=1 <p>When a connection request comes on the input port, if the sender is not filtered by the internal firewall (see command #FRWL), an unsolicited code is reported:</p> <p>+CONN FROM: <remote addr></p> <p>Where: <remote addr> - host address of the remote machine that contacted the device.</p>



@SKTL - Socket Listen Improved	SELINT 0 / 1
	<p>When the connection is established the CONNECT indication is given and the modem goes into data transfer mode.</p> <p>On connection close or when context is closed with #GPRS=0 the socket is closed and no listen is anymore active.</p> <p>If the context is closed by the network while in listening, the socket is closed, no listen is anymore active and an unsolicited code is reported:</p> <p style="text-align: center;">@SKTL: ABORTED</p> <p>Note: if all parameters are omitted the command returns the current socket listening status and the last settings of parameters <socket type>, <input port> and <closure type>, in the format:</p> <p>@SKTL: <status>,<socket type>,<input port>,<closure type></p> <p>Where</p> <p><status> - socket listening status 0 - socket not listening 1 - socket listening</p>
AT@SKTL?	Read command has the same effect as Execution command when parameters are omitted.
AT@SKTL=?	Test command returns the allowed values for parameters <mode> , <socket type> , <input port> and <closure type> .
Example	<p><i>Activate GPRS</i> AT#GPRS=1 +IP: ###.###.###.###</p> <p>OK</p> <p><i>Start listening</i> AT@SKTL=1,0,1024 OK</p> <p>or AT@SKTL=1,0,1024,255 OK</p> <p><i>Receive connection requests</i> +CONN FROM: 192.164.2.1 CONNECT</p> <p><i>exchange data with the remote host</i></p> <p><i>send escape sequence</i> +++</p>



@SKTL - Socket Listen Improved		SELINT 0 / 1
	NO CARRIER <i>Now listen is not anymore active</i> <i>to stop listening</i> AT@SKTL=0,0,1024, 255 OK	
Note	The main difference between this command and the #SKTD is that @SKTL does not contact any peer, nor does any interaction with the GPRS context status, leaving it ON or OFF according to the #GPRS setting, therefore when the connection made with @SKTL is closed the context (and hence the local IP address) is maintained.	

3.5.6.7.18. Socket Listen Ring Indicator - #E2SLRI

#E2SLRI - Socket Listen Ring Indicator		SELINT 0 / 1 / 2
AT#E2SLRI=[<n>]	Set command enables/disables the Ring Indicator pin response to a Socket Listen connect and, if enabled, the duration of the negative going pulse generated on receipt of connect. Parameter: <n> - RI enabling 0 - RI disabled for Socket Listen connect (factory default) 50..1150 - RI enabled for Socket Listen connect; a negative going pulse is generated on receipt of connect and <n> is the duration in ms of this pulse.	
AT#E2SLRI?	Read command reports whether the Ring Indicator pin response to a Socket Listen connect is currently enabled or not, in the format: #E2SLRI: <n>	
AT#E2SLRI=?	Test command returns the allowed values for parameter <status>.	

3.5.6.7.19. Firewall Setup - #FRWL

#FRWL - Firewall Setup		SELINT 0 / 1
AT#FRWL[= <action>, <ip_addr>, <net_mask>]	Execution command controls the internal firewall settings. Parameters: <action> - command action 0 - remove selected chain 1 - add an ACCEPT chain 2 - remove all chains (DROP everything); <ip_addr> and <net_mask> has no meaning in this case. <ip_addr> - remote address to be added into the ACCEPT chain; string	



#FRWL - Firewall Setup	SELINT 0 / 1
	<p>type, it can be any valid IP address in the format: xxx.xxx.xxx.xxx <net_mask> - mask to be applied on the <ip_addr>; string type, it can be any valid IP address mask in the format: xxx.xxx.xxx.xxx</p> <p>Command returns OK result code if successful.</p> <p>Note: the firewall applies for incoming (listening) connections only.</p> <p>Firewall general policy is DROP, therefore all packets that are not included into an ACCEPT chain rule will be silently discarded.</p> <p>When a packet comes from the IP address incoming_IP, the firewall chain rules will be scanned for matching with the following criteria:</p> <p>incoming_IP & <net_mask> = <ip_addr> & <net_mask></p> <p>If criteria is matched, then the packet is accepted and the rule scan is finished; if criteria is not matched for any chain the packet is silently dropped.</p> <p>Note: If all parameters are omitted the command reports the list of all ACCEPT chain rules registered in the Firewall settings in the format: #FRWL: <ip_addr>,<net_mask> #FRWL: <ip_addr>,<net_mask> OK</p>
AT#FRWL?	Read command has the same effect as Execution command when parameters are omitted.
AT#FRWL=?	Test command returns the allowed values for parameter <action> .
Example	<p><i>Let assume we want to accept connections only from our devices which are on the IP addresses ranging from 197.158.1.1 to 197.158.255.255</i></p> <p><i>We need to add the following chain to the firewall:</i> AT#FRWL=1,"197.158.1.1","255.255.0.0" OK</p>
Note	For outgoing connections made with #SKTOP and #SKTD the remote host is dynamically inserted into the ACCEPT chain for all the connection duration. Therefore the #FRWL command shall be used only for defining either the #SKTL or the @SKTL behaviour, deciding which hosts are allowed to connect to the local device.



#FRWL - Firewall Setup		SELINT 0 / 1
	Rules are not saved in NVM, at startup the rules list will be empty.	
#FRWL - Firewall Setup		SELINT 2
AT#FRWL= [<action>, <ip_address>, <net mask>]	<p>Execution command controls the internal firewall settings.</p> <p>Parameters:</p> <p><action> - command action 0 - remove selected chain 1 - add an ACCEPT chain 2 - remove all chains (DROP everything); <ip_addr> and <net_mask> has no meaning in this case.</p> <p><ip_addr> - remote address to be added into the ACCEPT chain; string type, it can be any valid IP address in the format: xxx.xxx.xxx.xxx</p> <p><net_mask> - mask to be applied on the <ip_addr>; string type, it can be any valid IP address mask in the format: xxx.xxx.xxx.xxx</p> <p>Command returns OK result code if successful.</p> <p>Note: the firewall applies for incoming (listening) connections only.</p> <p>Firewall general policy is DROP, therefore all packets that are not included into an ACCEPT chain rule will be silently discarded.</p> <p>When a packet comes from the IP address incoming_IP, the firewall chain rules will be scanned for matching with the following criteria:</p> <p>incoming_IP & <net_mask> = <ip_addr> & <net_mask></p> <p>If criteria is matched, then the packet is accepted and the rule scan is finished; if criteria is not matched for any chain the packet is silently dropped.</p>	
AT#FRWL?	<p>Read command reports the list of all ACCEPT chain rules registered in the Firewall settings in the format:</p> <p>#FRWL: <ip_addr>,<net_mask> #FRWL: <ip_addr>,<net_mask> OK</p>	
AT#FRWL=?	Test command returns the allowed values for parameter <action>.	
Example	<i>Let assume we want to accept connections only from our devices which are on the IP addresses ranging from 197.158.1.1 to 197.158.255.255</i>	



#FRWL - Firewall Setup		SELINT 2
	<p><i>We need to add the following chain to the firewall:</i> AT#FRWL=1, "197.158.1.1", "255.255.0.0" OK</p>	
Note	<p>For outgoing connections made with #SKTOP and #SKTD the remote host is dynamically inserted into the ACCEPT chain for all the connection duration. Therefore the #FRWL command shall be used only for defining the #SKTL behaviour, deciding which hosts are allowed to connect to the local device.</p> <p>Rules are not saved in NVM, at startup the rules list will be empty.</p>	

3.5.6.7.20. GPRS Data Volume - #GDATAVOL

#GDATAVOL - GPRS Data Volume	SELINT 2
<p>AT#GDATAVOL= [<mode>]</p>	<p>Execution command reports, for every active PDP context, the amount of data the last GPRS session (and the last GSM session, if GSM context is active) received and transmitted, or it will report the total amount of data received and transmitted during all past GPRS (and GSM) sessions, since last reset.</p> <p>Parameter: <mode> 0 - it resets the GPRS data counter for the all the available PDP contexts (1-5) and GSM data counter for GSM context 0 1 - it reports the last GPRS session data counter for the all the set PDP contexts (i.e. all the PDP contexts with APN parameter set using +CGDCONT) (and the last GSM session data counter for the GSM context, if set through #GSMCONT), in the format:</p> <p>#GDATAVOL: <cid>, <tot>, <sent>, <received> [<CR><LF>] #GDATAVOL: <cid>, <tot>, <sent>, <received> [...]</p> <p>where: <cid> - PDP context identifier 0 - specifies the GSM context 1..5 - numeric parameter which specifies a particular PDP context definition <tot> - number of bytes either received or transmitted in the last GPRS (or GSM) session for <cid> PDP context; <sent> - number of bytes transmitted in the last GPRS (or GSM) session for <cid> PDP context;</p>



#ICMP - ICMP Ping Support		SELINT 2
	ECHO_REPLY to every IP Address pinging it.	
AT#ICMP?	Read command returns whether the ICMP Ping support is currently enabled or not, in the format: #ICMP: <mode>	
AT#ICMP=?	Test command reports the supported range of values for the <mode> parameter.	

3.5.6.7.22. Maximum TCP Payload Size - #TCPMAXDAT

#TCPMAXDAT - Maximum TCP Payload Size		SELINT 2
AT#TCPMAXDAT= <size>	Set command allows to set the maximum TCP payload size in TCP header options. Parameter: <size> - maximum TCP payload size accepted in one single TCP/IP datagram; it is sent in TCP header options in SYN packet. 0 - the maximum TCP payload size is automatically handled by module (default). 496..1420 - maximum TCP payload size	
AT#TCPMAXDAT?	Read command reports the current maximum TCP payload size, in the format: #TCPMAXDAT: <size>	
AT#TCPMAXDAT=?	Test command reports the supported range of values for parameter <size>	

3.5.6.7.23. TCP Reassembly - #TCPREASS

#TCPREASS - TCP Reassembly		SELINT 2
AT#TCPREASS= <n>	Set command enables/disables the TCP reassembly feature , in order to handle fragmented TCP packets. Parameter: <n> 0 - disable TCP reassembly feature (default) 1 - enable TCP reassembly feature	



#TCPREASS - TCP Reassembly		SELINT 2
AT#TCPREASS?	Read command returns whether the TCP reassembly feature is enabled or not, in the format: #TCPREASS: <n>	
AT#TCPREASS=?	Test command returns the supported range of values for parameter <n>.	

3.5.6.7.24. PING request - #PING

#PING – Send PING request	
AT#PING= <IPAddr>[,<retryNum>[,<len>[,<timeout>[,<tll>]]]]	<p>This command is used to send Ping Echo Request messages and to receive the corresponding Echo Reply.</p> <p>Parameters:</p> <p><IPAddr> - address of the remote host, string type. This parameter can be either:</p> <ul style="list-style-type: none"> - any valid IP address in the format: "xxx.xxx.xxx.xxx" - any host name to be solved with a DNS query <p><retryNum> - the number of Ping Echo Request to send 1-64 (default 4)</p> <p><len> - the length of Ping Echo Request message 32-1460 (default 32)</p> <p><timeout> - the timeout, in 100 ms units, waiting a single Echo Reply 1-600 (default 50)</p> <p><tll> - time to live 1-255 (default 128)</p> <p>Once the single Echo Reply message is received a string like that is displayed:</p> <p>#PING: <replyId>,<Ip Address>,<replyTime>,<tll></p> <p>Where:</p> <p><replyId> - Echo Reply number <Ip Address> - IP address of the remote host <replyTime> - time, in 100 ms units, required to receive the response <tll> - time to live of the Echo Reply message</p> <p>Note1: when the Echo Request timeout expires (no reply received on time)</p>



#PING – Send PING request	
	<p>the response will contain <replyTime> set to 600 and <tll> set to 255</p> <p>Note2: To receive the corresponding Echo Reply is not required to enable separately AT#ICMP</p> <p>Note3: Before send PING Request the GPRS context must have been activated by AT#SGACT=1,1</p>
AT#ICMP=?	Test command reports the supported range of values for the #PING command parameters.
Example	<pre>AT#PING="www.telit.com" #PING: 01, "81.201.117.177", 6, 50 #PING: 02, "81.201.117.177", 5, 50 #PING: 03, "81.201.117.177", 6, 50 #PING: 04, "81.201.117.177", 5, 50 OK</pre>



3.5.6.8. E-mail Management AT Commands

3.5.6.8.1. E-mail SMTP Server - #ESMTP

#ESMTP - E-mail SMTP Server		SELINT 0 / 1
AT#ESMTP [=<smtp>]	<p>Set command sets the SMTP server address, used for E-mail sending. SMTP server can be specified as IP address or as nick name.</p> <p>Parameter: <smtp> - SMTP server address, string type. This parameter can be either: <ul style="list-style-type: none"> - any valid IP address in the format: xxx.xxx.xxx.xxx - any host name to be solved with a DNS query in the format: <host name> (factory default is the empty string "")</p> <p>Note: the max length for <smtp> is the output of Test command.</p> <p>Note: If parameter is omitted then the behaviour of Set command is the same of Read command</p>	
AT#ESMTP?	<p>Read Command reports the current SMTP server address, in the format:</p> <p>#ESMTP: <smtp></p>	
AT#ESMTP=?	Test command returns the max length for the parameter <smtp> .	
Example	AT#ESMTP="smtp.mydomain.com" OK	
Note	The SMTP server used shall be inside the APN space (the smtp server provided by the network operator) or it must allow the Relay, otherwise it will refuse to send the e-mail.	

#ESMTP - E-mail SMTP Server		SELINT 2
AT#ESMTP= [<smtp>]	<p>Set command sets the SMTP server address, used for E-mail sending. SMTP server can be specified as IP address or as nick name.</p> <p>Parameter: <smtp> - SMTP server address, string type. This parameter can be either: <ul style="list-style-type: none"> - any valid IP address in the format: xxx.xxx.xxx.xxx - any host name to be solved with a DNS query in the format: <host name> (factory default is the empty string "")</p> <p>Note: the max length for <smtp> is the output of Test command.</p>	
AT#ESMTP?	<p>Read Command reports the current SMTP server address, in the format:</p> <p>#ESMTP: <smtp></p>	



#ESMTP - E-mail SMTP Server		SELINT 2
AT#ESMTP=?	Test command returns the max length for the parameter <smtp>.	
Example	AT#ESMTP="smtp.mydomain.com" OK	
Note	The SMTP server used shall be inside the APN space (the smtp server provided by the network operator) or it must allow the Relay, otherwise it will refuse to send the e-mail.	

3.5.6.8.2. E-mail Sender Address - #EADDR

#EADDR - E-mail Sender Address		SELINT 0 / 1
AT#EADDR [=<e-addr>]	Set command sets the sender address string to be used for sending the e-mail. Parameter: <e-addr> - sender address, string type. - any string value up to max length reported in the Test command. (factory default is the empty string "") Note: If parameter is omitted then the behaviour of Set command is the same of Read command	
AT#EADDR?	Read command reports the current sender address, in the format: #EADDR: <e-addr>	
AT#EADDR=?	Test command returns the maximum allowed length of the string parameter <e-addr>.	
Example	AT#EADDR="me@email.box.com" OK AT#EADDR? #EADDR: "me@email.box.com" OK	

#EADDR - E-mail Sender Address		SELINT 2
AT#EADDR= [<e-addr>]	Set command sets the sender address string to be used for sending the e-mail. Parameter: <e-addr> - sender address, string type. - any string value up to max length reported in the Test command. (factory default is the empty string "")	
AT#EADDR?	Read command reports the current sender address, in the format: #EADDR: <e-addr>	



#EPASSW - E-mail Authentication Password		SELINT 2
	<p>Parameter:</p> <p><e-pwd> - e-mail authentication password, string type.</p> <ul style="list-style-type: none"> - any string value up to max length reported in the Test command. (factory default is the empty string "") <p>Note: if no authentication is required then the <e-pwd> parameter shall be empty "".</p>	
AT#EPASSW=?	Test command returns the maximum allowed length of the string parameter <e-pwd> .	
Example	AT#EPASSW="myPassword" OK	
Note	It is a different password field than the one used for GPRS authentication (see #PASSW).	

3.5.6.8.5. E-mail Sending With GPRS Context Activation - #SEMAIL

#SEMAIL - E-mail Sending With GPRS Context Activation		SELINT 0 / 1
AT#SEMAIL=<da>, <subj>	<p>Execution command activates a GPRS context, if not previously activated by #EMAILACT, and sends an e-mail message. The GPRS context is deactivated when the e-mail is sent.</p> <p>Parameters:</p> <p><da> - destination address, string type (maximum length 100 characters).</p> <p><subj> - subject of the message, string type (maximum length 100 characters).</p> <p>The device responds to the command with the prompt '>' and awaits for the message body text.</p> <p>To complete the operation send Ctrl-Z char (0x1A hex); to exit without writing the message send ESC char (0x1B hex).</p> <p>If e-mail message is successfully sent, then the response is OK. If message sending fails for some reason, an error code is reported.</p> <p>Note: if the length of one of the string type parameters exceeds the maximum length, then the string is truncated.</p> <p>Note: Care must be taken to ensure that during the command execution,</p>	



#SEMAIL - E-mail Sending With GPRS Context Activation		SELINT 0 / 1
	<p>no other commands are issued.</p> <p>To avoid malfunctions is suggested to wait for the OK or ERROR / +CMS ERROR:<err> response before issuing further commands.</p> <p>Note: maximum length for message body is 1024 bytes, trying to send more data will cause the surplus to be discarded and lost.</p>	
Example	<pre>AT#SEMAIL="me@myaddress.com","subject of the mail" >message body... this is the text of the mail message... CTRL-Z ..wait.. OK Message has been sent.</pre>	
Note	<p>This command is obsolete. It's suggested to use the couple #EMAILACT and #EMAILD instead of it.</p>	

#SEMAIL - E-mail Sending With GPRS Context Activation		SELINT 2
<pre>AT#SEMAIL=[<da>,< subj>]</pre>	<p>Execution command activates a GPRS context, if not previously activated by #EMAILACT, and sends an e-mail message. The GPRS context is deactivated when the e-mail is sent.</p> <p>Parameters: <da> - destination address, string type. (maximum length 100 characters) <subj> - subject of the message, string type. (maximum length 100 characters)</p> <p>The device responds to the command with the prompt '>' and awaits for the message body text.</p> <p>To complete the operation send Ctrl-Z char (0x1A hex); to exit without writing the message send ESC char (0x1B hex).</p> <p>If e-mail message is successfully sent, then the response is OK. If message sending fails for some reason, an error code is reported.</p> <p>Note: if the length of one of the string type parameters exceeds the maximum length, then the string is truncated.</p> <p>Note: Care must be taken to ensure that during the command execution, no other commands are issued.</p>	



#SEMAIL - E-mail Sending With GPRS Context Activation	SELINT 2
	<p>To avoid malfunctions is suggested to wait for the OK or ERROR / +CMS ERROR:<err> response before issuing further commands.</p> <p>Note: maximum length for message body is 1024 bytes, trying to send more data will cause the surplus to be discarded and lost.</p> <p>Note: this command is not allowed if GSM context is active (see AT#SGACT=0,1).</p>
AT#SEMAIL=?	Test command returns the OK result code.
Example	<pre>AT#SEMAIL="me@myaddress.com","subject of the mail" >message body... this is the text of the mail message... CTRL-Z ..wait.. OK Message has been sent.</pre>

3.5.6.8.6. E-mail GPRS Context Activation - #EMAILACT

#EMAILACT - E-mail GPRS Context Activation	SELINT 0 / 1
AT#EMAILACT=[<mode>]	<p>Execution command deactivates/activates the GPRS context, eventually proceeding with the authentication with the parameters given with #PASSW and #USERID.</p> <p>Parameter: <mode> - GPRS context activation mode 0 - GPRS context deactivation request 1 - GPRS context activation request</p> <p>Note: issuing AT#EMAILACT<CR> reports the current status of the GPRS context for the e-mail, in the format:</p> <p>#EMAILACT: <status></p> <p>where: <status> 0 - GPRS context deactivated 1 - GPRS context activated</p> <p>Note: issuing AT#EMAILACT=<CR> is the same as issuing the command</p>



#EMAILACT - E-mail GPRS Context Ativation	SELINT 2
	<p>Note: if the PDP context #1 has been activated issuing AT#EMAILACT=1, then</p> <ul style="list-style-type: none"> • if you request to deactivate the PDP context #1 issuing AT#GPRS=0 DTE receives the final result code OK but nothing really happens • if you request to deactivate the PDP context #1 during a call issuing AT#EMAILACT=0 and then, after the call termination, you want to activate the PDP context #1 again through #EMAILACT, you need to issue the following sequence of three commands <pre>AT#EMAILACT=1 OK AT#EMAILACT=0 OK AT#EMAILACT=1 OK</pre> <p><i>(Analogous considerations if you want to request the activation of PDP context #1 issuing AT#GPRS=1, see #GPRS)</i></p> <p>Note: this command is not allowed if GSM context is active (see AT#SGACT=0,1).</p>
<p>AT#EMAILACT?</p>	<p>Read command reports the current status of the GPRS context for the e-mail, in the format:</p> <p>#EMAILACT: <status></p> <p>where:</p> <p><status></p> <ul style="list-style-type: none"> 0 - GPRS context deactivated 1 - GPRS context activated
<p>AT#EMAILACT=?</p>	<p>Test command returns the allowed values for parameter <mode>.</p>
<p>Example</p>	<pre>AT#EMAILACT=1 OK Now GPRS Context has been activated</pre> <pre>AT# EMAILACT=0 OK Now GPRS context has been deactivated.</pre>
<p>Note</p>	<p>It is strongly recommended to use the same command (e.g. #EMAILACT) to activate the context, deactivate it and interrogate about its status.</p>



#EMAILD - E-mail Sending	SELINT 2
<p>AT#EMAILD=[<da>, <subj>]</p>	<p>Execution command sends an e-mail message if GPRS context has already been activated by either AT#SGACT=1,1 or AT#EMAILACT=1 or AT#GPRS=1.</p> <p>It is also possible to send an e-mail on the GSM context, if it has already been activated by AT#SGACT=0,1.</p> <p>Parameters: <da> - destination address, string type. (maximum length 100 characters) <subj> - subject of the message, string type. (maximum length 100 characters)</p> <p>The device responds to the command with the prompt '>' and awaits for the message body text.</p> <p>To complete the operation send Ctrl-Z char (0x1A hex); to exit without writing the message send ESC char (0x1B hex).</p> <p>If e-mail message is successfully sent, then the response is OK. If message sending fails for some reason, an error code is reported.</p> <p>Note: if the length of one of the string type parameters exceeds the maximum length, then the string is truncated.</p> <p>Note: Care must be taken to ensure that during the command execution, no other commands are issued.</p> <p>To avoid malfunctions is suggested to wait for the OK or ERROR / +CMS ERROR:<err> response before issuing further commands.</p> <p>Note: maximum length for message body is 1024 bytes, trying to send more data will cause the surplus to be discarded and lost.</p>
<p>AT#EMAILD=?</p>	<p>Test command returns the OK result code.</p>
<p>Example</p>	<pre>AT#EMAILD="me@myaddress.com","subject of the mail" >message body... this is the text of the mail message... CTRL-Z ..wait.. OK <i>Message has been sent.</i></pre>
<p>Note</p>	<p>The only difference between this command (set using GPRS context)</p>



#EMAILD - E-mail Sending		SELINT 2
	and the #SEMAIL is that this command does not interact with the GPRS context status, leaving it ON or OFF according to the #EMAILACT (#SGACT) setting, thus, when the connection made with #EMAILD is closed, the context status is maintained.	

3.5.6.8.8. E-mail Parameters Save - #ESAV

#ESAV - E-mail Parameters Save		SELINT 0 / 1
AT#ESAV	Execution command stores the e-mail parameters in the NVM of the device. The e-mail parameters to store are: - E-mail User Name - E-mail Password - E-mail Sender Address - E-mail SMTP server	
Note	If some parameters have not been previously specified then a default value will be taken.	

#ESAV - E-mail Parameters Save		SELINT 2
AT#ESAV	Execution command stores the e-mail parameters in the NVM of the device. The e-mail parameters to store are: - E-mail User Name - E-mail Password - E-mail Sender Address - E-mail SMTP server	
AT#ESAV=?	Test command returns the OK result code.	
Note	If some parameters have not been previously specified then a default value will be taken.	

3.5.6.8.9. E-mail Parameters Reset - #ERST

#ERST - E-mail Parameters Reset		SELINT 0 / 1
AT#ERST	Execution command resets the e-mail parameters to the "factory default" configuration and stores them in the NVM of the device. The e-mail parameters to reset are: - E-mail User Name - E-mail Password - E-mail Sender Address - E-mail SMTP server	



#ERST - E-mail Parameters Reset		SELINT 2
AT#ERST	Execution command resets the e-mail parameters to the "factory default" configuration and stores them in the NVM of the device. The e-mail parameters to reset are: - E-mail User Name - E-mail Password - E-mail Sender Address - E-mail SMTP server	
AT#ERST=?	Test command returns the OK result code.	

3.5.6.8.10. SMTP Read Message - #EMAILMSG

#EMAILMSG - SMTP Read Message		SELINT 0 / 1
AT#EMAILMSG	Execution command returns the last response from SMTP server.	
AT#EMAILMSG?	Read command has the same behaviour as Execution command.	

#EMAILMSG - SMTP Read Message		SELINT 2
AT#EMAILMSG	Execution command returns the last response from SMTP server.	
AT#EMAILMSG=?	Test command returns the OK result code.	

3.5.6.9. Easy Scan® Extension AT Commands



NOTE:

it is strongly suggested to issue all the Easy Scan® Extension AT commands with **NO SIM** inserted, to avoid a potential conflict with normal module operations, such as "incoming call", "periodic location update", "periodic routing area update" and so on.

3.5.6.9.1. Network Survey - #CSURV

#CSURV - Network Survey		SELINT 0 / 1
AT#CSURV [=<s>,<e>]	Execution command allows to perform a quick survey through channels belonging to the band selected by last #BND command issue, starting from channel <s> to channel <e>. If parameters are omitted, a full band scan is performed.	
AT*CSURV		



#CSURV - Network Survey	SELINT 0 / 1
<p>[=<s>,<e>] <i>(both syntax are possible)</i></p>	<p>Parameters: <s> - starting channel <e> - ending channel</p> <p>After issuing the command the device responds with the string:</p> <p>Network survey started...</p> <p>and, after a while, a list of informations, one for each received carrier, is reported, each of them in the format:</p> <p style="text-align: center;">(For BCCH-Carrier)</p> <p>arfcn: <arfcn> bsic: <bsic> rxLev: <rxLev> ber: <ber> mcc: <mcc> mnc: <mnc> lac: <lac> cellId: <cellId> cellStatus: <cellStatus> numArfcn: <numArfcn> arfcn: [<arfcn1> .. [<arfcn64>]] [numChannels: <numChannels> array: [<ba1> .. [<ba32>]] [pbcch: <pbcch> [nom: <nom> rac: <rac> spgc: <spgc> pat: <pat> nco: <nco> t3168: <t3168> t3192: <t3192> drxmax: <drxmax> ctrlAck: <ctrlAck> bsCVmax: <bsCVmax> alpha: <alpha> pcMeasCh: <pcMeasCh>]]] <CR><LF><CR><LF><CR><LF></p> <p>where:</p> <p><arfcn> - C0 carrier assigned radio channel (BCCH - Broadcast Control Channel)</p> <p><bsic> - base station identification code</p> <p><rxLev> - reception level (in dBm)</p> <p><ber> - bit error rate (in %)</p> <p><mcc> - mobile country code</p> <p><mnc> - mobile network code</p> <p><lac> - location area code</p> <p><cellId> - cell identifier</p> <p><cellStatus> - cell status</p> <p>..CELL_SUITABLE - C0 is a suitable cell. CELL_LOW_PRIORITY - the cell is low priority based on the received system information. CELL_FORBIDDEN - the cell is forbidden. CELL_BARRED - the cell is barred based on the received system information. CELL_LOW_LEVEL - the cell <rxLev> is low. CELL_OTHER - none of the above e.g. exclusion timer running, no BCCH available...etc.</p>



#CSURV - Network Survey	SELINT 0 / 1
	<p><numArfcn> - number of valid channels in the Cell Channel Description</p> <p><arfcn<i>n</i>> - arfcn of a valid channel in the Cell Channel Description (<i>n</i> is in the range 1..<numArfcn>)</p> <p><numChannels> - number of valid channels in the BCCH Allocation list; the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> if #CSURVEXT=0 this information is displayed only for serving cell if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p><ba<i>n</i>> - arfcn of a valid channel in the BA list (<i>n</i> is in the range 1..<numChannels>); the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> if #CSURVEXT=0 this information is displayed only for serving cell if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p><i>(The following informations will be printed only if GPRS is supported in the cell)</i></p> <p><pbccch> - packet broadcast control channel 0 - pbccch not activated on the cell 1 - pbccch activated on the cell</p> <p><nom> - network operation mode 1 2 3</p> <p><rac> - routing area code 0..255 -</p> <p><spgc> - SPLIT_PG_CYCLE support ..0 - SPLIT_PG_CYCLE is not supported on CCCH on this cell ..1 - SPLIT_PG_CYCLE is supported on CCCH on this cell</p> <p><pat> - priority access threshold 0 - 3..6 -</p> <p><nco> - network control order 0..2 -</p> <p><t3168> - timer 3168 <t3192> - timer 3192 <drxmax> - discontinuous reception max time (in seconds) <ctrlAck> - packed control ack <bsCVmax> - blocked sequenc countdown max value</p>



#CSURV - Network Survey	SELINT 0 / 1
	<p><alpha> - alpha parameter for power control <pcMeasCh> - type of channel which shall be used for downlink measurements for power control 0 - BCCH 1 - PDCH</p> <p style="text-align: center;">(For non BCCH-Carrier/)</p> <p>arfcn: <arfcn> rxLev: <rxLev></p> <p>where: <arfcn> - RF channel <rxLev> - reception level (in dBm)</p> <p>Lastly, the #CSURV output ends in two ways, depending on the last #CSURVF setting:</p> <p style="text-align: center;">if #CSURVF=0 or #CSURVF=1</p> <p>The output ends with the string:</p> <p>Network survey ended</p> <p style="text-align: center;">if #CSURVF=2</p> <p>the output ends with the string:</p> <p>Network survey ended (Carrier: <NoARFCN> BCCh: <NoBCCh>)</p> <p>where <NoARFCN> - number of scanned frequencies <NoBCCH> - number of found BCCh</p>
<p>AT#CSURV?</p> <p>AT*CSURV?</p>	<p>Read command has the same behaviour as Execution command with parameters omitted.</p>
<p>Example</p>	<p>AT#CSURV</p> <p>Network survey started...</p> <p>arfcn: 48 bsic: 24 rxLev: -52 ber: 0.00 mcc: 610 mnc: 1 lac: 33281 cellId: 3648 cellStatus: CELL_SUITABLE numArfcn: 2 arfcn: 30 48 numChannels: 5 array: 14 19 22 48 82</p> <p>arfcn: 14 rxLev: 8</p>



#CSURV - Network Survey	SELINT 0 / 1
	Network survey ended OK
Note	The command is executed within max. 2 minutes.

#CSURV - Network Survey	SELINT 2
<p>AT#CSURV[= [<s>,<e>]]</p> <p>AT*CSURV[= [<s>,<e>]] <i>(both syntax are possible; the second syntax is maintained only for backward compatibility and will not be present in future versions)</i></p>	<p>Execution command allows to perform a quick survey through channels belonging to the band selected by last #BND command issue, starting from channel <s> to channel <e>. Issuing AT#CSURV<CR>, a full band scan is performed.</p> <p>Parameters: <s> - starting channel <e> - ending channel</p> <p>After issuing the command the device responds with the string: Network survey started...</p> <p>and, after a while, a list of informations, one for each received carrier, is reported, each of them in the format:</p> <p align="center">(For BCCH-Carrier)</p> <p>arfcn: <arfcn> bsic: <bsic> rxLev: <rxLev> ber: <ber> mcc: <mcc> mnc: <mnc> lac: <lac> cellId: <cellId> cellStatus: <cellStatus> numArfcn: <numArfcn> arfcn: [<arfcn1> .. [<arfcn64>]] [numChannels: <numChannels> array: [<ba1> .. [<ba32>]] [pbcch: <pbcch> [nom: <nom> rac: <rac> spgc: <spgc> pat: <pat> nco: <nco> t3168: <t3168> t3192: <t3192> drxmax: <drxmax> ctrlAck: <ctrlAck> bsCVmax: <bsCVmax> alpha: <alpha> pcMeasCh: <pcMeasCh>]]] <CR><LF><CR><LF><CR><LF></p> <p>where:</p> <p><arfcn> - C0 carrier assigned radio channel (BCCH - Broadcast Control Channel) <bsic> - base station identification code; if #CSURVF last setting is 0, <bsic> is a decimal number, else it is a 2-digits octal number <rxLev> - decimal number; it is the reception level (in dBm) <ber> - decimal number; it is the bit error rate (in %) <mcc> - hexadecimal 3-digits number; it is the mobile country code <mnc> - hexadecimal 2-digits number; it is the mobile network code <lac> - location area code; if #CSURVF last setting is 0, <lac> is a decimal</p>



#CSURV - Network Survey	SELINT 2
	<p>number, else it is a 4-digits hexadecimal number</p> <p><cellId> - cell identifier; if #CSURVF last setting is 0, <cellId> is a decimal number, else it is a 4-digits hexadecimal number</p> <p><cellStatus> - string type; it is the cell status</p> <p>..CELL_SUITABLE - C0 is a suitable cell.</p> <p>CELL_LOW_PRIORITY - the cell is low priority based on the received system information.</p> <p>CELL_FORBIDDEN - the cell is forbidden.</p> <p>CELL_BARRED - the cell is barred based on the received system information.</p> <p>CELL_LOW_LEVEL - the cell <rxLev> is low.</p> <p>CELL_OTHER - none of the above e.g. exclusion timer running, no BCCH available...etc.</p> <p><numArfcn> - number of valid channels in the Cell Channel Description</p> <p><arfcn<i>n</i>> - arfcn of a valid channel in the Cell Channel Description (<i>n</i> is in the range 1..<numArfcn>)</p> <p><numArfcn> - decimal number; it is the number of valid channels in the Cell Channel Description</p> <p><arfcn<i>n</i>> - decimal number; it is the arfcn of a valid channel in the Cell Channel Description (<i>n</i> is in the range 1..<numArfcn>)</p> <p><numChannels> - decimal number; it is the number of valid channels in the BCCH Allocation list; the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> 2. if #CSURVEXT=0 this information is displayed only for serving cell 3. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p><ba<i>n</i>> - decimal number; it is the arfcn of a valid channel in the BA list (<i>n</i> is in the range 1..<numChannels>); the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> 2. if #CSURVEXT=0 this information is displayed only for serving cell 3. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p><i>(The following informations will be printed only if GPRS is supported in the cell)</i></p> <p><pbccch> - packet broadcast control channel</p> <p>0 - pbccch not activated on the cell</p> <p>1 - pbccch activated on the cell</p> <p><nom> - network operation mode</p> <p>1</p>



#CSURV - Network Survey	SELINT 2
<p>2 3</p> <p><rac> - routing area code 0..255 -</p> <p><spgc> - SPLIT_PG_CYCLE support ..0 - SPLIT_PG_CYCLE is not supported on CCCH on this cell ..1 - SPLIT_PG_CYCLE is supported on CCCH on this cell</p> <p><pat> - priority access threshold 0 - 3..6 -</p> <p><nco> - network control order 0..2 -</p> <p><t3168> - timer 3168 <t3192> - timer 3192</p> <p><drxmax> - discontinuous reception max time (in seconds) <ctrlAck> - packed control ack <bsCVmax> - blocked sequenc countdown max value <alpha> - alpha parameter for power control <pcMeasCh> - type of channel which shall be used for downlink measurements for power control 0 - BCCH 1 - PDCH</p> <p style="text-align: center;">(For non BCCH-Carrier)</p> <p>arfcn: <arfcn> rxLev: <rxLev></p> <p>where: <arfcn> - decimal number; it is the RF channel <rxLev> - decimal number; it is the reception level (in dBm)</p> <p>Lastly, the #CSURV output ends in two ways, depending on the last #CSURVF setting:</p> <p style="text-align: center;">if #CSURVF=0 or #CSURVF=1</p> <p>The output ends with the string:</p> <p>Network survey ended</p> <p style="text-align: center;">if #CSURVF=2</p> <p>the output ends with the string:</p>	



#CSURV - Network Survey	SELINT 2
	<p>Network survey ended (Carrier: <NoARFCN> BCCh: <NoBCCh>)</p> <p>where <NoARFCN> - number of scanned frequencies <NoBCCH> - number of found BCCh</p>
Example	<pre>AT#CSURV Network survey started... arfcn: 48 bsic: 24 rxLev: -52 ber: 0.00 mcc: 610 mnc: 1 lac: 33281 cellId: 3648 cellStatus: CELL_SUITABLE numArfcn: 2 arfcn: 30 48 numChannels: 5 array: 14 19 22 48 82 arfcn: 14 rxLev: 8 Network survey ended OK</pre>
Note	The command is executed within max. 2 minute.

3.5.6.9.2. Network Survey - #CSURVC

#CSURVC - Network Survey (Numeric Format)	SELINT 0 / 1
<p>AT#CSURVC [=<s>,<e>]</p> <p>AT*CSURVC [=<s>,<e>] <i>(both syntax are possible)</i></p>	<p>Execution command allows to perform a quick survey through channels belonging to the band selected by last #BND command issue, starting from channel <s> to channel <e>. If parameters are omitted, a full band scan is performed.</p> <p>Parameters: <s> - starting channel <e> - ending channel</p> <p>After issuing the command the device responds with the string:</p> <p>Network survey started...</p> <p>and, after a while, a list of informations, one for each received carrier, is reported, each of them in the format:</p> <p style="text-align: center;">(For BCCH-Carrier)</p> <p><arfcn>,<bsic>,<rxLev>,<ber>,<mcc>,<mnc>,<lac>,<cellId>,<cellStatus>,<numArfcn>[,<arfcn1> ..[<arfcn64>]]</p>



#CSURVC - Network Survey (Numeric Format)	SELINT 0 / 1
	<pre data-bbox="438 421 1453 571">[,<numChannels>[,<ba1> ..[<ba32>]][,<pbccch> [,<nom>,<rac>,<spgc>,<pat>,<nco>,<t3168>,<t3192>,<drxmax>,<ctrlAck>,<bsCVmax>,<alpha>,<pcMeasCh>]]] <CR><LF><CR><LF><CR><LF></pre> <p data-bbox="438 604 1453 638">where:</p> <ul data-bbox="438 638 1453 1957" style="list-style-type: none"> <arfcn> - C0 carrier assigned radio channel (BCCH - Broadcast Control Channel) <bsic> - base station identification code <rxLev> - reception level (in dBm) <ber> - bit error rate (in %) <mcc> - mobile country code <mnc> - mobile network code <lac> - location area code <cellId> - cell identifier <cellStatus> - cell status <ul style="list-style-type: none"> ..0 - C0 is a suitable cell (CELL_SUITABLE). 1 - the cell is low priority based on the received system information (CELL_LOW_PRIORITY). 2 - the cell is forbidden (CELL_FORBIDDEN). 3 - the cell is barred based on the received system information (CELL_BARRED). 4 - the cell <rxLev> is low (CELL_LOW_LEVEL). 5 - none of the above e.g. exclusion timer running, no BCCH available...etc.. (CELL_OTHER). <numArfcn> - number of valid channels in the Cell Channel Description <arfcn<i>n</i>> - arfcn of a valid channel in the Cell Channel Description (<i>n</i> is in the range 1..<numArfcn>) <numChannels> - number of valid channels in the BCCH Allocation list; the output of this information for non-serving cells depends on last #CSURVEXT setting: <ol style="list-style-type: none"> if #CSURVEXT=0 this information is displayed only for serving cell if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <ba<i>n</i>> - arfcn of a valid channel in the BA list (<i>n</i> is in the range 1..<numChannels>); the output of this information for non-serving cells depends on last #CSURVEXT setting: <ol style="list-style-type: none"> if #CSURVEXT=0 this information is displayed only for serving cell if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier.



#CSURVC - Network Survey (Numeric Format)	SELINT 0 / 1
	<p><i>(The following informations will be printed only if GPRS is supported in the cell)</i></p> <p><pbccch> - packet broadcast control channel 0 - pbccch not activated on the cell 1 - pbccch activated on the cell</p> <p><nom> - network operation mode 1 2 3</p> <p><rac> - routing area code 0..255 -</p> <p><spgc> - SPLIT_PG_CYCLE support ..0 - SPLIT_PG_CYCLE is not supported on CCCH on this cell ..1 - SPLIT_PG_CYCLE is supported on CCCH on this cell</p> <p><pat> - priority access threshold 0 - 3..6 -</p> <p><nco> - network control order 0..2 -</p> <p><t3168> - timer 3168 <t3192> - timer 3192</p> <p><drxmax> - discontinuous reception max time (in seconds) <ctrlAck> - packed control ack <bsCVmax> - blocked sequenc countdown max value <alpha> - alpha parameter for power control <pcMeasCh> - type of channel which shall be used for downlink measurements for power control 0 - BCCH 1 - PDCH</p> <p style="text-align: center;">(For non BCCH-Carrier)</p> <p><arfcn>,<rxLev></p> <p>where: <arfcn> - RF channel <rxLev> - reception level (in dBm)</p> <p>The output ends with the string:</p> <p>Network survey ended</p>
AT#CSURVC?	Read command has the same behaviour as the Execution command with parameters omitted



#CSURVC - Network Survey (Numeric Format)		SELINT 0 / 1
AT*CSURVC?		
Example	AT#CSURVC Network survey started... 48,24,-52,0.00,610,1,33281,3648,0,2,30 48,5,14 19 22 48 82 14,8 Network survey ended OK	
Note	The command is executed within max. 2 minute. The information provided by #CSURVC is the same as that provided by #CSURV . The difference is that the output of #CSURVC is in numeric format only.	

#CSURVC - Network Survey (Numeric Format)		SELINT 2
AT#CSURVC[= [<s>,<e>]] AT*CSURVC[= [=<s>,<e>]] <i>(both syntax are possible; the second syntax is maintained only for backward compatibility and will not be present in future versions)</i>	Execution command allows to perform a quick survey through channels belonging to the band selected by last #BND command issue, starting from channel <s> to channel <e> . Issuing AT#CSURVC<CR> , a full band scan is performed. Parameters: <s> - starting channel <e> - ending channel After issuing the command the device responds with the string: Network survey started... and, after a while, a list of informations, one for each received carrier, is reported, each of them in the format: <p style="text-align: center;">(For BCCH-Carrier)</p> <arfcn>,<bsic>,<rxLev>,<ber>,<mcc>,<mnc>,<lac>,<cellId>,<cellStatus>,<numArfcn>[,<arfcn1> ..[<arfcn64>]] [,<numChannels>[,<ba1> ..[<ba32>]]][,<pbccch> [,<nom>,<rac>,<spgc>,<pat>,<nco>,<t3168>,<t3192>,<drxmax>,<ctrlAck>,<bsCVmax>,<alpha>,<pcMeasCh>]]] <CR><LF><CR><LF><CR><LF> 	



#CSURVC - Network Survey (Numeric Format)	SELINT 2
	<p>where:</p> <p><arfcn> - C0 carrier assigned radio channel (BCCH - Broadcast Control Channel)</p> <p><bsic> - base station identification code; if #CSURVF last setting is 0, <bsic> is a decimal number, else it is a 2-digits octal number</p> <p><rxLev> - decimal number; it is the reception level (in dBm)</p> <p><ber> - decimal number; it is the bit error rate (in %)</p> <p><mcc> - hexadecimal 3-digits number; it is the mobile country code</p> <p><mnc> - hexadecimal 2-digits number; it is the mobile network code</p> <p><lac> - location area code; if #CSURVF last setting is 0, <lac> is a decimal number, else it is a 4-digits hexadecimal number</p> <p><cellId> - cell identifier; if #CSURVF last setting is 0, <cellId> is a decimal number, else it is a 4-digits hexadecimal number</p> <p><cellStatus> - string type; it is the cell status</p> <p>..0 - C0 is a suitable cell (CELL_SUITABLE).</p> <p>1 - the cell is low priority based on the received system information (CELL_LOW_PRIORITY).</p> <p>2 - the cell is forbidden (CELL_FORBIDDEN).</p> <p>3 - the cell is barred based on the received system information (CELL_BARRED).</p> <p>4 - the cell <rxLev> is low (CELL_LOW_LEVEL).</p> <p>5 - none of the above e.g. exclusion timer running, no BCCH available...etc.. (CELL_OTHER).</p> <p><numArfcn> - decimal number; it is the number of valid channels in the Cell Channel Description</p> <p><arfcn<i>n</i>> - decimal number; it is the arfcn of a valid channel in the Cell Channel Description (<i>n</i> is in the range 1..<numArfcn>)</p> <p><numChannels> - decimal number; it is the number of valid channels in the BCCH Allocation list; the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> 1. if #CSURVEXT=0 this information is displayed only for serving cell 2. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier. <p><ba<i>n</i>> - decimal number; it is the arfcn of a valid channel in the BA list (<i>n</i> is in the range 1..<numChannels>); the output of this information for non-serving cells depends on last #CSURVEXT setting:</p> <ol style="list-style-type: none"> 1. if #CSURVEXT=0 this information is displayed only for serving cell 2. if #CSURVEXT=1 or 2 this information is displayed also for every valid scanned BCCH carrier.



#CSURVC - Network Survey (Numeric Format)	SELINT 2
<p><i>(The following informations will be printed only if GPRS is supported in the cell)</i></p> <p><pbccch> - packet broadcast control channel 0 - pbccch not activated on the cell 1 - pbccch activated on the cell</p> <p><nom> - network operation mode 1 2 3</p> <p><rac> - routing area code 0..255 -</p> <p><spgc> - SPLIT_PG_CYCLE support ..0 - SPLIT_PG_CYCLE is not supported on CCCH on this cell ..1 - SPLIT_PG_CYCLE is supported on CCCH on this cell</p> <p><pat> - priority access threshold 0 - 3..6 -</p> <p><nco> - network control order 0..2 -</p> <p><t3168> - timer 3168 <t3192> - timer 3192</p> <p><drxmax> - discontinuous reception max time (in seconds) <ctrlAck> - packed control ack <bsCVmax> - blocked sequenc countdown max value <alpha> - alpha parameter for power control <pcMeasCh> - type of channel which shall be used for downlink measurements for power control 0 - BCCH 1 - PDCH</p> <p style="text-align: center;">(For non BCCH-Carrier)</p> <p><arfcn>,<rxLev></p> <p>where: <arfcn> - decimal number; it is the RF channel <rxLev> - decimal number; it is the reception level (in dBm)</p> <p>The last information from #CSURVC depends on the last #CSURVF setting:</p> <p style="text-align: center;">#CSURVF=0 or #CSURVF=1</p>	



#CSURVC - Network Survey (Numeric Format)		SELINT 2
	<p>The output ends with the string: Network survey ended</p> <p style="text-align: center;">#CSURVF=2</p> <p>the output ends with the string: Network survey ended (Carrier: <NoARFCN> BCCh: <NoBCCh>) where <NoARFCN> - number of scanned frequencies <NoBCCH> - number of found BCCh</p>	
Example	<pre>AT#CSURVC Network survey started... 48,24,-52,0.00,610,1,33281,3648,0,2,30 48,5,14 19 22 48 82 14,8 Network survey ended OK</pre>	
Note	<p>The command is executed within max. 2 minute.</p> <p>The information provided by #CSURVC is the same as that provided by #CSURV. The difference is that the output of #CSURVC is in numeric format only.</p>	

3.5.6.9.3. Network Survey - #CSURVU

#CSURVU - Network Survey Of User Defined Channels		SELINT 0 / 1
<p>AT#CSURVU=[<ch1>[,<ch2>[,... [,<ch10>]]]]</p> <p>AT*CSURVU=[<ch1>[,<ch2>[,... [,<ch10>]]]] <i>(both syntax are possible)</i></p>	<p>Execution command allows to perform a quick survey through the given channels. The range of available channels depends on the last #BND issue.</p> <p>The result format is like command #CSURV.</p> <p>Parameters: <ch<i>n</i>> - channel number (arfcn)</p> <p>Note: issuing AT#CSURVU=<CR> is the same as issuing the command AT#CSURVU=0<CR>.</p>	
Example	<pre>AT#CSURVU=59,110 Network survey started...</pre>	



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

#CSURVU - Network Survey Of User Defined Channels	SELINT 0 / 1
	<pre>arfcn: 59 bsic: 16 rxLev: -76 ber: 0.00 mcc: 546 mnc: 1 lac: 54717 cellId: 21093 cellStatus: CELL_SUITABLE numArfcn 2 arfcn: 36 59 arfcn: 110 rxLev: -107 Network survey ended OK</pre>
Note	The command is executed within max. 2 minute.

#CSURVU - Network Survey Of User Defined Channels	SELINT 2
AT#CSURVU=[<ch1>[,<ch2>[,... [,<ch10>]]]] AT*CSURVU=[<ch1>[,<ch2>[,... [,<ch10>]]]] <i>(both syntax are possible; the second syntax is maintained only for backward compatibility and will not be present in future versions)</i>	<p>Execution command allows to perform a quick survey through the given channels. The range of available channels depends on the last #BND issue.</p> <p>The result format is like command #CSURV.</p> <p>Parameters: <ch<i>n</i>> - channel number (arfcn)</p>
Example	<pre>AT#CSURVU=59,110 Network survey started... arfcn: 59 bsic: 16 rxLev: -76 ber: 0.00 mcc: 546 mnc: 1 lac: 54717 cellId: 21093 cellStatus: CELL_SUITABLE numArfcn 2 arfcn: 36 59 arfcn: 110 rxLev: -107 Network survey ended OK</pre>
Note	The command is executed within max. 2 minute.

3.5.6.9.4. Network Survey - #CSURVUC

#CSURVUC - Network Survey Of User Defined Channels (Numeric Format)	SELINT 0 / 1
AT#CSURVUC=[Execution command allows to perform a quick survey through the given



#CSURVUC - Network Survey Of User Defined Channels (Numeric Format)		SELINT 0 / 1
<p><ch1>[,<ch2>[,... [,<ch10>]]]]</p> <p>AT*CSURVUC=[<ch1>[,<ch2>[,... [,<ch10>]]]]</p> <p><i>(both syntax are possible)</i></p>	<p>channels. The range of available channels depends on the last #BND issue.</p> <p>The result format is like command #CSURVC.</p> <p>Parameters: <ch<i>n</i>> - channel number (arfcn)</p> <p>Note: issuing AT#CSURVUC=<CR> is the same as issuing the command AT#CSURVUC=0<CR>.</p>	
Example	<pre>AT#CSURVUC=59,110 Network survey started... 59,16,-76,0.00,546,1,54717,21093,0,2,36 59 110,-107 Network survey ended OK</pre>	
Note	<p>The command is executed within max. 2 minute.</p> <p>The information provided by #CSURVUC is the same as that provided by #CSURVU. The difference is that the output of #CSURVUC is in numeric format only.</p>	

#CSURVUC - Network Survey Of User Defined Channels (Numeric Format)		SELINT 2
<p>AT#CSURVUC=[<ch1>[,<ch2>[,... [,<ch10>]]]]</p> <p>AT*CSURVUC=[<ch1>[,<ch2>[,... [,<ch10>]]]]</p> <p><i>(both syntax are possible; the second syntax is maintained only for backward compatibility and will not be present in future versions)</i></p>	<p>Execution command allows to perform a quick survey through the given channels. The range of available channels depends on the last #BND issue.</p> <p>The result format is like command #CSURVC.</p> <p>Parameters: <ch<i>n</i>> - channel number (arfcn)</p>	
Example	<pre>AT#CSURVUC=59,110</pre>	



#CSURVUC - Network Survey Of User Defined Channels (Numeric Format)		SELINT 2
	<p>Network survey started...</p> <p>59,16,-76,0.00,546,1,54717,21093,0,2,36 59</p> <p>110,-107</p> <p>Network survey ended</p> <p>OK</p>	
Note	<p>The command is executed within max. 2 minute.</p> <p>The information provided by #CSURVUC is the same as that provided by #CSURVU. The difference is that the output of #CSURVUC is in numeric format only.</p>	

3.5.6.9.5. BCCH Network Survey - #CSURVB

#CSURVB - BCCH Network Survey		SELINT 0 / 1
AT#CSURVB=<n>	<p>Execution command performs a quick network survey through M (maximum number of available frequencies depending on last selected band) channels. The survey stops as soon as <n> BCCH carriers are found.</p> <p>The result format is like command #CSURV.</p> <p>Parameter: <n> - number of desired BCCH carriers 1..M</p>	
AT#CSURVB=?	<p>Test command reports the range of values for parameter <n> in the format:</p> <p>(1-M)</p> <p>where M is the maximum number of available frequencies depending on last selected band.</p>	

#CSURVB - BCCH Network Survey		SELINT 2
AT#CSURVB=[<n>]	<p>Execution command performs a quick network survey through M (maximum number of available frequencies depending on last selected band) channels. The survey stops as soon as <n> BCCH carriers are found.</p> <p>The result format is like command #CSURV.</p>	



#CSURVB - BCCH Network Survey		SELINT 2
	Parameter: <n> - number of desired BCCH carriers 1..M	
AT#CSURVB=?	Test command reports the range of values for parameter <n> in the format: (1-M) where M is the maximum number of available frequencies depending on last selected band.	

3.5.6.9.6. BCCH Network Survey - #CSURVBC

#CSURVBC - BCCH Network Survey (Numeric Format)		SELINT 0 / 1
AT#CSURVBC= <n>	Execution command performs a quick network survey through M (maximum number of available frequencies depending on last selected band) channels. The survey stops as soon as <n> BCCH carriers are found. The result is given in numeric format and is like command #CSURVC. Parameter: <n> - number of desired BCCH carriers 1..M	
AT#CSURVBC=?	Test command reports the range of values for parameter <n> in the format: (1-M) where M is the maximum number of available frequencies depending on last selected band.	

#CSURVBC - BCCH Network Survey (Numeric Format)		SELINT 2
AT#CSURVBC= [<n>]	Execution command performs a quick network survey through M (maximum number of available frequencies depending on last selected band) channels. The survey stops as soon as <n> BCCH carriers are found. The result is given in numeric format and is like command #CSURVC. Parameter: <n> - number of desired BCCH carriers 1..M	
AT#CSURVBC=?	Test command reports the range of values for parameter <n> in the format:	



#CSURVBC - BCCH Network Survey (Numeric Format)		SELINT 2
	(1-M)	
	where M is the maximum number of available frequencies depending on last selected band.	

3.5.6.9.7. Network Survey Format - #CSURVF

#CSURVF - Network Survey Format		SELINT 0 / 1
AT#CSURVF=[<format>]	Set command controls the format of the numbers output by all the Easy Scan®	
	Parameter: <format> - numbers format 0 - Decimal 1 - Hexadecimal values, no text 2 - Hexadecimal values with text	
	Note: issuing AT#CSURVF<CR> is the same as issuing the Read command.	
	Note: issuing AT#CSURVF=<CR> is the same as issuing the command AT#CSURVF=0<CR>.	
AT#CSURVF?	Read command reports the current number format, as follows: <format>	
AT#CSURVF=?	Test command reports the supported range of values for the parameter <format>.	

#CSURVF - Network Survey Format		SELINT 2
AT#CSURVF=[<format>]	Set command controls the format of the numbers output by all the Easy Scan®	
	Parameter: <format> - numbers format 0 - Decimal 1 - Hexadecimal values, no text 2 - Hexadecimal values with text	
AT#CSURVF?	Read command reports the current number format, as follows: <format>	
AT#CSURVF=?	Test command reports the supported range of values for the parameter <format>.	



3.5.6.9.8. <CR><LF> Removing On Easy Scan® Commands Family - #CSURVNLF

#CSURVNLF - <CR><LF> Removing On Easy Scan® Commands Family		SELINT 0 / 1
AT#CSURVNLF [=<value>]	Set command enables/disables the automatic <CR><LF> removing from each information text line. Parameter: <value> 0 - disables <CR><LF> removing; they'll be present in the information text (factory default) 1 - remove <CR><LF> from information text Note: if parameter is omitted the behaviour of Set command is the same as Read command.	
AT#CSURVNLF?	Read command reports whether automatic <CR><LF> removing is currently enabled or not, in the format: <value>	
AT#CSURVNLF=?	Test command reports the range of values for parameter <value>.	

#CSURVNLF - <CR><LF> Removing On Easy Scan® Commands Family		SELINT 2
AT#CSURVNLF= [<value>]	Set command enables/disables the automatic <CR><LF> removing from each information text line. Parameter: <value> 0 - disables <CR><LF> removing; they'll be present in the information text (factory default) 1 - remove <CR><LF> from information text	
AT#CSURVNLF?	Read command reports whether automatic <CR><LF> removing is currently enabled or not, in the format: <value>	
AT#CSURVNLF=?	Test command reports the range of values for parameter <value>.	

3.5.6.9.9. Extended Network Survey - #CSURVEXT

#CSURVEXT - Extended Network Survey	SELINT 0 / 1
--	---------------------



#CSURVEXT - Extended Network Survey		SELINT 2
AT#CSURVEXT=?	Test command reports the range of values for parameter <value>.	

3.5.6.9.10. PLMN Network Survey - #CSURVP

#CSURVP - PLMN Network Survey		SELINT 2
AT#CSURVP=<plmn>	<p>Execution command performs a quick network survey through channels. The survey stops as soon as a BCCH carriers belonging to the selected PLMN is found.</p> <p>The result format is like command #CSURV.</p> <p>Parameter: <plmn> - the desidered PLMN in numeric format</p>	
AT#CSURVP=?	Test command returns OK	

3.5.6.9.11. PLMN Network Survey (Numeric Format) - #CSURVPC

#CSURVPC - PLMN Network Survey (Numeric Format)		SELINT 2
AT#CSURVPC=<plmn>	<p>Execution command performs a quick network survey through channels. The survey stops as soon as a BCCH carriers belonging to the selected PLMN is found.</p> <p>The result is given in numeric format and is like command #CSURVC.</p> <p>Parameter: <plmn> - the desidered PLMN in numeric format</p>	
AT#CSURVPC=?	Test command returns OK	

3.5.6.10. SIM Toolkit AT Commands

3.5.6.10.1. SIM Toolkit Interface Activation - #STIA

#STIA - SIM Toolkit Interface Activation		SELINT 2
AT#STIA=[<mode> [,<timeout>]]	<p>Set command is used to activate the SAT sending of unsolicited indications when a proactive command is received from SIM.</p> <p>Parameters: <mode> 0 - disable SAT (default for all products, except GE865-QUAD and GE864-</p>	



#STIA - SIM Toolkit Interface Activation	SELINT 2
	<p>DUAL V2)</p> <p>1 - enable SAT without unsolicited indication #STN (default for GE865-QUAD and GE864-DUAL V2)</p> <p>2 - enable SAT and extended unsolicited indication #STN (see #STGI)</p> <p>3 - enable SAT and reduced unsolicited indication #STN (see #STGI)</p> <p>17 - enable SAT without unsolicited indication #STN and 3GPP TS 23.038 alphabet used</p> <p>18 - enable SAT and extended unsolicited indication #STN (see #STGI) and 3GPP TS 23.038 alphabet used</p> <p>19 - enable SAT and reduced unsolicited indication #STN (see #STGI) and 3GPP TS 23.038 alphabet used</p> <p>33 - enable SAT without unsolicited indication #STN and UCS2 alphabet used</p> <p>34 - enable SAT and extended unsolicited indication #STN (see #STGI) and UCS2 alphabet used</p> <p>35 - enable SAT and reduced unsolicited indication #STN (see #STGI) and UCS2 alphabet used</p> <p><timeout> - time-out for user responses</p> <p>1..255 - time-out in minutes (default 10). Any ongoing (but unanswered) proactive command will be aborted automatically after <timeout> minutes. In this case, the terminal response is either "ME currently unable to process command", or if applicable, "No response from user". In addition an unsolicited indication will be sent to the external application:</p> <p>#STN: <cmdTerminateValue></p> <p>where:</p> <p><cmdTerminateValue> is defined as <cmdType> + terminate offset; the terminate offset equals 100.</p> <p>Note: every time the SIM application issues a proactive command that requires user interaction an unsolicited code will be sent, if enabled with #STIA command, as follows:</p> <ul style="list-style-type: none"> if <mode> parameter of #STIA command has been set to 3 (reduced unsolicited indication) an unsolicited indication will be sent, indicating the type of proactive command issued by the SIM: <p>#STN: <cmdType></p>



#STIA - SIM Toolkit Interface Activation	SELINT 2
	<ul style="list-style-type: none"> if <mode> parameter of #STIA command has been set to 2 (extended unsolicited indication) the format of the unsolicited indication depends on the specific command: <ul style="list-style-type: none"> <i>if <cmdType>=1 (REFRESH)</i> <p>an unsolicited notification will be sent to the user:</p> <p>#STN: <cmdType>,<refresh type></p> <p>where:</p> <p><refresh type></p> <ul style="list-style-type: none"> 0 - SIM Initialization and Full File Change Notification; 1 - File Change Notification; 2 - SIM Initialization and File Change Notification; 3 - SIM Initialization; 4 - SIM Reset <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>In this case neither #STGI nor #STSR commands are required:</p> <ul style="list-style-type: none"> AT#STGI is accepted anyway. AT#STSR=<cmdType>,0 will answer OK but do nothing. </div> <ul style="list-style-type: none"> <i>if <cmdType>=17 (SEND SS)</i> <i>if <cmdType>=19 (SEND SHORT MESSAGE)</i> <i>if <cmdType>=20 (SEND DTMF)</i> <i>if <cmdType>=32 (PLAY TONE)</i> <p>an unsolicited notification will be sent if allowed by SIM (see GSM 11.14):</p> <p>#STN: <cmdType>[,<text>]</p> <p>where:</p> <p><text> - (optional) text to be displayed to user</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>In these cases neither #STGI nor #STSR commands are required:</p> <ul style="list-style-type: none"> AT#STGI is accepted anyway. </div>



#STIA - SIM Toolkit Interface Activation	SELINT 2
	<ul style="list-style-type: none"> • AT#STSR=<cmdType>,0 will answer OK but do nothing. <p>In case of SEND SHORT MESSAGE (<cmdType>=19) command if sending to network fails an unsolicited notification will be sent</p> <p>#STN: 119</p> <p style="text-align: center;"><i>if <cmdType>=33 (DISPLAY TEXT)</i></p> <p>an unsolicited notification will be sent if allowed by SIM (see GSM 11.14):</p> <p>#STN: <cmdType>[,<cmdDetails>{,<text>}]</p> <p>where:</p> <p><cmdDetails> - unsigned Integer used as a bit field. 0..255 - used as a bit field:</p> <ul style="list-style-type: none"> bit 1: <ul style="list-style-type: none"> 0 - normal priority 1 - high priority bits 2 to 7: reserved for future use bit 8: <ul style="list-style-type: none"> 0 - clear message after a delay 1 - wait for user to clear message <p><text> - (optional) text to be displayed to user</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>In this case:</p> <ol style="list-style-type: none"> 1. if <cmdDetails>/bit8 is 0 neither #STGI nor #STSR commands are required: <ul style="list-style-type: none"> • AT#STGI is accepted anyway. • AT#STSR=<cmdType>,0 will answer OK but do nothing. 2. If <cmdDetails>/bit8 is 1 #STSR command is required </div> <p style="text-align: center;"><i>if <cmdType>=40 (SET UP IDLE MODE TEXT)</i></p> <p>an unsolicited notification will be sent:</p> <p>#STN: <cmdType>[,<text>]</p> <p>where:</p>



#STIA - SIM Toolkit Interface Activation	SELINT 2
	<p><text> - (optional)text to be displayed to user</p> <div data-bbox="496 533 1382 685" style="border: 1px solid black; padding: 5px;"> <p>In these cases neither #STGI nor #STSR commands are required:</p> <ul style="list-style-type: none"> • AT#STGI is accepted anyway. • AT#STSR=<cmdType>,0 will answer OK but do nothing. </div> <p style="text-align: center;"><i>if <cmdType>=18 (SEND USSD)</i></p> <p>an unsolicited notification will be sent to the user:</p> <p>#STN: <cmdType>[,<text>]</p> <p>where:</p> <p><text> - optional text string sent by SIM</p> <div data-bbox="496 1093 1382 1245" style="border: 1px solid black; padding: 5px;"> <p>In this case:</p> <ul style="list-style-type: none"> • AT#STSR=18,20 can be sent to end USSD transaction. • AT#STGI is accepted anyway. • AT#STSR=<cmdType>,0 will answer OK but do nothing. </div> <p style="text-align: center;"><i>if <cmdType>=5 (SET UP EVENT LIST)</i></p> <p>an unsolicited notification will be sent:</p> <p>#STN: <cmdType>[,<event list mask>]</p> <p>where:</p> <p><event list mask> - (optional)hexadecimal number representing the list of events to monitor (see GSM 11.14)</p> <ul style="list-style-type: none"> - '00' = MT call - '01' = Call connected - '02' = Call disconnected - '03' = Location status - '04' = User activity - '05' = Idle screen available - '06' = Card reader status (if class "a" is supported) - '07' = Language selection - '08' = Browser Termination (if class "c" is supported)



#STIA - SIM Toolkit Interface Activation	SELINT 2
	<p>- '09' = Data available (if class "e" is supported) - '0A' = Channel status (if class "e" is supported)</p> <p>The hexadecimal number is actually a bit mask, where each bit, when set, indicates that the corresponding event has to be monitored (e.g., if <event list mask> is 0x0001, it means that MT call has to be monitored).</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>In these cases neither #STGI nor #STSR commands are required:</p> <ul style="list-style-type: none"> • AT#STGI is accepted anyway. • AT#STSR=<cmdType>,0 will answer OK but do nothing. </div> <p>All other commands:</p> <p>the unsolicited indication will report just the proactive command type:</p> <p>#STN: <cmdType></p> <p>Note: if the call control or SMS control facility in the SIM is activated, when the customer application makes an outgoing call, or sends an SS or USSD, or an SMS, the following #STN unsolicited indication could be sent, according to GSM 11.14, to indicate whether the outgoing call has been accepted, rejected or modified by the SIM, or if the SMS service centre address or destination has been changed:</p> <p>#STN: <cmdTerminateValue>,<Result>[,<TextInfo>[,<Number>[,<MODestAddr>]]]</p> <p>where</p> <p><cmdTerminateValue> 150 - SMS control response 160 - call/SS/USSD response</p> <p><Result> 0 - Call/SMS not allowed 1 - Call/SMS allowed 2 - Call/SMS allowed with modification</p> <p><Number> - Called number, Service Center Address or SS String in ASCII format.</p> <p><MODestAddr> - MO destination address in ASCII format.</p> <p><TextInfo> - alpha identifier provided by the SIM in ASCII format.</p>



#STIA - SIM Toolkit Interface Activation	SELINT 2
	<p>Note: an unsolicited result code</p> <p>#STN: 254</p> <p>is sent if the user has indicated the need to end the proactive SIM application session (AT#STSR=<cmdType>,16 i.e. “proactive SIM application session terminated by the user” according to GSM 11.14).</p> <p>The TA does not need to respond directly, i.e. AT#STSR is not required. It is possible to restart the SAT session from the main menu again with the command AT#STGI=37.</p> <p>Note: The settings are saved on user profile and available on following reboot. SIM Toolkit activation/deactivation is only performed at power on.</p>
AT#STIA?	<p>Read command can be used to get information about the SAT interface in the format:</p> <p>#STIA: <state>,<mode>,<timeout>,<SatProfile></p> <p>where:</p> <ul style="list-style-type: none"> <state> - the device is in one of the following state: <ul style="list-style-type: none"> 0 - SIM has not started its application yet 1 - SIM has started its application (SAT main menu ready) <mode> - SAT and unsolicited indications enabling status (see above) <timeout> - time-out for user responses (see above) <SatProfile> - SAT Terminal Profile according to GSM 11.14, i. e. the list of SIM Application Toolkit facilities that are supported by the ME. The profile cannot be changed by the TA. <p>Note: In SAT applications usually an SMS message is sent to the network provider containing service requests, e.g. to send the latest news. The provider returns a message with the requested information. Before activating SAT it is recommended to set the SMS text mode with command AT+CMGF=1 and to enable unsolicited indications for incoming SMS messages with command +CNMI.</p>
AT#STIA=?	<p>Test command returns the range of available values for the parameters <mode> and <timeout>.</p>
Note	<p>Just one instance at a time, the one which first issued AT#STIA=n (with <i>n</i> different from zero), is allowed to issue SAT commands, and this is valid till</p>



#STGI - SIM Toolkit Get Information	SELINT 2
<p>#STGI: <parameters></p> <p>where <parameters> depends upon the ongoing proactive command as follows:</p> <p style="text-align: center;"><i>if <cmdType>=1 (REFRESH)</i></p> <p>#STGI: <cmdType>,<refresh type> where: <refresh type></p> <ul style="list-style-type: none"> 0 - SIM Initialization and Full File Change Notification; 1 - File Change Notification; 2 - SIM Initialization and File Change Notification; 3 - SIM Initialization; 4 - SIM Reset <p style="text-align: center;"><i>if <cmdType>=5 (SET UP EVENT LIST)</i></p> <p>#STGI: <cmdType>,<event list mask></p> <p>where: <event list mask> - hexadecimal number representing the list of events to monitor (see GSM 11.14):</p> <ul style="list-style-type: none"> - '00' = MT call - '01' = Call connected - '02' = Call disconnected - '03' = Location status - '04' = User activity - '05' = Idle screen available - '06' = Card reader status (if class "a" is supported) - '07' = Language selection - '08' = Browser Termination (if class "c" is supported) - '09' = Data available (if class "e" is supported) - '0A' = Channel status (if class "e" is supported) <p>The hexadecimal number is actually a bit mask, where each bit, when set, indicates that the corresponding event has to be monitored (e.g., if <event list mask> is 0x0001, it means that MT call has to be monitored).</p> <p style="text-align: center;"><i>if <cmdType>=16 (SET UP CALL)</i></p>	



#STGI - SIM Toolkit Get Information	SELINT 2
<p>#STGI: <cmdType>,<commandDetails>,[<confirmationText>],<calledNumber></p> <p>where:</p> <p><commandDetails> - unsigned integer, used as an enumeration</p> <ul style="list-style-type: none"> 0 Set up call, but only if not currently busy on another call 1 Set up call, but only if not currently busy on another call, with redial 2 Set up call, putting all other calls (if any) on hold 3 Set up call, putting all other calls (if any) on hold, with redial 4 Set up call, disconnecting all other calls (if any) 5 Set up call, disconnecting all other calls (if any), with redial <p><confirmationText> - string for user confirmation stage</p> <p><calledNumber> - string containing called number</p> <p style="text-align: center;"> <i>if <cmdType>=17 (SEND SS)</i> <i>if <cmdType>=18 (SEND USSD)</i> <i>if <cmdType>=19 (SEND SHORT MESSAGE)</i> <i>if <cmdType>=20 (SEND DTMF)</i> <i>if <cmdType>=32 (PLAY TONE)</i> <i>if <cmdType>=40 (SET UP IDLE MODE TEXT)</i> </p> <p>#STGI: <cmdType>[,<text>]</p> <p>where:</p> <p><text> - text to be displayed to user</p> <p style="text-align: center;"><i>if <cmdType>=33 (DISPLAY TEXT)</i></p> <p>#STGI: <cmdType>,<cmdDetails>[,<text>]</p> <p>where:</p> <p><cmdDetails> - unsigned Integer used as a bit field.</p> <p>0..255 - used as a bit field:</p> <ul style="list-style-type: none"> bit 1: <ul style="list-style-type: none"> 0 - normal priority 1 - high priority bits 2 to 7: reserved for future use bit 8: <ul style="list-style-type: none"> 0 - clear message after a delay 	



#STGI - SIM Toolkit Get Information	SELINT 2
<p>1 - wait for user to clear message <text> - text to be displayed to user</p> <p style="text-align: center;"><i>if <cmdType>=34 (GET INKEY)</i></p> <p>#STGI: <cmdType>,<commandDetails>,<text></p> <p>where: <commandDetails> - unsigned Integer used as a bit field. 0..255 - used as a bit field:</p> <p>bit 1: 0 - Digits only (0-9, *, # and +) 1 - Alphabet set;</p> <p>bit 2: 0 - SMS default alphabet (GSM character set) 1 - UCS2 alphabet</p> <p>bit 3: 0 - Character sets defined by bit 1 and bit 2 are enabled 1 - Character sets defined by bit 1 and bit 2 are disabled and the "Yes/No" response is requested</p> <p>bits 4 to 7: 0</p> <p>bit 8: 0 - No help information available 1 - Help information available</p> <p><text> - String as prompt for text.</p> <p style="text-align: center;"><i>if <cmdType>=35 (GET INPUT)</i></p> <p>#STGI: <cmdType>,<commandDetails>,<text>,<responseMin>,<responseMax>[,<defaultText>]</p> <p>where: <commandDetails> - unsigned Integer used as a bit field. 0..255 - used as a bit field:</p> <p>bit 1: 0 - Digits only (0-9, *, #, and +) 1 - Alphabet set</p> <p>bit 2: 0 - SMS default alphabet (GSM character set)</p>	



#STGI - SIM Toolkit Get Information	SELINT 2
	<p>1 - UCS2 alphabet</p> <p>bit 3:</p> <p>0 - ME may echo user input on the display</p> <p>1 - User input shall not be revealed in any way. Hidden entry mode (see GSM 11.14) is only available when using digit input. In hidden entry mode only characters ('0'-'9', '*' and '#') are allowed.</p> <p>bit 4:</p> <p>0 - User input to be in unpacked format</p> <p>1 - User input to be in SMS packed format</p> <p>bits 5 to 7:</p> <p>0</p> <p>bit 8:</p> <p>0 - No help information available</p> <p>1 - Help information available</p> <p><text> - string as prompt for text</p> <p><responseMin> - minimum length of user input 0..255</p> <p><responseMax> - maximum length of user input 0..255</p> <p><defaultText> - string supplied as default response text</p> <p style="text-align: center;"><i>if <cmdType>=36 (SELECT ITEM)</i></p> <p>The first line of output is:</p> <p>#STGI: <cmdType>,<commandDetails>,<numOfItems>[,<titleText>] <CR><LF></p> <p>One line follows for every item, repeated for <numOfItems>:</p> <p>#STGI: <cmdType>,<itemId>,<itemText>[,<nextActionId>]</p> <p>where:</p> <p><commandDetails> - unsigned Integer used as a bitfield 0..255 - used as a bit field:</p> <p>bit 1:</p> <p>0 - Presentation type is not specified</p> <p>1 - Presentation type is specified in bit 2</p> <p>bit 2:</p> <p>0 - Presentation as a choice of data values if bit 1 = '1'</p> <p>1 - Presentation as a choice of navigation options if bit 1 is '1'</p>



#STGI - SIM Toolkit Get Information	SELINT 2
	<p> bit 3: 0 - No selection preference 1 - Selection using soft key preferred bits 4 to 7: 0 bit 8: 0 - No help information available 1 - Help information available <numOfItems> - number of items in the list <titleText> - string giving menu title <itemId> - item identifier 1..<numOfItems> <itemText> - title of item <nextActionId> - the next proactive command type to be issued upon execution of the menu item. 0 - no next action information available. </p> <p style="text-align: center;"><i>if <cmdType>=37 (SET UP MENU)</i></p> <p>The first line of output is:</p> <p>#STGI: <cmdType>,<commandDetails>,<numOfItems>,<titleText> <CR><LF></p> <p>One line follows for every item, repeated for <numOfItems>:</p> <p>#STGI: <cmdType>,<itemId>,<itemText>[,<nextActionId>]</p> <p>where:</p> <p><commandDetails> - unsigned Integer used as a bitfield 0..255 - used as a bit field:</p> <p> bit 1: 0 - no selection preference 1 - selection using soft key preferred bit 2 to 7: 0 bit 8: 0 - no help information available 1 - help information available <numOfItems> - number of items in the list <titleText> - string giving menu title </p>



#STGI - SIM Toolkit Get Information	SELINT 2
	<p><itemId> - item identifier 1..<numOfItems> <itemText> - title of item <nextActionId> - the next proactive command type to be issued upon execution of the menu item. 0 - no next action information available.</p> <p>Note: upon receiving the #STGI response, the TA must send #STSR command (see below) to confirm the execution of the proactive command and provide any required user response, e.g. selected menu item.</p>
AT#STGI?	<p>The read command can be used to request the currently ongoing proactive command and the SAT state in the format</p> <p>#STGI: <state>,cmdType> where: <state> - SAT interface state (see #STIA) <cmdType> - ongoing proactive command</p> <p>An error message will be returned if there is no pending command.</p>
AT#STGI=?	<p>Test command returns the range for the parameters <state> and <cmdType>.</p>
Note	<p>The unsolicited notification sent to the user:</p> <p>#STN: 37</p> <p>is an indication that the main menu of the SIM Application has been sent to the TA. It will be stored by the TA so that it can be displayed later at any time by issuing an AT#STGI=37 command.</p> <p>A typical SAT session on AT interface starts after an #STN: 37 unsolicited code is received, if enabled. At that point usually an AT#STGI=37 command is issued, and after the SAT main menu has been displayed on TE an AT#STSR=37,0,x command is issued to select an item in the menu (see below). The session usually ends with a SIM action like sending an SMS, or starting a call. After this, to restart the session from the beginning going back to SAT main menu it is usually required an AT#STSR=37,16 command.</p> <p>The unsolicited notification sent to the user:</p> <p>#STN:237</p>



#STGI - SIM Toolkit Get Information	SELINT 2
	is an indication that the main menu of the SIM Application has been removed from the TA, and it is no longer available. In this case AT#STGI=37 command response will be always ERROR .

3.5.6.10.3. SIM Toolkit Send Response - #STSR

#STSR - SIM Toolkit Send Response	SELINT 2
AT#STSR= [<cmdType> <userResponse> [,<data>]]	<p>The write command is used to provide to SIM user response to a command and any required user information, e.g. a selected menu item.</p> <p>Parameters:</p> <p><cmdType> - integer type; proactive command ID according to GSM 11.14 (see #STGI)</p> <p><userResponse> - action performed by the user</p> <ul style="list-style-type: none"> 0 - command performed successfully (call accepted in case of call setup) 16 - proactive SIM session terminated by user 17 - backward move in the proactive SIM session requested by the user 18 - no response from user 19 - help information required by the user 20 - USSD/SS Transaction terminated by user 32 - TA currently unable to process command 34 - user has denied SIM call setup request 35 - user cleared down SIM call before connection or network release <p><data> - data entered by user, depending on <cmdType>, only required if <Result> is 0:</p> <p style="text-align: center;"><i>Get Inkey</i></p> <p><data> contains the key pressed by the user; used character set should be the one selected with +CSCS.</p> <p>Note: if, as a user response, a binary choice (Yes/No) is requested by the SIM application using bit 3 of the <commandDetails> parameter the valid content of the <inputString> is:</p> <ul style="list-style-type: none"> a) "IRA", "8859-1", "PCCP437" charsets: "Y" or "y" (positive answer) and "N" or "n" (negative answer) b) UCS2 alphabet "0079" or "0059" (positive answer) and "006E" or "004E" (negative answer) <p style="text-align: center;"><i>Get Input</i></p> <p><data> - contains the string of characters entered by the user (see above)</p> <p style="text-align: center;"><i>Select Item</i></p>



#STSR - SIM Toolkit Send Response	SELINT 2
	<p><data> - contains the item identifier selected by the user</p> <p>Note: Use of icons is not supported. All icon related actions will respond with no icon available.</p>
AT#STSR?	<p>The read command can be used to request the currently ongoing proactive command and the SAT state in the format</p> <p>#STSR: <state>,<cmdType></p> <p>where: <state> - SAT interface state (see #STIA) <cmdType> - ongoing proactive command</p> <p>An error message will be returned if there is no pending command.</p>
AT#STSR=?	<p>Test command returns the range for the parameters <state> and <cmdType>.</p>

3.5.6.10.4. SIM Toolkit terminal Attach - #STTA

#STTA - SIM Toolkit Terminal Attach	SELINT 2
AT#STTA=<state>	<p>This command attaches/detaches the SIM Toolkit application to the AT instance reserved for this use.</p> <p>Parameters: <state>: attached state 0 - SIM Toolkit detaches 1 - SIM Toolkit attaches</p> <p>If SIM Toolkit application has been already attached/detached the command does nothing and returns OK.</p>
AT#STTA?	<p>Read command reports the current <state> in the format: #STTA: <state></p>
AT#STTA=?	<p>Test command reports the supported range of values for parameter <state></p>
Note	<p>The AT instance reserved for the SIM Toolkit application is the #3.</p> <p>Issuing AT#STTA=<state> when the AT instance has been already</p>



	attached to another service (CMUX, SMSATRUN/TCPATRUN, OTA) causes an ERROR result code to be returned.
--	--

3.5.6.11. Jammed Detect & Report AT Commands

3.5.6.11.1. Jammed Detect & Report - #JDR

#JDR - Jammed Detect & Report	SELINT 0 / 1
<p>AT#JDR[= [<mode> [,<MNPL>, <DCMN>]]]</p>	<p>Set command allows to control the Jammed Detect & Report feature.</p> <p>The MODULE can detect if a communication Jammer is active in its range and give indication to the user of this condition either on the serial line with an unsolicited code or on a dedicated GPIO by rising it.</p> <p>Parameters:</p> <p><mode> - behaviour mode of the Jammed Detect & Report</p> <ul style="list-style-type: none"> 0 - disables Jammed Detect & Report (factory default) 1 - enables the Jammed Detect; the Jammed condition is reported on pin GPIO2/JDR <ul style="list-style-type: none"> GPIO2/JDR Low - Normal Operating Condition GPIO2/JDR High - Jammed Condition. 2 - enables the Jammed Detect; the Jammed condition is reported with a single unsolicited result code on serial line, in the format: <p>#JDR: <status> where: <status> JAMMED - Jammed condition detected OPERATIVE - Normal Operating condition restored. This code will be shown only after a jammed condition has occurred.</p> 3 - enables the Jammed Detect; the MODULE will make both the actions as for <mode>=1 and <mode>=2. 4 - enables the Jammed Detect; the Jammed condition is reported with an unsolicited code every 3s on serial line, in the format: <p>#JDR: <status> where: <status> JAMMED - Jammed condition detected OPERATIVE - Normal Operating condition restored. This code will be shown only after a jammed condition has occurred.</p> 5 - enables the Jammed Detect; the MODULE will make both the actions as for <mode>=1 and <mode>=4.



#JDR - Jammed Detect & Report		SELINT 0 / 1
	<p><MNPL> - Maximum Noise Power Level 0..127 (factory default is 70)</p> <p><DCMN> - Disturbed Channel Minimum Number 0..254 (factory default is 5)</p> <p>Note: issuing AT#JDR<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#JDR=<CR> is the same as issuing the command AT#JDR=0<CR>.</p>	
AT#JDR?	<p>Read command reports the current behaviour mode, Maximum Noise Power Level and Disturbed Channel Minimum Number, in the format:</p> <p>#JDR: <mode>,<MNPL>,<DCMN></p>	
AT#JDR=?	<p>Test command reports the supported range of values for the parameters <mode>,<MNPL> and <DCMN></p>	
Example	<pre>AT#JDR=2 OK ...jammer enters in the range... #JDR: JAMMED ...jammer exits the range... #JDR: OPERATIVE</pre>	
Note	<p>It is suggested not to change the default setting for Maximum Noise Power Level and Disturbed Channel Minimum Number.</p> <p>If the device is installed in a particular environment where the default values are not satisfactory the two parameters <MNPL> and <DCMN> permit to adapt the detection to all conditions.</p>	

#JDR - Jammed Detect & Report		SELINT 2
AT#JDR= [<mode> [,<MNPL>, <DCMN>]]	<p>Set command allows to control the Jammed Detect & Report feature.</p> <p>The MODULE can detect if a communication Jammer is active in its range and give indication to the user of this condition either on the serial line with an unsolicited code or on a dedicated GPIO by rising it.</p> <p>Parameters: <mode> - behaviour mode of the Jammed Detect & Report 0 - disables Jammed Detect & Report (factory default)</p>	



#JDR - Jammed Detect & Report	SELINT 2
	<p>1 - enables the Jammed Detect; the Jammed condition is reported on pin GPIO2/JDR GPIO2/JDR Low - Normal Operating Condition GPIO2/JDR High - Jammed Condition.</p> <p>2 - enables the Jammed Detect; the Jammed condition is reported with a single unsolicited result code on serial line, in the format:</p> <p>#JDR: <status> where: <status> JAMMED - Jammed condition detected OPERATIVE - Normal Operating condition restored. This code will be shown only after a jammed condition has occurred.</p> <p>3 - enables the Jammed Detect; the MODULE will make both the actions as for <mode>=1 and <mode>=2.</p> <p>4 - enables the Jammed Detect; the Jammed condition is reported with an unsolicited code every 3s on serial line, in the format:</p> <p>#JDR: <status> where: <status> JAMMED - Jammed condition detected OPERATIVE - Normal Operating condition restored. This code will be shown only after a jammed condition has occurred.</p> <p>5 - enables the Jammed Detect; the MODULE will make both the actions as for <mode>=1 and <mode>=4.</p> <p>6 - enables the Jammed Detect (this value is available only for 10.00.xxx release); the Jammed condition is reported in the format:</p> <p>#JDR: <status> where: <status> JAMMED - Jammed condition detected OPERATIVE - Normal Operating condition restored. This code will be shown only after a jammed condition has occurred UNKNOWN – default state before first successful PLMN searching</p> <p><MNPL> - Maximum Noise Power Level 0..127 (factory default is 70) <DCMN> - Disturbed Channel Minimum Number 0..254 (factory default is 5)</p>
AT#JDR?	Read command reports the current behaviour mode, Maximum Noise



#JDR - Jammed Detect & Report	SELINT 2
	Power Level and Disturbed Channel Minimum Number, in the format: #JDR: <mode>,<MNPL>,<DCMN>
AT#JDR=?	Test command reports the supported range of values for the parameters <mode>,<MNPL> and <DCMN>
Example	<pre> AT#JDR=2 OK ...jammer enters in the range... #JDR: JAMMED ...jammer exits the range... #JDR: OPERATIVE AT#JDR=6 #JDR: JAMMED //when jammed OK AT#JDR=6 #JDR: OPERATIVE //when in normal operating mode OK AT#JDR=6 #JDR: UNKNOWN // default state before 1st PLMN searching OK </pre>
Note	<p>It is suggested not to change the default setting for Maximum Noise Power Level and Disturbed Channel Minimum Number.</p> <p>If the device is installed in a particular environment where the default values are not satisfactory the two parameters <MNPL> and <DCMN> permit to adapt the detection to all conditions.</p>



#WSCRIPT - Write Script	SELINT 0 / 1
	<p>after command line is terminated with <CR>; after that a file can be entered from TE, sized <size> bytes.</p> <p>The operations completes when all the bytes are received.</p> <p>If writing ends successfully, the response is OK; otherwise an error code is reported.</p> <p>Note: the file name should be passed between quotes; every textual script file must have .py extension, whilst every pre-compiled executable script file must have .pyo extension; file names are case sensitive.</p> <p>Note: when sending the script be sure that the line terminator is <CR><LF> and that your terminal program does not change it.</p> <p>Note: with the hidden attribute it is possible to protect your files from being viewed and copied, only the file name can be viewed, its content is hidden even if the file is still being run correctly. It's your care to maintain knowledge on what the file contains.</p>
AT#WSCRIPT=?	Test command returns OK result code.
Example	<pre>AT#WSCRIPT="First.py " ,54,0 >>> here receive the prompt: depending on your editor settings it's possible that the prompt overrides the above line; then type or send the script, sized 54 bytes OK</pre> <p>Script has been stored.</p>
Note	It's recommended to use the extension .py only for textual script files and the extension .pyo only for pre-compiled executable script files.

#WSCRIPT - Write Script	SELINT 2
AT#WSCRIPT= [<script_name>, <size>, [,<hidden>]]	<p>Execution command causes the MODULE to store a file in the Easy Script® related NVM, naming it <script_name></p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>The file should be sent using RAW ASCII file transfer. It is important to set properly the port settings. In particular: Flow control: hardware. Baud rate: 115200 bps</p> </div> <p>Parameters: <script_name> - name of the file in NVM, string type (max 16 chars, case sensitive).</p>



#WSCRIPT - Write Script	SELINT 2
	<p><size> - file size in bytes <hidden> - file hidden attribute 0 - file content is readable with #RSCRIPT (default). 1 - file content is hidden, #RSCRIPT command will report empty file.</p> <p>The device shall prompt a five character sequence <CR><LF><greater_than><greater_than><greater_than> (IRA 13, 10, 62, 62, 62) after command line is terminated with <CR>; after that a file can be entered from TE, sized <size> bytes.</p> <p>The operations completes when all the bytes are received.</p> <p>If writing ends successfully, the response is OK; otherwise an error code is reported.</p> <p>Note: the file name should be passed between quotes; every textual script file must have .py extension, whilst every pre-compiled executable script file must have .pyo extension; file names are case sensitive.</p> <p>Note: when sending the script be sure that the line terminator is <CR><LF> and that your terminal program does not change it.</p> <p>Note: with the hidden attribute it is possible to protect your files from being viewed and copied, only the file name can be viewed, its content is hidden even if the file is still being run correctly. It's your care to maintain knowledge on what the file contains.</p>
AT#WSCRIPT=?	Test command returns OK result code.
Example	<pre>AT#WSCRIPT="First.py " ,54,0 >>> here receive the prompt; then type or send the textual script, sized 54 bytes OK Textual script has been stored</pre>
Note	It's recommended to use the extension .py only for textual script files and the extension .pyo only for pre-compiled executable script files.

3.5.6.12.2. Select Active Script - #ESCRIP

#ESCRIP - Select Active Script	SELINT 0 / 1
AT#ESCRIP[=	Set command selects either



#ESCRIP - Select Active Script		SELINT 0 / 1
[<script_name>]]	<p>a) the name of the textual script file that will be compiled and executed by the Easy Script® compiler at startup according to last #STARTMODESCR setting, or</p> <p>b) the name of the pre-compiled executable file that will be executed at startup according to last #STARTMODESCR setting.</p> <p>We call this file (either textual or pre-compiled) the current script.</p> <p>Parameter: <script_name> - file name, string type (max 16 chars, case sensitive).</p> <p>Note: all textual script files must have .py extension; all pre-compiled executable files must have .pyo extension.</p> <p>Note: <script_name> must match to the name of a file written by #WSCRIPT in order to have it run.</p> <p>Note: the command does not check whether a textual script named <script_name> does exist or not in the Easy Script® related NVM. If the file <script_name> is not present at startup then the compiler will not execute.</p> <p>Note: issuing AT#ESCRIP<CR> is the same as issuing the Read command.</p> <p>Note: issuing AT#ESCRIP=<CR> is the same as issuing the command AT#ESCRIP=""<CR>.</p>	
AT#ESCRIP?	Read command reports as a quoted string the file name of the current script .	
AT#ESCRIP=?	Test command returns OK result code.	

#ESCRIP - Select Active Script		SELINT 2
AT#ESCRIP= [<script_name>]	<p>Set command selects either</p> <p>c) the name of the textual script file that will be compiled and executed by the Easy Script® compiler at startup according to last #STARTMODESCR setting, or</p> <p>d) the name of the pre-compiled executable file that will be executed at startup according to last #STARTMODESCR setting.</p> <p>We call this file (either textual or pre-compiled) the current script.</p> <p>Parameter:</p>	



#ESCRIP - Select Active Script	SELINT 2
	<p><script_name> - file name, string type (max 16 chars, case sensitive).</p> <p>Note: all textual script files must have .py extension; all pre-compiled executable files must have .pyo extension.</p> <p>Note: <script_name> must match to the name of a file written by #WSCRIPT in order to have it run.</p> <p>Note: the command does not check whether a textual script named <script_name> does exist or not in the Easy Script® related NVM. If the file <script_name> is not present at startup then the compiler will not execute.</p>
AT#ESCRIP?	Read command reports as a quoted string the file name of the current script.
AT#ESCRIP=?	Test command returns OK result code.

3.5.6.12.3. Script Execution Start Mode - #STARTMODESCR

#STARTMODESCR - Script Execution Start Mode	SELINT 0 / 1
<p>AT#STARTMODESCR[= <script_start_mode> [,<script_start_to>]]</p>	<p>Set command sets the current script (see #ESCRIP) execution start mode.</p> <p>Parameter:</p> <p><script_start_mode> - currente script execution start mode</p> <p>0 - current script will be executed at startup only if the DTR line is found Low (that is: COM is not open on a PC), otherwise the Easy Script® interpreter will not execute and the MODULE will behave normally answering only to AT commands on the serial port (factory default).</p> <p>1 - current script will be executed at startup only if the user does not send any AT command on the serial port for the time interval specified in <script_start_to> parameter, otherwise the Easy Script® interpreter will not execute and the MODULE will behave normally answering only to AT commands on the serial port. The DTR line is not tested.</p> <p>2 - current script will be executed at startup in any case. DTR line and if the user does not send any AT command on the serial port have no influence on script execution. But AT command interface will be available on serial port ASC0 and connected to third AT parser instance. See "Easy Script in Python" document for further details on this execution start mode.</p>



#STARTMODESCR - Script Execution Start Mode	SELINT 0 / 1
	<p><script_start_to> - current script start time-out; 10..60 - time interval in seconds; this parameter is used only if parameter <script_start_mode> is set to 1; it is the waiting time for an AT command on the serial port to disable active script execution start. If the user does not send any AT command on the serial port for the time specified in this parameter active script will not be executed (default is 10).</p> <p>Note: issuing AT#STARTMODESCR<CR> is the same as issuing the Read command.</p>
AT#STARTMODESCR?	<p>Read command reports the current script start mode and the current script start time-out, in the format:</p> <p>#STARTMODESCR= <script_start_mode>,<script_start_timeout></p>
AT#STARTMODESCR=?	<p>Test command returns the range of available values for parameters <script_start_mode> and <script_start_timeout>, in the format:</p> <p>#STARTMODESCR: (0-2),(10-60)</p>

#STARTMODESCR - Script Execution Start Mode	SELINT 2
<p>AT#STARTMODESCR= <script_start_mode> [,<script_start_to>]</p>	<p>Set command sets the current script (see #ESCRIP) execution start mode.</p> <p>Parameter:</p> <p><script_start_mode> - currente script execution start mode</p> <p>0 - current script will be executed at startup only if the DTR line is found Low (that is: COM is not open on a PC), otherwise the Easy Script® interpreter will not execute and the MODULE will behave normally answering only to AT commands on the serial port (factory default).</p> <p>1 - current script will be executed at startup only if the user does not send any AT command on the serial port for the time interval specified in <script_start_to> parameter, otherwise the Easy Script® interpreter will not execute and the MODULE will behave normally answering only to AT commands on the serial port. The DTR line is not tested.</p> <p>2 - current script will be executed at startup in any case. DTR line and if the user does not send any AT command on the serial port have no influence on script execution. But AT command interface will be available on serial port ASC0 and connected to third AT parser instance. See "Easy Script in Python" document for further</p>



#RSCRIPT - Read Script		SELINT 0 / 1
AT#RSCRIPT= <script_name>	<p>Execution command reports the content of file <script_name>.</p> <p>Parameter: <script_name> - file name, string type (max 16 chars, case sensitive).</p> <p>The device shall prompt a three character sequence <less_than><less_than><less_than> (IRA 60, 60, 60) followed by the file content.</p> <p>Note: if the file <script_name> was saved with the hidden attribute, then an empty file is reported with the OK result code.</p> <p>Note: If the file <script_name> is not present an error code is reported.</p>	
AT#RSCRIPT=?	Test command returns OK result code.	
Example	<pre>AT#RSCRIPT="First.py "</pre> <p><i>hereafter receive the prompt: depending on your editor settings it's possible that the prompt overrides the above line; then the script is displayed, immediately after the prompt</i></p> <pre><<<import MDM MDM.send('AT\r',10) Ans=MDM.receive(20) OK</pre>	

#RSCRIPT - Read Script		SELINT 2
AT#RSCRIPT= [<script_name>]	<p>Execution command reports the content of file <script_name>.</p> <p>Parameter: <script_name> - file name, string type (max 16 chars, case sensitive).</p> <p>The device shall prompt a five character sequence <CR><LF><less_than><less_than><less_than> (IRA 13, 10, 60, 60, 60) followed by the file content.</p> <p>Note: if the file <script_name> was saved with the hidden attribute, then an empty file is reported with the OK result code.</p> <p>Note: If the file <script_name> is not present an error code is reported.</p>	
AT#RSCRIPT=?	Test command returns OK result code.	
Example	AT#RSCRIPT="First.py "	



#RSCRIPT - Read Script	SELINT 2
	<p><i>hereafter receive the prompt; then the script is displayed, immediately after the prompt</i></p> <pre><<<import MDM MDM.send('AT\r',10) Ans=MDM.receive(20) OK</pre>

3.5.6.12.6. List Script Names - #LSCRIPT

#LSCRIPT - List Script Names	SELINT 0 / 1
AT#LSCRIPT	<p>Execution command reports either the list of file names for the files currently stored in the Easy Script® related NVM and the available free NVM memory in the format:</p> <pre>[#LSCRIPT: <script_name1> <size1>... [<CR><LF><CR><LF>#LSCRIPT: <script_namen> <size_n>]] <CR><LF><CR><LF>#LSCRIPT: free bytes: <free_NVM></pre> <p>where:</p> <p><script-name> - file name, quoted string type (max 16 chars, case sensitive)</p> <p><size_n> - size of script in bytes</p> <p><free_NVM> - size of available NVM memory in bytes</p>
AT#LSCRIPT?	Read command has the same behavior of Execution command.
Example	<pre>AT#LSCRIPT #LSCRIPT: First.py 51 #LSCRIPT: Second.py 178 #LSCRIPT: Third.py 95 #LSCRIPT: free bytes: 20000 OK</pre>

#LSCRIPT - List Script Names	SELINT 2
AT#LSCRIPT	<p>Execution command reports either the list of file names for the files currently stored in the Easy Script® related NVM and the available free NVM memory in the format:</p> <pre>[#LSCRIPT: <script_name1>,<size1>... [<CR><LF>#LSCRIPT: <script_name_n>,<size_n>]] <CR><LF>#LSCRIPT: free bytes: <free_NVM></pre>



#LCSCRIPT - List Script Names	SELINT 2
	<p>[#LCSCRIPT: <script_name>,<size>[,<crc>]]</p> <p>where:</p> <p><script-name> - file name, quoted string type (max 16 chars, case sensitive)</p> <p><size> - size of script in bytes</p> <p><crc> - CRC16 poly ($x^{16}+x^{12}+x^5+1$) of script in hex format</p> <p>Parameter:</p> <p><script_name> - file name, string type (max 16 chars, case sensitive).</p> <p>Note: CRC16 is calculated using the standard CRC16-CCITT $x^{16}+x^{12}+x^5+1$ polynomial (0x1021 representation) with initial value FFFF.</p> <p>Note: if file <script_name> is in use than CRC16 cannot be calculated and execution command does not report <crc>.</p> <p>Note: if file <script_name> is not in the list of files stored in NVM execution command exits with error message.</p>
AT#LCSCRIPT=?	Test command returns OK result code.
Example	<pre> AT#LCSCRIPT #LCSCRIPT: "First.py",51,8FD6 #LCSCRIPT: "Second.py",178,A034 #LCSCRIPT: "Third.py",120,7C48 #LCSCRIPT: free bytes: 20000 OK AT#LCSCRIPT="Second.py" #LCSCRIPT: "Second.py",178,A034 OK If file Third.py is already in use. AT#LCSCRIPT #LCSCRIPT: "First.py",51,8FD6 #LCSCRIPT: "Second.py",178,A034 #LCSCRIPT: "Third.py",120 #LCSCRIPT: free bytes: 20000 OK </pre>



3.5.6.12.7. Delete Script - #DSCRIPT

#DSCRIPT - Delete Script		SELINT 0 / 1
AT#DSCRIPT= <script_name>	<p>Execution command deletes a file from Easy Script® related NVM memory.</p> <p>Parameter:</p> <p><script_name> - name of the file to delete, string type (max 16 chars, case sensitive)</p> <p>Note: if the file <script_name> is not present an error code is reported.</p>	
AT#DSCRIPT=?	Test command returns OK result code.	
Example	AT#DSCRIPT="Third.py" OK	

#DSCRIPT - Delete Script		SELINT 2
AT#DSCRIPT= [<script_name>]	<p>Execution command deletes a file from Easy Script® related NVM memory.</p> <p>Parameter:</p> <p><script_name> - name of the file to delete, string type (max 16 chars, case sensitive)</p> <p>Note: if the file <script_name> is not present an error code is reported.</p>	
AT#DSCRIPT=?	Test command returns OK result code.	
Example	AT#DSCRIPT="Third.py" OK	

3.5.6.12.8. Reboot - #REBOOT

#REBOOT - Reboot		SELINT 0 / 1
AT#REBOOT	<p>Execution command reboots immediately the unit.</p> <p>It can be used to reboot the system after a remote update of the script in order to have the new one running.</p>	
AT#REBOOT?	Read command has the same behaviour of Execution command.	
AT#REBOOT=?	Test command returns OK result code.	
Example	AT#REBOOT OK ... Module Reboots ...	



#REBOOT - Reboot		SELINT 2
AT#REBOOT	Execution command reboots immediately the unit. It can be used to reboot the system after a remote update of the script in order to have the new one running.	
AT#REBOOT=?	Test command returns OK result code.	
Example	AT#REBOOT OK ... Module Reboots ...	

3.5.6.12.9. CMUX Interface Enable - #CMUXSCR

#CMUXSCR - CMUX Interface Enable		SELINT 2
AT#CMUXSCR= <enable>,[<rate>]	<p>Set command enables/disables the 3GPP TS 27.010 multiplexing protocol control channel (see +CMUX) at startup before the current script (see #ESCRIP) execution and specifies the DTE speed at which the device sends and receives CMUX frames (used to fix the DTE-DCE interface speed).</p> <p>Parameters:</p> <p><enable> - enables/disables CMUX interface at startup. 0 - it disables CMUX interface at startup, before current script execution (factory default) 1 - it enables CMUX interface at startup, before current script execution</p> <p><rate> 300 1200 2400 4800 9600 19200 38400 57600 115200 (default)</p> <p>If <rate> is omitted the value is unchanged</p> <p><enable> and <rate> values are saved in NVM</p>	



#CMUXSCR - CMUX Interface Enable		SELINT 2
AT#CMUXSCR ?	Read command returns the current value of #CMUXSCR parameters in the format: #CMUXSCR: <enable>,<rate>	
AT#CMUXSCR=?	Test command reports the range for the parameters <enable> and <rate>	

3.5.6.13. GPS AT Commands Set

3.5.6.13.1. GPS Controller Power Management - \$GPSP

\$GPSP - GPS Controller Power Management		SELINT 0 / 1 / 2
AT\$GPSP=<status>	Set command allows to manage power-up or down of the GPS controller Parameter: <status> 0 - GPS controller is powered down 1 - GPS controller is powered up (default) Note: for the GPS product (GE863-GPS): if the GPS controller is powered down while VAUX pin is enabled they'll both also be also powered off.	



\$GPSAT - GPS Antenna Type Definition		SELINT 0 / 1 / 2
AT\$GPSAT=<type>	<p>Set command selects the GPS antenna used.</p> <p>Parameter: <type> 0 - GPS Antenna not power supplied by the module 1 - GPS Antenna power supplied by the module (default)</p> <p>Note: if current <type> is 0, either \$GPSAV and \$GPSAI have no meaning.</p> <p>Note: the current setting is stored through \$GPSSAV</p>	
AT\$GPSAT?	<p>Read command returns the currently used antenna, in the format:</p> <p>\$GPSAT: <type></p>	
AT\$GPSAT=?	Test command reports the range of supported values for parameter <type>	
Example	AT\$GPSAT=1 OK	
Note	Refer to the HW user guide for the compatible GPS antennas	

3.5.6.13.6. GPS Antenna Supply Voltage Readout - \$GPSAV

\$GPSAV - GPS Antenna Supply Voltage Readout		SELINT 0 / 1 / 2
AT\$GPSAV	Execution command returns the measured GPS antenna's supply voltage in mV	
AT\$GPSAV?	Read command has the same meaning as the Execution command	
AT\$GPSAV=?	Test command returns the OK result code	
Example	AT\$GPSAV \$GPSAV: 3800 OK	
Note	It has meaning only if current \$GPSAT setting is not 0	

3.5.6.13.7. GPS Antenna Current Readout - \$GPSAI

\$GPSAI - GPS Antenna Current Readout		SELINT 0 / 1 / 2
AT\$GPSAI	<p>Execution command reports the GPS antenna's current consumption in the format:</p> <p>\$GPSAI:<value>[,<status>]</p> <p>where: <value> - the measured current in mA <status> 0 - GPS antenna OK 1 - GPS antenna consumption out of the limits</p>	



\$GPSAP - GPS Antenna Protection		SELINT 0 / 1 / 2
	OK <i>Antenna protection activated with 50mA limit</i>	
Note	The module is already provided of an Hardware protection for the high current consumption that is automatically activated if the consumption exceeds 50mA	

3.5.6.13.9. GPS NMEA Serial Port Speed - \$GPSS

\$GPSS - GPS Serial Port Speed		SELINT 0 / 1 / 2
AT\$GPSS=<speed>	Set command allows to select the speed of the NMEA serial port. Parameter: <speed> 4800 - (default) 9600 19200 38400 57600 Note: the new setting is stored through \$GPSSAV	
AT\$GPSS?	Read command returns the current serial ports speed in the format: \$GPSS: <speed>	
AT\$GPSS=?	Test command returns the available range for <speed>	

3.5.6.13.10. Unsolicited NMEA Data Configuration - \$GPSNMUN

\$GPSNMUN - Unsolicited NMEA Data Configuration		SELINT 0 / 1 / 2
AT\$GPSNMUN= <enable> [,<GGA>,<GLL>, <GSA>,<GSV>, <RMC>,<VTG >]	Set command permits to activate an Unsolicited streaming of GPS data (in NMEA format) through the standard GSM serial port and defines which NMEA sentences will be available Parameters: <enable> 0 - NMEA data stream de-activated (default) 1 - NMEA data stream activated with the following unsolicited response syntax:	



\$GPSNMUN - Unsolicited NMEA Data Configuration	SELINT 0 / 1 / 2
	<p>\$GPSNMUN:<CR><NMEA SENTENCE><CR> 2 - NMEA data stream activated with the following unsolicited response syntax: <NMEA SENTENCE><CR> 3 - dedicated NMEA data stream; it is not possible to send AT commands; with the escape sequence '+++' the user can return to command mode</p> <p><GGA> - Global Positioning System Fix Data 0 - disable (default) 1 - enable</p> <p><GLL> - Geographical Position - Latitude/Longitude 0 - disable (default) 1 - enable</p> <p><GSA> - GPS DOP and Active Satellites 0 - disable (default) 1 - enable</p> <p><GSV> - GPS Satellites in View 0 - disable (default) 1 - enable</p> <p><RMC> - recommended Minimum Specific GPS Data 0 - disable (default) 1 - enable</p> <p><VTG> - Course Over Ground and Ground Speed 0 - disable (default) 1 - enable</p>
AT\$GPSNMUN?	<p>Read command returns whether the unsolicited GPS NMEA data streaming is currently enabled or not, along with the NMEA sentences availability status, in the format:</p> <p>\$GPSNMUN:<enable>,<GGA>,<GLL>,<GSA>,<GSV>,<RMC>,<VTG ></p>
AT\$GPSNMUN=?	<p>Test command returns the supported range of values for parameters <enable>, <GGA>, <GLL>, <GSA>, <GSV>, <RMC>, <VTG></p>
Example	<p>AT\$GPSNMUN=1,0,0,1,0,0,0 OK <i>These sets the GSA as available sentence in the unsolicited message</i></p> <p>AT\$GPSNMUN=0 OK <i>Turn-off the unsolicited mode</i></p> <p>AT\$GPSNMUN? \$GPSNMUN: 1,0,0,1,0,0,0 OK <i>Give the current frame selected (GSA)</i></p>



\$GPSNMUN - Unsolicited NMEA Data Configuration		SELINT 0 / 1 / 2
	The unsolicited message will be: \$GPSNMUN: \$GPGSA,A,3,23,20,24,07,13,04,02,,,,,2.4,1.6,1.8*3C	
Reference	NMEA 01803 Specifications	
Note	<p><i>The command is available in "Controlled Mode" only</i></p> <p><i>The available NMEA Sentences are depending on the GPS receiver used</i></p> <p><i>In GE863-GPS and GM862-GPS the fields PDOP and VDOP are not available</i> <i>Use NMEA serial port instead if full DOP info are needed</i></p>	

3.5.6.13.11. Get Acquired Position - \$GPSACP

\$GPSACP - Get Acquired Position		SELINT 0 / 1 / 2
AT\$GPSACP	<p>Execution command returns information about the last GPS position in the format:</p> <p>\$GPSACP: <UTC>,<latitude>,<longitude>,<hdop>,<altitude>,<fix>,<cog>,<spkm>,<spkn>,<date>,<nsat></p> <p>where:</p> <p><UTC> - UTC time (hhmmss.sss) referred to GGA sentence</p> <p><latitude> - format is ddmm.mmmm N/S (referred to GGA sentence)</p> <p>where:</p> <p>dd - degrees 00..90</p> <p>mm.mmmm - minutes 00.0000..59.9999</p> <p>N/S: North / South</p> <p><longitude> - format is dddmm.mmmm E/W (referred to GGA sentence)</p> <p>where:</p> <p>ddd - degrees 000..180</p> <p>mm.mmmm - minutes 00.0000..59.9999</p> <p>E/W: East / West</p> <p><hdop> - x.x - Horizontal Dilution of Precision (referred to GGA sentence)</p> <p><altitude> - x.x Altitude - mean-sea-level (geoid) in meters (referred to GGA sentence)</p> <p><fix> -</p> <p>0 - Invalid Fix</p> <p>2 - 2D fix</p>	



\$GPSACP - Get Acquired Position		SELINT 0 / 1 / 2
	3 - 3D fix <cog> - ddd.mm - Course over Ground (degrees, True) (referred to VTG sentence) where: ddd - degrees 000..360 mm - minutes 00..59 <spkm> - x.x Speed over ground (Km/hr) (referred to VTG sentence) <spkn> - x.x- Speed over ground (knots) (referred to VTG sentence) <date> - ddmmyy Date of Fix (referred to RMC sentence) where: dd - day 01..31 mm - month 01..12 yy - year 00..99 - 2000 to 2099 <nsat> - nn - Total number of satellites in use (referred to GGA sentence) 00..12	
AT\$GPSACP?	Read command has the same meaning as the Execution command	
AT\$GPSACP=?	Test command returns the OK result code	
Example	AT\$GPSACP \$GPSACP: 080220.479,4542.82691N,01344.26820E,259.07,3,2.1,0.1,0.0,0.0 ,270705,09 OK	

3.5.6.13.12. Direct Access to GPS Module - \$GPSCON

\$GPSCON - Direct Access to GPS Module		SELINT 0 / 1 / 2
AT\$GPSCON	Execution command allows to set the GSM baseband in transparent mode in order to have a direct access to the serial port of the GPS module. The GSM module will transfer directly the received data to the GPS module, without checking or elaborating them. Note: the command is usable only in "controlled mode". Note: in case of an incoming call from GSM, this will be visible on the RING	



\$GPSCON - Direct Access to GPS Module		SELINT 0 / 1 / 2
	pin of serial port. Note: the escape sequence is “+++” Note: the Serial Port Speed can be maximum 38400 bps	
AT\$GPSCON=?	Test command returns the OK result code	

3.5.6.13.13. Set The GPS Module In Programming Mode - \$GPSPRG

\$GPSPRG - Set The GPS Module In Programming Mode		SELINT 0 / 1 / 2
AT\$GPSPRG	Execution command allows to switch on the GPS part in BOOT mode and set the GSM processor in Transparent Mode, in order to permit the re-programming of th GPS flash memory. Note: the escape sequence is “+++” Note: it is possible to issue \$GPSPRG only if the Serial Port Speed is fixed 38400 bps	
AT\$GPSPRG?	Read command has the same effect as Execution command.	
AT\$GPSPRG=?	Test command returns the OK result code	

3.5.6.13.14. Set The GPS Module In Power Saving Mode - \$GPSPS

\$GPSPS - Set The GPS Module In Power Saving Mode		SELINT 0 / 1
AT\$GPSPS[= <mode [,<PTF_Period>]]	Set command allows to set the GPS module in Power saving mode. Parameters: <mode> - the GPS receiver can operate in three modes 0 - full power mode, power saving disabled (default); it is the standard operating mode; power is supplied to the receiver continuously and the GPS receiver continues to operate without an interrupt. 1 - tricklepower mode; the power to the SiRF chipset is cycled periodically, so that it operates only a fraction of the time; power is applied only when a position fix is scheduled. 2 - push-to-fix mode; the GPS receiver is generally off, but turns on frequently enough to collect ephemeris data to maintain the GPS1 real-time clock calibration so that, upon user request, a position fix can be provided quickly after power-up. <PTF_Period> - push-to-fix period, numeric value in secs; when mode is push-to-fix, the receiver turns on periodically according to this parameter; default value is 1800 sec. This parameter has meaning only	



\$GPSPS - Set The GPS Module In Power Saving Mode		SELINT 0 / 1
	when <mode>=2 NOTE: with at\$gpsps=2,x, during the push to fix period VAUX is turned off. VAUX can be controlled by AT#VAUX command, too.	
AT\$GPSPS?	Read command returns the current power saving mode and push-to-fix period, in the format: \$GPSPS: <mode>,<PTF_Period>	
AT\$GPSPS	Execution command has the same effect as the Read command	
AT\$GPSPS=?	Test command returns the available range for <mode> and <PTF_Period>	
Note	Available in "controlled mode" only	

\$GPSPS - Set The GPS Module In Power Saving Mode		SELINT 2
AT\$GPSPS= <mode [,<PTF_Period>]	Set command allows to set the GPS module in Power saving mode. Parameters: <mode> - the GPS receiver can operate in three modes 0 - full power mode, power saving disabled (default); it is the standard operating mode; power is supplied to the receiver continuously and the GPS receiver continues to operate without an interrupt. 1 - tricklepower mode; the power to the SiRF chipset is cycled periodically, so that it operates only a fraction of the time; power is applied only when a position fix is scheduled. 2 - push-to-fix mode; the GPS receiver is generally off, but turns on frequently enough to collect ephemeris data to maintain the GPS1 real-time clock calibration so that, upon user request, a position fix can be provided quickly after power-up. <PTF_Period> - push-to-fix period, numeric value in secs; when mode is push-to-fix, the receiver turns on periodically according to this parameter; default value is 1800 sec. This parameter has meaning only when <mode>=2 NOTE: with at\$gpsps=2,x, during the push to fix period VAUX is turned off. VAUX can be controlled by AT#VAUX command, too.	
AT\$GPSPS?	Read command returns the current power saving mode and push-to-fix period, in the format: \$GPSPS: <mode>,<PTF_Period>	
AT\$GPSPS=?	Test command returns the available range for <mode> and <PTF_Period>	
Note	Available in "controlled mode" only	

3.5.6.13.15. Wake Up GPS From Power Saving Mode - \$GPSWK



3.5.6.13.18. GPS Controller Disabling - \$GPSCMODE

\$GPSCMODE - GPS Controller Disabled at Start-up With Charger Inserted		SELINT 0 / 1 / 2
AT\$GPSCMODE=<n> >	<p>Execution command allows to keep off the GSP controller when the module is woken up by charger insertion. The GPS controller can be turned on by AT\$GPSP=1.</p> <p>Parameter: <n> 0 – GPS controller on at start-up (factory default) 1 – GSP controller off at start-up with charger inserted</p> <p>Note: the new setting is stored through \$GPSSAV</p>	
AT\$GPSCMODE ?	<p>Read command reports whether GPS controller is enabled or not when the module is turned on by the charger insertion, in the format:</p> <p>\$GPSCMODE : <n></p>	
AT\$GPSCMODE =?	reports the supported values for <n> parameter..	

3.5.6.14. SAP AT Commands Set

3.5.6.14.1. Remote SIM Enable - #RSEN

#RSEN – Remote SIM Enable	SELINT 2
AT#RSEN=<mode> [,<sapformat> [,<role> [,<muxch> [,<beacon> [,<scriptmode>]]]]	<p>Set command is used to enable/disable the Remote SIM feature. The command returns ERROR if requested on a non multiplexed interface</p> <p>Parameter: <mode> 0 - disable 1 - enable <sapformat> 1 - binary SAP (default) <role> 0 - remote SIM Client (default)</p> <ul style="list-style-type: none"> • If the ME doesn't support the Easy Script Extension® or • <scriptmode> is omitted or • <scriptmode> is 0 <p><muxch> - MUX Channel Number; mandatory if <mode>=1 1..3</p> <p><i>If the ME support the Easy Script Extension® and</i></p>



#RSEN – Remote SIM Enable	SELINT 2
	<p><i><scriptmode> is 1</i></p> <p><muxch> - MDM interface number in scripts; mandatory if <mode>=1 1 - MDM interface 2 - MDM2 interface</p> <p><beacon> - retransmission timer of SAP Connection Request 0 - only one transmission (default) 1..100 - timer interval in seconds.</p> <p><scriptmode> - script mode enable; setting this subparameter has a meaning only if the ME supports the Easy Script® Extension 0 - disable script mode (see subparameter <muxch>) 1 - enable script mode (see subparameter <muxch>)</p> <p>Note: enabling the Remote SIM feature when the SIM is already inserted causes the module to:</p> <ul style="list-style-type: none"> • de-register from the actual network • de-initialize the current SIM. <p>Note: issuing the command on a not multiplexed interface (see +CMUX) cause an ERROR to be raised in all the situations except when:</p> <ul style="list-style-type: none"> • the ME supports the Easy Script Extension® and • <scriptmode> is 1 <p>Note: if the Remote SIM feature has been activated the SAP connection status is signalled with the following URC:</p> <p>#RSEN: <conn> where <conn> - connection status 0 - disconnected 1 - connected</p>
AT#RSEN?	<p>Read command returns the SAP connection status in the format:</p> <p>#RSEN: <conn> where <conn> - connection status, as before</p>
AT#RSEN=?	<p>Test command reports the range of values for all the parameters.</p>



4. List of acronyms

ARFCN	Absolute Radio Frequency Channel Number
AT	Attention command
BA	BCCH Allocation
BCCH	Broadcast Control Channel
CA	Cell Allocation
CBM	Cell Broadcast Message
CBS	Cell Broadcast Service
CCM	Current Call Meter
CLIR	Calling Line Identification Restriction
CTS	Clear To Send
CUG	Closed User Group
DCD	Data Carrier Detect
DCE	Data Communication Equipment
DCS	Digital Cellular System
DGPS	Differential GPS, the use of GPS measurements, which are differentially corrected
DNS	Domain Name System
DSR	Data Set Ready
DTE	Data Terminal Equipment
DTMF	Dual Tone Multi Frequency
DTR	Data Terminal Ready
GGA	GPS Fix data
GLL	Geographic Position – Latitude/Longitude
GLONASS	Global positioning system maintained by the Russian Space Forces
GMT	Greenwich Mean Time
GNSS	Any single or combined satellite navigation system (GPS, GLONASS and combined GPS/GLONASS)
GPRS	Global Packet Radio Service
GPS	Global Positioning System
GSA	GPS DOP and Active satellites
GSM	Global System Mobile
GSV	GPS satellites in view
HDLC	High Level Data Link Control
HDOP	Horizontal Dilution of Precision
IMEI	International Mobile Equipment Identity
IMSI	International Mobile Subscriber Identity
IP	Internet Protocol



AT Commands Reference Guide
80000ST10025a Rev. 9 – 2010-10-04

IRA	International Reference Alphabet
IWF	Interworking Function
MO	Mobile Originated
MT	<i>either</i> Mobile Terminated <i>or</i> Mobile Terminal
NMEA	National Marine Electronics Association
NVM	Non Volatile Memory
PCS	Personal Communication Service
PDP	Packet Data Protocol
PDU	Packet Data Unit
PIN	Personal Identification Number
PPP	Point to Point Protocol
PUK	Pin Unblocking Code
RLP	Radio Link Protocol
RMC	Recommended minimum Specific data
RTS	Request To Send
SAP	SIM Access Profile
SCA	Service Center Address
SMS	Short Message Service
SMSC	Short Message Service Center
SMTP	Simple Mail Transport Protocol
TA	Terminal Adapter
TCP	Transmission Control Protocol
TE	Terminal Equipment
UDP	User Datagram Protocol
USSD	Unstructured Supplementary Service Data
UTC	Coordinated Universal Time
VDOP	Vertical dilution of precision
VTG	Course over ground and ground speed
WAAS	Wide Area Augmentation System

